CHRYSLER and IMPERIAL SERVICE MANUAL SUPPLEMENT

MODELS RC-1 (NEWPORT) RC-2 (WINDSOR) RC-3 (NEW YORKER) RY-1 (IMPERIAL)

This Supplement contains service information for the new 1961 Chrysler and Imperial Models. Only changes and improvements affecting the servicing of the new models are included. If the information desired is not found in this Supplement, the servicing procedures are the same as those outlined in the corresponding models covered in the 1960 Chrysler and Imperial Service Manual 81-070-0026.

In order to use this Supplement to best advantage with the previous Chrysler and Imperial Service Manual 81-070-0026, the corresponding or superseding car models must be understood. The supersedence of these models is as follows:

CHRYSLER MODELS	1961		1960	
Newport	RC-1	Windsor	PC-1	
Windsor	RC-2	Saratoga	PC-2	
New Yorker	RC-3		PC-3	
IMPERIAL MODELS				
Custom, Crown, and LeBaron	RY-1		PY-1	

The service tools referred to in this Supplement are available through the Miller Manufacturing Company, 17640 Grand River Avenue, Detroit 27, Michigan, U.S.A. unless otherwise specified.

Extra copies of this Supplement are available at \$2.00 each plus any local taxes, under Part Number 81-071-0057. Order from Chrysler and Imperial Division, P. O. Box 1658, Detroit 31, Michigan.

CHRYSLER AND IMPERIAL DIVISION

Chrysler Corporation

DETROIT 31, MICHIGAN

Chrysler Corporation reserves the right to make changes in design or to make additions to or improvements in its product without imposing any obligations upon itself to install them on its products previously manufactured.

GROUP INDEX

Group	Title	Page
	Introduction and General Specifications	1
0	Lubrication and Maintenance	5
1	Accessories (Radios, Heaters Mirrors)	<i>′</i> 10
2	Front Suspension	27
3	Rear Axle	29
4	Parking Brakes	33
5	Service Brakes	34
6	Clutch	36
7	Cooling System	42
7A	Accessory Belt Drives	44
8	Electrical and Instruments	45
9	Engine	95
10	Engine Oiling System	101
17	Exhaust System	102
13	Frame	102
14	Fuel System (Pump, Carburetor, Tank)	103
16	Propeller Shaft and Universal Joints	130
17	Springs and Shock Absorbers	131
19	Steering Gear (Pumps, Steer ing Gear Arm, Idler Arm)	- 132
21	Transmission (Torque Converter)	143
22	Wheels, Bearings and Tires	157
23	Body and Sheet Metal	159
24	Air-Conditioning	174
	· · · · · · · · · · · · · · · · · · ·	



Fig. 1—1961 Imperial and Chrysler Models

LICENSE DATA

The following method of numbering vehicles and their engines made in Detroit production Plants will be used on the 1961 Models.

The starting vehicle number will be as follows:

CHRYSLE	R	
Newport	RC-1 81-131	00001
Newport Town & Country	RC-1 85-131	00001
Windsor	RC-2 82-131	00001
New Yorker	RC-3 83-131	00001
New Yorker Town & Country	RC-3 87-131	00001
Chrysler 300G	RC3-300 84-131	00001

IMPERIAL

Imperial Custom	RY-1 91-14100001
Imperial Crown	RY-1 92-14100001
Imperial LeBaron	RY-1 <u>93-14100001</u>
Model	
Serial Number	

The engine numbers will provide the following information: "R" represents the 1961 Model. "36" represents the 361 cu. in. displacement. "38" represents 383 cu. in displacement. "41" represents 413 cu. in. displacement. The next digit is the month built and the last digit the day built. For example; if the engines are built on August 4, 1960, the engine numbers would read as follows:

Newport	R-36-8-4
Windsor	R-38-8-4
New Yorker	R-41-8-4
Chrysler 300G	R-41-8-4
Imperial	R-41-8-4



Fig. 2-Vehicle Number

The vehicle number is stamped on a metal plate attached to the left front door body hinge pillar, as shown in Figure 2.




Fig. 3—Engine Number

The engine number is stamped on a boss on the top side of the cylinder block just back of the water pump, as shown in Figure 3.

		Starting Vehicle Numbers 1961 Models			
Item	Body Style	Newport RC-1	Windsor RC-2	New Yorker RC-3	Imperial RY-1
	Four Door Sedan Town and Country. Four Door Sedan Four Door Sedan Town and Country. Four Door Hardtop (Custom) Four Door Hardtop (Crown) Four Door Hardtop (LeBaron)	81-13100001 85-13100001	82-13100001	83-13100001 87-13100001	91-14100001 92-14100001 93-14100001
Wheelbase	Four Door Sedan Convertible Coupe Two Door (hard top) Town and Country Four Door (hard top)	122 122 122 122 122 122	$ \begin{array}{c} 122\\ -\\ 122\\ -\\ 122\\ 122 \end{array} $	$126 \\ 126 $	129 129
Tread (Front)	Four Door Sedan Convertible Coupe Two Door (hard top) Town and Country Four Door (hard top)	$61.0 \\ 61.0 \\ 61.0 \\ 61.0 \\ 61.0 \\ 61.0$	$ \begin{array}{r} 61.0\\ -\\ 61.0\\ -\\ 61.0 \end{array} $	$61.2 \\ 61.2 \\ 61.2 \\ 61.2 \\ 61.2 \\ 61.2 \\ 61.2$	
Tread (Rear)	Four Door Sedan Convertible Coupe Two Door (hard top) Town and Country Four Door (hard top)	59.7 59.7 59.7 59.7 59.7 59.7	59.7 	$ \begin{array}{c} 60.0 \\ 60.0 \\ 60.0 \\ 60.0 \\ 60.0 \\ 60.0 \end{array} $	
Length with Bumper	Four Door Sedan Convertible Coupe Two Door (hard top) Town and Country. Four Door (hard top)	$215.6 \\ 215.6 \\ 215.6 \\ 216.1 \\ 215.6 \\ 215.6 \\$	215.6 215.6 215.6	$219.6 \\ 219.6 \\ 219.6 \\ 220.1 \\ 219.6$	$227.3 \\ 227.3 \\ - \\ 227.3 \\ - \\ 227.3 \\ - \\ - \\ 227.3 \\ - \\ - \\ - \\ - \\ - \\ - \\ - \\ - \\ - \\ $
Width with Bumper	Four Door Sedan Convertible Coupe Two Door (hard top) Town and Country Four Door (hard top)	79.4 79.4 79.4 79.7 79.7 79.4	79.4 $\overline{79.4}$ $\overline{79.4}$ $\overline{79.4}$	79.4 79.4 79.4 79.7 79.7 79.4	81.7 81.7 81.7
Rear Axle with TorqueFlite Transmission	Four Door Sedan Convertible Coupe Two Door (hard top) Town and Country Four Door (hard top)	2.93 2.93 2.93 2.93 2.93 2.93	2.93 — 2.93 — 2.93	2.93 2.93 2.93 2.93 2.93 2.93	2.93 2.93 2.93
Tire Size	Four Door Sedan Convertible Coupe Two Door (hard top) Town and Country Four Door (hard top)	8.00 x 14 8.00 x 14 8.00 x 14 8.50 x 14 8.50 x 14 8.00 x 14	8.00 x 14 8.00 x 14 8.00 x 14	8.50 x 14 8.50 x 14 8.50 x 14 9.00 x 14 8.50 x 14	8.20 x 15 8.20 x 15

GENERAL DATA AND SPECIFICATIONS

LUBRICATION CHART

PSF Power Steering Reservoir (Check Level) 2,000 Miles . ΕO EO Change Engine Oil at 1,000 and Every 2,000 Miles DCL Thereafter Change Engine Oil Filter at 3,000 and Every 4,000-**Miles Thereafter** s HTE Master Cylinder Fluid (Check Level) 2,000 Miles Install New Fuel Filter 23,000 Miles EO Engine Ventilation Outlet Air Cleaner 2,000 Miles AA сι Upper Ball Joints (2) 2,000 Miles ~ EO CL Lower Ball Joints (2) 2,000 Miles WB CL Tie Rod Ball Ends (4) 2.000 Miles . ΔΔ Automatic Transmission Maintenance 10,000 Miles UJ2 Universal Joints-Disassemble-Clean 21,000 Miles MP Rear Axle (Check Level) 2,000 Miles -(Drain and Refill) 21,000 Miles-SGL Rear Axle (Check Level) (Sure Grip) 2,000 Miles (Drain and Refill) 21,000 Miles RECOMMENDED TIRE PRESSURES (COLD) Front Rear ALL MODELS 24 24 NOTE: Cold fire pressures are listed above. Normal driving will cause a pressure build up of 2 to 3 pounds; fast driving 4 to 6 pounds. Never re-duce (bleed) built-up pressure in fires since under-inflation will result when fires col off. For sustained high speed driving, add 5 pounds pressure over the normal starting (cold) pressure. KEY TO LUBRICANTS Automatic Trans. Fluid Type "A" AA Suffix "A" AF Anti-Freeze AP Air Pressure С Check Condition CL Chassis Lubricant DCL **Distributor Cam Lubricant** IMPERIAL EO Engine Oil HTF High Temperature Brake Fluid MCL Speedometer Cable Lubricant ML Lubriplate MP Multi-Purpose Gear Lubricant PDO Penetrating Dripless Oil Power Steering Fluid PSF RR **Rust Resistor** s **Manifold Heat Control Valve Solvent** SGL Sure Grip Lubricant SL Stainless Stick Lubricant UJ2 Universal Joint Lubricant WB Wheel Bearing Lubricant-Medium 61 x 216

Distributor Oil Cup 2,000 Miles. Wick under Rotor 10,000 Miles

Distributor Cam 10,000 Miles

Clean Carburetor Air Cleaner, 6,000 Miles Install New Carburetor Air Cleaner Element 15,000 Miles

Manifold Heat Control Valve 2,000 Miles Part No. 1879318 MoPar Manifold Heat Control Valve Solvent

Automatic Transmission (Check Fluid Level) 2,000 Miles

Engine Ventilation Inlet Air Cleaner 2,000 Miles

Front Wheel Bearings—Remove—Clean—Repack 10,000 Miles

PARTS WHICH SHOULD NOT BE LUBRICATED	
Alternator bearings	
Rubber bushings	
Oilite bearings	
Rear springs, bolts and shackles	
Starter bearings	
Carburetor air cleaner	
Carburetor linkage	
Accelerator pedal linkage	
Steering gear arm pivot	
Gearshift and automatic transmission drive selector linkage	
Brake pedal and linkage	
Idler arm pivots	
Upper and lower control arm bushings	
Fan belt idler pulley	
Water pump	
Rear wheel bearings	

ENGINE OIL RECOMMENDATIONS

When adding or changing engine oil, use lubricants which have both the SAE designation and the MS Service Classification printed on the container. High quality, well refined engine oils usually have both classifications on the containers. Choice of brands should include the reputation of the refiner and marketer.

Use oils for anticipated temperatures as follows:


	Recommended Viscosity No.	Multi-Grade Options
Above -32°F.	SAE 30	SA'E 20W-40
		SAE 10W-30
Above $\pm 10^{\circ}$ F.	SAE 20W	SAE 20W-40
		SAE 10W-30
Above - 10°F.	SAE TOW	SAE 10W-30
		SAE 5W-20
Below - 10°F.	SAE 5W	SAE 5W-20

CAPACITIES	-
Engine Oil	5 gts.
(Add 1 gt. when replacing filte	
Cooling System	16 qts.
(Add 1 qt. for heater)	
Rear Axle	3 ½ pts.
Transmission (refill)	
TorqueFlite	22 pts.

Fig. 1-Lubrication Chart (Imperial)

6 --- LUBRICATION AND MAINTENANCE

LUBRICATION CHART



Distributor Oil Cup 2,000 Miles. Wick under Rotor 10,000 Miles

Distributor Cam 10,000 Miles

Clean Carburetor Air Cleaner, 6,000 Miles Install New Carburetor Air Cleaner Element

15,000 Miles Manifold Heat Control Valve 2,000 Miles

Automatic Transmission (Check Fluid Level) 2,000 Miles

Engine Ventilation Inlet Air Cleaner 2,000 Miles Front Wheel Bearings-Remove-Clean-Repack

10,000 Miles Gear Shift Tube and Lower Support (1) 2.000 Miles

Gearshift Lever Pivot—Remove—

Lubricate—Install 10,000 Miles

Clutch Torque Shaft (1) 2,000 Miles

PARTS WHICH SHOULD NOT BE LUBRICATED Alternator bearings **Rubber bushings Oilite bearings** Rear springs, bolts and shackles Starter bearings **Carburetor air cleaner Carburetor linkage** Accelerator pedal linkage Steering gear arm pivot Gearshift and automatic transmission drive selector linkage Brake and clutch pedals, and linkage Clutch release bearing Idler arm pivots Upper and lower control arm bearings Fan belt idler pulley Water pump

Rear wheel bearings

ENGINE OIL RECOMMENDATIONS

When adding or changing engine oil, use lubricants which have both the SAE designation and the MS Service Classification printed on the container. High quality, well refined engine oils usually have both classifications on the containers. Choice of brands should include the reputation of the refiner and marketer.

Use ails for anticipated temperatures as follows: Recommended Multi-Grade

	Viscosity No.	Options
Above 32°F.	SAE 30	SAE 20W-40
		SAE 10W-30
Above $\pm 10^\circ$ F.	SAE 20W	SAE 20W-40
		SAE 10W-30
Above - 10°F.	SAE 10W	SAE 10W-30
		SAE 5W-20
Below — 10°F.	SAE 5W	SAE 5W-20

5 qts.
ter element)
16 qts.
3 ½ pis.
22 pts.
4 ¼ pts.
ł

Fig. 2—Lubrication Chart (Chrysler)