

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
------	---------------------------	------	---------------------------

PARTS PACKAGES

- 1-09-1 SIGNAL LAMP PACKAGE,
HANDBRAKE Part No. 1770 727
Consists of:
1 - 142 453 Bulb
1 - 1753 862 Bezel
1 - ---- Housing
1 - ---- Switch
1 - ---- Spacer
1 - ---- Socket
1 - 431 942 Screw
1 - ---- Washer
- SIGNAL LAMP PACKAGE,
HANDBRAKE Part No. 1770 721
Consists of:
1 - 142 433 Bulb
1 - 1770 720 Lamp
1 - ---- Nut
1 - 431 942 Screw
1 - ---- Socket
1 - ---- Switch
1 - ---- Washer
- 1-10-1 BACK-UP LAMP
PACKAGE Part No. 1819 087
Consists of:
2 - 142 456 Bulb
1 - 1302 807 Gasket
2 - ---- Socket
1 - 1343 998 Switch
2 - 1753 534 Terminal
2 - 903 895 Terminal
1 - ---- Wiring
1 - ---- Wiring
- BACK-UP LAMP
PACKAGE Part No. 1838 385
Consists of:
1 - 1676 629 Actuator
1 - 142 456 Bulb
1 - ---- Lamp
2 - ---- Nut
2 - ---- Rivet
2 - ---- Spacer
1 - 1704 234 Switch
1 - ---- Socket
- SIGNAL LAMP PACKAGE,
HANDBRAKE Part No. 1838 386
Consists of:
2 - 142 456 Bulb
2 - ---- Clip
1 - 1302 807 Gasket
2 - 1810 712 Lamp
4 - ---- Screw
1 - 1343 998 Switch
1 - ---- Wiring
1 - ---- Wiring
- SIGNAL LAMP PACKAGE,
HANDBRAKE Part No. 1838 387
Consists of:
1 - 1676 629 Actuator

(Cont'd)

- 2 - 142 456 Bulb
2 - ---- Clip
2 - 1810 712 Lamp
2 - ---- Rivet
4 - ---- Screw
1 - 1704 234 Switch
1 - ---- Wiring
- SIGNAL LAMP PACKAGE,
HANDBRAKE Part No. 1838 391
Consists of:
2 - 142 456 Bulb
1 - 1302 807 Gasket
1 - 1343 998 Switch
2 - 1842 209 Socket
1 - ---- Wiring
- SIGNAL LAMP PACKAGE,
HANDBRAKE Part No. 1838 392
Consists of:
1 - 1676 629 Actuator
2 - 142 456 Bulb
2 - ---- Rivet
1 - 1841 710 Switch
2 - 1842 209 Socket
- SIGNAL LAMP PACKAGE,
HANDBRAKE Part No. 1841 973
Consists of:
2 - 142 456 Bulb
1 - 1302 807 Gasket
1 - 1343 998 Switch
2 - 1842 209 Socket
1 - ---- Wiring
- SIGNAL LAMP PACKAGE,
HANDBRAKE Part No. 1841 974
Consists of:
1 - 1841 711 Actuator
2 - 142 456 Bulb
2 - ---- Rivet
1 - 1841 711 Switch
2 - 1842 209 Socket
- SIGNAL LAMP PACKAGE,
HANDBRAKE Part No. 1841 976
Consists of:
1 - 1676 629 Actuator
2 - 142 456 Bulb
2 - ---- Rivet
1 - 1841 710 Switch
2 - ---- Socket
- 1-12-1 CIGAR LIGHTER
PACKAGE Part No. 1770 761
Consists of:
1 - 131 282 Bulb
1 - ---- Cable
1 - 1704 222 Escutcheon
1 - ---- Knob
1 - 1752 403 Shell
1 - 1770 756 Socket

(Pkg. Cont'd)

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

1955-58 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
1-13-1	LIGHT PACKAGE, UNDERHOOD Part No. 1770 734 Consists of: 1 - 151 577 Bulb 1 - ---- --- Cable 1 - 1308 484 Clip 1 - 689 867 "Y" Cable 1 - 1770 830 Light 1 - ---- --- Screw 1 - ---- --- Washer		SPORTONE MOULDING PACKAGE Part No. E1879 541 Consists of: 16 - 6000 606 Clip 16 - 6000 239 Clip 1 - 1863 628 Insert 1 - 1863 629 Insert 1 - 1878 936 Insert 1 - 1878 937 Insert 1 - 1878 940 Insert 1 - 1878 941 Insert 1 - 1950 098 Moulding 1 - 1950 099 Moulding 8 - 1878 938 Moulding 2 - ---- --- Screw 2 - 274 791 Screw 16 - ---- --- Screw 16 - 6006 031 Washer
1-14-4	MAP LAMP PACKAGE. . . Part No. 1770 751 Consists of: 1 - 151 578 Bulb 1 - ---- --- Housing 1 - 1753 874 Lens 2 - ---- --- Screw 1 - ---- --- Socket		
1-14-40	COURTESY LIGHT PACKAGE Part No. 1770 736 Consists of: 1 - 142 453 Bulb 1 - ---- --- Socket 2 - 1571 542 Switch COURTESY LIGHT PACKAGE Part No. 1842 277 Consists of: 2 - ---- --- Bracket 2 - 142 453 Bulb 2 - 120 376 Nut 1 - ---- --- Socket 2 - 1571 542 Switch		SPORTONE MOULDING PACKAGE Part No. E1879 542 Consists of: 16 - 6000 606 Clip 16 - 6000 239 Clip 1 - 1902 638 Insert 1 - 1902 639 Insert 1 - 1878 928 Insert 1 - 1878 929 Insert 1 - 1878 932 Insert 1 - 1878 933 Insert 1 - 1878 934 Insert 1 - 1878 935 Insert 1 - 1950 102 Moulding 1 - 1950 103 Moulding 8 - 1878 938 Moulding 2 - ---- --- Screw 2 - 274 791 Screw 16 - ---- --- Screw 16 - 6006 031 Washer
1-19-1	GLOVE COMPARTMENT LIGHT PACKAGE Part No. 1770 738 Consists of: 1 - 151 578 Bulb 1 - 1704 491 Lamp 1 - ---- --- Socket GLOVE COMPARTMENT LIGHT PACKAGE Part No. 1648 614 Consists of: 1 - 131 282 Bulb 1 - ---- --- Socket		SPORTONE MOULDING PACKAGE Part No. E1879 543 Consists of: 16 - 6000 606 Clip 16 - 6000 239 Clip 1 - 1902 638 Insert 1 - 1902 639 Insert 1 - 1878 936 Insert 1 - 1878 937 Insert 1 - 1878 940 Insert 1 - 1878 941 Insert 1 - 1950 102 Moulding 1 - 1950 103 Moulding 8 - 1878 938 Moulding 2 - ---- --- Screw 2 - 274 791 Screw 16 - ---- --- Screw 16 - 6006 031 Washer
1-23-1	SPORTONE MOULDING PACKAGE Part No. E1879 540 Consists of: 16 - 6000 606 Clip 16 - 6000 239 Clip 1 - 1863 628 Insert 1 - 1863 629 Insert 1 - 1878 928 Insert 1 - 1878 929 Insert 1 - 1878 932 Insert 1 - 1878 933 Insert 1 - 1878 934 Insert 1 - 1878 935 Insert 1 - 1950 098 Moulding 1 - 1950 099 Moulding 8 - 1878 938 Moulding 2 - ---- --- Screw 2 - 274 791 Screw 16 - ---- --- Screw 16 - 6006 031 Washer		SPORTONE MOULDING PACKAGE Part No. E1879 544 Consists of: 16 - 6000 606 Clip 1 - 1863 628 Insert 1 - 1863 629 Insert 1 - 1878 928 Insert 1 - 1878 929 Insert

(Pkg. Cont'd)

★ Indicates use as required.

⊠ Indicates parts not listed in any previous parts book.

Printed in U.S.A.

Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)	1 - 1878 932 Insert 1 - 1878 933 Insert 1 - 1879 002 Insert 1 - 1879 003 Insert 1 - 1950 176 Moulding 1 - 1950 177 Moulding 2 - ---- --- Screw 2 - 274 791 Screw	(Cont'd)	2 - 274 791 Screw 20 - 6006 031 Washer SPORTONE MOULDING PACKAGE Part No. EI879 550 Consists of: 24 - 6006 262 Clip 12 - 6006 303 Clip 2 - 6006 265 Clip 20 - 6000 236 Clip 16 - 6000 606 Clip 1 - 1863 574 Moulding 1 - 1863 575 Moulding 1 - 1878 916 Moulding 1 - 1878 917 Moulding 1 - 1878 918 Moulding 1 - 1878 919 Moulding 6 - 1878 914 Moulding 1 - 1950 098 Moulding 1 - 1950 099 Moulding 1 - 1834 130 Moulding 1 - 1834 131 Moulding 1 - 1902 640 Plate 1 - 1902 641 Plate 1 - 1878 920 Plate 1 - 1878 921 Plate 20 - 6000 238 Screw 2 - 274 791 Screw 20 - 6006 031 Washer
	SPORTONE MOULDING PACKAGE Part No. EI879 545 Consists of: 16 - 6000 606 Clip 1 - 1902 638 Insert 1 - 1902 639 Insert 1 - 1878 928 Insert 1 - 1878 929 Insert 1 - 1878 932 Insert 1 - 1878 933 Insert 1 - 1879 002 Insert 1 - 1879 003 Insert 1 - 1950 080 Moulding 1 - 1950 081 Moulding 2 - ---- --- Screw 2 - 274 791 Screw		SPORTONE MOULDING PACKAGE Part No. EI879 551 Consists of: 12 - 6006 303 Clip 20 - 6000 236 Clip 16 - 6000 606 Clip 6 - 1878 914 Moulding 1 - 1950 098 Moulding 1 - 1950 099 Moulding 1 - 1834 130 Moulding 1 - 1834 131 Moulding 20 - 6000 238 Screw 2 - 274 791 Screw 20 - 6006 031 Washer
	SPORTONE MOULDING PACKAGE Part No. EI879 548 Consists of: 24 - 6006 262 Clip 12 - 6006 303 Clip 2 - 6006 265 Clip 20 - 6000 236 Clip 16 - 6000 606 Clip 1 - 1863 574 Moulding 1 - 1863 575 Moulding 1 - 1878 916 Moulding 1 - 1878 917 Moulding 1 - 1878 918 Moulding 1 - 1878 919 Moulding 6 - 1878 914 Moulding 1 - 1950 098 Moulding 1 - 1950 099 Moulding 1 - 1878 926 Moulding 1 - 1878 927 Moulding 1 - 1902 640 Plate 1 - 1902 641 Plate 1 - 1878 920 Plate 1 - 1878 921 Plate 20 - 6000 238 Screw 2 - 274 791 Screw 20 - 6006 031 Washer		SPORTONE MOULDING PACKAGE Part No. EI879 552 Consists of: 12 - 6006 303 Clip 24 - 6006 262 Clip 2 - 6006 265 Clip 16 - 6000 606 Clip 1 - 1863 574 Moulding 1 - 1863 575 Moulding 1 - 1878 916 Moulding 1 - 1878 917 Moulding 1 - 1878 918 Moulding 1 - 1878 919 Moulding 6 - 1878 914 Moulding 1 - 1950 098 Moulding 1 - 1950 099 Moulding 1 - 1902 640 Plate 1 - 1902 641 Plate 1 - 1878 920 Plate 1 - 1878 921 Plate 2 - 274 791 Screw
	SPORTONE MOULDING PACKAGE Part No. EI879 549 Consists of: 12 - 6006 303 Clip 20 - 6000 236 Clip 16 - 6000 606 Clip 6 - 1878 914 Moulding 1 - 1950 098 Moulding 1 - 1950 099 Moulding 1 - 1878 926 Moulding 1 - 1878 927 Moulding 20 - 6000 238 Screw		
	(Pkg. Cont'd)		

★ Indicates use as required.

□ Indicates parts not listed in any previous parts book.

1955-58 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	SPORTONE MOULDING	(Cont'd)	
	PACKAGE Part No. E1879 553	12 - 6000 613 Clip	
	Consists of:	1 - 1863 728 Medallion	
	12 - 6006 303 Clip	1 - 1863 626 Moulding	
	16 - 6000 606 Clip	1 - 1863 627 Moulding	
	6 - 1878 914 Moulding	1 - 1863 640 Moulding	
	1 - 1950 098 Sill	1 - 1863 641 Moulding	
	1 - 1950 099 Sill	1 - 1950 084 Moulding	
	2 - 274 791 Screw	1 - 1950 085 Moulding	
	SPORTONE MOULDING	1 - 1950 090 Moulding	
	PACKAGE Part No. E1879 554	1 - 1950 091 Moulding	
	Consists of:	1 - 1950 208 Moulding	
	12 - 6006 303 Clip	1 - 1950 209 Moulding	
	16 - 6000 606 Clip	2 - 6010 153 Clip	
	20 - 6000 236 Clip	8 - 446 059 Nut	
	6 - 1878 914 Moulding	10 - 6000 028 Nut	
	1 - 1950 102 Moulding	1 - 1863 742 Plate	
	1 - 1950 103 Moulding	2 - ---- --- Screw	
	1 - 1878 926 Moulding		
	1 - 1878 927 Moulding	SPORTONE MOULDING	
	2 - 274 791 Screw	PACKAGE Part No. E1952 291	
	20 - 6000 238 Screw	Consists of:	
	20 - 6006 031 Washer	8 - 6000 050 Clip	
	SPORTONE MOULDING	10 - 6000 608 Clip	
	PACKAGE Part No. E1879 555	24 - ---- --- Clip	
	Consists of:	6 - 6000 613 Clip	
	12 - 6006 303 Clip	1 - 1863 728 Medallion	
	16 - 6000 606 Clip	1 - 1863 626 Moulding	
	20 - 6000 236 Clip	1 - 1863 627 Moulding	
	6 - 1878 914 Moulding	1 - 1863 640 Moulding	
	1 - 1950 102 Moulding	1 - 1863 641 Moulding	
	1 - 1950 103 Moulding	1 - 1950 082 Moulding	
	1 - 1834 130 Moulding	1 - 1950 083 Moulding	
	1 - 1834 131 Moulding	1 - 1950 086 Moulding	
	2 - 274 791 Screw	1 - 1950 087 Moulding	
	20 - 6000 238 Screw	1 - 1950 088 Moulding	
	20 - 6006 031 Washer	1 - 1950 089 Moulding	
	SPORTONE MOULDING	1 - 1950 208 Moulding	
	PACKAGE Part No. E1879 556	1 - 1950 209 Moulding	
	Consists of:	2 - ---- --- Nut	
	12 - 6006 303 Clip	8 - 6000 490 Nut	
	16 - 6000 606 Clip	8 - 446 059 Nut	
	2 - 274 791 Clip	2 - ---- --- Nut	
	6 - 1878 914 Moulding	10 - 6000 028 Nut	
	1 - 1950 102 Moulding	1 - 1863 742 Plate	
	1 - 1950 103 Moulding	2 - ---- --- Screw	
	SPORTONE MOULDING		
	PACKAGE Part No. E1952 286	1-45-1 SKIRT PACKAGE,	
	Consists of:	FENDER Part No. 1752 675	
	10 - 6010 030 Clip	Consists of:	
	2 - 6010 002 Clip	1 - ---- --- Bracket	
	8 - ---- --- Clip	2 - ---- --- Bracket	
	1 - 1863 622 Moulding	1 - ---- --- Bracket	
	1 - 1863 623 Moulding	6 - ---- --- Lockwasher	
	1 - 1950 094 Moulding	6 - ---- --- Nut	
	1 - 1950 095 Moulding	1 - ---- --- Skirt	
	2 - 446 059 Nut	1 - ---- --- Skirt	
	SPORTONE MOULDING	6 - ---- --- Screw	
	PACKAGE Part No. E1952 290		
	Consists of:	SKIRT PACKAGE,	
	8 - 6000 050 Clip	FENDER Part No. 1752 676	
	10 - 6000 608 Clip	Consists of:	
	18 - ---- --- Clip	1 - ---- --- Bracket	
		1 - ---- --- Bracket	
		2 - ---- --- Bracket	
		2 - ---- --- Lockwasher	
		2 - ---- --- Nut	
		1 - ---- --- Skirt	

(Pkg. Cont'd)

(Pkg. Cont'd)

★ Indicates use as required.
 □ Indicates parts not listed in any previous parts book.

Printed in U.S.A.
 Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)	1 - ---- --- Skirt	(Cont'd)	1 - 1779 072 "Y" Connector and Lead-In Wire
	2 - ---- --- Screw		2 - 1841 057 Gasket
	2 - ---- --- Screw		4 - ---- --- Nut, w/Washer
1-74-1	ROOF LUGGAGE RACK		4 - ---- --- Washer
	PACKAGE Part No. E1833 506		
	Consists of:		
	4 - 1682 770 Bracket		RADIO ANTENNA
	2 - 1682 771 Bracket		PACKAGE Part No. 1779 243
	2 - 1776 454 Bracket		Consists of:
	2 - 1776 456 Bracket		2 - 1779 156 Adapter
	2 - 1776 455 Bracket		2 - 1779 157 Adapter
	4 - 1759 503 Bow		2 - ---- --- Brace and Clamp
	28 - 180 016 Bolt		1 - ---- --- Body, Mast and Shield, Right
	3 - 1775 076 Channel		1 - 1819 804 Body, Mast and Shield, Left
	2 - 1682 776 Cap		2 - ---- --- Collar
	2 - 1682 777 Cap		1 - 1779 072 "Y" Connector and Lead-In Wire
	8 - 120 375 Nut		4 - ---- --- Clip
	4 - 6000 123 Nut		2 - 1779 103 Gasket
	3 - 1775 077 Pad		2 - 1658 332 Nut, w/Grommet
	6 - 1682 778 Pad		2 - 1658 328 Nut
	2 - ---- --- Plate		2 - ---- --- Screw
	4 - 1774 074 Rail		
	2 - 1774 075 Rail		RADIO ANTENNA
	8 - 1775 075 Strip		PACKAGE Part No. 1779 629
	24 - 1697 627 Support		Consists of:
	16 - ---- --- Screw		1 - ---- --- Adapter
	24 - ---- --- Screw		1 - ---- --- Adapter
	12 - ---- --- Screw		1 - ---- --- Brace
	2 - ---- --- Silencer		1 - ---- --- Body, Mast and Shield
			1 - ---- --- Collar
1-82-2	WINDSHIELD WASHER		1 - 1779 072 "Y" Connector and Lead-In Wire
	PACKAGE Part No. 1770 728		1 - 1658 332 Nut, w/Grommet
	Consists of:		1 - 1658 328 Nut
	1 - ---- --- Bracket		1 - ---- --- Screw
	1 - 1779 782 Container		
	1 - ---- --- Cap		RADIO ANTENNA
	1 - ---- --- Gasket		PACKAGE Part No. 1779 646
	1 - ---- --- Hose		Consists of:
	1 - ---- --- Hose		1 - ---- --- Adapter
	1 - 138 557 Lockwasher		1 - ---- --- Adapter
	1 - ---- --- Nozzle		1 - ---- --- Antenna
	1 - ---- --- Nut		1 - ---- --- Cable
	1 - ---- --- Nut		1 - ---- --- Collar
	1 - 1770 918 Pump		1 - 1779 072 "Y" Connector and Lead-In Wire
	1 - 1571 028 Strainer		1 - ---- --- Gasket
	1 - 1527 513 Valve		1 - ---- --- Grommet
			1 - ---- --- Lead
1-88-1	RADIO ANTENNA		1 - ---- --- Nut
	PACKAGE Part No. 1769 436		1 - ---- --- Nut
	Consists of:		1 - ---- --- Screw
	1 - 1769 444 Adapter		1 - ---- --- Strap
	1 - 1769 443 Adapter		1 - 1779 863 Switch
	1 - ---- --- Body and Mast		1 - ---- --- Washer
	1 - ---- --- Collar		
	1 - ---- --- Cover		2-04-1
	1 - ---- --- Cover		PIN PACKAGE, FRONT
	1 - ---- --- Gasket		SUSPENSION KING . . . Part No. 933 435
	1 - 1658 332 Nut and Grommet		Consists of:
	1 - 1658 328 Nut		2 - ---- --- Bearing, Thrust
	1 - 145 415 Screw		4 - ---- --- Bushing, Pin
			4 - ---- --- Plug, Oil Seal
	RADIO ANTENNA		4 - ---- --- Plug, Oil Seal
	PACKAGE Part No. 1779 068		2 - 117 920 Plug, Oil Seal Upper
	Consists of:		2 - ---- --- Pin, King
	1 - 1838 163 Body and Mast, Left		2 - ---- --- Pin, Lock
	1 - 1838 162 Body and Mast, Right		4 - ---- --- Shim, Bearing
	4 - ---- --- Clip		
	(Pkg. Cont'd)		

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.

Prices and specifications subject to change without notice.

1955-58 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	<p>PIN PACKAGE, FRONT SUSPENSION KING . . . Part No. 947 557 Consists of: 2 - ---- --- Bearing, Thrust 2 - ---- --- Bushing, Pin Lower 2 - ---- --- Bushing, Pin Upper 2 - ---- --- Plug, Oil Seal Lower 2 - 117 920 Plug, Oil Seal Upper 2 - ---- --- Pin, King 2 - ---- --- Pin, Lock 2 - ---- --- Shim, Bearing</p> <p>PIN PACKAGE, FRONT SUSPENSION KING . . . Part No. 1311 059 Consists of: 2 - ---- --- Bearing, Thrust 2 - ---- --- Bearing, Pin Upper 2 - ---- --- Bushing, Pin Lower 4 - ---- --- Plug, Oil Seal 2 - ---- --- Pin, King 2 - ---- --- Pin, Lock 4 - ---- --- Shim, Bearing</p> <p>PIN PACKAGE, FRONT SUSPENSION KING . . . Part No. 1321 260 Consists of: 2 - ---- --- Bearing, Thrust 2 - ---- --- Bearing, Pin Upper 2 - ---- --- Bushing, Pin Lower 4 - ---- --- Plug, Oil Seal 2 - ---- --- Pin, King 2 - ---- --- Pin, Lock 2 - ---- --- Seal, Lower Bushing 4 - ---- --- Shim, Bearing</p> <p>PIN PACKAGE, FRONT SUSPENSION KING . . Part No. 1450 218 Consists of: 2 - ---- --- Bearing, Thrust 2 - ---- --- Bushing, Pin Lower 2 - ---- --- Bushing, Pin Upper 2 - ---- --- Pin, King 2 - ---- --- Pin, Lock 2 - ---- --- Plug, Oil Seal Lower 2 - ---- --- Plug, Oil Seal Upper 2 - ---- --- Seal, Lower Bushing 2 - ---- --- Shim, Bearing</p> <p>PIN PACKAGE, FRONT SUSPENSION KING . . . Part No. 1653 444 Consists of: 2 - ---- --- Bearing, Thrust 2 - ---- --- Bearing, Pin Upper 2 - ---- --- Bushing, Pin Lower 2 - 1556 997 Pin, King 4 - ---- --- Plug, Oil Seal 2 - ---- --- Seal, Lower Bushing 4 - ---- --- Shim, Bearing</p> <p>PIN PACKAGE, FRONT SUSPENSION KING . . . Part No. 1653 445 Consists of: 2 - ---- --- Bearing, Thrust 2 - ---- --- Bearing, Pin Upper</p>	<p>(Cont'd)</p> <p>2 - ---- --- Bushing, Pin Lower 2 - ---- --- Pin, King 2 - ---- --- Plug, Oil Seal Lower 2 - 117 920 Plug, Oil Seal Upper 2 - ---- --- Seal, Lower Bushing 4 - ---- --- Shim, Bearing</p> <p>PIN PACKAGE, FRONT SUSPENSION KING . . . Part No. 1752 456 Consists of: 2 - ---- --- Bearing, Thrust 2 - ---- --- Bushing, Pin Lower 2 - ---- --- Bushing, Pin Upper 2 - ---- --- Pin, King 2 - ---- --- Plug, Oil Seal Lower 2 - 117 920 Plug, Oil Seal Upper 2 - ---- --- Seal, Lower Bushing 4 - ---- --- Shim, Bearing</p> <p>2-07-1 END PACKAGE, TIE ROD. Part No. 951 302 Consists of: 1 - ---- --- Bolt, Tie Rod End Clamp 1 - ---- --- Clamp, Tie Rod End 1 - ---- --- End, Tie Rod 1 - 9411 022 Nipple, Lubricant 1 - 128 178 Nut, Tie Rod End 1 - ---- --- Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter 1 - 1318 177 Seal, Tie Rod End Dust</p> <p>END PACKAGE, TIE ROD. Part No. 951 303 Consists of: 1 - ---- --- Bolt, Tie Rod End Clamp 1 - ---- --- Clamp, Tie Rod End 1 - ---- --- End, Tie Rod 1 - 9411 022 Nipple, Lubricant 1 - 128 178 Nut, Tie Rod End 1 - ---- --- Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter 1 - 1318 177 Seal, Tie Rod End Dust</p> <p>END PACKAGE, TIE ROD. Part No. 1315 410 Consists of: 1 - ---- --- Bolt, Tie Rod End Clamp 1 - ---- --- Clamp, Tie Rod End 1 - ---- --- End, Tie Rod 1 - ---- --- Nipple, Lubricant 1 - ---- --- Nut, Tie Rod End 1 - ---- --- Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter 1 - 1322 964 Seal, Tie Rod End Dust</p> <p>END PACKAGE, TIE ROD OUTER Part No. 1818 998 Consists of: 1 - ---- --- Bolt, Tie Rod End Clamp 1 - ---- --- Clamp, Tie Rod End 1 - ---- --- End, Tie Rod Outer 1 - ---- --- Nipple, Lubricant</p>	

(Pkg. Cont'd)

(Pkg. Cont'd)

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.
 Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)	1 - ---- --- Nut, Tie Rod End	2-08-3	BUSHING PACKAGE, FRONT SUSPENSION UPPER CONTROL ARM PIN Part No. 1321 130 Consists of: 1 - ---- --- Bushing, Pin 2 - ---- --- Seal, Dust
	1 - ---- --- Nut, Tie Rod End Clamp		BUSHING PACKAGE, FRONT SUSPENSION UPPER CONTROL ARM PIN Part No. 1321 131 Consists of: 1 - ---- --- Bushing, Pin 2 - ---- --- Seal, Dust
	1 - 108 636 Pin, Tie Rod End Nut Cotter	2-08-4	PIN AND NUT PACKAGE, FRONT SUSPENSION UPPER CONTROL ARM Part No. 1238 409 Consists of: 1 - ---- --- Nut, Pin 1 - ---- --- Pin, Arm 1 - ---- --- Washer, Nut
	1 - 1735 470 Seal, Tie Rod End Dust		PIN AND NUT PACKAGE, FRONT SUSPENSION UPPER CONTROL ARM Part No. 1241 500 Consists of: 1 - ---- --- Nut, Pin 1 - ---- --- Pin, Arm 1 - ---- --- Washer, Nut
	END PACKAGE, TIE ROD INNER Part No. 1818 999 Consists of: 1 - ---- --- Bolt, Tie Rod End Clamp 1 - ---- --- Clamp, Tie Rod End 1 - ---- --- End, Tie Rod Inner 1 - ---- --- Nipple, Lubricant 1 - ---- --- Nut, Tie Rod End 1 - ---- --- Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter 1 - 1735 470 Seal, Tie Rod End Dust	2-08-57	BALL JOINT PACKAGE, FRONT SUSPENSION UPPER . . Part No. 1752 476 Consists of: 1 - ---- --- Ball Joint, Assembly 1 - 128 027 Nut, Ball Joint Stud 1 - ---- --- Pin, Ball Joint Stud Nut Cotter 1 - 1734 267 Retainer, Ball Joint Outer Seat 1 - 1731 264 Seal, Ball Joint Inner 1 - 1734 266 Seal, Ball Joint Outer 1 - 1672 960 Washer, Ball Joint Stud Nut
	END PACKAGE, TIE ROD INNER Part No. 1881 820 Consists of: 1 - ---- --- Bolt, Tie Rod End Clamp 1 - ---- --- Clamp, Tie Rod End 1 - 1673 081 End, Tie Rod Inner 1 - ---- --- Nipple, Lubricant 1 - ---- --- Nut, Tie Rod End 1 - ---- --- Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter 1 - 1673 045 Seal, Tie Rod End Dust		BALL JOINT PACKAGE, FRONT SUSPENSION UPPER . . Part No. 1843 245 Consists of: 1 - ---- --- Ball Joint, Assembly 1 - 128 025 Nut, Ball Joint Stud 1 - ---- --- Pin, Ball Joint Stud Nut Cotter 1 - ---- --- Retainer, Ball Joint Outer Seat 1 - 1731 435 Seal, Ball Joint Inner 1 - ---- --- Seal, Ball Joint Outer 1 - 1672 960 Washer, Ball Joint Stud Nut
	END PACKAGE, TIE ROD INNER Part No. 1881 821 Consists of: 1 - ---- --- Bolt, Tie Rod End Clamp 1 - ---- --- Clamp, Tie Rod End 1 - 1673 080 End, Tie Rod Inner 1 - ---- --- Nipple, Lubricant 1 - ---- --- Nut, Tie Rod End 1 - ---- --- Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter 1 - 1673 045 Seal, Tie Rod End Dust		BALL JOINT PACKAGE, FRONT SUSPENSION UPPER . . Part No. 1843 246 Consists of: 1 - ---- --- Ball Joint, Assembly 1 - 128 027 Nut, Ball Joint Stud 1 - ---- --- Pin, Ball Joint Stud Nut Cotter 1 - 1734 267 Retainer, Ball Joint Outer Seat
2-08-1	PIN PACKAGE, FRONT SUSPENSION UPPER CONTROL ARM OUTER PIVOT Part No. 1326 077 Consists of: 1 - ---- --- Bushing, Pin 1 - ---- --- Nut, Pin 1 - ---- --- Pin, Arm 2 - ---- --- Seal, Dust 1 - ---- --- Washer, Nut		
	PIN PACKAGE, FRONT SUSPENSION UPPER CONTROL ARM OUTER PIVOT Part No. 1326 078 Consists of: 1 - ---- --- Bushing, Pin 1 - ---- --- Nut, Pin 1 - ---- --- Pin, Arm 2 - ---- --- Seal, Dust 1 - ---- --- Washer, Nut		

(Pkg. Cont'd)

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.

Prices and specifications subject to change without notice.

1955-58 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)		2-10-4	PIN and NUT PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM Part No. 1241 500 Consists of: 1 - ---- --- Nut, Pin 1 - ---- --- Pin, Arm 1 - ---- --- Washer, Nut
2-08-58	BOLT and BUSHING PACKAGE, FRONT SUSPENSION UPPER CONTROL ARM SUPPORT BRACKET Part No. E1881 646 Consists of: 2 - ---- --- Bolt, Bushing 2 - ---- --- Bushing, Arm 2 - 271 506 Nut, Bolt 2 - ---- --- Washer, Lock		PIVOT REPAIR PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM OUTER Part No. 1326 086 Consists of: 1 - ---- --- Bushing, Pin 1 - ---- --- Nut, Pin 1 - ---- --- Pin, Arm 1 - ---- --- Seal, Front Dust 1 - ---- --- Seal, Rear Dust 1 - ---- --- Washer, Nut
	BOLT and BUSHING PACKAGE, FRONT SUSPENSION UPPER CONTROL ARM SUPPORT BRACKET . . Part No. E1881 649 Consists of: 2 - ---- --- Bolt, Bushing 2 - ---- --- Bushing, Arm 2 - 120 371 Nut, Bolt 2 - 120 384 Washer, Lock		PIVOT REPAIR PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM OUTER Part No. 1326 087 Consists of: 1 - ---- --- Bushing, Pin 1 - ---- --- Nut, Pin 1 - ---- --- Pin, Arm 1 - ---- --- Seal, Front Dust 1 - ---- --- Seal, Rear Dust 1 - ---- --- Washer, Nut
2-09-1	BAR REPAIR PACKAGE, FRONT SUSPEN- SION UPPER CONTROL ARM INNER PIVOT Part No. 1603 298 Consists of: 1 - ---- --- Bar, Pivot 2 - ---- --- Bushing, Pivot Bar 2 - ---- --- Seal, Bushing Dust	2-10-5	BAR REPAIR PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM INNER PIVOT Part No. 1603 296 Consists of: 1 - ---- --- Bar, Pivot 2 - ---- --- Bushing, Pivot Bar 2 - ---- --- Seal, Bushing Dust
	BAR REPAIR PACKAGE, FRONT SUSPENSION UPPER CONTROL ARM INNER PIVOT Part No. 1603 299 Consists of: 1 - ---- --- Bar, Pivot 2 - 1611 270 Bushing, Pivot Bar 2 - ---- --- Seal, Bushing Dust		BAR REPAIR PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM INNER PIVOT Part No. 1603 297 Consists of: 1 - ---- --- Bar, Pivot 2 - ---- --- Bushing Pivot Bar 2 - 9411 025 Nipple, Lubricant 2 - ---- --- Seal, Bushing Dust
2-09-7	BUSHING and SEAL PACKAGE, FRONT SUSPENSION UPPER CONTROL ARM INNER PIVOT BAR . . . Part No. E1879 502 Consists of: 2 - ---- --- Bushing, Inner Pivot Bar 2 - ---- --- Seal, Inner Pivot Bar Dust	2-10-55	BALL JOINT PACKAGE, FRONT SUSPENSION LOWER . . Part No. 1843 247 Consists of: 1 - ---- --- Ball Joint, Assembly 1 - 128 027 Nut, Ball Joint Stud 1 - ---- --- Pin, Ball Joint Stud Nut Cotter 1 - 1825 009 Seal, Ball Joint 1 - 1672 960 Washer, Ball Joint Stud Nut
	BUSHING and SEAL PACKAGE, FRONT SUSPENSION UPPER CONTROL ARM INNER PIVOT BAR . . Part No. E1879 503 Consists of: 2 - ---- --- Bushing, Inner Pivot Bar 2 - ---- --- Seal, Inner Pivot Bar Dust		BALL JOINT PACKAGE, FRONT SUSPENSION LOWER . . Part No. 1843 248 Consists of: 1 - ---- --- Ball Joint, Assembly 1 - 1671 405 Nut, Ball Joint Stud 1 - 119 209 Pin, Ball Joint Stud Nut Cotter 1 - 1825 303 Seal, Ball Joint 1 - 1672 961 Washer, Ball Joint Stud Nut
2-10-2	BUSHING PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM PIN Part No. 1064 677 Consists of: 1 - ---- --- Bushing, Pin 2 - ---- --- Seal, Dust		
	BUSHING PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM PIN Part No. 1064 678 Consists of: 1 - ---- --- Bushing, Pin 2 - ---- --- Seal, Dust		

★ Indicates use as required.

□ Indicates parts not listed in any previous parts book.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
2-10-57	<p>BUSHING and RETAINER PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM STRUT Part No. 1879 435 Consists of: 1 - 1734 321 Bushing, Arm Strut 1 - 128 027 Nut, Arm Strut Bushing 1 - 119 209 Pin, Arm Strut Bushing Nut Cotter 2 - 1734 341 Retainer, Arm Strut Bushing</p>	(Cont'd)	<p>1 - 1671 446 Lock, End Anchor 1 - 1674 445 Seat, End Anchor Adjusting Bolt 1 - 1674 446 Swivel, End Anchor Adjusting Bolt</p>
2-10-61	<p>SHAFT AND BUSHING PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM. Part No. 1881 647 Consists of: 1 - ---- --- Bushing, Shaft 1 - ---- --- Nut, Bushing 1 - 128 213 Nut, Shaft 1 - 137 214 Pin, Arm 1 - 119 209 Pin, Bushing Nut Cotter 1 - ---- --- Shaft, Arm 1 - ---- --- Washer, Bushing 1 - ---- --- Washer, Shaft Nut</p>	<p>ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING REAR END LEFT Part No. E2084 014</p>	<p>Consists of: 1 - 1735 531 Anchor, End 1 - 1674 451 Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1674 452 Seat, End Anchor Adjusting Bolt 1 - 1674 453 Swivel, End Anchor Adjusting Bolt</p>
<p>SHAFT and BUSHING PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM Part No. 1881 650</p>	<p>Consists of: 1 - ---- --- Bushing, Shaft 1 - ---- --- Nut, Bushing 1 - ---- --- Nut, Shaft 1 - ---- --- Pin, Arm 1 - 119 209 Pin, Bushing 1 - ---- --- Shaft, Arm 1 - 1636 019 Washer, Bushing 1 - ---- --- Washer, Shaft Nut</p>	<p>ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING, REAR END RIGHT Part No. E2084 015</p>	<p>Consists of: 1 - 1735 530 Anchor, End 1 - 1674 451 Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1674 452 Seat, End Anchor Adjusting Bolt 1 - 1674 453 Swivel, End Anchor Adjusting Bolt</p>
2-14-8	<p>ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING, REAR END LEFT Part No. E2084 011 Consists of: 1 - 1735 503 Anchor, End 1 - 1674 444 Bolt, End Anchor Adjusting 1 - 1671 446 Lock, End Anchor 1 - 1674 445 Seat, End Anchor Adjusting Bolt 1 - 1674 446 Swivel, End Anchor Adjusting Bolt</p>	<p>ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING, REAR END Part No. E2084 016</p>	<p>Consists of: 1 - 1735 529 Anchor, End 1 - 1674 451 Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1674 452 Seat, End Anchor Adjusting 1 - 1674 453 Swivel, End Anchor Adjusting Bolt</p>
2-15-4	<p>ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING, REAR END RIGHT Part No. E2084 012</p>	<p>BUSHING PACKAGE, FRONT SUSPENSION UPPER and LOWER CONTROL ARM Part No. 1881 648</p>	<p>Consists of: 1 - ---- --- Bushing, Lower 2 - ---- --- Bushing, Upper</p>
<p>Consists of: 1 - 1735 502 Anchor, End 1 - 1674 444 Bolt, End Anchor Adjusting 1 - 1671 446 Lock, End Anchor 1 - 1674 445 Seat, End Anchor Adjusting Bolt</p>	<p>1 - 1674 446 Swivel, End Anchor Adjusting Bolt</p>	<p>BUSHING PACKAGE, FRONT SUSPENSION UPPER and LOWER CONTROL ARM Part No. 1881 651</p>	<p>Consists of: 1 - ---- --- Bushing, Lower 2 - ---- --- Bushing, Upper</p>
<p>ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING, REAR END Part No. E2084 013</p>	<p>Consists of: 1 - 1674 440 Anchor, End 1 - 1674 444 Bolt, End Anchor Adjusting</p>	4-03-5	<p>LINING PACKAGE, PARKING BRAKE Part No. 1843 178</p>
(Pkg. Cont'd)	<p>Consists of: 10 Feet - ---- --- Lining 78 - ---- --- Rivets 30 - ---- --- Rivets</p>	<p>★ Indicates use as required. ☐ Indicates parts not listed in any previous parts book.</p>	<p>Printed in U.S.A. Prices and specifications subject to change without notice.</p>

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
5-03-1	LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1243 726 Consists of: 6 - ---- --- Lining 2 - ---- --- Lining		LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1692 676 Consists of: 6 - ---- --- Lining 2 - ---- --- Lining
	LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1311 048 Consists of: 6 - ---- --- Lining 2 - ---- --- Lining		LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1692 677 Consists of: 6 - ---- --- Lining 2 - ---- --- Lining
	LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1311 049 Consists of: 8 - ---- --- Lining		LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1692 685 Consists of: 8 - ---- --- Lining
	LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1316 217 Consists of: 6 - ---- --- Lining 2 - ---- --- Lining		LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1818 506 Consists of: 8 - ---- --- Lining
	LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1316 218 Consists of: 6 - ---- --- Lining 2 - ---- --- Lining		LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1818 512 Consists of: 4 - ---- --- Lining 4 - ---- --- Lining
	LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1603 253 Consists of: 6 - ---- --- Lining 2 - ---- --- Lining		LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1818 594 Consists of: 4 - ---- --- Lining 4 - ---- --- Lining
	LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1603 254 Consists of: 6 - ---- --- Lining 2 - ---- --- Lining		LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1843 028 Consists of: 8 - ---- --- Lining
	LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1603 329 Consists of: 4 - ---- --- Lining 2 - ---- --- Lining 2 - ---- --- Lining		LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1879 349 Consists of: 8 - ---- --- Lining
	LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1603 330 Consists of: 4 - ---- --- Lining 2 - ---- --- Lining 2 - ---- --- Lining		LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1879 396 Consists of: 8 - ---- --- Lining
	LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1653 452 Consists of: 8 - ---- --- Lining		LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1879 398 Consists of: 4 - ---- --- Lining 4 - ---- --- Lining
	LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1692 653 Consists of: 8 - ---- --- Lining		LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1879 399 Consists of: 8 - ---- --- Lining
			LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1879 401 Consists of: 8 - ---- --- Lining

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.

Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1879 404 Consists of: 4 - ---- --- Lining 4 - ---- --- Lining	(Cont'd)	1 - 958 659 Cup, Secondary 1 - 1617 379 Seal, Valve 1 - 1318 446 Valve 1 - 857 443 Washer, Piston Cup
	LINING PACKAGE, WHEEL BRAKE SHOE. . Part No. 1879 690 Consists of: 8 - ---- --- Lining		SERVICE PACKAGE, MASTER CYLINDER . . Part No. 1881 645 Consists of: 1 - 1316 628 Boot 1 - ---- --- Cup, Piston 1 - 958 659 Cup, Secondary 1 - 1828 659 Piston 1 - 1617 379 Seal, Valve 1 - 1318 446 Valve 1 - 857 443 Washer, Piston Cup
5-39-1	SERVICE PACKAGE, MASTER CYLINDER . . Part No. 1316 360 Consists of: 1 - ---- --- Boot 1 - ---- --- Cup, Piston 1 - ---- --- Cup, Secondary 1 - ---- --- Seal, Valve 1 - 1318 446 Valve 1 - ---- --- Washer, Piston Cup		SERVICE PACKAGE, MASTER CYLINDER . . Part No. 1881 987 Consists of: 1 - 1828 388 Boot 1 - ---- --- Cup, Piston 1 - 958 659 Cup, Secondary 1 - ---- --- Piston 1 - 1617 379 Seal, Valve 1 - 1318 446 Valve 1 - 857 443 Washer, Piston Cup
	SERVICE PACKAGE, MASTER CYLINDER . . Part No. 1881 643 Consists of: 1 - ---- --- Boot 1 - ---- --- Cup, Piston 1 - ---- --- Cup, Secondary 1 - ---- --- Piston 1 - ---- --- Seal, Valve 1 - 1318 446 Valve 1 - ---- --- Washer, Piston Cup	5-39-2	BOOT, COLLAR and STOP PACKAGE, MASTER CYLINDER Part No. 1316 271 Consists of: 1 - 1316 628 Boot 1 - 1316 627 Collar 1 - ---- --- Stop
	SERVICE PACKAGE, MASTER CYLINDER . . Part No. 1881 645 Consists of: 1 - 1316 628 Boot 1 - ---- --- Cup, Piston 1 - 958 659 Cup, Secondary 1 - 855 891 Piston 1 - 1617 379 Seal, Valve 1 - 1318 446 Valve 1 - 857 443 Washer, Piston Cup	5-39-4	COVER PACKAGE, MASTER CYLINDER . . Part No. 1752 470 Consists of: 1 - 1731 226 Baffle 1 - 1731 225 Cover 1 - 1737 171 Gasket, Cover 1 - 1731 227 Screw, Cover
	SERVICE PACKAGE, MASTER CYLINDER . . Part No. 1603 235 Consists of: 1 - 1316 628 Boot 1 - ---- --- Cup, Piston 1 - 958 659 Cup, Secondary 1 - 1617 379 Seal, Valve 1 - 1318 446 Valve 1 - 857 443 Washer, Piston Cup	5-63-1	SERVICE PACKAGE, WHEEL CYLINDER . . . Part No. 947 580 Consists of: 2 - 1136 872 Boot 2 - 854 038 Cup, Piston
	SERVICE PACKAGE, MASTER CYLINDER . . Part No. 1879 302 Consists of: 1 - 1828 388 Boot 1 - ---- --- Cup, Piston 1 - 958 659 Cup, Secondary 1 - 1828 659 Piston 1 - 1617 379 Seal, Valve 1 - 1318 446 Valve 1 - 857 443 Washer, Piston Cup		SERVICE PACKAGE, WHEEL CYLINDER . . . Part No. 1450 449 Consists of: 2 - 1402 454 Boot 2 - 1405 010 Boot 2 - 77 526 Cup, Piston
	SERVICE PACKAGE, MASTER CYLINDER . . Part No. 1879 303 Consists of: 1 - 1828 388 Boot 1 - ---- --- Cup, Piston		SERVICE PACKAGE, WHEEL CYLINDER . . . Part No. 1450 450 Consists of: 4 - 1402 454 Boot 4 - 639 056 Cup, Piston
			SERVICE PACKAGE, WHEEL CYLINDER . . . Part No. 1818 639 Consists of: 2 - 1136 872 Boot 2 - 1674 080 Cup, Piston

(Pkg. Cont'd)

★ Indicates use as required.
 □ Indicates parts not listed in any previous parts book.

Printed in U.S.A.
 Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
5-63-3	SERVICE PACKAGE, WHEEL CYLINDER PISTON Part No. 1643 178 Consists of: 2 - 1136 872 Boot 2 - 854 038 Cup, Piston 2 - 1140 752 Expander, Piston Cup 2 - 1140 493 Piston 2 - 1141 029 Spring, Piston Return 1 - 1140 556 Spring, Piston Return	(Cont'd)	1 - ---- Seal, Piston Guide 1 - 1631 881 Seat, Check Valve 1 - ---- Seat, Air Valve 1 - 1634 494 Strap, Push Rod Boot Retainer 1 - 1631 873 Valve, Check 1 - ---- Valve, Control 1 - ---- Wick, Guide Seal
	SERVICE PACKAGE, WHEEL CYLINDER PISTON Part No. 1818 834 Consists of: 2 - 1136 872 Boot 2 - 1674 080 Cup, Piston 2 - 1674 081 Expander, Piston Cup 2 - 1312 830 Piston 2 - 1614 894 Spring, Piston Return 1 - 1633 106 Spring, Piston Return		REPAIR PACKAGE, POWER BRAKE Part No. 1675 001 Consists of: 1 - 1674 949 Seal, Air Valve 1 - 1674 949 Seal, Vacuum Valve 1 - 1674 952 Valve, Vacuum 1 - 1674 957 "O" Ring, Housing to Guide 1 - 1674 972 Seal, Bearing to Sleeve 1 - 1674 974 "O" Ring, Bearing to Mounting Plate 1 - 1674 989 "O" Ring, Valve Operating Rod 1 - 1674 991 "O" Ring, Valve Housing to Cover
5-100-1	REPAIR PACKAGE, POWER BRAKE Part No. 1634 497 Consists of: 1 - ---- Buffer, Air Valve Seat 1 - ---- Bumper, Guide Return (thin) 1 - ---- Bumper, Guide Return (thick) 1 - 1631 919 Clip, Push Rod Retainer 1 - ---- Cup, Primary 1 - ---- Cup, Secondary 1 - ---- Cup, Piston Dome 1 - ---- Diaphragm, Valve 1 - 1631 879 Gasket, Output Plug 1 - ---- "O" Ring, Vacuum Chamber Body 1 - ---- "O" Ring, Piston to Guide 1 - ---- "O" Ring, Valve Seat to Guide 1 - ---- Seal, Primary Cup 1 - ---- Seal, Metering Hole 1 - ---- Seal, Piston Guide 1 - 1631 881 Seat, Check Valve 1 - ---- Seat, Air Valve 1 - 1634 494 Strap, Boot Retainer 1 - 1631 873 Valve, Check 1 - ---- Valve, Control 1 - ---- Wick, Guide Seal		REPAIR PACKAGE, POWER BRAKE Part No. 1675 147 Consists of: 1 - 1675 112 Diaphragm, Valve Applying 1 - 1675 123 Diaphragm, Poppet Valve Seat 1 - 1675 137 Gasket, Inspection Hole Screw 1 - 1675 138 Gasket, Air Cleaner Plate 1 - 1675 124 Hose, Vacuum 1 - 1675 135 "O" Ring, Shell 1 - 1673 620 Retainer, Valve Stem Spring 2 - 1675 104 Ring, Valve Stem Snap 1 - 1675 100 Seal, Piston Rod 1 - 1675 128 Seal, Valve Stem 1 - 1675 118 Seat, Poppet Valve, Assy. 1 - 1675 099 Washer, Piston Rod Stop Cushion
	REPAIR PACKAGE, POWER BRAKE Part No. 1639 526 Consists of: 1 - ---- Buffer, Air Valve Seat 1 - ---- Bumper, Guide Return (thin) 1 - ---- Bumper, Guide Return (thick) 1 - 1631 919 Clip, Push Rod Retainer 1 - ---- Cup, Secondary 1 - ---- Cup, Piston Dome 1 - ---- Diaphragm, Valve 1 - 1631 879 Gasket, Output Plug 1 - ---- "O" Ring, Vacuum Chamber Body 1 - ---- "O" Ring, Piston to Guide 1 - ---- "O" Ring, Valve Seat to Guide 1 - 1639 519 Plug, Master Cylinder 1 - ---- Seal, Metering Hole		REPAIR PACKAGE, POWER BRAKE Part No. 1940 788 Consists of: 1 - 1940 790 Bearing, Piston Rod 1 - 1675 112 Diaphragm, Valve Applying 1 - 1675 123 Diaphragm, Poppet Valve Seat 1 - 1675 137 Gasket, Inspection Hole Screw 1 - 1675 124 Hose, Vacuum 1 - 1673 620 Retainer, Valve Stem Spring 2 - 1675 104 Ring, Valve Stem Snap 1 - ---- Seal, Piston Rod 1 - 1675 128 Seal, Valve Stem 1 - 1739 853 Seal, Shell 1 - 1675 118 Seat, Poppet Valve, Assy. 1 - 1675 099 Washer, Piston Rod Stop Cushion
		5-100-3	SEAL PACKAGE, POWER BRAKE CYLINDER Part No. 1940 787 Consists of: 1 - 1940 790 Bearing, Piston Rod 1 - ---- Seal, Piston Rod

(Pkg. Cont'd)

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.
Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
5-100-152	PACKING PACKAGE, POWER BRAKE PISTON Part No. 1673 621 Consists of: 1 - 1675 010 Packing, Piston 1 - 1675 011 Ring, Piston Packing 1 - 1675 013 Wick, Piston Packing	(Cont'd)	1 - ---- Clip, Lever 1 - ---- Screw, Adjusting 1 - ---- Nut
PACKING PACKAGE, POWER BRAKE PISTON Part No. 1820 003 Consists of: 1 - 1739 834 Packing, Piston 1 - 1739 835 Ring, Piston Packing 1 - 1675 013 Wick, Piston Packing	LEVER PACKAGE, CLUTCH RELEASE . . . Part No. E1881 802 Consists of: 1 - ---- Lever, Release 1 - ---- Pin, Lever 1 - ---- Spring, Lever 1 - ---- Strut, Lever 1 - ---- Eyebolt, w/Nut		
6-01-3	SET PACKAGE, CLUTCH Part No. E1752 404 Consists of: 1 - 1730 055 Cover, w/Pressure Plate 1 - 1554 585 Disc, Driving	7-14-10	CLAMP PACKAGE, RADIATOR HOSE Part No. 1450 499 Consists of: 50 - ---- Clamps, Small
SET PACKAGE, CLUTCH Part No. 1818 774 Consists of: 1 - 1730 055 Cover, w/Pressure Plate 1 - 1820 226 Disc, Driving	7-42-1	PUMP PACKAGE, WATER Part No. 1450 779 Consists of: 2 - 1537 951 Gasket, Housing to Cylinder Block 2 - ---- Gasket, Housing to Cylinder Head 1 - 50 082 Gasket, Outlet Elbow 1 - ---- Pump	
6-17-3	LEVER PACKAGE, CLUTCH RELEASE . . . Part No. E1879 651 Consists of: 1 - ---- Lever, Release 1 - ---- Pin, Lever 1 - ---- Spring, Lever 1 - ---- Strut, Lever 1 - ---- Eyebolt, w/Nut	PUMP PACKAGE, WATER Part No. 1603 326 Consists of: 1 - 1326 325 Gasket, Mounting 1 - ---- Pump	
LEVER PACKAGE, CLUTCH RELEASE . . . Part No. 1879 682 Consists of: 1 - ---- Lever, Release 1 - ---- Pin, Lever 1 - ---- Spring, Lever 1 - ---- Strut, Lever 1 - ---- Eyebolt, w/Nut	PUMP PACKAGE, WATER Part No. 1643 164 Consists of: 1 - 1329 288 Gasket, Mounting 1 - ---- Pump		
LEVER PACKAGE, CLUTCH RELEASE . . . Part No. E1879 654 Consists of: 1 - ---- Lever, Release 1 - ---- Pin, Lever 1 - ---- Washer, Adjusting Screw 1 - ---- Clip, Lever 1 - ---- Screw, Adjusting 1 - ---- Nut	PUMP PACKAGE, WATER Part No. 1643 173 Consists of: 1 - 1618 645 Gasket, Mounting 1 - ---- Pump		
LEVER PACKAGE, CLUTCH RELEASE . . . Part No. 1879 652 Consists of: 1 - ---- Lever, Release 1 - ---- Pin, Lever 1 - ---- Spring, Lever 1 - ---- Strut, Lever 1 - ---- Eyebolt, w/Nut	PUMP PACKAGE, WATER Part No. 1643 290 Consists of: 1 - 167 191 Gasket, Mounting 1 - ---- Pump		
LEVER PACKAGE, CLUTCH RELEASE . . . Part No. E1879 655 Consists of: 1 - ---- Lever, Release 1 - ---- Pin, Lever 1 - ---- Washer, Adjusting Screw	PUMP PACKAGE, WATER Part No. 1643 299 Consists of: 1 - 1670 256 Gasket, Inlet Elbow 1 - 1618 645 Gasket, Mounting 1 - ---- Pump		
(Pkg. Cont'd)	PUMP PACKAGE, WATER Part No. 1653 423 Consists of: 1 - 1326 619 Gasket, Inlet Elbow 1 - 1327 475 Gasket, Mounting 1 - ---- Pump		

★ Indicates use as required.
 □ Indicates parts not listed in any previous parts book.

Printed in U.S.A.
 Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	PUMP PACKAGE, WATER Part No. 1692 686 Consists of: 1 - 1674 702 Gasket, Mounting 1 - - - - - Pump	(Cont'd)	1 - 1329 288 Gasket, Body 1 - 1401 671 Impeller 1 - - - - - Pin, Front Bushing 1 - - - - - Pin, Hub 1 - 600 811 Ring, Seal Retainer 1 - - - - - Seal 1 - 1401 670 Shaft 1 - 1123 841 Washer, Grease Retainer 1 - 1674 679 Washer, Seal Retainer 1 - - - - - Washer, Thrust
	PUMP PACKAGE, WATER Part No. 1692 799 Consists of: 1 - 1671 894 Gasket, Mounting 1 - - - - - Pump		
	PUMP PACKAGE, WATER Part No. 1752 218 Consists of: 1 - 1327 475 Gasket, Mounting 1 - - - - - Pump		
	PUMP PACKAGE, WATER Part No. 1752 219 Consists of: 1 - 1673 782 Gasket, Mounting 1 - - - - - Pump		
	PUMP PACKAGE, WATER Part No. 1752 422 Consists of: 1 - 1676 031 Gasket, Mounting 1 - - - - - Pump		
	PUMP PACKAGE, WATER Part No. 1818 610 Consists of: 1 - 1737 705 Gasket, Mounting 1 - - - - - Pump		
7-42-4	REPAIR KIT, WATER PUMP Part No. 1325 977 Consists of: 1 - Bushing, Front 1 - - - - - Bushing, Rear 2 - 323 186 Gasket, Body 2 - 626 322 Gasket, Body Cover 1 - 600 799 Gasket, Body Cover Plate 1 - 1326 324 Gasket, Body Cover Plate 1 - 1326 325 Gasket, Body to Cylinder Block 1 - 600 800 Gasket, Body to Cylinder Block 1 - 622 772 Gasket, By-Pass Elbow 1 - 1558 419 Impeller 10 - - - - - Pin, Hub 1 - - - - - Pin, Hub 1 - 112 020 Pin, Hub 1 - - - - - Pin, Front Bushing 1 - - - - - Seal 1 - 1139 400 Shaft 1 - 51 019 Washer, Cover Plate 1 - 1123 841 Washer, Grease Retainer 1 - 1674 679 Washer, Seal Retainer 1 - - - - - Washer, Thrust		
	REPAIR KIT, WATER PUMP Part No. 1450 021 Consists of: 1 - 1405 842 Bushing, Front 1 - - - - - Bushing, Rear		
			REPAIR KIT, WATER PUMP Part No. 1450 046 Consists of: 1 - 1405 842 Bushing, Front 1 - - - - - Bushing, Rear 1 - 1327 475 Gasket, Body 1 - 1326 619 Gasket, Inlet Elbow 1 - 1401 676 Impeller 1 - - - - - Pin, Front Bushing 1 - - - - - Pin, Hub 1 - 600 811 Ring, Seal Retainer 1 - - - - - Seal 1 - 1401 670 Shaft 1 - 1123 841 Washer, Grease Retainer 1 - 1674 679 Washer, Seal Retainer 1 - - - - - Washer, Thrust
			REPAIR KIT, WATER PUMP Part No. 1450 780 Consists of: 2 - 1537 949 Gasket, Cover Plate 2 - 1537 951 Gasket, Housing to Cylinder Block 2 - 1537 950 Gasket, Housing to Cylinder Head 1 - 50 082 Gasket, Outlet Elbow 1 - 1639 214 Impeller 1 - - - - - Seal 1 - - - - - Shaft, w/Bearing 1 - - - - - Thrower 5 - - - - - Washer, Cover Plate Screw 1 - 1674 679 Washer, Seal Retainer
			REPAIR KIT, WATER PUMP Part No. 1643 229 Consists of: 1 - 1634 365 Impeller 1 - 600 811 Ring, Seal Retainer 1 - - - - - Seal 1 - - - - - Shaft, w/Bearing 1 - - - - - Thrower 1 - 1674 679 Washer, Seal Retainer
			REPAIR KIT, WATER PUMP Part No. 1643 207 Consists of: 1 - 1329 288 Gasket, Body 1 - 1639 184 Impeller 1 - - - - - Seal 1 - - - - - Shaft, w/Bearing 1 - - - - - Thrower 1 - 1674 679 Washer, Seal Retainer

(Pkg. Cont'd)

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.

Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER		CODE	PART NAME AND PART NUMBER
	REPAIR KIT, WATER		(Cont'd)	
	PUMP Part No. 1752 301			1 - 1327 475 Gasket, Water Pump Body
	Consists of:			1 - 1326 619 Gasket, Water Pump Inlet Elbow
	1 - 1327 475 Gasket, Body			8 - 1558 025 Seal, Intake Valve Stem Oil
	1 - 1730 442 Impeller			GASKET SET, ENGINE . . Part No. E1603 294
	1 - ---- Seal			Consists of:
	1 - ---- Shaft, w/Bearing			1 - 1328 371 Gasket, Chain Case Cover
	1 - ---- Throwing			2 - 1634 419 Gasket, Cylinder Head
	1 - 1674 679 Washer, Seal Retainer			2 - 1328 365 Gasket, Cylinder Head Cover
	REPAIR KIT, WATER			1 - 50 082 Gasket, Cylinder Water Outlet
	PUMP Part No. 1879 410			3 - 1636 570 Gasket, Exhaust Pipe Flange
	Consists of:			1 - 1538 543 Gasket, Exhaust Pipe Flange Right Front
	1 - 1674 702 Gasket, Body			1 - 1400 185 Gasket, Fuel Pump Flange
	1 - 1852 594 Impeller			1 - 1730 609 Gasket, Fuel Pump Flange
	1 - ---- Seal			1 - 1326 836 Gasket, Ignition Distributor
	1 - ---- Shaft, w/Bearing			2 - 1329 345 Gasket, Intake Manifold
	1 - ---- Throwing			2 - ---- Gasket, Oil Pan
	1 - 1674 679 Washer, Seal Retainer			2 - ---- Gasket, Oil Pan Front and Rear
	REPAIR KIT, WATER			1 - 1552 291 Gasket, Oil Pump Body
	PUMP Part No. 1752 435			1 - 1328 820 Gasket, Valve Tappet Cover
	Consists of:			1 - 1329 288 Gasket, Water Pump Body
	1 - 1618 645 Gasket, Body			2 - 1329 336 Gasket, Water Pump Housing to Cylinder Block
	1 - 1635 783 Impeller			2 - 1328 845 Gasket, Water Pump Housing to Cylinder Head
	1 - ---- Seal			8 - 1558 025 Oil Seal, Intake Valve Stem
	1 - ---- Shaft, w/Bearing			8 - 1630 241 Shield, Intake Valve Stem Oil
	1 - ---- Throwing			GASKET SET, ENGINE . . Part No. E1603 320
	1 - 1674 679 Washer, Seal Retainer			Consists of:
	REPAIR KIT, WATER			1 - 1326 847 Gasket, Air Cleaner to Carburetor
	PUMP Part No. 1843 447			1 - 1615 551 Gasket, Carburetor Flange
	Consists of:			1 - 1328 371 Gasket, Chain Case Cover
	1 - 1671 191 Gasket, Body			2 - 1738 505 Gasket, Cylinder Head
	1 - 1671 894 Gasket, Body			2 - 1556 205 Gasket, Cylinder Head Cover
	1 - 1673 782 Gasket, Body			1 - 50 082 Gasket, Cylinder Water Outlet
	1 - 1737 705 Gasket, Body			3 - 1636 571 Gasket, Exhaust Pipe Flange
	1 - 1637 724 Impeller			1 - 1730 609 Gasket, Fuel Pump Flange
	1 - ---- Seal			1 - 1400 185 Gasket, Fuel Pump Flange
	1 - ---- Shaft, w/Bearing			1 - 1326 836 Gasket, Ignition Distributor
	1 - ---- Throwing			2 - 1483 553 Gasket, Intake Manifold
	1 - 1674 679 Washer, Seal Retainer			2 - ---- Gasket, Oil Pan
	REPAIR KIT, WATER			2 - ---- Gasket, Oil Pan Front and Rear
	PUMP Part No. 1843 447			1 - 1325 006 Gasket, Valve Tappet Cover
	Consists of:			2 - 1537 951 Gasket, Water Pump Housing to Cylinder Block
	1 - 1671 191 Gasket, Body			2 - 1537 950 Gasket, Water Pump Housing to Cylinder Head
	1 - 1671 894 Gasket, Body			1 - 1326 619 Gasket, Water Pump Inlet Elbow
	1 - 1673 782 Gasket, Body			GASKET SET, ENGINE . . Part No. 1643 111
	1 - 1737 705 Gasket, Body			Consists of:
	1 - 1637 724 Impeller			1 - 1326 847 Gasket, Air Cleaner to Carburetor
	1 - ---- Seal			1 - 1537 668 Gasket, Carburetor Flange
	1 - ---- Shaft, w/Bearing			1 - 1615 551 Gasket, Carburetor Flange
	1 - ---- Throwing			1 - 1634 701 Gasket, Carburetor Flange
	1 - 1674 679 Washer, Seal Retainer			1 - 1328 371 Gasket, Chain Case Cover
9-01-5	GASKET SET, ENGINE . . Part No. E1603 276			
	Consists of:			
	1 - 1535 887 Gasket, Air Cleaner			
	1 - 1326 847 Gasket, Air Cleaner to Carburetor			
	1 - 1326 948 Gasket, Carburetor Flange			
	1 - 1615 551 Gasket, Carburetor Flange			
	1 - 1631 364 Gasket, Carburetor Flange			
	1 - 1327 370 Gasket, Chain Case Cover			
	2 - 1558 386 Gasket, Cylinder Head			
	2 - 1327 377 Gasket, Cylinder Head Cover			
	1 - 50 082 Gasket, Cylinder Water Outlet Elbow			
	3 - 1636 570 Gasket, Exhaust Pipe Flange			
	1 - 1400 185 Gasket, Fuel Pump Flange			
	1 - 1326 836 Gasket, Ignition Distributor			
	2 - 1670 257 Gasket, Intake Manifold			
	2 - ---- Gasket, Oil Pan			
	2 - ---- Gasket, Oil Pan Front and Rear			
	1 - 1552 291 Gasket, Oil Pump Body			
	1 - 863 220 Gasket, Thermostat			
	2 - 1328 047 Gasket, Valve Tappet Cover			
	(Pkg. Cont'd)			(Pkg. Cont'd)

* Indicates use as required.

⊠ Indicates parts not listed in any previous parts book.

1955-58 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)	<ul style="list-style-type: none"> 2 - 1634 419 Gasket, Cylinder Head 2 - 1552 952 Gasket, Cylinder Head Cover 1 - 50 082 Gasket, Cylinder Water Outlet Connection 1 - 1538 543 Gasket, Exhaust Pipe Flange 3 - 1636 570 Gasket, Exhaust Pipe Flange 1 - 1400 185 Gasket, Fuel Pump Flange 1 - 1730 609 Gasket, Fuel Pump Flange 1 - 1326 836 Gasket, Ignition Distributor 2 - 1329 345 Gasket, Intake Manifold 2 - 1550 859 Gasket, Oil Pan 1 - 1552 291 Gasket, Oil Pump Body 2 - ---- --- Gasket, Oil Pan Front and Rear 1 - 1328 820 Gasket, Valve Tappet Cover 1 - 1329 288 Gasket, Water Pump Body 2 - 1329 336 Gasket, Water Pump Housing to Cylinder Block 2 - 1328 845 Gasket, Water Pump Housing to Cylinder Head 8 - 1558 025 Oil Seal, Intake Valve Stem <p>GASKET SET, ENGINE. . . Part No.E1643 253 Consists of:</p> <ul style="list-style-type: none"> 1 - 1535 887 Gasket, Air Cleaner 2 - 1555 466 Gasket, Carburetor Flange 1 - 1631 364 Gasket, Carburetor Flange 1 - 1328 371 Gasket, Chain Case Cover 2 - 1738 505 Gasket, Cylinder Head 2 - 1324 221 Gasket, Cylinder Head Cover 1 - 50 082 Gasket, Cylinder Water Outlet 3 - 1636 571 Gasket, Exhaust Pipe Flange 1 - 1400 185 Gasket, Fuel Pump Flange 1 - 1730 609 Gasket, Fuel Pump Flange 1 - 1326 836 Gasket, Ignition Distributor 2 - 1483 553 Gasket, Intake Manifold 2 - ---- --- Gasket, Oil Pan 2 - 1325 011 Gasket, Oil Pan Front and Rear 1 - 1325 006 Gasket, Valve Tappet Cover 2 - 1537 951 Gasket, Water Pump Housing to Cylinder Block 2 - 1537 950 Gasket, Water Pump Housing to Cylinder Head 8 - 1558 025 Oil Seal, Valve Stem <p>GASKET SET, ENGINE. . . Part No.E1653 413 Consists of:</p> <ul style="list-style-type: none"> 1 - 1326 847 Gasket, Air Cleaner to Carburetor 1 - 1535 887 Gasket, Air Cleaner to Carburetor 1 - 1615 551 Gasket, Carburetor Flange 1 - 1739 564 Gasket, Carburetor Flange 1 - 1327 370 Gasket, Chain Case Cover 2 - 1674 711 Gasket, Cylinder Head 2 - 1327 377 Gasket, Cylinder Head Cover 1 - 50 082 Gasket, Cylinder Water Outlet 3 - 1636 570 Gasket, Exhaust Pipe Flange 1 - 1400 185 Gasket, Fuel Pump Flange 1 - 1326 836 Gasket, Ignition Distributor 2 - 1670 257 Gasket, Intake Manifold 2 - 1327 464 Gasket, Oil Pan 	(Cont'd)	<ul style="list-style-type: none"> 2 - ---- --- Gasket, Oil Pan, Front and Rear 1 - 863 220 Gasket, Thermostat 2 - 1328 047 Gasket, Valve Tappet 1 - 1327 475 Gasket, Water Pump Body 1 - 1326 619 Gasket, Water Pump Inlet Elbow <p>GASKET SET, ENGINE. . . Part No.E1653 415 Consists of:</p> <ul style="list-style-type: none"> 1 - 1328 371 Gasket, Chain Case Cover 2 - 1826 128 Gasket, Cylinder Head 2 - 1556 205 Gasket, Cylinder Head Cover 1 - 50 082 Gasket, Cylinder Water Outlet 3 - 1636 571 Gasket, Exhaust Pipe Flange 1 - 1730 609 Gasket, Fuel Pump Flange 1 - 1326 836 Gasket, Ignition Distributor 2 - 1483 553 Gasket, Intake Manifold 2 - ---- --- Gasket, Oil Pan 2 - ---- --- Gasket, Oil Pan, Front and Rear 1 - 1325 006 Gasket, Valve Tappet Cover 2 - 1537 951 Gasket, Water Pump Housing to Cylinder Block 2 - 1537 950 Gasket, Water Pump Housing to Cylinder Head 1 - 1326 619 Gasket, Water Pump Inlet Elbow <p>GASKET SET, ENGINE. . . Part No.E1653 417 Consists of:</p> <ul style="list-style-type: none"> 1 - 1328 371 Gasket, Chain Case Cover 2 - 1826 128 Gasket, Cylinder Head 2 - 1324 221 Gasket, Cylinder Head Cover 1 - 50 082 Gasket, Cylinder Water Outlet 3 - 1636 571 Gasket, Exhaust Pipe Flange 1 - 1730 609 Gasket, Fuel Pump Flange 1 - 1326 836 Gasket, Ignition Distributor 2 - 1483 553 Gasket, Intake Manifold 2 - ---- --- Gasket, Oil Pan 2 - ---- --- Gasket, Oil Pan, Front and Rear 1 - 1325 006 Gasket, Valve Tappet Cover 2 - 1537 951 Gasket, Water Pump Housing to Cylinder Block 2 - 1537 950 Gasket, Water Pump Housing to Cylinder Head <p>GASKET SET, ENGINE. . . Part No. 1752 440 Consists of:</p> <ul style="list-style-type: none"> 1 - 952 062 Gasket, Air Cleaner to Carburetor 1 - 1326 847 Gasket, Air Cleaner to Carburetor 1 - 622 772 Gasket, By-Pass Elbow 1 - 637 191 Gasket, Carburetor Flange 1 - 1552 874 Gasket, Carburetor Flange 1 - 1615 860 Gasket, Carburetor Flange 1 - 1630 472 Gasket, Carburetor Flange 1 - 1122 450 Gasket, Chain Case Cover 1 - 695 441 Gasket, Chain Case Cover Plate 1 - 1326 319 Gasket, Cylinder Head

(Pkg. Cont'd)

(Pkg. Cont'd)

★ Indicates use as required.

□ Indicates parts not listed in any previous parts book.

Printed in U.S.A.
Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)	1 - 1636 571 Gasket, Exhaust Pipe Flange	(Cont'd)	1 - 50 082 Gasket, Cylinder Water Outlet
	1 - 688 482 Gasket, Fuel Pump Flange		2 - 1636 571 Gasket, Exhaust Pipe Flange
	1 - 1313 836 Gasket, Fuel Pump Flange		1 - 1730 609 Gasket, Fuel Pump Flange
	1 - 1313 837 Gasket, Fuel Pump Flange		1 - 1326 836 Gasket, Ignition Distributor
	1 - ---- --- Gasket, Manifold Center		2 - 1733 030 Gasket, Intake Manifold
	1 - ---- --- Gasket, Manifold End		2 - ---- --- Gasket, Oil Pan
	1 - 866 680 Gasket, Oil Pan Front and Rear		2 - ---- --- Gasket, Oil Pan Front and Rear
	1 - ---- --- Gasket, Oil Pan, Left		2 - 1325 006 Gasket, Valve Tappet Cover
	1 - ---- --- Gasket, Oil Pan, Right		1 - 1671 894 Gasket, Water Pump Body
	1 - 618 622 Gasket, Oil Pressure Relief Valve Cap		2 - 1537 951 Gasket, Water Pump Housing to Cylinder Block
	1 - 695 442 Gasket, Oil Pump Body		2 - 1537 950 Gasket, Water Pump Housing to Cylinder Head
	1 - 1124 984 Gasket, Oil Pump Cover		
	2 - ---- --- Gasket, Valve Spring Cover		GASKET SET, ENGINE. . Part No. 1879 667
	4 - 693 959 Gasket, Valve Spring Cover Screw		Consists of:
	1 - 50 082 Gasket, Water Outlet Elbow		1 - 1328 371 Gasket, Chain Case Cover
	1 - 1735 011 Gasket, Water Pump Body		2 - 1852 191 Gasket, Cylinder Head
	1 - 1735 036 Gasket, Water Pump Housing to Cylinder Block		2 - 1552 952 Gasket, Cylinder Head Cover
	1 - 1326 325 Gasket, Water Pump to Block		1 - 50 082 Gasket, Cylinder Water Outlet
			3 - 1636 570 Gasket, Exhaust Pipe Flange
	GASKET SET, ENGINE. . Part No. 1752 443		1 - 1538 543 Gasket, Exhaust Pipe Flange, Right Front
	Consists of:		1 - 1730 609 Gasket, Fuel Pump Flange
	1 - 1618 685 Gasket, Chain Case Cover		1 - 1326 836 Gasket, Ignition Distributor
	2 - 1731 552 Gasket, Cylinder Head		2 - 1734 850 Gasket, Intake Manifold
	2 - 1827 403 Gasket, Cylinder Head Cover		2 - ---- --- Gasket, Oil Pan
	1 - 50 082 Gasket, Cylinder Water Outlet		2 - ---- --- Gasket, Oil Pan, Front and Rear
	2 - 1636 570 Gasket, Exhaust Pipe Flange		1 - 1552 291 Gasket, Oil Pump Body
	1 - 1400 185 Gasket, Fuel Pump Flange		1 - 1328 820 Gasket, Valve Tappet Cover
	1 - 1326 836 Gasket, Ignition Distributor		1 - 1329 288 Gasket, Water Pump Body
	2 - 1828 052 Gasket, Intake Manifold		1 - 1671 191 Gasket, Water Pump Body
	1 - 1637 570 Gasket, Intake Manifold, Front		1 - 1673 782 Gasket, Water Pump Body
	1 - 1637 571 Gasket, Intake Manifold, Rear		2 - 1329 336 Gasket, Water Pump Housing to Cylinder Block
	2 - ---- --- Gasket, Oil Pan		2 - 1328 845 Gasket, Water Pump Housing to Cylinder Head
	2 - ---- --- Gasket, Oil Pan Front and Rear		
	1 - 1552 291 Gasket, Oil Pump Body		GASKET SET, ENGINE. . Part No. E1843 261
	1 - 1618 645 Gasket, Water Pump Body		Consists of:
	1 - 1676 031 Gasket, Water Pump Body		1 - 1737 763 Gasket, Chain Case Cover
			2 - 1737 636 Gasket, Cylinder Head
	GASKET SET, ENGINE. . Part No. E1752 445		2 - 1821 440 Gasket, Cylinder Head Cover
	Consists of:		1 - 50 082 Gasket, Cylinder Water Outlet Elbow
	1 - 1732 789 Gasket, Chain Case Cover		2 - 1821 640 Gasket, Exhaust Pipe Flange
	2 - 1827 703 Gasket, Cylinder Head		2 - 1855 029 Gasket, Exhaust Pipe Flange
	2 - 1327 377 Gasket, Cylinder Head Cover		1 - 1400 185 Gasket, Fuel Pump Flange
	1 - 50 082 Gasket, Cylinder Water Outlet		1 - 1326 836 Gasket, Ignition Distributor
	2 - 1636 571 Gasket, Exhaust Pipe Flange		1 - 1737 709 Gasket, Intake Manifold
	1 - 1400 185 Gasket, Fuel Pump Flange		1 - 1737 770 Gasket, Oil Pan
	1 - 1326 836 Gasket, Ignition Distributor		1 - 618 622 Gasket, Oil Pressure Relief Valve Cap
	2 - 1637 582 Gasket, Intake Manifold		8 - 150 189 Gasket, Spark Plug
	2 - 1327 464 Gasket, Oil Pan		1 - 1737 705 Gasket, Water Pump Body
	2 - ---- --- Gasket, Oil Pan Front and Rear		2 - 1737 761 Gasket, Water Pump to Cylinder Block
	2 - 1328 047 Gasket, Valve Tappet		
	1 - 1327 475 Gasket, Water Pump Body		GASKET SET, ENGINE. . Part No. E1843 264
			Consists of:
	GASKET SET, ENGINE. . Part No. 1752 447		1 - 1328 371 Gasket, Chain Case Cover
	Consists of:		2 - 1826 128 Gasket, Cylinder Head
	1 - 1328 371 Gasket, Chain Case Cover		
	2 - 1826 128 Gasket, Cylinder Head		
	2 - 1324 221 Gasket, Cylinder Head Cover		
	(Pkg. Cont'd)		

★ Indicates use as required.

□ Indicates parts not listed in any previous parts book.

Printed in U.S.A.

Prices and specifications subject to change without notice.

1955-58 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)			
	2 - 1556 205 Gasket, Cylinder Head Cover		GASKET PACKAGE, CRANKSHAFT BEARING CAP NO. 5 . . Part No. E1752 493
	1 - 50 082 Gasket, Cylinder Water Outlet		Consists of:
	2 - 1636 571 Gasket, Exhaust Pipe Flange		1 - ---- Oil Seal, Right
	1 - 1730 609 Gasket, Fuel Pump Flange		1 - ---- Oil Seal, Left
	1 - 1326 836 Gasket, Ignition Distributor	9-11-1	OIL SEAL PACKAGE, CRANKSHAFT REAR
	2 - 1733 030 Gasket, Intake Manifold		BEARING Part No. 1326 093
	2 - ---- Oil Pan		Consists of:
	2 - ---- Gasket, Oil Pan Front and Rear		2 - ---- Oil Seal, Bearing
	1 - 1325 006 Gasket, Valve Tappet Cover		1 - ---- Oil Seal, Bearing Cap, Left
	1 - 1671 894 Gasket, Water Pump Body		1 - ---- Oil Seal, Bearing Cap, Right
	2 - 1537 951 Gasket, Water Pump Housing to Cylinder Block		
	2 - 1537 950 Gasket, Water Pump Housing to Cylinder Head		OIL SEAL PACKAGE, CRANKSHAFT REAR
			BEARING Part No. 1450 866
	GASKET SET, ENGINE. . Part No. E1879 316		Consists of:
	Consists of:		1 - 1555 716 Gasket, Cap, Left
	1 - 1328 371 Gasket, Chain Case Cover		1 - 1555 715 Gasket, Cap, Right
	2 - 1852 271 Gasket, Cylinder Head		2 - ---- Oil Seal
	2 - 1552 952 Gasket, Cylinder Head Cover		
	1 - 50 082 Gasket, Cylinder Water Outlet		OIL SEAL PACKAGE, CRANKSHAFT REAR
	3 - 1636 570 Gasket, Exhaust Pipe Flange		BEARING Part No. E1692 746
	1 - 1730 609 Gasket, Fuel Pump Flange		Consists of:
	1 - 1326 836 Gasket, Ignition Distributor		2 - ---- Oil Seal
	2 - 1734 850 Gasket, Intake Manifold		1 - ---- Oil Seal, Bearing Cap, Left
	2 - ---- Gasket, Oil Pan		1 - ---- Oil Seal, Bearing Cap, Right
	2 - ---- Gasket, Oil Pan Front and Rear		
	8 - 150 189 Gasket, Spark Plug		OIL SEAL PACKAGE, CRANKSHAFT REAR
	1 - 1328 820 Gasket, Valve Tappet Cover		BEARING Part No. E1818 781
	1 - 1673 782 Gasket, Water Pump Body		Consists of:
	2 - 1329 336 Gasket, Water Pump Housing to Cylinder Block		2 - ---- Oil Seal, Crankshaft Rear Bearing
	2 - 1328 845 Gasket, Water Pump Housing to Cylinder Head		2 - ---- Oil Seal, Crankshaft Rear Bearing Retainer
		9-39-1	GASKET PACKAGE, VALVE GRIND Part No. 1325 976
	GASKET SET, ENGINE. . Part No. 1879 671		Consists of:
	Consists of:		1 - 1326 319 Gasket, Cylinder Head
	1 - 1328 371 Gasket, Chain Case Cover		2 - 863 220 Gasket, Thermostat
	2 - 1852 191 Gasket, Cylinder Head		2 - ---- Gasket, Valve Spring
	2 - 1328 365 Gasket, Cylinder Head Cover		4 - ---- Gasket, Valve Spring Cover Screw
	1 - 50 082 Gasket, Cylinder Water Outlet		1 - 50 082 Gasket, Water Outlet Connection
	3 - 1636 570 Gasket, Exhaust Pipe Flange		1 - 622 772 Gasket, Water Pump By-Pass
	1 - 1730 609 Gasket, Fuel Pump Flange		
	1 - 1326 836 Gasket, Ignition Distributor		GASKET PACKAGE, VALVE GRIND Part No. E1603 277
	2 - 1734 850 Gasket, Intake Manifold		Consists of:
	2 - ---- Gasket, Oil Pan		2 - 1558 386 Gasket, Cylinder Head
	2 - ---- Gasket, Oil Pan, Front and Rear		2 - 1327 377 Gasket, Cylinder Head Cover
	1 - 1328 820 Gasket, Valve Tappet Cover		3 - 1636 570 Gasket, Exhaust Pipe Flange
	1 - 1673 782 Gasket, Water Pump Body		2 - 1670 257 Gasket, Intake Manifold
	2 - 1329 336 Gasket, Water Pump Housing to Cylinder Block		2 - 1328 047 Gasket, Valve Tappet Cover
	2 - 1328 845 Gasket, Water Pump Housing to Cylinder Head		8 - 1558 025 Oil Seal, Intake Valve Stem
9-10-2	GASKET PACKAGE, CRANKSHAFT BEARING CAP NO. 5 . . Part No. 1326 091		GASKET PACKAGE, VALVE GRIND Part No. E1603 295
	Consists of:		Consists of:
	1 - ---- Oil Seal, Right		2 - 1634 419 Gasket, Cylinder Head
	1 - ---- Oil Seal, Left		2 - 1328 365 Gasket, Cylinder Head Cover
			1 - 1538 543 Gasket, Exhaust Pipe Flange
			(Pkg. Cont'd)

* Indicates use as required.
 B Indicates parts not listed in any previous parts book.

Printed in U.S.A.
 Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)	3 - 1636 570 Gasket, Exhaust Pipe Flange	(Cont'd)	2 - 1324 221 Gasket, Cylinder Head Cover
	2 - 1329 345 Gasket, Intake Manifold		3 - 1636 571 Gasket, Exhaust Pipe Flange
	1 - 1328 820 Gasket, Valve Tappet Cover		2 - 1483 553 Gasket, Intake Manifold
	2 - 1328 845 Gasket, Water Pump Housing to Cylinder Head		1 - 1325 006 Gasket, Valve Tappet Cover
	8 - 1630 241 Shield, Intake Valve Stem Oil		2 - 1537 950 Gasket, Water Pump Housing to Cylinder Head
	8 - 1558 025 Oil Seal, Intake Valve Stem		
	GASKET PACKAGE, VALVE GRIND Part No.E1603 321		GASKET PACKAGE, VALVE GRIND Part No.E1752 444
	Consists of:		Consists of:
	2 - 1738 505 Gasket, Cylinder Head		2 - 1731 552 Gasket, Cylinder Head
	2 - 1556 205 Gasket, Cylinder Head Cover		2 - 1827 403 Gasket, Cylinder Head Cover
	3 - 1636 571 Gasket, Exhaust Pipe Flange		2 - 1636 570 Gasket, Exhaust Pipe Flange
	2 - 1483 553 Gasket, Intake Manifold		2 - 1828 052 Gasket, Intake Manifold
	1 - 1325 006 Gasket, Valve Tappet Cover		1 - 1637 570 Gasket, Intake Manifold, Front
	2 - 1537 950 Gasket, Water Pump		1 - 1637 571 Gasket, Intake Manifold, Rear
	GASKET PACKAGE, VALVE GRIND Part No.E1643 112		GASKET PACKAGE, VALVE GRIND Part No.E1752 446
	Consists of:		Consists of:
	2 - 1634 419 Gasket, Cylinder Head		2 - 1827 703 Gasket, Cylinder Head
	2 - 1552 952 Gasket, Cylinder Head Cover		2 - 1327 377 Gasket, Cylinder Head Cover
	3 - 1636 570 Gasket, Exhaust Pipe Flange		2 - 1636 571 Gasket, Exhaust Pipe Flange
	1 - 1538 543 Gasket, Exhaust Pipe Flange		2 - 1637 582 Gasket, Intake Manifold
	2 - 1329 345 Gasket, Intake Manifold		2 - 1328 047 Gasket, Valve Tappet
	1 - 1328 820 Gasket, Valve Tappet Cover		
	2 - 1328 845 Gasket, Water Pump Housing to Cylinder Head		GASKET PACKAGE, VALVE GRIND Part No.E1752 448
	8 - 1558 025 Oil Seal, Intake Valve Stem		Consists of:
	GASKET PACKAGE, VALVE GRIND Part No.E1643 254		2 - 1826 128 Gasket, Cylinder Head
	Consists of:		2 - 1324 221 Gasket, Cylinder Head Cover
	2 - 1738 505 Gasket, Cylinder Head		2 - 1636 571 Gasket, Exhaust Pipe Flange
	2 - 1324 221 Gasket, Cylinder Head Cover		2 - 1733 030 Gasket, Intake Manifold
	3 - 1636 571 Gasket, Exhaust Pipe Flange		1 - 1325 006 Gasket, Valve Tappet Cover
	2 - 1483 553 Gasket, Intake Manifold		2 - 1537 950 Gasket, Water Pump Housing to Cylinder Head
	1 - 1325 006 Gasket, Valve Tappet Cover		
	2 - 1537 950 Gasket, Water Pump Housing to Cylinder Head		GASKET PACKAGE, VALVE GRIND Part No.E1752 453
	8 - 1558 025 Oil Seal, Valve Stem		Consists of:
	GASKET PACKAGE, VALVE GRIND Part No.E1653 414		2 - 1826 128 Gasket, Cylinder Head
	Consists of:		2 - 1556 205 Gasket, Cylinder Head Cover
	2 - 1674 711 Gasket, Cylinder Head		2 - 1636 571 Gasket, Exhaust Pipe Flange
	2 - 1327 377 Gasket, Cylinder Head Cover		2 - 1733 030 Gasket, Intake Manifold
	3 - 1636 570 Gasket, Exhaust Pipe Flange		1 - 1325 006 Gasket, Valve Tappet Cover
	2 - 1670 257 Gasket, Intake Manifold		2 - 1537 950 Gasket, Water Pump Housing to Cylinder Head
	2 - 1328 047 Gasket, Valve Tappet		
	GASKET PACKAGE, VALVE GRIND Part No.E1653 416		GASKET PACKAGE, VALVE GRIND Part No.E1752 681
	Consists of:		Consists of:
	2 - 1826 128 Gasket, Cylinder Head		2 - 1852 864 Gasket, Cylinder Head
	2 - 1556 205 Gasket, Cylinder Head Cover		2 - 1552 952 Gasket, Cylinder Head Cover
	3 - 1636 571 Gasket, Exhaust Pipe Flange		3 - 1636 570 Gasket, Exhaust Pipe Flange
	2 - 1483 553 Gasket, Intake Manifold		1 - 1538 543 Gasket, Exhaust Pipe Flange, Right Front
	1 - 1325 006 Gasket, Valve Tappet Cover		2 - 1734 850 Gasket, Intake Manifold
	2 - 1537 950 Gasket, Water Pump Housing to Cylinder Head		1 - 1328 820 Gasket, Valve Tappet Cover
	GASKET PACKAGE, VALVE GRIND Part No.E1653 418		2 - 1328 845 Gasket, Water Pump Housing to Cylinder Head
	Consists of:		
	2 - 1826 128 Gasket, Cylinder Head		

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.

Prices and specifications subject to change without notice.

1955-58 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	GASKET PACKAGE, VALVE GRIND Part No. E1843 263 Consists of: 2 - 1737 636 Gasket, Cylinder Head 2 - 1821 440 Gasket, Cylinder Head Cover 2 - 1821 640 Gasket, Exhaust Pipe Flange 2 - 1855 029 Gasket, Exhaust Pipe Flange 1 - 1737 709 Gasket, Intake Manifold 2 - 1737 761 Gasket, Water Pump to Cylinder Block	(Cont'd)	1 - ---- --- Nut 1 - 604 504 Plate 1 - 604 505 Shaft 1 - 1670 514 Shield 1 - 644 876 Spacer 1 - 683 057 Stop 1 - 960 003 Thermostat
	GASKET PACKAGE, VALVE GRIND Part No. E1879 317 Consists of: 2 - 1852 271 Gasket, Cylinder Head 2 - 1552 952 Gasket, Cylinder Head Cover 3 - 1636 570 Gasket, Exhaust Pipe Flange 2 - 1734 850 Gasket, Intake Manifold 2 - 1328 820 Gasket, Valve Tappet Cover 2 - 1328 845 Gasket, Water Pump Housing to Cylinder Head		PACKAGE, MANIFOLD HEAT CONTROL Part No. E1752 419 Consists of: 1 - 1736 012 Bolt 2 - 651 251 Bushing 1 - 601 420 Gasket 1 - 1409 594 Lock 1 - ---- --- Nut 1 - 604 504 Plate 1 - 1632 470 Shaft 1 - 1670 514 Shield 1 - 644 876 Spacer 1 - 683 057 Stop 1 - 960 003 Thermostat
	GASKET PACKAGE, VALVE GRIND Part No. E1879 668 Consists of: 2 - 1852 191 Gasket, Cylinder Head 2 - 1552 952 Gasket, Cylinder Head Cover 3 - 1636 570 Gasket, Exhaust Pipe Flange 1 - 1538 543 Gasket, Exhaust Pipe Flange, Right and Front 2 - 1734 850 Gasket, Intake Manifold 1 - 1328 820 Gasket, Valve Tappet Cover 2 - 1328 845 Gasket, Water Pump Housing to Cylinder Head	10-07-3	SHAFT and ROTOR PACKAGE, OIL PUMP DRIVE Part No. 1316 143 Consists of: 1 - 1314 602 Rotor, Outer 1 - ---- --- Shaft, Drive Assembly
	GASKET PACKAGE, VALVE GRIND Part No. E1879 672 Consists of: 2 - 1852 191 Gasket, Cylinder Head 2 - 1328 365 Gasket, Cylinder Head Cover 3 - 1636 570 Gasket, Exhaust Pipe Flange 2 - 1734 850 Gasket, Intake Manifold 1 - 1328 820 Gasket, Valve Tappet Cover 2 - 1328 845 Gasket, Water Pump Housing to Cylinder Head	10-24-1	GASKET PACKAGE, OIL PAN Part No. 933 438 Consists of: 2 - 866 680 Gasket, Oil Pan Front and Rear 1 - ---- --- Gasket, Oil Pan Left 1 - ---- --- Gasket, Oil Pan Right
9-40-1	GASKET SET, VALVE SPRING COVER Part No. 980 583 Consists of: 2 - ---- --- Gasket, Cover 4 - ---- --- Gasket, Stud Nut		GASKET PACKAGE, OIL PAN Part No. 1315 483 Consists of: 2 - ---- --- Gasket, Oil Pan Front and Rear 2 - ---- --- Gasket, Oil Pan Right and Left
9-50-1	GASKET SET, MANIFOLD Part No. 780 460 Consists of: 1 - ---- --- Gasket, Center 4 - ---- --- Gasket, End		GASKET PACKAGE, OIL PAN Part No. 1450 047 Consists of: 2 - ---- --- Gasket, Oil Pan Front and Rear 2 - ---- --- Gasket, Oil Pan Right and Left
9-58-1	PACKAGE, MANIFOLD HEAT CONTROL Part No. E1752 418 Consists of: 1 - 1736 012 Bolt 2 - 651 251 Bushing 1 - 601 420 Gasket 1 - 1409 594 Lock		GASKET PACKAGE, OIL PAN Part No. 1450 996 Consists of: 2 - ---- --- Gasket, Oil Pan Front and Rear 2 - ---- --- Gasket, Oil Pan Right and Left
			GASKET PACKAGE, OIL PAN Part No. 1643 294 Consists of: 2 - ---- --- Gasket, Oil Pan Front and Rear 2 - ---- --- Gasket, Oil Pan Right and Left

(Pkg. Cont'd)

★ Indicates use as required.
 □ Indicates parts not listed in any previous parts book.

Printed in U.S.A.
 Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
10-24-2	SEAL and PLATE PACKAGE, OIL PAN FRONT END OIL Part No. 1115 100 Consists of: 1 - ---- --- Plate, Oil Pan Front End Oil Seal 1 - 1066 873 Seal, Oil Pan Front End Oil	(Cont'd)	1 - ---- --- Clamp 2 - 120 369 Nut 2 - 120 382 Washer, Lock
10-26-1	OIL FILTER KIT Part No. 1123 152 Consists of: 1 - ---- --- Filter, Oil	CLAMP PACKAGE, EXHAUST PIPE Part No. 1325 982 Consists of: 1 - 181 639 Bolt 1 - ---- --- Clamp 1 - 120 369 Nut 1 - 120 382 Washer, Lock	
10-26-2	ADAPTER PACKAGE, OIL FILTER Part No. 1450 553 Consists of: 1 - 1320 517 Bracket, w/Clamp 1 - 137 420 Elbow 1 - 431 537 Nipple 2 - ---- --- Screw, Oil Filter Attaching 1 - ---- --- Tube, Engine to Oil Filter 1 - ---- --- Tube, Oil Filter to Engine 2 - 120 382 Washer, Lock 1 - 120 394 Washer, Plain	CLAMP PACKAGE, EXHAUST PIPE Part No. 1450 618 Consists of: 2 - 181 646 Bolt 1 - ---- --- Clamp 2 - 120 369 Nut 2 - 120 382 Washer, Lock	
10-26-8	CARTRIDGE, OIL FILTER Part No. 1610 435 Consists of: 1 - ---- --- Cartridge, Oil Filter 1 - 852 750 Gasket, Cover 1 - 1122 887 Gasket, Cover 1 - 1312 606 Gasket, Cover	CLAMP PACKAGE, EXHAUST PIPE Part No. 1603 350 Consists of: 2 - 181 639 Bolt 1 - ---- --- Clamp 2 - 120 369 Nut 2 - 120 382 Washer, Lock	
	CARTRIDGE, OIL FILTER Part No. 1634 447 Consists of: 1 - ---- --- Cartridge, Oil Filter 1 - ---- --- Gasket, Cover 1 - ---- --- Gasket, Retainer	CLAMP PACKAGE, EXHAUST PIPE Part No. 1603 351 Consists of: 2 - 181 639 Bolt 1 - ---- --- Clamp 2 - 120 369 Nut 2 - 120 382 Washer, Lock	
	CARTRIDGE, OIL FILTER Part No. 1821 552 Consists of: 1 - ---- --- Cartridge, Oil Filter 1 - ---- --- Gasket, Cover	CLAMP PACKAGE, EXHAUST PIPE Part No. 1603 364 Consists of: 2 - 120 376 Nut 1 - ---- --- Saddle 1 - ---- --- U-Bolt 2 - 120 214 Washer, Lock	
11-02-1	CLAMP PACKAGE, INTERMEDIATE TAIL PIPE Part No. 1843 008 Consists of: 2 - 120 376 Nut 1 - ---- --- Saddle 1 - ---- --- U-Bolt 2 - 120 214 Washer, Lock	CLAMP PACKAGE, EXHAUST PIPE Part No. 1603 365 Consists of: 2 - 120 376 Nut 1 - ---- --- Saddle 1 - ---- --- U-Bolt 2 - 120 214 Washer, Lock	
	CLAMP PACKAGE, INTERMEDIATE TAIL PIPE Part No. 1843 009 Consists of: 2 - 120 376 Nut 1 - ---- --- Saddle 1 - ---- --- U-Bolt 2 - 120 214 Washer, Lock	CLAMP PACKAGE, EXHAUST PIPE Part No. 1843 008 Consists of: 2 - 120 376 Nut 1 - ---- --- Saddle 1 - ---- --- U-Bolt 2 - 120 214 Washer, Lock	
11-08-1	CLAMP PACKAGE, EXHAUST PIPE Part No. 1064 458 Consists of: 2 - 181 639 Bolt	CLAMP PACKAGE, EXHAUST PIPE Part No. 1843 009 Consists of: 2 - 120 376 Nut 1 - ---- --- Saddle 1 - ---- --- U-Bolt 2 - 120 214 Washer, Lock	

(Pkg. Cont'd)

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.
 Prices and specifications subject to change without notice.

1955-58 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	CLAMP PACKAGE, EXHAUST PIPE Part No. 1843 010 Consists of: 2 - 120 368 Nut 1 - ---- --- Saddle 1 - ---- --- U-Bolt 2 - 120 214 Washer, Lock		CLAMP PACKAGE, TAIL PIPE SUPPORT . . Part No. 1843 009 Consists of: 2 - 120 376 Nut 1 - ---- --- Saddle 1 - ---- --- U-Bolt 2 - 120 214 Washer, Lock
	CLAMP PACKAGE, EXHAUST PIPE Part No. 1843 407 Consists of: 2 - 120 376 Nut 1 - ---- --- Saddle 1 - ---- --- U-Bolt 2 - 120 214 Washer, Lock 2 - 120 387 Washer, Plain		SUPPORT PACKAGE, TAIL PIPE, REAR . . . Part No. 1881 684 Consists of: 2 - ---- --- Bolt 2 - ---- --- Nut 1 - ---- --- Support 2 - ---- --- Washer, Lock 2 - ---- --- Washer, Plain
	CLAMP PACKAGE, EXHAUST PIPE Part No. 1843 409 Consists of: 4 - 120 376 Nut 1 - ---- --- Saddle 2 - ---- --- U-Bolt 4 - 120 214 Washer, Lock		SUPPORT PACKAGE, TAIL PIPE FRONT . . . Part No. 1881 685 Consists of: 2 - ---- --- Bolt 2 - ---- --- Nut 1 - ---- --- Support 2 - ---- --- Washer, Lock 2 - ---- --- Washer, Plain
11-09-1	CLAMP PACKAGE, TAIL PIPE Part No. 1064 458 Consists of: 2 - 181 639 Bolt 1 - ---- --- Clamp 2 - 120 369 Nut 2 - 120 382 Washer, Lock	14-30-4	REPAIR PACKAGE, CARBURETOR Part No. E1631 365 Consists of: 1 - ---- --- Ball, Discharge Check 1 - ---- --- Ball, Inlet Check 1 - ---- --- Gasket, Air Horn 1 - ---- --- Gasket, By-Pass Jet 1 - ---- --- Gasket, Discharge Nozzle 1 - ---- --- Gasket, Discharge Nozzle Screw 2 - ---- --- Gasket, Metering Jet 1 - ---- --- Gasket, Main Body 1 - ---- --- Gasket, Thermostat Cover 2 - ---- --- Jet, Main Metering 1 - ---- --- Jet, Power By-Pass 1 - ---- --- Needle, w/Seat, Float 2 - ---- --- Pin, Cotter 1 - ---- --- Pump, w/Rod 2 - ---- --- Plug, Channel 1 - ---- --- Spring, Float Pin 1 - ---- --- Spring, Pump 2 - ---- --- Valve, Idle Needle
	CLAMP PACKAGE, TAIL PIPE Part No. 1064 459 Consists of: 2 - 181 639 Bolt 1 - ---- --- Clamp 2 - 120 369 Nut 2 - 120 382 Washer, Lock		REPAIR PACKAGE, CARBURETOR Part No. E1631 682 Consists of: 1 - ---- --- Ball, Discharge Check 1 - ---- --- Ball, Inlet Check 1 - ---- --- Gasket, Air Horn 1 - ---- --- Gasket, By-Pass Jet 1 - ---- --- Gasket, Discharge Nozzle 1 - ---- --- Gasket, Discharge Nozzle Screw 2 - ---- --- Gasket, Metering Jet 1 - ---- --- Gasket, Main Body 1 - ---- --- Gasket, Thermostat Cover 2 - ---- --- Jet, Main Metering 1 - ---- --- Jet, Power By-Pass 1 - ---- --- Needle, w/Seat, Float
	CLAMP PACKAGE, TAIL PIPE Part No. 1843 008 Consists of: 2 - 120 376 Nut 1 - ---- --- Saddle 1 - ---- --- U-Bolt 2 - 120 214 Washer, Lock		
	CLAMP PACKAGE, TAIL PIPE Part No. 1843 009 Consists of: 2 - 120 376 Nut 1 - ---- --- Saddle 1 - ---- --- U-Bolt 2 - 120 214 Washer, Lock		
11-10-1	CLAMP PACKAGE, TAIL PIPE SUPPORT . . Part No. 1843 008 Consists of: 2 - 120 376 Nut 1 - ---- --- Saddle 1 - ---- --- U-Bolt 2 - 120 214 Washer, Lock		

(Pkg. Cont'd)

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)	2 - ---- Pin, Cotter 2 - ---- Plug, Channel 1 - ---- Pump, w/Rod 1 - ---- Spring, Float Pin 1 - ---- Spring, Pump 2 - ---- Valve, Idle Needle REPAIR PACKAGE, CARBURETOR Part No. E1676 720 Consists of: 1 - ---- Ball, Discharge Check 1 - ---- Ball, Inlet Check 1 - ---- Gasket, Air Horn 1 - ---- Gasket, By-Pass Jet 1 - ---- Gasket, Discharge Nozzle 1 - ---- Gasket, Discharge Nozzle Screw 2 - ---- Gasket, Metering Jet 1 - ---- Gasket, Main Body 1 - ---- Gasket, Thermostat Cover 2 - ---- Jet, Main Metering 1 - ---- Jet, Power By-Pass 1 - ---- Needle, w/Seat, Float 2 - ---- Pin, Cotter 2 - ---- Plug, Channel 1 - ---- Pump, w/Rod 1 - ---- Spring, Float Pin 1 - ---- Spring, Pump 2 - ---- Valve, Idle Needle REPAIR PACKAGE, CARBURETOR Part No. E1676 721 Consists of: 1 - ---- Ball, Discharge Check 1 - ---- Ball, Inlet Check 1 - ---- Gasket, Air Horn 1 - ---- Gasket, By-Pass Jet 1 - ---- Gasket, Discharge Nozzle 1 - ---- Gasket, Discharge Nozzle Screw 2 - ---- Gasket, Metering Jet 1 - ---- Gasket, Main Body 1 - ---- Gasket, Thermostat Cover 2 - ---- Jet, Main Metering 1 - ---- Jet, Power By-Pass 1 - ---- Needle, w/Seat, Float 3 - ---- Pin, Cotter 1 - ---- Plug 1 - ---- Pump, w/Rod 1 - ---- Retainer, Pump Link 1 - ---- Spring, Float Pin 1 - ---- Spring, Pump 2 - ---- Valve, Idle Needle REPAIR PACKAGE, CARBURETOR Part No. E1676 722 Consists of: 1 - ---- Ball, Discharge Check 1 - ---- Ball, Inlet Check 1 - ---- Gasket, Air Horn 1 - ---- Gasket, By-Pass Jet 1 - ---- Gasket, Discharge Nozzle 1 - ---- Gasket, Discharge Nozzle Screw 2 - ---- Gasket, Metering Jet 1 - ---- Gasket, Main Body	(Cont'd) 1 - ---- Gasket, Thermostat Cover 2 - ---- Jet, Main Metering 1 - ---- Jet, Power By-Pass 1 - ---- Needle, w/Seat, Float 3 - ---- Pin, Cotter 2 - ---- Plug 1 - ---- Pump, w/Rod 1 - ---- Retainer, Pump Link 1 - ---- Spring, Float Pin 1 - ---- Spring, Pump 2 - ---- Valve, Idle Needle REPAIR PACKAGE, CARBURETOR Part No. E1826 152 Consists of: 1 - ---- Ball, Discharge Check 1 - ---- Ball, Inlet Check 1 - ---- Gasket, Air Horn 1 - ---- Gasket, By-Pass Jet 1 - ---- Gasket, Discharge Nozzle 1 - ---- Gasket, Discharge Nozzle Screw 2 - ---- Gasket, Metering Jet 1 - ---- Gasket, Main Body 2 - ---- Jet, Main Metering 1 - ---- Jet, Power By-Pass 1 - ---- Needle, w/Seat, Float 2 - ---- Pin, Cotter 2 - ---- Plug 1 - ---- Pump, w/Rod 1 - ---- Retainer, Pump Link 1 - ---- Spring, Float Pin 1 - ---- Spring, Pump 2 - ---- Valve, Idle Needle REPAIR PACKAGE, CARBURETOR Part No. E1826 271 Consists of: 1 - ---- Ball, Discharge Check 1 - ---- Ball, Inlet Check 1 - ---- Gasket, Air Horn 1 - ---- Gasket, By-Pass Jet 1 - ---- Gasket, Discharge Nozzle 1 - ---- Gasket, Discharge Nozzle Screw 2 - ---- Gasket, Metering Jet 1 - ---- Gasket, Main Body 1 - ---- Gasket, Thermostat Cover 2 - ---- Jet, Main Metering 1 - ---- Jet, Power By-Pass 1 - ---- Needle, w/Seat, Float 2 - ---- Pin, Cotter 2 - ---- Plug 1 - ---- Pump, w/Rod 1 - ---- Retainer, Pump Link 1 - ---- Spring, Float Pin 1 - ---- Spring, Pump 2 - ---- Valve, Idle Needle REPAIR PACKAGE, CARBURETOR Part No. E1826 272 Consists of: 1 - ---- Ball, Discharge Check 1 - ---- Ball, Inlet Check 1 - ---- Gasket, Air Horn 1 - ---- Gasket, By-Pass Jet 1 - ---- Gasket, Discharge Nozzle	

★ Indicates use as required.
 □ Indicates parts not listed in any previous parts book.

Printed in U.S.A.
 Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)	1 - ---- Gasket, Discharge Nozzle Screw	(Cont'd)	2 - ---- Jet, Main Metering
	2 - ---- GASKet, Main Metering Jet		1 - ---- Gasket, Venturi Housing
	1 - ---- Gasket, Main Body		1 - ---- Gasket, Venturi Cover
	1 - ---- Gasket, Thermostat Cover		1 - ---- Needle, w/Seat, Float
	2 - ---- Jet, Main Metering		1 - ---- Pump, w/Rod
	1 - ---- Jet, Power By-Pass		1 - ---- Spring, Step-Up Rod
	1 - ---- Needle, w/Seat, Float		REPAIR PACKAGE,
	2 - ---- Pin, Cotter		CARBURETOR Part No. 1826 464
	2 - ---- Plug		Consists of:
	1 - ---- Pump, w/Rod		1 - ---- Gasket, Air Cleaner
	1 - ---- Retainer, Pump Link		1 - ---- Gasket, Air Horn
	1 - ---- Spring, Float Pin		1 - ---- Gasket, Body to Flange
	1 - ---- Spring, Pump		1 - ---- Gasket, Choke Coil Housing
	2 - ---- Valve, Idle Needle		1 - ---- Gasket, Dust Cover
	REPAIR PACKAGE,		1 - ---- Gasket, Flange
	CARBURETOR Part No. 1826 423		1 - ---- Gasket, Pump Jet Housing
	Consists of:		2 - ---- Jet, Metering Rod
	1 - ---- Ball, Discharge Check		1 - ---- Needle, w/Seat, Primary
	1 - ---- Ball, Inlet Check		1 - ---- Needle, w/Seat, Secondary
	1 - ---- Gasket, Air Horn		1 - ---- Pump, w/Rod
	1 - ---- Gasket, By-Pass Jet		2 - ---- Rod, Metering
	1 - ---- Gasket, Discharge Nozzle		1 - ---- Spring, Vacuum Piston
	1 - ---- Gasket, Discharge Nozzle Screw		REPAIR PACKAGE,
	2 - ---- Gasket, Main Metering Jet		CARBURETOR Part No. 1826 465
	1 - ---- Gasket, Main Body		Consists of:
	2 - ---- Jet, Main Metering		1 - ---- Gasket, Air Horn
	1 - ---- Jet, Power By-Pass		1 - ---- Gasket, Body to Flange
	1 - ---- Needle, w/Seat, Float		1 - ---- Gasket, Choke Coil Housing
	2 - ---- Pin, Cotter		1 - ---- Gasket, Flange
	2 - ---- Plug		1 - ---- Gasket, Step-Up Piston
	1 - ---- Pump, w/Rod		1 - ---- Gasket, Venturi Cover
	1 - ---- Retainer, Pump Link		1 - ---- Gasket, Venturi Housing
	1 - ---- Spring, Float Pin		2 - ---- Jet, Main Metering
	1 - ---- Spring, Pump		1 - ---- Needle, w/Seat, Float
	2 - ---- Valve, Idle Needle		1 - ---- Pump, w/Rod
	REPAIR PACKAGE,		1 - ---- Spring, Step-Up Piston
	CARBURETOR Part No. 1826 458		REPAIR PACKAGE,
	Consists of:		CARBURETOR Part No. 1826 466
	1 - ---- Gasket, Air Horn		Consists of:
	1 - ---- Gasket, Body to Flange		1 - ---- Gasket, Air Horn
	1 - ---- Gasket, Choke Coil Housing		1 - ---- Gasket, Body to Flange
	1 - ---- Gasket, Flange		1 - ---- Gasket, Choke Coil Housing
	1 - ---- Gasket, Step-Up Piston		1 - ---- Gasket, Flange
	1 - ---- Jet, Main Metering		1 - ---- Gasket, Step-Up Piston
	1 - ---- Needle, w/Seat, Float		1 - ---- Gasket, Venturi Cover
	1 - ---- Plug, High Speed Passage		1 - ---- Gasket, Venturi Housing
	1 - ---- Pump, w/Rod		2 - ---- Jet, Main Metering
	1 - ---- Spring, Step-Up Piston		1 - ---- Needle, w/Seat, Float
	1 - ---- Tube, Idle Orifice		1 - ---- Pump, w/Rod
	1 - ---- Tube, Main Vent		1 - ---- Spring, Step-Up Piston
	REPAIR PACKAGE,		REPAIR PACKAGE,
	CARBURETOR Part No. 1826 461		CARBURETOR Part No. 1826 468
	Consists of:		Consists of:
	1 - ---- Gasket, Air Horn		1 - ---- Gasket, Air Horn
	1 - ---- Gasket, Body to Flange		1 - ---- Gasket, Body to Flange
	1 - ---- Gasket, Choke Coil Housing		1 - ---- Gasket, Choke Coil Housing
	1 - ---- Gasket, Flange		1 - ---- Gasket, Flange
	1 - ---- Gasket, Step-Up Piston		1 - ---- Gasket, Step-Up Piston
	1 - ---- Gasket, Step-Up Piston		1 - ---- Gasket, Venturi Cover
	1 - ---- Gasket, Venturi Cover		1 - ---- Gasket, Venturi Housing
	(Pkg. Cont'd)		2 - ---- Jet, Main Metering
			1 - ---- Needle, w/Seat, Float
			1 - ---- Pump, w/Rod
			1 - ---- Spring, Step-Up Piston

★ Indicates use as required.

⊠ Indicates parts not listed in any previous parts book.

Printed in U.S.A.

Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	REPAIR PACKAGE, CARBURETOR Part No. E1826 469 Consists of: 1 - - - - - Gasket, Air Horn 1 - - - - - Gasket, Body to Flange 1 - - - - - Gasket, Choke Coil Housing 1 - - - - - Gasket, Dust Cover 1 - - - - - Gasket, Flange 1 - - - - - Gasket, Pump Jet Housing 2 - - - - - Jet, Metering Rod 1 - - - - - Needle, w/Seat, Primary 1 - - - - - Needle, w/Seat, Secondary 1 - - - - - Pump, w/Rod 2 - - - - - Rod, Metering 1 - - - - - Spring, Vacuum Piston		REPAIR PACKAGE, CARBURETOR Part No. E1826 473 Consists of: 1 - - - - - Gasket, Air Horn 1 - - - - - Gasket, Body to Flange 1 - - - - - Gasket, Flange 1 - - - - - Gasket, Step-Up Piston 1 - - - - - Gasket, Venturi Cover 1 - - - - - Gasket, Venturi Housing 2 - - - - - Jet, Main Metering 1 - - - - - Needle, w/Seat, Float 1 - - - - - Pump, w/Rod 1 - - - - - Spring, Step-Up Piston
	REPAIR PACKAGE, CARBURETOR Part No. E1826 470 Consists of: 1 - - - - - Gasket, Air Horn 1 - - - - - Gasket, Body to Flange 1 - - - - - Gasket, Choke Coil Housing 1 - - - - - Gasket, Dust Cover 1 - - - - - Gasket, Flange 1 - - - - - Gasket, Pump Jet Housing 2 - - - - - Jet, Metering Rod 1 - - - - - Needle, w/Seat, Primary 1 - - - - - Needle, w/Seat, Secondary 1 - - - - - Pump, w/Rod 2 - - - - - Rod, Metering 1 - - - - - Spring, Vacuum Piston		REPAIR PACKAGE, CARBURETOR Part No. E1826 474 Consists of: 1 - - - - - Gasket, Body to Flange 1 - - - - - Gasket, Choke Coil Housing 1 - - - - - Gasket, Flange 1 - - - - - Gasket, Step-Up Piston 1 - - - - - Gasket, Venturi Cover 1 - - - - - Gasket, Venturi Housing 2 - - - - - Jet, Main Metering 1 - - - - - Needle, w/Seat, Float 1 - - - - - Pump, w/Rod 1 - - - - - Spring, Step-Up Piston
	REPAIR PACKAGE, CARBURETOR Part No. E1826 471 Consists of: 1 - - - - - Gasket, Air Horn 1 - - - - - Gasket, Body to Flange 1 - - - - - Gasket, Choke Coil Housing 1 - - - - - Gasket, Flange 1 - - - - - Gasket, Step-Up Piston 1 - - - - - Jet, Main Metering 1 - - - - - Needle, w/Seat, Float 1 - - - - - Plug, High Speed Passage 1 - - - - - Pump, w/Rod 1 - - - - - Spring, Step-Up Piston 1 - - - - - Tube, Idle Orifice 1 - - - - - Tube, Main Vent		REPAIR PACKAGE, CARBURETOR Part No. E1826 475 Consists of: 1 - - - - - Gasket, Air Cleaner 1 - - - - - Gasket, Air Horn 1 - - - - - Gasket, Body to Flange 1 - - - - - Gasket, Choke Coil Housing 1 - - - - - Gasket, Dust Cover 1 - - - - - Gasket, Flange 1 - - - - - Gasket, Pump Jet Housing 2 - - - - - Jet, Metering Rod 1 - - - - - Needle, w/Seat, Primary 1 - - - - - Needle, w/Seat, Secondary 1 - - - - - Pump, w/Rod 2 - - - - - Rod, Metering 1 - - - - - Spring, Vacuum Piston
	REPAIR PACKAGE, CARBURETOR Part No. E1826 472 Consists of: 1 - - - - - Gasket, Air Horn 1 - - - - - Gasket, Body to Flange 1 - - - - - Gasket, Choke Coil Housing 1 - - - - - Gasket, Flange 1 - - - - - Gasket, Step-Up Piston 1 - - - - - Gasket, Venturi Cover 1 - - - - - Gasket, Venturi Housing 2 - - - - - Jet, Main Metering 1 - - - - - Needle, w/Seat, Float 1 - - - - - Pump, w/Rod 1 - - - - - Spring, Step-Up Piston		REPAIR PACKAGE, CARBURETOR Part No. E1826 476 Consists of: 1 - - - - - Gasket, Air Horn 1 - - - - - Gasket, Body to Flange 1 - - - - - Gasket, Dust Cover 1 - - - - - Gasket, Flange 1 - - - - - Gasket, Pump Jet Housing 2 - - - - - Jet, Metering Rod 1 - - - - - Needle, w/Seat, Primary 1 - - - - - Needle, w/Seat, Secondary 1 - - - - - Pump, w/Rod 2 - - - - - Rod, Metering 1 - - - - - Spring, Vacuum Piston
			REPAIR PACKAGE, CARBURETOR Part No. E1826 477 Consists of: 1 - - - - - Gasket, Air Horn 1 - - - - - Gasket, Body to Flange 1 - - - - - Gasket, Choke Coil Housing

(Pkg. Cont'd)

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.
 Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)		(Cont'd)	
1 - ----	Gasket, Flange	1 - ----	Gasket, Flange
1 - ----	Gasket, Step-Up Piston	1 - ----	Gasket, Step-Up Piston
1 - ----	Jet, Main Metering	1 - ----	Gasket, Venturi Cover
1 - ----	Needle, w/Seat, Float	1 - ----	Gasket, Venturi Housing
1 - ----	Plug, High Speed Passage	2 - ----	Jet, Main Metering
1 - ----	Pump, w/Rod	1 - ----	Needle, w/Seat, Float
1 - ----	Spring, Step-Up Piston	1 - ----	Pump, w/Rod
1 - ----	Tube, Idle Orifice	2 - ----	Rod, Step-Up
1 - ----	Tube, Main Vent	1 - ----	Spring, Step-Up Piston
REPAIR PACKAGE, CARBURETOR Part No. E1826 479		REPAIR PACKAGE, CARBURETOR Part No. E1826 483	
Consists of:		Consists of:	
1 - ----	Gasket, Air Cleaner	1 - ----	Gasket, Air Cleaner
1 - ----	Gasket, Air Horn	1 - ----	Gasket, Air Horn
1 - ----	Gasket, Body to Flange	1 - ----	Gasket, Body to Flange
1 - ----	Gasket, Choke Coil Housing	1 - ----	Gasket, Choke Coil Housing
1 - ----	Gasket, Dust Cover	1 - ----	Gasket, Dust Cover
1 - ----	Gasket, Flange	1 - ----	Gasket, Flange
1 - ----	Gasket, Heat Tube Cap	1 - ----	Gasket, Heat Tube Cap
1 - ----	Gasket, Pump Jet Housing	1 - ----	Gasket, Pump Jet Housing
2 - ----	Jet, Metering Rod	2 - ----	Jet, Metering Rod
1 - ----	Needle, w/Seat, Primary	1 - ----	Needle, w/Seat, Primary
1 - ----	Needle, w/Seat, Secondary	1 - ----	Needle, w/Seat, Secondary
1 - ----	Pump, w/Rod	1 - ----	Pump, w/Rod
2 - ----	Rod, Metering	2 - ----	Rod, Metering
1 - ----	Spring, Vacuum Piston	1 - ----	Spring, Vacuum Piston
REPAIR PACKAGE, CARBURETOR Part No. E1826 480		REPAIR PACKAGE, CARBURETOR Part No. E1826 484	
Consists of:		Consists of:	
1 - ----	Gasket, Air Horn	1 - ----	Gasket, Air Horn
1 - ----	Gasket, Body to Flange	1 - ----	Gasket, Body to Flange
1 - ----	Gasket, Choke Coil Housing	1 - ----	Gasket, Choke Coil Housing
1 - ----	Gasket, Flange	1 - ----	Gasket, Flange
1 - ----	Gasket, Heat Tube Cap	1 - ----	Gasket, Heat Tube Cap
1 - ----	Gasket, Step-Up Piston	1 - ----	Gasket, Step-Up Piston
1 - ----	Gasket, Venturi Cover	1 - ----	Gasket, Venturi Cover
1 - ----	Gasket, Venturi Housing	1 - ----	Gasket, Venturi Housing
2 - ----	Jet, Main Metering	2 - ----	Jet, Main Metering
1 - ----	Needle, w/Seat, Float	1 - ----	Needle, w/Seat
1 - ----	Pump, w/Rod	1 - ----	Pump, w/Rod
1 - ----	Spring, Step-Up Piston	1 - ----	Spring, Step-Up Piston
REPAIR PACKAGE, CARBURETOR Part No. E1826 481		REPAIR PACKAGE, CARBURETOR Part No. E1826 485	
Consists of:		Consists of:	
1 - ----	Gasket, Air Horn	1 - ----	Gasket, Air Horn
1 - ----	Gasket, Body to Flange	1 - ----	Gasket, Body to Flange
1 - ----	Gasket, Dust Cover	1 - ----	Gasket, Dust Cover
1 - ----	Gasket, Flange	1 - ----	Gasket, Flange
1 - ----	Gasket, Pump Jet Housing	1 - ----	Gasket, Pump Jet Housing
2 - ----	Jet, Metering Rod	2 - ----	Jet, Metering Rod
1 - ----	Needle, w/Seat, Primary	1 - ----	Needle, w/Seat, Primary
1 - ----	Needle, w/Seat, Secondary	1 - ----	Needle, w/Seat, Secondary
1 - ----	Pump, w/Rod	1 - ----	Pump, w/Rod
2 - ----	Rod, Metering	2 - ----	Rod, Metering
1 - ----	Spring, Vacuum Piston	1 - ----	Spring, Vacuum Piston
REPAIR PACKAGE, CARBURETOR Part No. E1826 482		REPAIR PACKAGE, CARBURETOR Part No. E1826 486	
Consists of:		Consists of:	
1 - ----	Gasket, Air Horn	1 - ----	Gasket, Air Cleaner
1 - ----	Gasket, Body to Flange	1 - ----	Gasket, Air Horn
	(Pkg. Cont'd)		(Pkg. Cont'd)

★ Indicates use as required.
 □ Indicates parts not listed in any previous parts book.

Printed in U.S.A.
 Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)	1 - ---- Gasket, Body to Flange	(Cont'd)	2 - ---- Jet, Metering Rod
	1 - ---- Gasket, Choke Coil Housing		1 - ---- Needle, w/Seat, Primary
	1 - ---- Gasket, Dust Cover		1 - ---- Needle, w/Seat, Secondary
	1 - ---- Gasket, Flange		1 - ---- Pump, w/Rod
	1 - ---- Gasket, Heat Tube Cap		2 - ---- Rod, Metering
	1 - ---- Gasket, Pump Jet Housing		1 - ---- Spring, Vacuum Piston
	2 - ---- Jet, Metering Rod		
	1 - ---- Needle, w/Seat, Primary		REPAIR PACKAGE,
	1 - ---- Needle, w/Seat, Secondary		CARBURETOR Part No. E1826 493
	1 - ---- Pump, w/Rod		Consists of:
	2 - ---- Rod, Metering		1 - ---- Gasket, Air Horn
	1 - ---- Spring, Vacuum Piston		1 - ---- Gasket, Body to Flange
			1 - ---- Gasket, Choke Coil Housing
	REPAIR PACKAGE,		1 - ---- Gasket, Dust Cover
	CARBURETOR Part No. E1826 489		1 - ---- Gasket, Flange
	Consists of:		2 - ---- Jet, Metering Rod
	1 - ---- Gasket, Air Horn		1 - ---- Needle, w/Seat, Primary
	1 - ---- Gasket, Body to Flange		1 - ---- Needle, w/Seat, Secondary
	1 - ---- Gasket, Dust Cover		1 - ---- Pump, w/Rod
	1 - ---- Gasket, Flange		2 - ---- Rod, Metering
	1 - ---- Gasket, Pump Jet Housing		1 - ---- Spring, Vacuum Piston
	2 - ---- Jet, Metering Rod		
	1 - ---- Needle, w/Seat, Primary		REPAIR PACKAGE,
	1 - ---- Needle, w/Seat, Secondary		CARBURETOR Part No. E1826 494
	1 - ---- Pump, w/Rod		Consists of:
	2 - ---- Rod, Metering		1 - ---- Gasket, Air Horn
	1 - ---- Spring, Vacuum Piston		1 - ---- Gasket, Body to Flange
			1 - ---- Gasket, Choke Coil Housing
	REPAIR PACKAGE,		1 - ---- Gasket, Dust Cover
	CARBURETOR Part No. 1826 490		1 - ---- Gasket, Flange
	Consists of:		1 - ---- Gasket, Heat Tube Cap
	1 - ---- Gasket, Air Horn		1 - ---- Gasket, Pump Jet Housing
	1 - ---- Gasket, Body to Flange		2 - ---- Jet, Metering Rod
	1 - ---- Gasket, Choke Coil Housing		1 - ---- Needle, w/Seat, Primary
	1 - ---- Jet, Main Metering		1 - ---- Needle, w/Seat, Secondary
	1 - ---- Needle, w/Seat, Float		1 - ---- Pump, w/Rod
	1 - ---- Pump, w/Rod		2 - ---- Rod, Metering
	1 - ---- Spring, Step-Up Piston		1 - ---- Spring, Vacuum Piston
	1 - ---- Tube, Idle Orifice		
	1 - ---- Tube, Main Vent		REPAIR PACKAGE,
			CARBURETOR Part No. E1826 495
	REPAIR PACKAGE,		Consists of:
	CARBURETOR Part No. E1826 491		1 - ---- Gasket, Air Horn
	Consists of:		1 - ---- Gasket, Body to Flange
	1 - ---- Gasket, Air Horn		1 - ---- Gasket, Dust Cover
	1 - ---- Gasket, Body to Flange		1 - ---- Gasket, Flange
	1 - ---- Gasket, Choke Coil Housing		1 - ---- Gasket, Pump Jet Housing
	1 - ---- Gasket, Dust Cover		2 - ---- Jet, Metering Rod
	1 - ---- Gasket, Flange		1 - ---- Needle, w/Seat, Primary
	1 - ---- Gasket, Pump Jet Housing		1 - ---- Needle, w/Seat, Secondary
	2 - ---- Jet, Metering Rod		1 - ---- Pump, w/Rod
	1 - ---- Needle, w/Seat, Primary		2 - ---- Rod, Metering
	1 - ---- Needle, w/Seat, Secondary		1 - ---- Spring, Vacuum Piston
	1 - ---- Pump, w/Rod		
	2 - ---- Rod, Metering		REPAIR PACKAGE,
	1 - ---- Spring, Vacuum Piston		CARBURETOR Part No. E1826 496
			Consists of:
	REPAIR PACKAGE,		1 - ---- Gasket, Air Horn
	CARBURETOR Part No. E1826 492		1 - ---- Gasket, Body to Flange
	Consists of:		1 - ---- Gasket, Choke Coil Housing
	1 - ---- Gasket, Air Horn		1 - ---- Gasket, Dust Cover
	1 - ---- Gasket, Body to Flange		1 - ---- Gasket, Flange
	1 - ---- Gasket, Choke Coil Housing		1 - ---- Gasket, Heat Tube Cap
	1 - ---- Gasket, Dust Cover		1 - ---- Gasket, Pump Jet Housing
	1 - ---- Gasket, Flange		2 - ---- Jet, Metering Rod
	1 - ---- Gasket, Pump Jet Housing		1 - ---- Needle, w/Seat, Primary
			(Pkg. Cont'd)
			(Pkg. Cont'd)

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.

Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)	<p>1 - ---- Needle, w/Seat, Secondary</p> <p>1 - ---- Pump, w/Rod</p> <p>2 - ---- Rod, Metering</p> <p>1 - ---- Spring, Vacuum Piston</p> <p>REPAIR PACKAGE, CARBURETOR Part No.E1826 499</p> <p>Consists of:</p> <p>1 - ---- Gasket, Air Horn</p> <p>1 - ---- Gasket, Body to Flange</p> <p>1 - ---- Gasket, Choke Coil Housing</p> <p>1 - ---- Gasket, Dust Cover</p> <p>1 - ---- Gasket, Flange</p> <p>1 - ---- Gasket, Pump Jet Housing</p> <p>2 - ---- Jet, Metering Rod</p> <p>1 - ---- Needle, w/Seat, Primary</p> <p>1 - ---- Needle, w/Seat, Secondary</p> <p>1 - ---- Pump, w/Rod</p> <p>2 - ---- Rod, Metering</p> <p>1 - ---- Spring, Vacuum Piston</p> <p>REPAIR PACKAGE, CARBURETOR Part No.E1826 501</p> <p>Consists of:</p> <p>1 - ---- Gasket, Air Horn</p> <p>1 - ---- Gasket, Body to Flange</p> <p>1 - ---- Gasket, Choke Coil Housing</p> <p>1 - ---- Gasket, Dust Cover</p> <p>1 - ---- Gasket, Flange</p> <p>1 - ---- Gasket, Heat Tube Cap</p> <p>1 - ---- Gasket, Pump Jet Housing</p> <p>2 - ---- Jet, Metering Rod</p> <p>1 - ---- Needle, w/Seat, Primary</p> <p>1 - ---- Needle, w/Seat, Secondary</p> <p>1 - ---- Pump, w/Rod</p> <p>2 - ---- Rod, Metering</p> <p>1 - ---- Spring, Vacuum Piston</p> <p>REPAIR PACKAGE, CARBURETOR Part No.E1826 502</p> <p>Consists of:</p> <p>1 - ---- Gasket, Air Horn</p> <p>1 - ---- Gasket, Body to Flange</p> <p>1 - ---- Gasket, Dust Cover</p> <p>1 - ---- Gasket, Flange</p> <p>1 - ---- Gasket, Pump Jet Housing</p> <p>2 - ---- Jet, Metering Rod</p> <p>1 - ---- Needle, w/Seat, Primary</p> <p>1 - ---- Needle, w/Seat, Secondary</p> <p>1 - ---- Pump, w/Rod</p> <p>2 - ---- Rod, Metering</p> <p>1 - ---- Spring, Vacuum Piston</p> <p>REPAIR PACKAGE, CARBURETOR Part No.E1826 516</p> <p>Consists of:</p> <p>1 - ---- Gasket, Air Cleaner</p> <p>1 - ---- Gasket, Air Horn</p> <p>1 - ---- Gasket, Body to Flange</p> <p>1 - ---- Gasket, Choke Coil Housing</p> <p>1 - ---- Gasket, Dust Cover</p> <p>1 - ---- Gasket, Flange</p> <p>1 - ---- Gasket, Pump Jet Housing</p> <p>2 - ---- Jet, Metering Rod</p>	(Cont'd)	<p>1 - ---- Needle, w/Seat, Primary</p> <p>1 - ---- Needle, w/Seat, Secondary</p> <p>1 - ---- Pump, w/Rod</p> <p>1 - ---- Rod, Metering</p> <p>1 - ---- Spring, Vacuum Piston</p> <p>REPAIR PACKAGE, CARBURETOR Part No.E1826 539</p> <p>Consists of:</p> <p>1 - ---- Ball, Discharge Check</p> <p>1 - ---- Ball, Inlet Check</p> <p>1 - ---- Gasket, Air Horn</p> <p>1 - ---- Gasket, Main Body</p> <p>2 - ---- Gasket, Metering Jet Plug</p> <p>1 - ---- Gasket, Power By-Pass Jet</p> <p>1 - ---- Gasket, Pump Discharge Nozzle</p> <p>1 - ---- Gasket, Pump Discharge Nozzle Screw</p> <p>2 - ---- Jet, Main Metering</p> <p>1 - ---- Jet, Power By-Pass</p> <p>1 - ---- Needle, w/Seat, Float</p> <p>2 - ---- Pin, Cotter</p> <p>2 - ---- Plug, Channel</p> <p>1 - ---- Pump, w/Rod</p> <p>1 - ---- Retainer, Pump Link</p> <p>1 - ---- Spring, Float Pin</p> <p>1 - ---- Spring, Pump</p> <p>1 - ---- Valve, Idle Needle</p> <p>REPAIR PACKAGE, CARBURETOR Part No.E1826 540</p> <p>Consists of:</p> <p>1 - ---- Ball, Discharge Check</p> <p>1 - ---- Ball, Inlet Check</p> <p>1 - ---- Gasket, Air Horn</p> <p>1 - ---- Gasket, Main Body</p> <p>2 - ---- Gasket, Metering Jet Plug</p> <p>1 - ---- Gasket, Power By-Pass Jet</p> <p>1 - ---- Gasket, Pump Discharge Nozzle</p> <p>1 - ---- Gasket, Pump Discharge Nozzle Screw</p> <p>2 - ---- Jet, Main Metering</p> <p>1 - ---- Jet, Power By-Pass</p> <p>1 - ---- Needle, w/Seat, Float</p> <p>2 - ---- Pin, Cotter</p> <p>2 - ---- Plug, Channel</p> <p>1 - ---- Pump, w/Rod</p> <p>1 - ---- Retainer, Pump Link</p> <p>1 - ---- Spring, Float Pin</p> <p>1 - ---- Spring, Pump</p> <p>1 - ---- Valve, Idle Needle</p> <p>REPAIR PACKAGE, CARBURETOR Part No.E1826 542</p> <p>Consists of:</p> <p>1 - ---- Gasket, Air Cleaner</p> <p>1 - ---- Gasket, Body to Flange</p> <p>1 - ---- Gasket, Choke Coil Housing</p> <p>1 - ---- Gasket, Flange</p> <p>1 - ---- Gasket, Heat Tube Cap</p> <p>1 - ---- Gasket, Step-Up Piston</p> <p>1 - ---- Gasket, Venturi Cover</p> <p>1 - ---- Gasket, Venturi Housing</p>
	(Pkg. Cont'd)		(Pkg. Cont'd)

★ Indicates use as required.
 □ Indicates parts not listed in any previous parts book.

Printed in U.S.A.
 Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)			
	2 - ---- Jet, Main Metering		REPAIR PACKAGE,
	1 - ---- Needle, w/Seat, Float		CARBURETOR Part No. E1826 550
	1 - ---- Pump, w/Rod		Consists of:
	1 - ---- Spring, Step-Up Piston		1 - ---- Gasket, Air Horn
			1 - ---- Gasket, Body to Flange
	REPAIR PACKAGE,		1 - ---- Gasket, Flange
	CARBURETOR Part No. E1826 543		1 - ---- Gasket, Step-Up Piston
	Consists of:		1 - ---- Gasket, Venturi Cover
	1 - ---- Gasket, Air Cleaner		1 - ---- Gasket, Venturi Housing
	1 - ---- Gasket, Body to Flange		2 - ---- Jet, Main Metering
	1 - ---- Gasket, Choke Coil Housing		1 - ---- Needle, w/Seat, Float
	1 - ---- Gasket, Flange		1 - ---- Pump, w/Rod
	1 - ---- Gasket, Heat Tube Cap		1 - ---- Spring, Step-Up Piston
	1 - ---- Gasket, Step-Up Piston		
	1 - ---- Gasket, Venturi Cover		REPAIR PACKAGE,
	1 - ---- Gasket, Venturi Housing		CARBURETOR Part No. 1826 551
	2 - ---- Jet, Main Metering		Consists of:
	1 - ---- Needle, w/Seat, Float		1 - ---- Gasket, Air Horn
	1 - ---- Pump, w/Rod		1 - ---- Gasket, Body to Flange
	1 - ---- Spring, Step-Up Piston		1 - ---- Gasket, Dust Cover
			1 - ---- Gasket, Flange
	REPAIR PACKAGE,		1 - ---- Gasket, Pump Jet Housing
	CARBURETOR Part No. E1826 544		2 - ---- Jet, Metering Rod
	Consists of:		2 - ---- Needle, w/Seat, Float
	1 - ---- Gasket, Air Horn		1 - ---- Pump, w/Rod
	1 - ---- Gasket, Body to Flange		2 - ---- Rod, Metering
	1 - ---- Gasket, Flange		1 - ---- Spring, Vacuum Piston
	1 - ---- Gasket, Step-Up Piston		
	1 - ---- Gasket, Venturi Cover		REPAIR PACKAGE,
	1 - ---- Gasket, Venturi Housing		CARBURETOR Part No. E1826 553
	2 - ---- Jet, Main Metering		Consists of:
	1 - ---- Needle, w/Seat, Float		1 - ---- Gasket, Air Horn
	1 - ---- Pump, w/Rod		1 - ---- Gasket, Flange
	1 - ---- Spring, Step-Up Piston		1 - ---- Gasket, Pump Jet Housing
			2 - ---- Gasket, Primary Cluster
	REPAIR PACKAGE,		2 - ---- Gasket, Secondary Cluster
	CARBURETOR Part No. E1826 546		1 - ---- Jet, Metering
	Consists of:		2 - ---- Needle, w/Seat, Float
	1 - ---- Gasket, Air Horn		1 - ---- Pump, w/Rod
	1 - ---- Gasket, Choke Coil Housing		2 - ---- Rod, Step-Up
	1 - ---- Gasket, Flange		2 - ---- Spring, Vacuum Piston
	1 - ---- Gasket, Heat Tube Cap		
	1 - ---- Gasket, Pump Jet Housing		REPAIR PACKAGE,
	2 - ---- Gasket, Primary Cluster		CARBURETOR Part No. 1826 555
	2 - ---- Gasket, Secondary Cluster		Consists of:
	2 - ---- Jet, Metering Rod		1 - ---- Gasket, Air Horn
	2 - ---- Needle, w/Seat, Float		1 - ---- Gasket, Flange
	1 - ---- Pump, w/Rod		1 - ---- Gasket, Pump Jet Housing
	2 - ---- Rod, Step-Up		2 - ---- Gasket, Primary Cluster
	2 - ---- Spring, Vacuum Piston		2 - ---- Gasket, Secondary Cluster
			2 - ---- Jet, Metering
	REPAIR PACKAGE,		2 - ---- Needle, w/Seat, Float
	CARBURETOR Part No. E1826 548		1 - ---- Pump, w/Rod
	Consists of:		2 - ---- Rod, Step-Up
	1 - ---- Gasket, Air Horn		2 - ---- Spring, Vacuum Piston
	1 - ---- Gasket, Choke Coil Housing		
	1 - ---- Gasket, Flange		REPAIR PACKAGE,
	1 - ---- Gasket, Heat Tube Cap		CARBURETOR Part No. E1826 563
	1 - ---- Gasket, Pump Jet Housing		Consists of:
	2 - ---- Gasket, Primary Cluster		1 - ---- Gasket, Air Cleaner
	2 - ---- Gasket, Secondary Cluster		1 - ---- Gasket, Air Horn
	2 - ---- Jet, Metering Rod		1 - ---- Gasket, Flange
	2 - ---- Needle, w/Seat, Float		1 - ---- Gasket, Pump Jet Housing
	1 - ---- Pump, w/Rod		2 - ---- Gasket, Primary Cluster
	2 - ---- Rod, Step-Up		2 - ---- Gasket, Secondary Cluster
	2 - ---- Spring, Vacuum Piston		2 - ---- Jet, Metering Rod

(Pkg. Cont'd)

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.

Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)	2 - ---- --- Needle, w/Seat, Float 1 - ---- --- Pump, w/Rod 2 - ---- --- Rod, Step-Up 2 - ---- --- Spring, Vacuum Piston REPAIR PACKAGE, CARBURETOR Part No.E1826 564 Consists of: 1 - ---- --- Gasket, Air Cleaner 1 - ---- --- Gasket, Air Horn 1 - ---- --- Gasket, Choke Coil Housing 1 - ---- --- Gasket, Heat Tube Cap 1 - ---- --- Gasket, Flange 1 - ---- --- Gasket, Pump Jet Housing 2 - ---- --- Gasket, Primary Cluster 2 - ---- --- Gasket, Secondary Cluster 2 - ---- --- Jet, Metering Rod 2 - ---- --- Needle, w/Seat, Float 1 - ---- --- Pump, w/Rod 2 - ---- --- Rod, Step-Up 2 - ---- --- Spring, Vacuum Piston REPAIR PACKAGE, CARBURETOR Part No.E1826 565 Consists of: 1 - ---- --- Gasket, Air Horn 1 - ---- --- Gasket, Body to Flange 1 - ---- --- Gasket, Choke Coil Housing 1 - ---- --- Gasket, Dust Cover 1 - ---- --- Gasket, Flange 1 - ---- --- Gasket, Heat Tube Cap 1 - ---- --- Gasket, Pump Jet Housing 2 - ---- --- Jet, Metering Rod 2 - ---- --- Needle, w/Seat, Float 1 - ---- --- Pump, w/Rod 2 - ---- --- Rod, Metering 1 - ---- --- Spring, Vacuum Piston REPAIR PACKAGE, CARBURETOR Part No.E1826 589 Consists of: 1 - ---- --- Ball, Discharge Check 1 - ---- --- Ball, Inlet Check 1 - ---- --- Gasket, Air Horn 1 - ---- --- Gasket, Body to Flange 1 - ---- --- Gasket, Choke Coil Housing 2 - ---- --- Gasket, Metering Jet Plug 1 - ---- --- Gasket, Power By-Pass Jet 1 - ---- --- Gasket, Pump Discharge Nozzle 1 - ---- --- Gasket, Pump Discharge Nozzle Screw 2 - ---- --- Jet, Main Metering 1 - ---- --- Jet, Power By-Pass 1 - ---- --- Needle, w/Seat, Float 2 - ---- --- Pin, Cotter 2 - ---- --- Plug 1 - ---- --- Pump, w/Rod 1 - ---- --- Spring, Float Pin 1 - ---- --- Spring, Pump 14-30-7 GASKET PACKAGE, CARBURETOR Part No. 1631 366 Consists of: 1 - ---- --- Gasket, Air Horn..	(Cont'd)	1 - ---- --- Gasket, Body to Flange 1 - ---- --- Gasket, Choke Coil Housing 2 - ---- --- Gasket, Metering Jet Plug 1 - ---- --- Gasket, Needle and Seat 1 - ---- --- Gasket, Power By-Pass Jet 1 - ---- --- Gasket, Pump Discharge Nozzle 1 - ---- --- Gasket, Pump Discharge Nozzle Screw 2 - ---- --- Pin, Cotter GASKET PACKAGE, CARBURETOR Part No.E1631 368 Consists of: 1 - ---- --- Gasket, Air Horn 1 - ---- --- Gasket, Body to Flange 1 - ---- --- Gasket, Choke Coil Housing 2 - ---- --- Gasket, Metering Jet Plug 1 - ---- --- Gasket, Needle and Seat 1 - ---- --- Gasket, Power By-Pass Jet 1 - ---- --- Gasket, Pump Discharge Nozzle 1 - ---- --- Gasket, Pump Discharge Nozzle Screw 2 - ---- --- Pin, Cotter GASKET PACKAGE, CARBURETOR Part No.E1826 433 Consists of: 1 - ---- --- Gasket, Air Horn 1 - ---- --- Gasket, Bowl Strainer 1 - ---- --- Gasket, Body to Flange 1 - ---- --- Gasket, Choke Coil Housing 1 - ---- --- Gasket, Dust Cover 1 - ---- --- Gasket, Flange 2 - ---- --- Gasket, Needle Seat 1 - ---- --- Gasket, Passage Plug 2 - ---- --- Gasket, Piston Housing 1 - ---- --- Gasket, Pump Jet Housing GASKET PACKAGE, CARBURETOR Part No.E1826 439 Consists of: 1 - ---- --- Gasket, Air Horn 1 - ---- --- Gasket, Body to Flange 1 - ---- --- Gasket, Choke Coil Housing 1 - ---- --- Gasket, Flange 1 - ---- --- Gasket, Needle Seat 1 - ---- --- Gasket, Step-Up Jet 1 - ---- --- Gasket, Step-Up Piston GASKET PACKAGE, CARBURETOR Part No.E1826 441 Consists of: 1 - ---- --- Gasket, Air Horn 1 - ---- --- Gasket, Body to Flange 1 - ---- --- Gasket, Choke Coil Housing 1 - ---- --- Gasket, Flange 1 - ---- --- Gasket, Needle Seat 1 - ---- --- Gasket, Step-Up Jet 1 - ---- --- Gasket, Step-Up Piston GASKET PACKAGE, CARBURETOR Part No.E1826 442 Consists of: 1 - ---- --- Gasket, Air Horn

(Pkg. Cont'd)

(Pkg. Cont'd)

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.
 Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)			
	1 - ---- Gasket, Body to Flange		GASKET, PACKAGE
	1 - ---- Gasket, Choke Coil Housing		CARBURETOR Part No.E1826 507
	1 - ---- Gasket, Flange		Consists of:
	2 - ---- Gasket, Metering Jet		1 - ---- Gasket, Air Horn
	1 - ---- Gasket, Needle Seat		1 - ---- Gasket, Body to Flange
	1 - ---- Gasket, Step-Up Piston		1 - ---- Gasket, Bowl Strainer
	1 - ---- Gasket, Venturi Cover		1 - ---- Gasket, Choke Coil Housing
	1 - ---- Gasket, Venturi Housing		1 - ---- Gasket, Dust Cover
			1 - ---- Gasket, Flange
	GASKET PACKAGE,		1 - ---- Gasket, Needle Seat
	CARBURETOR Part No.E1826 444		1 - ---- Gasket, Passage Plug
	Consists of:		2 - ---- Gasket, Piston Housing
	1 - ---- Gasket, Air Horn		1 - ---- Gasket, Jet Pump Housing
	1 - ---- Gasket, Body to Flange		
	1 - ---- Gasket, Choke Coil Housing		GASKET PACKAGE,
	1 - ---- Gasket, Flange		CARBURETOR Part No.E1826 508
	2 - ---- Gasket, Metering Jet		Consists of:
	1 - ---- Gasket, Needle Seat		1 - ---- Gasket, Air Cleaner
	1 - ---- Gasket, Step-Up Piston		1 - ---- Gasket, Air Horn
	1 - ---- Gasket, Venturi Cover		1 - ---- Gasket, Body to Flange
	1 - ---- Gasket, Venturi Housing		1 - ---- Gasket, Bowl Strainer
			1 - ---- Gasket, Choke Coil Housing
	GASKET PACKAGE,		1 - ---- Gasket, Diaphragm Housing
	CARBURETOR Part No.E1826 445		1 - ---- Gasket, Diaphragm to Housing
	Consists of:		1 - ---- Gasket, Dust Cover
	1 - ---- Gasket, Air Horn		1 - ---- Gasket, Flange
	1 - ---- Gasket, Body to Flange		1 - ---- Gasket, Heat Tube Cap
	1 - ---- Gasket, Bowl Strainer		2 - ---- Gasket, Needle Seat
	1 - ---- Gasket, Choke Coil Housing		1 - ---- Gasket, Piston Housing
	1 - ---- Gasket, Dust Cover		1 - ---- Gasket, Pump Jet Housing
	1 - ---- Gasket, Flange		1 - ---- Gasket, Pump Relief Valve
	2 - ---- Gasket, Needle Seat		
	1 - ---- Gasket, Passage Plug		GASKET PACKAGE,
	2 - ---- Gasket, Piston Housing		CARBURETOR Part No.E1826 509
	1 - ---- Gasket, Pump Jet Housing		Consists of:
			1 - ---- Gasket, Air Horn
	GASKET PACKAGE,		1 - ---- Gasket, Body to Flange
	CARBURETOR Part No.E1826 446		1 - ---- Gasket, Choke Coil Housing
	Consists of:		1 - ---- Gasket, Flange
	1 - ---- Gasket, Air Horn		1 - ---- Gasket, Heat Tube Cap
	1 - ---- Gasket, Body to Flange		2 - ---- Gasket, Metering Jet
	1 - ---- Gasket, Choke Coil Housing		1 - ---- Gasket, Needle Seat
	1 - ---- Gasket, Flange		1 - ---- Gasket, Step-Up Piston
	2 - ---- Gasket, Metering Jet		1 - ---- Gasket, Venturi Cover
	1 - ---- Gasket, Needle Seat		1 - ---- Gasket, Venturi Housing
	1 - ---- Gasket, Step-Up Piston		
	1 - ---- Gasket, Venturi Cover		GASKET PACKAGE,
	1 - ---- Gasket, Venturi Housing		CARBURETOR Part No.E1826 510
			Consists of:
	GASKET PACKAGE,		1 - ---- Gasket, Air Horn
	CARBURETOR Part No.E1826 504		1 - ---- Gasket, Body to Flange
	Consists of:		2 - ---- Gasket, Bowl Strainer
	1 - ---- Gasket, Air Horn		1 - ---- Gasket, Dust Cover
	1 - ---- Gasket, Body to Flange		1 - ---- Gasket, Flange
	1 - ---- Gasket, Bowl Strainer		1 - ---- Gasket, Needle Seat
	1 - ---- Gasket, Choke Coil Housing		1 - ---- Gasket, Passage Plug
	1 - ---- Gasket, Dust Cover		1 - ---- Gasket, Piston Housing
	1 - ---- Gasket, Diaphragm Housing		1 - ---- Gasket, Pump Jet Housing
	1 - ---- Gasket, Flange		
	2 - ---- Gasket, Needle Seat		GASKET PACKAGE,
	2 - ---- Gasket, Piston Housing		CARBURETOR Part No.E1826 511
	1 - ---- Gasket, Pump Jet Housing		Consists of:
	1 - ---- Gasket, Pump Relief Valve		1 - ---- Gasket, Air Horn
			(Pkg. Cont'd)

★ Indicates use as required.

⊞ Indicates parts not listed in any previous parts book.

Printed in U.S.A.

Prices and specifications subject to change without notice.

1955-58 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)	1 - ---- Gasket, Body to Flange 1 - ---- Gasket, Flange 2 - ---- Gasket, Metering Jet 1 - ---- Gasket, Needle Seat 1 - ---- Gasket, Step-Up Piston 1 - ---- Gasket, Venturi Cover 1 - ---- Gasket, Venturi Housing GASKET PACKAGE, CARBURETOR Part No.E1826 513 Consists of: 1 - ---- Gasket, Air Horn 1 - ---- Gasket, Body to Flange 2 - ---- Gasket, Bowl Strainer 1 - ---- Gasket, Choke Coil Housing 1 - ---- Gasket, Dust Cover 1 - ---- Gasket, Flange 1 - ---- Gasket, Heat Tube Cap 1 - ---- Gasket, Pump Jet Housing GASKET PACKAGE, CARBURETOR Part No.E1826 514 Consists of: 1 - ---- Gasket, Air Horn 1 - ---- Gasket, Body to Flange 2 - ---- Gasket, Bowl Strainer 1 - ---- Gasket, Choke Coil Housing 1 - ---- Gasket, Dust Cover 1 - ---- Gasket, Flange 1 - ---- Gasket, Heat Tube Cap 1 - ---- Gasket, Pump Jet Housing GASKET PACKAGE, CARBURETOR Part No.E1826 544 Consists of: 1 - ---- Gasket, Air Horn 1 - ---- Gasket, Body to Flange 1 - ---- Gasket, Flange 1 - ---- Gasket, Step-Up Piston 1 - ---- Gasket, Venturi Cover 1 - ---- Gasket, Venturi Housing GASKET PACKAGE, CARBURETOR Part No.E1826 552 Consists of: 1 - ---- Gasket, Air Horn 1 - ---- Gasket, Flange 1 - ---- Gasket, Pump Jet Housing 2 - ---- Gasket, Primary Cluster 2 - ---- Gasket, Secondary Cluster GASKET PACKAGE, CARBURETOR Part No.E1826 554 Consists of: 1 - ---- Gasket, Air Horn 1 - ---- Gasket, Flange 1 - ---- Gasket, Pump Jet Housing 2 - ---- Gasket, Primary Cluster 2 - ---- Gasket, Secondary Cluster GASKET PACKAGE, CARBURETOR Part No.E1826 561 Consists of: 1 - ---- Gasket, Air Cleaner 1 - ---- Gasket, Air Horn 1 - ---- Gasket, Flange 1 - ---- Gasket, Pump Jet Housing	(Cont'd)	2 - ---- Gasket, Primary Cluster 2 - ---- Gasket, Secondary Cluster GASKET PACKAGE, CARBURETOR Part No.E1826 562 Consists of: 1 - ---- Gasket, Air Cleaner 1 - ---- Gasket, Air Horn 1 - ---- Gasket, Choke Coil Housing 1 - ---- Gasket, Flange 1 - ---- Gasket, Heat Tube Cap 1 - ---- Gasket, Pump Jet Housing 2 - ---- Gasket, Primary Cluster 2 - ---- Gasket, Secondary Cluster 14-67-1 FILTER PACKAGE, FUEL Part No. 1879 513 Consists of: 4 - 274 461 Clamp 1 - 1263 079 Clip 1 - ---- Filter 2 - ---- Hose 1 - 1826 835 Nut 14-67-5 ELEMENT PACKAGE, FUEL FILTER Part No. 1879 458 Consists of: 1 - ---- Element 1 - 1320 527 Gasket ELEMENT PACKAGE, FUEL FILTER Part No.E1879 519 Consists of: 1 - ---- Element 1 - ---- Gasket 14-67-8 BOWL PACKAGE, FUEL FILTER Part No. 1879 294 Consists of: 1 - ---- Bowl 1 - ---- Gasket 14-73-1 PUMP PACKAGE, FUEL Part No.E1631 490 Consists of: 1 - ---- Gasket 1 - ---- Pump PUMP PACKAGE, FUEL Part No.E1637 366 Consists of: 1 - ---- Gasket 1 - ---- Pump PUMP PACKAGE, FUEL Part No. 1637 367 Consists of: 1 - ---- Gasket 1 - ---- Pump PUMP PACKAGE, FUEL Part No.E1692 790 Consists of: 1 - ---- Gasket 1 - ---- Pump

(Pkg. Cont'd)

★ Indicates use as required.

□ Indicates parts not listed in any previous parts book.

Printed in U.S.A.

Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	PUMP PACKAGE, FUEL Part No. E1752 460 Consists of: 1 - ---- Gasket 1 - ---- Pump	14-73-5	REPAIR KIT, FUEL PUMP DIAPHRAGM Part No. 1450 022 Consists of: 1 - ---- Diaphragm, Air Dome 1 - ---- Diaphragm, Pump 1 - ---- Gasket, Mounting 1 - ---- Plug, Cam Lever Pin 1 - ---- Spring, Cam Lever Pin
	PUMP PACKAGE, FUEL Part No. E1752 462 Consists of: 1 - ---- Gasket 1 - ---- Pump		REPAIR KIT, FUEL PUMP DIAPHRAGM Part No. E1643 171 Consists of: 1 - ---- Diaphragm, Air Dome 1 - ---- Diaphragm, Pump 1 - ---- Gasket, Mounting 1 - ---- Plug, Cam Lever Pin 1 - ---- Retainer, Cam Lever Pin
	PUMP PACKAGE, FUEL Part No. 1752 463 Consists of: 1 - ---- Gasket 1 - ---- Pump		REPAIR KIT, FUEL PUMP DIAPHRAGM Part No. E1752 557 Consists of: 1 - ---- Diaphragm, Air Dome 1 - ---- Diaphragm, Pump 1 - ---- Gasket, Mounting 1 - ---- Plug, Cam Lever Pin 1 - ---- Retainer, Cam Lever Pin
	PUMP PACKAGE, FUEL Part No. E1818 827 Consists of: 1 - ---- Gasket 1 - ---- Pump		
	PUMP PACKAGE, FUEL Part No. E1843 267 Consists of: 2 - ---- Bolt 1 - ---- Gasket 1 - ---- Pump		
	PUMP PACKAGE, FUEL Part No. 1843 287 Consists of: 2 - ---- Bolt 1 - ---- Gasket 1 - ---- Pump	14-73-7	REPAIR KIT, FUEL PUMP ROCKER ARM Part No. 1450 246 Consists of: 1 - ---- Gasket, Mounting 1 - ---- Lever, Cam 1 - ---- Spring, Diaphragm 1 - ---- Spring, Cam Lever Return
	PUMP PACKAGE, FUEL Part No. E1843 359 Consists of: 2 - ---- Bolt 1 - ---- Gasket 1 - ---- Pump		REPAIR KIT, FUEL PUMP ROCKER ARM Part No. E1603 327 Consists of: 1 - ---- Gasket, Mounting 1 - ---- Lever, Cam 1 - ---- Pin, Cam Lever 1 - ---- Plug, Cam Lever Pin
	PUMP PACKAGE, FUEL Part No. 1843 399 Consists of: 1 - ---- Gasket 1 - ---- Pump		REPAIR KIT, FUEL PUMP ROCKER ARM Part No. E1603 390 Consists of: 1 - ---- Gasket, Mounting 1 - ---- Lever, Cam 1 - ---- Pin, Cam Lever 1 - ---- Plug, Cam Lever Pin
	PUMP PACKAGE, FUEL Part No. 1843 400 Consists of: 2 - ---- Bolt 1 - ---- Gasket 1 - ---- Pum		
	PUMP PACKAGE, FUEL Part No. 1879 296 Consists of: 2 - ---- Bolt 1 - ---- Gasket 1 - ---- Pump	14-86-35	CAP PACKAGE, FILLER TUBE Part No. 1879 488 Consists of: 1 - ---- Bar, Cap 1 - ---- Cap 1 - ---- Nut, w/Washer

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.
 Prices and specifications subject to change without notice.

1955-58 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
16-03-1	JOINT PACKAGE, UNIVERSAL, FRONT Part No. 1450 446 Consists of: 1 - ---- --- Pin, Centering 2 - ---- --- Button, Centering 1 - 1532 943 Clamp, Large 1 - 870 540 Clamp, Small 1 - ---- --- Cover, Dust 2 - 1532 906 Washer, Thrust 1 - 1532 904 Cover, Grease 1 - 1530 286 Gasket, Cover 2 - 1532 900 Ball and Roller	(Cont'd)	1 - 870 540 Clamp, Small 1 - 1532 943 Clamp, Large 2 - 580 687 Ball and Roller
	JOINT PACKAGE, UNIVERSAL, REAR Part No. 1603 233 Consists of: 1 - ---- --- Cross Assy. 2 - 1532 930 Roller and Bushing 2 - 1611 646 Block, Roller and Bearing 2 - 858 025 Retainer, Roller Bushing		JOINT PACKAGE, UNIVERSAL, FRONT Part No. 1752 680 Consists of: 1 - 1635 092 Cover, Grease 2 - 605 004 Washer, Thrust 1 - 1635 098 Gasket, Cover 1 - 870 540 Clamp, Small 1 - ---- --- Pin, Centering 1 - 1532 943 Clamp, Large 2 - ---- --- Button, Centering 1 - ---- --- Cover, Dust 2 - 1739 927 Ball and Roller
	JOINT PACKAGE, UNIVERSAL Part No. 1603 398 Consists of: 1 - ---- --- Pin, Centering 1 - 1616 185 Gasket, Cover 1 - 602 820 Cover, Grease 2 - 605 004 Washer, Thrust 2 - ---- --- Button, Centering 2 - 1550 466 Ball and Roller 1 - 639 973 Spring 1 - ---- --- Cover, Dust 1 - 870 539 Clamp, Large 1 - 870 540 Clamp, Small		JOINT PACKAGE, UNIVERSAL Part No. 1752 624 Consists of: 1 - ---- --- Cross Assy. 4 - 1739 913 Roller and Bushing 4 - 858 006 Retainer, Roller Bushing
	JOINT PACKAGE, UNIVERSAL, FRONT Part No. 1643 288 Consists of: 1 - ---- --- Pin, Centering 2 - ---- --- Button, Centering 1 - 1637 316 Clamp, Small 1 - 1637 317 Clamp, Large 1 - ---- --- Cover, Dust 2 - 1532 906 Washer, Thrust 1 - 1532 904 Cover, Grease 1 - 1530 286 Gasket, Cover 2 - 1532 900 Ball and Roller	16-06-2	JOINT PACKAGE, UNIVERSAL Part No. 1752 623 Consists of: 1 - ---- --- Cross Assy. 2 - 1739 913 Roller and Bushing 2 - 858 006 Retainer, Roller Bushing 2 - 1739 914 Block, Roller and Bearing
	JOINT PACKAGE, UNIVERSAL Part No. 1818 779 Consists of: 1 - ---- --- Cross Assy. 4 - 1672 044 Roller and Bushing 4 - 858 025 Retainer, Roller Bushing		BUTTON and PIN PACKAGE, UNIVERSAL JOINT . . . Part No. 1450 447 Consists of: 1 - ---- --- Pin, Centering 2 - ---- --- Button, Centering
	JOINT PACKAGE, UNIVERSAL, FRONT Part No. 1643 287 Consists of: 1 - ---- --- Pin, Centering 1 - 1635 098 Gasket, Cover 1 - 1635 092 Cover, Grease 2 - 581 535 Washer, Thrust 2 - ---- --- Button, Centering 1 - ---- --- Cover, Dust		BUTTON and PIN PACKAGE, UNIVERSAL JOINT . . . Part No. 1243 720 Consists of: 1 - ---- --- Pin, Centering 2 - ---- --- Button, Centering
	(Pkg. Cont'd)		16-07-4 DUST COVER PACKAGE, UNIVERSAL JOINT . . . Part No. 1603 397 Consists of: 1 - ---- --- Cover, Dust 1 - 870 539 Clamp, Large 1 - 870 540 Clamp, Small
			DUST COVER PACKAGE, UNIVERSAL JOINT . . . Part No. 1450 448 Consists of: 1 - ---- --- Cover, Dust 1 - 870 540 Clamp, Small 1 - 1532 943 Clamp, Large
			DUST COVER PACKAGE, UNIVERSAL JOINT . . . Part No. 1643 289 Consists of: 1 - ---- --- Cover, Dust 1 - 1637 316 Clamp, Small 1 - 1637 317 Clamp, Large

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
17-11-1	BUSHING PACKAGE, REAR SPRING. Part No. 1450 089 Consists of: 4 - ---- --- Bushing		ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 1879 305 Consists of: 1 - ---- --- Absorber 2 - 1319 902 Bushing
17-12-3	INTER-LEAF PACKAGE, REAR SPRING. Part No. 1731 728 Consists of: 2 - 1673 489 Bolt, Rear Spring Center 4 - 1488 207 Clip, Rear Spring Alignemnt 2 - 1730 159 Clip, Rear Spring Alignment 2 - ---- --- Interliner 2 - ---- --- Leaves 2 - 120 368 Nut, Rear Spring Center 6 - 120 377 Nut, Rear Spring Alignment Clip Screw 6 - 1485 510 Screw, Rear Spring Alignment Clip 6 - 1530 398 Washer, Rear Spring Alignment Clip		ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 1879 306 Consists of: 1 - ---- --- Absorber 2 - 1319 902 Bushing
17-16-1	SHACKLE and BUSHING PACKAGE, REAR SPRING Part No. 1450 087 Consists of: 4 - ---- --- Bushing 2 - 126 022 Nut 2 - ---- --- Shackle	19-01-3	OVERHAUL PACKAGE, STEERING GEAR Part No. 1752 214 Consists of: 2 - 866 929 Bushing, Shaft - Upper 2 - 669 077 Cage, w/Roller, Worm Thrust Bearing 1 - 619 311 Cup, Worm Upper Thrust Bearing 1 - 632 685 Cup, Worm Lower Thrust Bearing 1 - 1142 262 Gasket, Shaft Cover 1 - 653 194 Seal, Tube Oil 1 - 661 116 Seal, Column Jacket Oil 1 - 661 117 Seal, Column Jacket Oil 1 - 1730 985 Seal, Shaft Oil 10 - 1142 261 Shim, Housing Cover
	SHACKLE and BUSHING PACKAGE, REAR SPRING Part No. 1450 961 Consists of: 4 - ---- --- Bushing 2 - 126 022 Nut 2 - ---- --- Shackle		OVERHAUL PACKAGE, STEERING GEAR Part No. 1752 217 Consists of: 2 - 1615 679 Bushing, Shaft - Upper 2 - 669 077 Cage, w/Roller, Worm Thrust Bearing 1 - 618 311 Cup, Worm Upper Thrust Bearing 1 - 632 685 Cup, Worm Lower Thrust Bearing 1 - 1142 262 Gasket, Shaft Cover 1 - 653 194 Seal, Tube Oil 1 - 661 117 Seal, Column Jacket Oil 1 - 1730 985 Seal, Shaft Oil 10 - 1142 261 Shim, Housing Cover
17-23-3	ABSORBER and BUSHING PACKAGE, FRONT SHOCK Part No. 1879 684 Consists of: 1 - ---- --- Absorber 2 - 1614 385 Bushing, Upper Mounting 2 - 1635 588 Bushing, Lower Mounting		OVERHAUL PACKAGE, STEERING GEAR Part No. 1843 262 Consists of: 1 - 1615 679 Bushing, Shaft - Lower 1 - 1673 962 Bushing, Shaft - Upper 2 - 669 077 Cage, w/Roller, Worm Thrust Bearing 1 - 618 311 Cup, Worm Upper Thrust Bearing
	ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 1450 037 Consists of: 1 - ---- --- Absorber 2 - 1319 902 Bushing		
	ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 1450 917 Consists of: 1 - ---- --- Absorber 2 - 1319 902 Bushing		
	ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 1752 259 Consists of: 1 - ---- --- Absorber 2 - 1319 902 Bushing		

(Pkg. Cont'd)

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

1955-58 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)	<p>1 - 632 685 Cup, Worm Lower Thrust Bearing</p> <p>1 - 1142 262 Gasket, Shaft Cover</p> <p>1 - 1730 985 Seal, Shaft Oil</p> <p>1 - 653 194 Seal, Tube Oil</p> <p>1 - 661 117 Seal, Column Jacket Oil</p> <p>10 - 1142 261 Shim, Housing Cover</p> <p>OVERHAUL PACKAGE, STEERING GEAR Part No. 1843 255 Consists of:</p> <p>3 - 857 706 Bushing, Shaft</p> <p>2 - 640 086 Cage, w/Roller, Worm Thrust Bearing</p> <p>1 - 376 751 Cup, Worm Upper Thrust Bearing</p> <p>1 - 637 539 Cup, Worm Lower Thrust Bearing</p> <p>1 - 1738 206 Gasket, Shaft Cover</p> <p>1 - 1730 985 Seal, Shaft Oil</p> <p>10 - 1123 313 Shim, Housing Cover</p>		<p>TUBE PACKAGE, POWER STEERING GEAR Part No. 1879 715 Consists of:</p> <p>2 - 1822 667 Insert</p> <p>1 - 1822 668 Insulator</p> <p>1 - ---- --- Tube</p> <p>TUBE PACKAGE, POWER STEERING GEAR Part No. 1879 716 Consists of:</p> <p>2 - 1822 667 Insert</p> <p>1 - 1822 668 Insulator</p> <p>1 - ---- --- Tube</p>
19-02-1	<p>HOUSING PACKAGE, POWER STEERING GEAR Part No. 1879 537 Consists of:</p> <p>1 - 1822 735 Housing</p> <p>1 - 1822 671 "O" Ring, Piston Ring Back-Up</p> <p>1 - 1822 672 Ring, Piston</p> <p>1 - 1822 736 Worm, w/Piston</p>	19-15-29	<p>WORM CONNECTOR PACKAGE, POWER STEERING GEAR Part No. 1879 490 Consists of:</p> <p>1 - ---- --- Connector, Worm</p> <p>1 - 1673 971 Nut, Worm</p>
19-14-7	<p>BEARING and COLLAR PACKAGE, POWER STEERING GEAR COLUMN JACKET . . . Part No. 1879 708 Consists of:</p> <p>1 - ---- --- Bearing</p> <p>1 - ---- --- Collar</p> <p>1 - ---- --- Spring</p> <p>2 - ---- --- Washer</p>	19-54-9	<p>GASKET and SEAL PACKAGE, POWER STEERING PUMP Part No. 1826 188 Consists of:</p> <p>1 - 1733 003 Gasket, End Cap and Body</p> <p>1 - 1733 014 Gasket, Flow Valve</p> <p>1 - 1733 013 Gasket, Body and Bearing Cap</p> <p>1 - 1733 019 Gasket, Discharge Fitting</p> <p>1 - 1733 018 Seal, Body to Valve</p> <p>1 - 1733 015 Seal, Bearing Cap</p> <p>1 - 1733 020 Seal, Body and Fitting</p> <p>1 - 1733 024 Seal, Drive Shaft</p>
19-14-10	<p>SUPPORT and INSULATOR PACKAGE, POWER STEERING GEAR COLUMN JACKET . . . Part No. 1879 713 Consists of:</p> <p>1 - 1850 547 Insulator</p> <p>1 - ---- --- Support</p>	19-54-18	<p>BRACKET PACKAGE, POWER STEERING PUMP Part No. 1843 024 Consists of:</p> <p>1 - ---- --- Bracket, Mounting - Front</p> <p>1 - ---- --- Bracket, Mounting - Rear</p>
19-15-2	<p>BALL PACKAGE, POWER STEERING GEAR WORM CONNECTOR Part No. 1450 995 Consists of:</p> <p>40 - ---- --- Balls</p>	19-54-54	<p>RING, ROTOR and VANES PACKAGE, POWER STEERING PUMP VANE CAM . . . Part No. 1653 468 Consists of:</p> <p>1 - ---- --- Ring</p> <p>1 - ---- --- Rotor</p> <p>10 - ---- --- Vane</p>
19-15-5	<p>TUBE PACKAGE, POWER STEERING GEAR Part No. 1879 714 Consists of:</p> <p>2 - 1822 667 Insert</p> <p>1 - 1822 668 Insulator</p> <p>1 - ---- --- Tube</p>		<p>RING, ROTOR and VANES PACKAGE, POWER STEERING PUMP VANE CAM . . . Part No. 1752 454 Consists of:</p> <p>1 - ---- --- Ring</p> <p>1 - ---- --- Rotor</p> <p>10 - ---- --- Vane</p>
			<p>RING, ROTOR and VANES PACKAGE, POWER STEERING PUMP VANE CAM . . . Part No. 1826 159 Consists of:</p> <p>1 - ---- --- Ring</p> <p>1 - ---- --- Rotor</p> <p>10 - ---- --- Vane</p>

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
19-54-64	ELEMENT and SEAL PACKAGE, POWER STEERING PUMP FILTER Part No. 1653 467 Consists of: 1 - 1639 739 Element, Filter 1 - 1316 813 "O" Ring, Pump Cover Plug 1 - 1639 723 "O" Ring, Pump Pressure Plate 1 - 1639 730 "O" Ring, Body to Vane Cam Ring 1 - 1639 736 "O" Ring, Vane Cam Ring to Tank 1 - 1639 734 Seal, Drive Shaft Oil 2 - 1539 287 Washer, Pump Tank Screw Sealing	(Cont'd)	1 - 1486 204 "O" Ring, Housing Cover 2 - 1556 759 "O" Ring, Housing Head 1 - 1486 205 "O" Ring, Piston Pin 2 - 1486 204 "O" Ring, Piston Rod 2 - 1316 864 "O" Ring, Valve Rod 2 - 1316 813 "O" Ring, Piston Rod Support Pin 1 - 1329 971 "O" Ring, Shaft Adjusting Screw 3 - 686 626 Seal, Shaft Cover Screw Oil
	ELEMENT and SEAL PACKAGE, POWER STEERING PUMP FILTER Part No. 1752 455 Consists of: 1 - 1786 696 Filter, Pump Oil 2 - 1786 710 "O" Ring, Pump Oil Seal 3 - 1826 164 "O" Ring, Tank to Body Oil Seal 2 - 1826 171 "O" Ring, Pump to Cover 1 - 1786 691 "O" Ring, Pump Control Valve Plug 1 - 1639 734 Seal, Pump Drive Shaft Oil		"O" RING and SEAL PACKAGE, POWER STEERING GEAR Part No. 1603 230 Consists of: 1 - 1537 577 "O" Ring, Housing Cover 2 - 1557 217 "O" Ring, Housing Head 1 - 1537 581 "O" Ring, Shaft Cover 1 - 1486 205 "O" Ring, Piston Pin 2 - 1537 603 "O" Ring, Piston Rod 2 - 1316 864 "O" Ring, Valve Rod 1 - 1557 217 "O" Ring, Shaft Cover
19-54-98	PULLEY and BELT PACKAGE, POWER STEERING PUMP Part No. 1843 197 Consists of: 1 - 1401 625 Belt, Pump 1 - 1826 051 Pulley, Pump		"O" RING and SEAL PACKAGE, POWER STEERING GEAR Part No. 1752 480 Consists of: 2 - 1556 759 "O" Ring, Housing Head 1 - 1734 077 "O" Ring, Shaft Cover 1 - 1329 971 "O" Ring, Shaft Adjusting Screw 1 - 1486 205 "O" Ring, Piston Pin 2 - 1486 204 "O" Ring, Piston Rod 2 - 1316 864 "O" Ring, Valve Rod 2 - 686 626 Seal, Shaft Cover Screw Oil
	PULLEY and BELT PACKAGE, POWER STEERING PUMP Part No. 1843 145 Consists of: 1 - 1326 615 Belt, Pump 1 - 1825 975 Pulley, Pump		"O" RING and SEAL PACKAGE, POWER STEERING GEAR Part No. 1881 715 Consists of: 1 - ---- --- Gasket, Valve Housing Plug 1 - 1733 615 "O" Ring, Shaft Cover 1 - 1316 849 "O" Ring, Housing 1 - 1536 268 "O" Ring, Pressure Control Valve 2 - 1556 385 "O" Ring, Housing Port 1 - 1486 205 "O" Ring, Cylinder Head Ferrule 2 - 1733 562 "O" Ring, Cylinder Head 1 - 1822 149 "O" Ring, Reaction-Lower 1 - 1733 612 "O" Ring, Valve Housing 1 - 1733 602 "O" Ring, Column Support 1 - 1822 324 Seal, Worm Shaft Inner 1 - 1822 203 Seal, Shaft Adjusting Screw 1 - 1822 151 Seal, Reaction-Upper 1 - 1730 985 Seal, Shaft Oil
19-54-128	FLOW CONTROL VALVE PLUG and SNAP RING PACKAGE, POWER STEERING PUMP Part No. 1843 196 Consists of: 1 - 1827 461 Belt, Pump 1 - 1827 293 Pulley, Pump		
19-54-128	FLOW CONTROL VALVE PLUG and SNAP RING PACKAGE, POWER STEERING PUMP Part No. 1879 353 Consists of: 1 - ---- --- Plug 1 - ---- --- Ring		
19-55-1	"O" RING and SEAL PACKAGE, POWER STEERING GEAR Part No. 1603 229 Consists of: 1 - 1558 254 Gasket, Shaft Cover 1 - 1531 495 Gasket, Shaft Cover (Pkg. Cont'd)	19-56-6	PISTON RING and RETAINER PACKAGE, POWER STEERING GEAR Part No. 1692 656 Consists of: 2 - ---- --- Retainer 2 - 1634 561 Ring

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.

Prices and specifications subject to change without notice.

1955-58 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	PISTON RING and RETAINER PACKAGE, POWER STEERING GEAR Part No. 1692 657 Consists of: 2 - ---- --- Retainer 2 - 1618 789 Ring PISTON RING, RETAINER and SEAL PACKAGE, POWER STEERING GEAR Part No. 1879 745 Consists of: 1 - ---- --- Retainer, Piston Ring Seal 1 - ---- --- Ring, Piston 1 - ---- --- Seal, Piston Ring Back-Up	(Cont'd)	1 - 1408 518 Gasket, Extension 1 - 854 801 Gasket, Gearshift Housing 2 - 857 309 Gasket, Selector Ball Spring 2 - 865 180 Gasket, Pinion Bearing Retainer 1 - 1408 466 Seal, Gearshift Housing 1 - 1536 267 Seal, Selector Shaft
19-57-2	PISTON and SPRING PACKAGE, POWER STEERING GEAR PRESSURE CONTROL VALVE . . . Part No. 1879 509 Consists of: 1 - ---- --- Piston 1 - 1822 442 Spring		GASKET and SEAL PACKAGE, POWERFLITE TRANS- MISSION, PARTIAL . . . Part No. 1603 251 Consists of: 1 - 1408 254 Gasket, Extension 1 - 1408 255 Gasket, Output Shaft Support 1 - 1408 282 Gasket, Oil Pan 1 - 1408 245 Seal, Frt. Oil Pump Housing 1 - 1486 536 Seal, Reaction Shaft 1 - 1738 265 Seal, Reaction Shaft
21-01-1	SMALL PARTS PACKAGE, STD. TRANSMISSION . . Part No. E1752 685 Consists of: 1 - 602 007 Bearing, Shaft Pilot 2 - 865 180 Gasket, Pinion Bearing Retainer 1 - 1408 518 Gasket, Extension 1 - 854 801 Gasket, Gearshift Housing 1 - 865 170 Gasket, Case to Clutch Housing 2 - 601 129 Plate, Countershaft Rear 1 - 601 108 Ring, Pilot Bearing 2 - 631 823 Ring, Pinion Bearing 2 - 631 824 Ring, Pinion Bearing 1 - 640 280 Ring, Shaft Bearing 66 - 666 927 Roller, Countershaft and Idle Gear 2 - 608 804 Washer, Countershaft Thrust 1 - 631 877 Washer, Pinion Bearing Snap Ring 2 - 666 924 Washer, Reverse Idler Gear		GASKET SET, AUTO. 3 SPEED TRANSMISSION . Part No. E1692 675 Consists of: 1 - 1636 298 Gasket, Output Shaft Support 1 - 1638 666 Gasket, Extension 1 - 1636 448 Gasket, Oil Pan 1 - 1824 553 Ring, Reaction Shaft Seal 1 - 1408 245 Seal, Front Oil Pump Housing
			GASKET SET, STD. TRANSMISSION Part No. E1752 479 Consists of: 2 - 601 130 Gasket, Bearing Retainer 1 - 1635 273 Gasket, Case to Adapter 1 - 1853 856 Gasket, Gearshift Housing
21-01-3	GASKET SET, STD. TRANSMISSION Part No. 1450 231 Consists of: 1 - 865 170 Gasket, Case to Clutch Housing 1 - 854 801 Gasket, Gearshift Housing 2 - 601 130 Gasket, Pinion Bearing Retainer 1 - 1408 518 Gasket, Extension 2 - 857 309 Gasket, Selector Ball Spring 2 - 686 626 Grommet, Extension Screw 1 - ---- --- Seal, Gearshift Selector Shaft 1 - 1408 466 Seal, Gearshift Housing GASKET SET, STD. TRANSMISSION Part No. 1450 232 Consists of: 1 - 865 170 Gasket, Case to Clutch Housing		GASKET and SEAL PACKAGE, POWERFLITE TRANS- MISSION, COMPLETE . Part No. 1843 228 Consists of: 1 - 1408 254 Gasket, Extension 1 - 1408 255 Gasket, Output Shaft Support 1 - 1408 282 Gasket, Oil Pan 1 - 1672 066 Gasket, Valve Body 1 - 1117 819 Gasket, Regulator Valve Spring Retainer 1 - 1408 375 Gasket, Torque Converter Valve Spring Retainer 1 - 1316 864 "O" Ring, Control Cable 1 - 1736 376 Ring, Output Shaft Seal 1 - 1408 245 Seal, Front Oil Pump Housing 1 - 1486 536 Seal, Reaction Shaft 1 - 1738 265 Seal, Reaction Shaft 1 - 1738 263 Seal, Hub 1 - 1738 261 Seal, Direct Clutch Piston Ring
	(Pkg. Cont'd)		(Pkg. Cont'd)

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)			
	1 - 1671 763 Seal, Output Shaft Rear Bearing	21-113-24	SWITCH PACKAGE, TRANS- MISSION NEUTRAL STARTER Part No. 1704 283 Consists of: 1 - 1316 849 "O" Ring, Mounting 1 - ---- --- Switch, Neutral Starter 1 - 1704 482 Washer, Mounting
	2 - 1401 256 Seal, Oil Strainer Tube		
	1 - 863 987 Seal, Drain Plug		
21-01-20	PLATE and SPRING PACKAGE, STD. TRANSMISSION SYNCHRONIZER, w/STRUT TYPE SYNCHRONIZER. Part No. 1450 736 Consists of: 3 - ---- --- Plate, Shifting 2 - ---- --- Spring, Synchronizer	21-118-1	GASKET SET, AUTO. 3 SPEED TRANSMISSION FRONT OIL PUMP . . . Part No. 1843 230 Consists of: 1 - 1636 303 Gasket, Regulator Valve Body 1 - 1117 819 Gasket, Regulator Valve Spring Retainer 1 - 1408 375 Gasket, Torque Converter Control Valve Spring Retainer 1 - 1738 263 Oil Seal, Impeller Hub 1 - 1824 553 Ring, Reaction Shaft Seal 1 - 1408 245 Seal, Front Oil Pump Housing 1 - 1738 264 Seal, Front Oil Pump Drive Sleeve
21-01-36	SWITCH PACKAGE, TRANS- MISSION GOVERNOR, w/OVERDRIVE Part No. E1605 139 Consists of: 1 - ---- --- Gasket, Mounting 1 - ---- --- Switch		
21-03-3	CASE PACKAGE, AUTO. 3 SPEED TRANSMISSION . Part No. E1879 421 Consists of: 1 - 1736 473 Body, Valve, w/Transfer Plate 1 - 1736 236 Case, Transmission 1 - 1736 219 Guide, Kickdown Piston Rod 1 - 1823 667 Housing, Rear Oil Pump 1 - 1736 344 Lever, Kickdown Band 1 - 1736 226 Piston, Accumulator 1 - 1736 218 Piston, Kickdown Servo 1 - 1736 221 Rod, Kickdown Piston 1 - 1736 224 Ring, Kickdown Piston Seal, Large 1 - 1322 363 Ring, Kickdown Piston Seal, Medium 1 - 1314 249 Ring, Kickdown Piston Seal, Small 1 - 1329 642 Ring, Kickdown Piston Rod Guide 1 - 1736 233 Ring, Accumulator Piston Seal, Large 1 - 1672 287 Ring, Accumulator 1 - 1736 222 Spring, Kickdown Piston 1 - 1736 228 Spring, Accumulator		
			GASKET SET, AUTO. 3 SPEED TRANSMISSION REAR OIL PUMP and EXTENSION Part No. E1843 231 Consists of: 1 - 1636 298 Gasket, Output Shaft Support 1 - 1638 666 Gasket, Extension 1 - 1671 763 Oil Seal, Output Shaft Rear Bearing 2 - 1636 470 Ring, Governor Support Seal
21-05-1	SHAFT PACKAGE, AUTO. 3 SPEED TRANSMISSION OUTPUT. Part No. E1843 319 Consists of: 1 - 1736 468 Screw, Locating 1 - 1736 471 Shaft, Output 1 - 1736 424 Valve, Governor	21-118-37	SLEEVE PACKAGE, POWERFLITE TRANS- MISSION FRONT OIL PUMP Part No. 1752 606 Consists of: 1 - 1738 264 Seal, Front Oil Pump Drive Sleeve 1 - ---- --- Sleeve, Front Oil Pump Drive
21-05-24	SUPPORT and OIL PUMP HOUSING PACKAGE, AUTO. 3 SPEED TRANSMISSION Part No. E1879 489 Consists of: 1 - 1823 667 Housing, Oil Pump 1 - 1823 809 Support, Output Shaft	21-131-1	BODY PACKAGE, POWERFLITE TRANSMISSION REGULATOR VALVE. . Part No. 1643 243 Consists of: 1 - ---- --- Body, Regulator Valve 1 - 1630 812 Spring, Torque Converter Control Valve 1 - 1630 811 Valve, Torque Converter Control
		21-133-3	GASKET and SEAL RING PACKAGE, AUTO. 3 SPEED TRANSMISSION FRONT and REAR CLUTCH and INPUT SHAFT. Part No. 1843 229 Consists of: 1 - 1636 448 Gasket, Oil Pan 1 - 1672 074 Gasket, Cable Adapter Housing

(Pkg. Cont'd)

★ Indicates use as required.

□ Indicates parts not listed in any previous parts book.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)	1 - 1824 551 Ring, Front Clutch Piston Seal, Inner 1 - 1824 549 Ring, Front Clutch Piston Seal, Outer 1 - 1323 593 Ring, Input Shaft, Large 1 - 1941 831 Ring, Input Shaft, Small 1 - 1824 550 Ring, Rear Clutch Piston Seal, Outer 1 - 1824 552 Ring, Rear Clutch Piston Seal, Inner 1 - 1314 249 Ring, Output Shaft Seal, Large 1 - 1736 376 Ring, Output Shaft Seal, Small 2 - 1636 324 Ring, Intermediate Shaft Seal, Small 4 - 1672 287 Ring, Intermediate Shaft Seal, Large 2 - 1636 469 Ring, Rear Clutch Seal 2 - 1401 256 Seal, Oil Strainer Tube	PLATE and DISC PACKAGE, POWERFLITE TRANSMISSION DIRECT CLUTCH DRIVING Part No. 1643 259 Consists of: 7 - ---- --- Disc 7 - ---- --- Plate	
21-133-4	RETAINER PACKAGE, AUTO. 3 SPEED TRANS- MISSION FRONT CLUTCH PISTON Part No. E1843 290 Consists of: 1 - 1736 393 Plate, Front Clutch Cushion Spring 1 - 1736 429 Retainer, Front Clutch Piston 1 - 1736 392 Spring, Front Clutch Cushion	21-134-2 CARRIER PACKAGE, AUTO. 3 SPEED TRANS- MISSION KICKDOWN PLANET PINION Part No. E1843 160 Consists of: 1 - 1736 194 Carrier, Planet Pinion 1 - 1736 187 Drum, Low and Reverse Band 1 - 1736 193 Gear, Reverse Annulus 1 - 1736 207 Hub, Overrunning Clutch	
	RETAINER PACKAGE, AUTO. 3 SPEED TRANS- MISSION FRONT CLUTCH PISTON Part No. E1879 746 Consists of: 8 - 1736 409 Lever, Front Clutch 1 - 1736 408 Plate, Front Clutch Cushion Spring 1 - 1736 407 Piston, Front Clutch 1 - 1736 393 Plate, Front Clutch Cushion Spring 1 - 1736 429 Retainer, Front Clutch Piston 1 - 1736 410 Retainer, Front Clutch Piston Lever 1 - 1736 392 Spring, Front Clutch Cushion	21-135-2 CARRIER PACKAGE, AUTO. 3 SPEED TRANSMISSION LOW and REVERSE PLANET PINION Part No. E1843 160 Consists of: 1 - 1736 194 Carrier, Planet Pinion 1 - 1736 187 Drum, Low and Reverse Band 1 - 1736 193 Gear, Reverse Annulus 1 - 1736 207 Hub, Overrunning Clutch	
21-133-28	PLATE and PISTON PACKAGE, AUTO. 3 SPEED TRANSMISSION FRONT CLUTCH Part No. E1843 435 Consists of: 4 - 1736 409 Lever, Clutch 1 - 1736 407 Piston, Clutch 1 - 1736 408 Plate, Clutch Pressure 1 - 1736 410 Retainer, Piston Lever	21-138-2 REPAIR PACKAGE, POWER- FLITE TRANSMISSION GOVERNOR Part No. 1653 463 Consists of: 1 - ---- --- Body, Governor 1 - 1329 702 Ring, Weight 1 - 1559 495 Ring, Weight 1 - ---- --- Screw, Locating 1 - 1556 082 Shaft, Valve 2 - 1638 461 Snap Ring, Shaft 1 - 1559 498 Spring, Weight 1 - 1315 155 Valve, Governor 1 - 1559 494 Weight, Governor, Outer 1 - 1559 496 Weight, Governor, Intermediate 1 - 1559 497 Weight, Governor, Inner	
21-133-37	PLATE and DISC PACKAGE, POWERFLITE TRANSMISSION DIRECT CLUTCH DRIVING Part No. 1450 209 Consists of: 6 - ---- --- Disc 6 - ---- --- Plate	REPAIR PACKAGE, POWER- FLITE TRANSMISSION GOVERNOR Part No. 1653 464 Consists of: 1 - ---- --- Body, Governor 1 - 1329 702 Ring, Weight 2 - 1638 461 Ring, Shaft 1 - 1630 708 Ring, Outer Weight 1 - 1556 082 Shaft, Valve 1 - 1736 468 Screw, Locating 1 - 1559 498 Spring, Weight 1 - 1315 155 Valve, Governor 1 - 1559 501 Weight, Governor, Outer 1 - 1559 502 Weight, Governor, Inner 1 - 1559 503 Weight, Governor, Intermediate	

★ Indicates use as required.

□ Indicates parts not listed in any previous parts book.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	REPAIR PACKAGE, AUTO. 3 SPEED TRANSMISSION GOVERNOR Part No. E1752 604 Consists of: 1 - ---- --- Body, Governor 1 - 1636 464 Ring, Inner Weight 1 - 1636 465 Ring, Outer Weight 2 - 1638 461 Ring, Valve Shaft 1 - 1736 468 Screw, Locating 1 - 1636 463 Spring, Weight 1 - 1556 082 Shaft, Valve 1 - 1315 155 Valve, Governor 1 - 1636 461 Weight, Governor, Outer 1 - 1636 462 Weight, Governor, Inner	(Cont'd)	1 - 1736 232 Plate, Valve Body Upper 1 - 1732 140 Plate, Valve Body Lower 1 - 1732 141 Plug, Governor Compensator
	REPAIR PACKAGE, AUTO. 3 SPEED TRANSMISSION GOVERNOR Part No. 1752 684 Consists of: 1 - ---- --- Body, Governor 1 - 1736 468 Screw, Locating 1 - 1556 082 Shaft, Valve 1 - 1636 463 Spring, Weight 1 - 1636 464 Snap Ring, Inner Weight 1 - 1636 465 Snap Ring, Outer Weight 2 - 1638 461 Snap Ring, Valve Shaft 1 - 1736 424 Valve, Governor 1 - 1636 461 Weight, Governor, Outer 1 - 1636 462 Weight, Governor, Inner	21-139-28 VALVE and SPRING PACKAGE, POWERFLITE TRANSMISSION THROTTLE Part No. E1752 242 Consists of: 1 - 1672 218 Spring, Throttle Valve 1 - ---- --- Valve, Throttle	
	REPAIR PACKAGE, AUTO. 3 SPEED TRANSMISSION GOVERNOR Part No. 1843 499 Consists of: 1 - ---- --- Body, Governor 1 - 1736 468 Screw, Locating 1 - 1556 082 Shaft, Valve 1 - 1636 464 Snap Ring, Inner Weight 1 - 1636 465 Snap Ring, Outer Weight 2 - 1638 461 Snap Ring, Valve Shaft 1 - 1736 424 Valve, Governor 1 - 1823 726 Weight, Governor, Outer 1 - 1636 462 Weight, Governor, Inner	23-11-21 LETTER "C" AND INSERT PACKAGE, REAR DOOR OUT- MOULDING Part No. E1881 863 Consists of: 1 - ---- --- Insert 1 - ---- --- Letter	
21-139-3	BODY PACKAGE, AUTO, 3 SPEED TRANSMISSION REAR VALVE Part No. E1752 343 Consists of: 1 - 1732 131 Body, Valve Rear 1 - 1732 132 Valve, Relay	23-14-53 HANDLE PACKAGE, DOOR VENT WING Part No. 1450 156 Consists of: 1 - ---- --- Button 1 - ---- --- Key 1 - ---- --- Pin 1 - ---- --- Spring 1 - ---- --- Washer	
	BODY PACKAGE, AUTO. 3 SPEED TRANSMISSION LOWER VALVE Part No. E1752 344 Consists of: 1 - 1732 139 Body, Valve Lower 1 - ---- --- Plate, Valve Body Upper 1 - 1732 140 Plate, Valve Body Lower 1 - 1732 141 Plug, Governor Compensator	HANDLE PACKAGE, DOOR VENT WING, RIGHT . . Part No. 1833 481 Consists of: 1 - ---- --- Button 1 - ---- --- Handle 1 - ---- --- Pin 1 - ---- --- Spring 1 - ---- --- Washer	
	BODY PACKAGE, AUTO. 3 SPEED TRANSMISSION LOWER VALVE Part No. E1818 601 Consists of: 1 - 1732 139 Body, Valve Lower	HANDLE PACKAGE, DOOR VENT WING, RIGHT . . Part No. 1833 503 Consists of: 1 - ---- --- Handle 1 - ---- --- Key 1 - ---- --- Pin 1 - ---- --- Spring 1 - ---- --- Washer	
		HANDLE PACKAGE, DOOR VENT WING, LEFT . . Part No. 1833 674 Consists of: 1 - ---- --- Handle 1 - ---- --- Key 1 - ---- --- Pin 1 - ---- --- Spring 1 - ---- --- Washer	

(Pkg. Cont'd)

★ Indicates use as required.
□ Indicates parts not listed in any previous parts book.

1955-58 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	HANDLE PACKAGE, DOOR VENT WING, LEFT . . Part No. 1833 675 Consists of: 1 - ---- Button 1 - ---- Handle 1 - ---- Pin 1 - ---- Spring 1 - ---- Washer	(Cont'd)	1 - ---- Cylinder, Door, Left 1 - ---- Cylinder, Ignition 1 - ---- Cylinder, Tailgate 2 - ---- Keys
23-17-2	CYLINDER AND KEYS PACKAGE, DOOR AND IGNITION LOCK Part No. 1315 511 Consists of: 2 - ---- Cylinders, Door 1 - ---- Cylinder, Ignition 2 - ---- Keys	23-17-4	CYLINDER AND KEYS PACKAGE, DECK LID AND GLOVE BOX LOCK Part No. 1520 069 Consists of: 1 - ---- Cylinder, Deck Lid 2 - ---- Keys 1 - ---- Latch, Glove Box
	CYLINDER AND KEYS PACKAGE, DOOR AND IGNITION LOOK Part No. 1649 536 Consists of: 2 - ---- Cylinders, Door 1 - ---- Cylinder, Ignition 2 - ---- Keys		CYLINDER AND KEYS PACKAGE, DECK LID AND GLOVE BOX LOCK Part No. 1520 432 Consists of: 1 - ---- Cylinder, Deck Lid 2 - ---- Keys 1 - ---- Latch
	CYLINDER AND KEYS PACKAGE, DOOR AND IGNITION LOCK Part No. 1685 060 Consists of: 2 - ---- Cylinders, Door 1 - ---- Cylinder, Ignition 2 - ---- Keys		CYLINDER AND KEYS PACKAGE, DECK LID AND GLOVE BOX LOCK Part No. 1602 861 Consists of: 1 - ---- Cylinder, Deck Lid 2 - ---- Keys 1 - ---- Latch, Glove Box
	CYLINDER AND KEYS PACKAGE, DOOR AND IGNITION LOCK Part No. 1698 638 Consists of: 1 - ---- Cylinder, Door, Right 1 - ---- Cylinder, Door, Left 1 - ---- Cylinder, Ignition 2 - ---- Keys		CYLINDER AND KEYS PACKAGE, DECK LID AND GLOVE BOX LOCK Part No. 1698 229 Consists of: 1 - ---- Cylinder, Deck Lid 2 - ---- Keys 1 - ---- Latch, Glove Box
	CYLINDER AND KEYS PACKAGE, DOOR AND IGNITION LOCK Part No. 1698 668 Consists of: 1 - ---- Cylinder, Door, Right 1 - ---- Cylinder, Door, Left 1 - ---- Cylinder, Ignition 2 - ---- Keys		CYLINDER AND KEYS PACKAGE, DECK LID AND GLOVE BOX LOCK Part No. 1698 586 Consists of: 1 - ---- Cylinder, Deck Lid 2 - ---- Keys 1 - ---- Latch, Glove Box
	CYLINDER AND KEYS PACKAGE, DOOR AND IGNITION LOCK Part No. 1698 986 Consists of: 1 - ---- Cylinder, Door, Right 1 - ---- Cylinder, Door, Left 1 - ---- Cylinder, Ignition 2 - ---- Keys	23-17-5	CYLINDER AND KEYS PACKAGE, DECK LID LOCK . . . Part No. 1455 721 Consists of: 1 - ---- Cylinder 2 - ---- Keys
	CYLINDER AND KEYS PACKAGE, DOOR, IGNITION AND ELECTRIC TAILGATE WINDOW LEFT LOCK Part No. E1838 985 Consists of: 1 - ---- Cylinder, Door, Right (Pkg. Cont'd)		CYLINDER AND KEYS PACKAGE, DECK LID LOCK Part No. 1520 635 Consists of: 1 - ---- Cylinder 2 - ---- Keys
			CYLINDER AND KEYS PACKAGE, DECK LID LOCK . . . Part No. 1698 992 Consists of: 1 - ---- Cylinder 2 - ---- Keys

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	CYLINDER AND KEYS PACKAGE, DECK LID LOCK Part No. B1830 769 Consists of: 1 - - - - - Cylinder 2 - - - - - Keys	23-17-45	CYLINDER AND KEYS PACKAGE, TAILGATE AND GLOVE BOX LOCK . . . Part No. 1520 364 Consists of: 1 - - - - - Cylinder, Tailgate 2 - - - - - Keys 1 - - - - - Latch, Glove Box
23-17-24	CYLINDER AND KEYS PACKAGE, DOOR LOCK Part No. 1315 510 Consists of: 2 - - - - - Cylinders 2 - - - - - Keys		CYLINDER AND KEYS PACKAGE, TAILGATE AND GLOVE BOX LOCK Part No. 1623 564 Consists of: 1 - - - - - Cylinder, Tailgate 2 - - - - - Keys 1 - - - - - Latch, Glove Box
	CYLINDER AND KEYS PACKAGE, DOOR LOCK Part No. 1649 537 Consists of: 2 - - - - - Cylinders 2 - - - - - Keys	23-17-49	CYLINDER and KEYS PACKAGE, TAILGATE LOCK . . . Part No. 1332 807 Consists of: 1 - - - - - Cylinder 2 - - - - - Keys
	CYLINDER AND KEYS PACKAGE, DOOR LOCK, RIGHT. . . Part No. 1685 062 Consists of: 1 - - - - - Cylinder 2 - - - - - Keys		CYLINDER AND KEYS PACKAGE, TAILGATE LOCK . . . Part No. 1520 450 Consists of: 1 - - - - - Cylinder 2 - - - - - Keys
	CYLINDER AND KEYS PACKAGE, DOOR LOCK, LEFT. . . Part No. 1685 063 Consists of: 1 - - - - - Cylinder 2 - - - - - Keys		CYLINDER AND KEYS PACKAGE, TAILGATE LOCK . . . Part No. 1819 404 Consists of: 1 - - - - - Cylinder 2 - - - - - Keys
	CYLINDER AND KEYS PACKAGE, DOOR LOCK, RIGHT. . . Part No. 1698 988 Consists of: 1 - - - - - Cylinder 2 - - - - - Keys		CYLINDER AND KEYS PACKAGE, TAILGATE LOCK . . . Part No. 1830 041 Consists of: 1 - - - - - Cylinder 2 - - - - - Keys
	CYLINDER AND KEYS PACKAGE, DOOR LOCK, LEFT . . Part No. 1698 989 Consists of: 1 - - - - - Cylinder 2 - - - - - Keys	23-17-59	CYLINDER AND KEYS PACKAGE, DECK LID, REAR DOOR AND GLOVE BOX LOCK . . . Part No. 1649 531 Consists of: 1 - - - - - Cylinder, Deck Lid 2 - - - - - Cylinder, Rear Door 2 - - - - - Keys 1 - - - - - Latch, Glove Box
	CYLINDER AND KEYS PACKAGE, DOOR LOCK, RIGHT . . Part No. 1698 990 Consists of: 1 - - - - - Cylinder 2 - - - - - Keys		CYLINDER AND KEYS PACKAGE, DECK LID, REAR DOOR AND GLOVE BOX LOCK . . Part No. 1649 585 Consists of: 1 - - - - - Cylinder, Deck Lid 2 - - - - - Cylinder, Rear Door 2 - - - - - Keys 1 - - - - - Latch, Glove Box
	CYLINDER AND KEYS PACKAGE, DOOR LOCK, LEFT. . . Part No. 1698 991 Consists of: 1 - - - - - Cylinder 2 - - - - - Keys	23-17-72	CYLINDER AND KEYS PACKAGE, TIRE WELL COVER LOCK Part No. 1830 044 Consists of: 1 - - - - - Cylinder 2 - - - - - Keys
	CYLINDER AND KEYS PACKAGE, DOOR LOCK, RIGHT . . Part No. 1772 432 Consists of: 1 - - - - - Cylinder 2 - - - - - Keys		
	CYLINDER AND KEYS PACKAGE, DOOR LOCK, LEFT . . . Part No. 1772 433 Consists of: 1 - - - - - Cylinder 2 - - - - - Keys		

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.
 Prices and specifications subject to change without notice.

1955-58 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
23-18-120	TERMINAL AND INSULATOR PACKAGE, ELECTRIC DOOR LOCK SOLENOID Part No. 1843 226 Consists of: 10 - ---- --- Insulators 10 - ---- --- Terminals, Female 10 - ---- --- Terminals, Male	23-67-164	SWITCH CONTACT, END PLATE and GASKET PACKAGE, WINDSHIELD WIPER MOTOR, FOR SINGLE SPEED AUTO LITE MOTORS Part No. E1879 602 Consists of: 1 - 1605 572 Gasket 1 - 1818 890 Contact and Plate
23-21-3	MIRROR PACKAGE, REAR VIEW OUTSIDE, RIGHT Part No. 1692 714 Consists of: 1 - 1656 049 Block 1 - ---- --- Mirror 2 - ---- --- Screws MIRROR PACKAGE, REAR VIEW OUTSIDE, LEFT Part No. 1692 715 Consists of: 1 - 1656 049 Block 1 - ---- --- Mirror 2 - ---- --- Screws	24-24-15	INSULATOR PACKAGE, TEMPERATURE CONTROL RESISTOR Part No. E1843 412 Consists of: 1 - ---- --- Insulator 1 - ---- --- Nut, Insulator Mounting 2 - ---- --- Screw, Insulator Mounting 2 - ---- --- Washer, Insulator Mounting 2 - ---- --- Washer, Insulator Mounting 2 - ---- --- Washer, Temperature Control
23-34-261	HINGE AND SPRING PACKAGE, QUARTER PANEL FUEL TANK OPENING COVER. . . . Part No. 1879 538 Consists of: 1 - ---- --- Assembly, Hinge 1 - 1707 504 Spring	24-25-17	CLUTCH PACKAGE, COMPRESSOR 6 VOLT Part No. 1604 981 Consists of: 1 - 1616 839 Bracket, Motor Brush 1 - ---- --- Clutch, Compressor Drive 1 - 1632 487 Screw, Mounting 1 - ---- --- Washer
23-47-414	COIL PACKAGE, ELECTRIC SEAT ADJUSTER SOLENOID . . . Part No. 1830 290 Consists of: 1 - ---- --- Cap 1 - ---- --- Coil 1 - ---- --- Cover	24-25-93	CLUTCH PACKAGE, COMPRESSOR Part No. 1658 651 Consists of: 1 - ---- --- Clutch 1 - ---- --- Pulley, Bearing and Hub
23-58-381	ROTOR PACKAGE, FOLDING TOP LIFT PUMP Part No. 1641 650 Consists of: 1 - ---- --- Rotor, Inner 1 - ---- --- Rotor, Outer		PLATE PACKAGE, COMPRESSOR HEAD VALVE. Part No. 1631 269 Consists of: 1 - ---- --- Gasket, Cylinder Head 1 - ---- --- Gasket, Crankcase 1 - ---- --- Plate, Valve 2 - ---- --- Valve, Suction
23-67-10	GEAR AND GASKET PACKAGE, WINDSHIELD WIPER MOTOR FOR SINGLE OR TWO SPEED AUTO LITE MOTORS . . Part No. E1879 601 Consists of: 1 - 1605 572 Gasket 1 - 1594 973 Gear		PLATE PACKAGE, COMPRESSOR HEAD VALVE Part No. 1631 607 Consists of: 1 - 1377 904 Gasket, Cylinder Head 1 - 1378 313 Gasket, Crankcase 2 - ---- --- Pad, Suction Valve 1 - ---- --- Plate, Valve 2 - ---- --- Valve, Suction
	GEAR AND GASKET PACKAGE, WINDSHIELD WIPER MOTOR, FOR VARIABLE SPEED MOTORS Part No. E1879 598 Consists of: 1 - 1752 513 Gasket 1 - 1818 685 Gear		

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

Printed in U.S.A.

Prices and specifications subject to change without notice.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	PLATE PACKAGE, COMPRESSOR HEAD VALVE Part No. 1631 269 Consists of: 1 - ---- --- Gasket, Valve Plate 1 - ---- --- Gasket, Crankcase 1 - ---- --- Plate, Valve 2 - ---- --- Valve, Suction	(Cont'd)	1 - 1377 825 Gasket, Oil Sump 1 - 1378 081 Gasket, Suction Service Valve 1 - 1378 245 Gasket, Suction Screen 1 - ---- --- Plug, Oil Pressure 1 - 1378 318 Spring, Valve
24-25-109	VALVE PACKAGE, COMPRESSOR SHUT- OFF Part No. 1631 273 Consists of: 1 - 1631 294 Gasket, Valve 1 - ---- --- Valve, Suction Shut-Off	24-26-20	RECEIVER DRIER PACKAGE Part No. 1880 658 Consists of: 1 - ---- --- Gasket, Receiver Drier 1 - ---- --- Receiver, Drier
	VALVE PACKAGE, COMPRESSOR SHUT- OFF Part No. 1631 610 Consists of: 1 - ---- --- Gasket, Valve 1 - ---- --- Valve, Shut-Off	24-28-163	BRUSH PACKAGE, BLOWER MOTOR Part No. 1571 050 Consists of: 2 - ---- --- Brush 1 - 1571 033 Spring
	VALVE PACKAGE, COMPRESSOR SUCTION Part No. 1676 761 Consists of: 1 - 1631 294 Gasket, Valve 1 - ---- --- Valve, Suction		BRUSH PACKAGE, BLOWER MOTOR Part No. 1627 011 Consists of: 2 - ---- --- Brush 2 - ---- --- Spring
24-25-249	BALL PACKAGE, RELIEF VALVE Part No. E1843 474 Consists of: 1 - ---- --- Ball, Relief Valve 1 - 1731 531 Gasket, Discharge Service Valve (Pkg. Cont'd)	24-28-322	INDICATOR PACKAGE, LIQUID Part No. 1880 657 Consists of: 1 - ---- --- Indicator, w/Cap 1 - ---- --- Gasket

NOTES
