

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
------	---------------------------	------	---------------------------

PARTS PACKAGES

- 1-02-1 COVER PACKAGE,
DECK LID TIRE Part No.*1881 824
Consists of:
1 - 1954 501 Insert
1 - 1954 507 Medallion
2 - ---- --- Nut
2 - 6010 007 Nut and Washer
1 - 1954 500 Panel
1 - 1963 410 Welt
- 1-04-1 DIMMER PACKAGE, AUTOMATIC
HEADLAMP Part No. 1881 763
Consists of:
1 - ---- --- Base, Scanner
3 - 1843 226 Insulator
1 - ---- --- Nut
1 - ---- --- Scanner
2 - 145 136 Screw, Control Unit Mounting
2 - 164 359 Screw, Scanner Base
Mounting
1 - ---- --- Screw, Scanner Mounting
2 - 1971 162 Spacer
2 - ---- --- Spacer
2 - ---- --- Spacer
3 - 1971 165 Terminal, Control Unit
1 - 1971 160 Unit, Control
- 1-04-16 TERMINAL and INSULATOR
PACKAGE, AUTOMATIC
HEADLAMP DIMMER. . Part No. 1843 226
Consists of:
10 - ---- --- Insulator
10 - ---- --- Terminal, Female
10 - ---- --- Terminal, Male
TERMINAL and INSULATOR
PACKAGE, AUTOMATIC
HEADLAMP DIMMER. . Part No. 1843 227
Consists of:
10 - 1843 227 Insulator
10 - ---- --- Terminal, Female
- 1-06-1 LIGHT PACKAGE, EMERGENCY
FLASHING WARNING. . Part No.E2084 277
Consists of:
1 - ---- --- Cable
1 - ---- --- Cable
1 - 1972 138 Flasher
1 - 1972 137 Knob
1 - 1972 136 Switch
1 - ---- --- Wiring
LIGHT PACKAGE, EMERGENCY
FLASHING WARNING. . Part No.E2084 278
Consists of:
1 - ---- --- Adapter
1 - ---- --- Cable
1 - ---- --- Cable
1 - 1972 138 Flasher
1 - 1972 137 Knob
1 - 1972 136 Switch
1 - ---- --- Wiring
- 1-09-1 LAMP PACKAGE, HAND
BRAKE SIGNAL. Part No. 1886 822
Consists of:
1 - ---- --- Bracket
1 - 142 453 Bulb
1 - ---- --- Lamp

(Pkg. Cont'd)

- Cont'd
1 - ---- --- Nut, Lamp Mounting
1 - ---- --- Nut, Switch Bracket Mounting
1 - 120 376 Nut, Switch Mounting
1 - 431 942 Screw
1 - 1838 957 Switch
1 - ---- --- Socket, w/Cables
1 - 1843 227 Terminal
1 - ---- --- Washer, Lock
- 1-10-1 LAMP PACKAGE,
BACK-UP Part No. 1887 605
Consists of:
2 - 151 576 Bulb
1 - 1302 807 Gasket
2 - ---- --- Socket, w/Grommet
1 - 1343 998 Switch
1 - ---- --- Wiring
LAMP PACKAGE,
BACK-UP Part No. 1887 606
Consists of:
1 - 1676 629 Actuator
2 - 151 576 Bulb
2 - ---- --- Rivet
2 - ---- --- Socket, w/Grommet
1 - ---- --- Switch, w/Cables
LAMP PACKAGE,
BACK-UP Part No. 1887 607
Consists of:
2 - 151 576 Bulb
1 - 1302 807 Gasket
2 - ---- --- Socket, w/Cable
1 - 1343 998 Switch
1 - ---- --- Wiring
LAMP PACKAGE,
BACK-UP Part No. 1887 608
Consists of:
1 - 1676 629 Actuator
2 - 151 576 Bulb
2 - ---- --- Rivet
2 - ---- --- Socket, w/Cable
1 - 1887 346 Switch, w/Cables
LAMP PACKAGE,
BACK-UP Part No. 1887 610
Consists of:
1 - 1676 629 Actuator
2 - 151 576 Bulb
2 - ---- --- Rivet
2 - 1841 697 Socket
1 - 1887 346 Switch, w/Cables
LAMP PACKAGE,
BACK-UP Part No. 1887 611
Consists of:
2 - 151 576 Bulb
1 - 1302 807 Gasket
2 - 1842 209 Socket
1 - 1343 998 Switch
1 - ---- --- Wiring
LAMP PACKAGE,
BACK-UP Part No. 1887 612
Consists of:
1 - 1676 629 Actuator
2 - 151 576 Bulb
2 - ---- --- Rivet
2 - 1842 209 Socket
1 - ---- --- Switch, w/Cables

★ Indicates use as required.
 □ Indicates parts not listed in any previous parts book.
 * Indicates change or addition.

1959 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
1-12-1	LIGHTER PACKAGE, CIGAR Part No. 1886 701 Consists of: 1 - ---- --- Knob, w/Heat Element 1 - 1752 403 Shell, w/Clamp 1 - 1770 756 Socket, w/Wire 1 - ---- --- Switch, to Cigar Lighter Fuel Cable		CLOCK PACKAGE, INSTRUMENT PANEL Part No. 1886 885 Consists of: 1 - 152 240 Bulb 1 - ---- --- Clock
1-13-1	LAMP PACKAGE, UNDERHOOD Part No. 1880 255 Consists of: 1 - ---- --- Bracket 1 - 151 578 Bulb 2 - ---- --- Screw 1 - ---- --- Socket, w/Cables 1 - ---- --- Switch, w/Bracket 1 - ---- --- Washer	1-30-1	LAMP PACKAGE, TRUNK COMPARTMENT Part No. 1779 409 Consists of: 1 - ---- --- Bracket, w/Socket and Wire 1 - 151 578 Bulb 1 - 166 617 Screw 1 - 1571 542 Switch
1-14-4	LAMP PACKAGE, MAP . Part No. 1886 894 Consists of: 1 - 142 453 Bulb 1 - ---- --- Housing 1 - 1838 155 Lens 1 - ---- --- Socket, w/Cable LAMP PACKAGE, MAP AND COURTESY Part No. 1887 008 Consists of: 1 - 151 578 Bulb 2 - 132 688 Screw 1 - ---- --- Socket, w/Cable 1 - ---- --- Switch	1-48-21	CONTROL PACKAGE, HEATER Part No. 1887 242 Consists of: 1 - ---- --- Clip, Hose 1 - ---- --- Control 1 - 1779 259 Elbow, Hose Return 1 - 1880 556 Housing, Cable 1 - ---- --- Knob, w/Mounting Clip 1 - 1779 257 Nipple, Hose Return 1 - 1971 061 Nipple, Hose Inlet 1 - ---- --- Plate, Face 2 - ---- --- Nut, Face Plate Mounting Speed 1 - ---- --- Stop, P/Button Extension Light 2 - ---- --- Tube, Defroster
1-14-40	LAMP PACKAGE, COURTESY Part No. 1842 277 Consists of: 2 - ---- --- Bracket 2 - 142 453 Bulb 2 - 120 376 Nut 1 - ---- --- Socket, w/Wires 2 - 1571 542 Switch		CONTROL PACKAGE, HEATER Part No. 1887 243 Consists of: 1 - ---- --- Cable, w/Housing 1 - ---- --- Clip, Hose 1 - 1880 328 Control 1 - 1779 259 Elbow, Hose Return 1 - ---- --- Knob, w/Set Screw 1 - 1779 257 Nipple, Hose Return 2 - ---- --- Tube, Defroster
1-19-1	LIGHT PACKAGE, GLOVE COMPARTMENT Part No. 1648 614 Consists of: 1 - 131 282 Bulb 1 - ---- --- Socket, w/Switch and Wire LIGHT PACKAGE, GLOVE COMPARTMENT Part No. 1886 298 Consists of: 1 - 127 934 Bulb 1 - ---- --- Socket, w/Switch		CONTROL PACKAGE, HEATER Part No. 1887 244 Consists of: 1 - 1880 348 Bezel, w/Studs 1 - ---- --- Cable, w/Housing 1 - ---- --- Clip, Hose 1 - 1880 314 Control 1 - 1841 948 Knob, w/Set Screw 1 - 1779 257 Nipple, Hose Return 1 - ---- --- Sleeve, Arm 2 - ---- --- Tube, Defroster
1-21-1	CLOCK PACKAGE, INSTRUMENT PANEL Part No. 1886 882 Consists of: 1 - 152 240 Bulb 1 - ---- --- Clock 1 - ---- --- Lamp, w/Cable 2 - ---- --- Nut, w/Washer 1 - 162 462 Screw 2 - ---- --- Washer CLOCK PACKAGE, INSTRUMENT PANEL Part No. 1886 883 Consists of: 1 - ---- --- Clock 1 - ---- --- Nut 1 - ---- --- Wiring CLOCK PACKAGE, INSTRUMENT PANEL Part No. 1886 884 Consists of: 1 - 152 240 Bulb 1 - ---- --- Clock 1 - ---- --- Wiring		CONTROL PACKAGE, HEATER Part No. 1887 245 Consists of: 1 - 1880 285 Bezel, w/Studs 1 - ---- --- Cable, w/Housing 1 - ---- --- Clip, Hose 1 - 1880 271 Control 1 - 106 653 Fuse, Wiring 1 - 1841 950 Knob, w/Set Screw 1 - 1779 257 Nipple, Hose Return 1 - ---- --- Sleeve, Arm 2 - ---- --- Tube, Defroster

★ Indicates use as required.

⊠ Indicates parts not listed in any previous parts book.

May 25, 1959 Supersedes Oct. 27, 1958.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
1-48-137	DEFROSTER PACKAGE, REAR SHELF PANEL. . . Part No. 1887 398 Consists of: 1 - 1819 014 Bezel, Inlet 1 - ----- Blower 1 - ----- Cable, Switch Feed 1 - 1819 018 Grille, Inlet 1 - ----- Grille 1 - ----- Housing, w/Nozzle 2 - ----- Lockwasher, Housing Mounting to Grille 4 - ----- Lockwasher, Blower Plate Mounting 2 - ----- Nut, Housing Mounting to Grille 4 - ----- Nut, Blower Plate Mounting 1 - ----- Plate, Mounting 3 - 162 906 Screw, Mounting 1 - 1779 862 Switch, w/Mounting Nut 1 - ----- Switch, to Motor Cable 1 - ----- Tube	Cont'd	4 - - - - - Nut, Speaker Mounting 1 - - - - - Nut, Fader Switch Mounting 1 - - - - - Speaker, to Fader Switch Cable 1 - - - - - Speaker, Front Radio Speaker to Fader Switch Cable 1 - - - - - Speaker 1 - 1819 889 Switch, Fader
1-82-2	WASHER PACKAGE, WINDSHIELD Part No. 1887 356 Consists of: 1 - - - - - Bracket, Reservoir Mounting, Center 1 - - - - - Bracket, Reservoir Mounting, Front 1 - - - - - Bracket, Reservoir Mounting, Rear 1 - 1838 001 Cap, Reservoir 1 - - - - - Clip, Check Valve Mounting 1 - 1887 477 Hose, Check Valve to Pump 1 - 1887 477 Hose, Check Valve to Strainer 1 - - - - - Hose, Check Valve to Tee 1 - - - - - Hose, Tee to Left Nozzle 1 - - - - - Hose, Tee to Right Nozzle 2 - - - - - Nozzle 1 - - - - - Nut, Foot Control Pump Mounting 2 - - - - - Nut, Nozzle Mounting 1 - 1887 148 Pump, Foot Control 1 - 1841 957 Reservoir 1 - 444 267 Screw, Check Valve Mounting 1 - 1571 028 Strainer 1 - 1523 160 Tee 1 - 1880 222 Valve, Check 1 - 138 557 Washer, Foot Control Pump Mounting Lock 2 - - - - - Washer, Nozzle Mounting Lock	1-88-1	ANTENNA PACKAGE, RADIO Part No. 1769 436 Consists of: 1 - 1769 443 Adapter, Lower 1 - 1769 444 Adapter, Upper 1 - - - - - Body, w/Mast 1 - - - - - Collar, Grounding 1 - - - - - Cover, Fender Shield Hole 1 - - - - - Cover, Fender Shield Hole 1 - - - - - Gasket, Upper Adapter 1 - 1658 328 Nut, Antenna Mounting 1 - 1658 332 Nut, Cap, w/Grommet 1 - 145 415 Screw, Cover
1-87-2	RADIO SPEAKER PACKAGE, REAR SHELF Part No. 1819 766 Consists of: 1 - 1819 014 Bezel 1 - 1971 091 Grille 4 - 271 498 Nut 1 - - - - - Speaker 1 - 1769 430 Wiring RADIO SPEAKER PACKAGE, REAR SHELF Part No. 1887 938 Consists of: 1 - 1819 014 Bezel 1 - 1971 091 Grille 1 - 1689 693 Knob, Fader Switch		ANTENNA PACKAGE, RADIO Part No. 1779 068 Consists of: 1 - 1838 163 Body, w/Mast, Left 1 - 1838 162 Body, w/Mast, Right 4 - 639 853 Clip, Wiring 1 - 1779 072 Connector, "Y", w/Lead-In Wire 2 - 1841 057 Gasket, Mounting 4 - 271 169 Nut, w/Washer 4 - - - - - Washer, Cup ANTENNA PACKAGE, RADIO Part No. 1779 629 Consists of: 1 - - - - - Adapter, Lower 1 - - - - - Adapter, Upper 1 - - - - - Body, w/Mast and Shield 1 - - - - - Brace 1 - - - - - Collar, Grounding 1 - 1779 072 Connector, "Y", w/Lead-In Wire 1 - - - - - Gasket, Upper Adapter 1 - 1658 332 Nut, Cap, w/Grommet 1 - 1658 328 Nut, Hex. 1 - 180 018 Screw, Brace to Floor Pan ANTENNA PACKAGE, RADIO Part No. 1886 703 Consists of: 1 - 1886 710 Adapter, Lower Left 1 - 1886 709 Adapter, Lower Right 1 - 1886 717 Adapter, Upper Left 1 - 1886 716 Adapter, Upper Right 1 - 1886 713 Body, w/Mast, Left 1 - - - - - Body, w/Mast, Right 4 - 639 853 Clip, Lead Wire 2 - - - - - Collar, Grounding 1 - 1779 072 Connector, "Y", w/Lead-In Wire 2 - 1971 383 Gasket, Antenna Mounting 2 - - - - - Gasket, Upper Adapter 2 - 1886 705 Nut, Dome

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.
 * Indicates exchange or addition.

1959 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	ANTENNA PACKAGE, RADIO Part No. 1887 065 Consists of: 1 - ---- --- Adapter, Lower 1 - ---- --- Adapter, Upper 1 - 1887 124 Antenna 1 - ---- --- Cable, Switch Feed 1 - ---- --- Collar, Grounding 1 - 1779 072 Connector, "Y", w/Lead-In Wire 1 - ---- --- Gasket, Upper Adapter 1 - ---- --- Grommet 1 - ---- --- Lead, Switch to Motor 1 - ---- --- Nut, Dome 1 - ---- --- Nut, Lock 1 - 6006 121 Screw, Strap 1 - ---- --- Strap 1 - 1779 863 Switch 1 - 120 392 Washer		SPOTLIGHT PACKAGE . Part No. 1886 136 Consists of: 1 - ---- --- Bushing 1 - ---- --- Clamp, Cable Mounting 1 - ---- --- Clip, Conduit Mounting 1 - ---- --- Collar 1 - ---- --- Conduit 1 - ---- --- Grommet 1 - ---- --- Screw, Bracket Clamping 3 - 107 261 Screw, Bracket Mounting 1 - 125 978 Screw, Conduit Mounting Clip 1 - ---- --- Spacer 1 - ---- --- Spotlight
	ANTENNA PACKAGE, RADIO Part No. 1887 120 Consists of: 1 - 1769 443 Adapter, Lower 1 - 1769 444 Adapter, Upper 1 - 1887 059 Antenna 1 - ---- --- Cable, Circuit Breaker to Switch 1 - ---- --- Collar, Grounding 1 - ---- --- Cover, Shield Hole 1 - ---- --- Gasket, Upper Adapter 1 - ---- --- Grommet 1 - ---- --- Nut, Dome 1 - ---- --- Nut, Lock 1 - 120 375 Nut, Strap Mounting 2 - 145 415 Screw, Cover 1 - 180 016 Screw, Strap, w/Washer 1 - ---- --- Strap 1 - ---- --- Strap 1 - 1879 863 Switch 1 - 121 753 Washer, Lock 1 - 120 392 Washer, Plain		SPOTLIGHT PACKAGE . Part No. 1971 045 Consists of: 1 - ---- --- Bushing 1 - ---- --- Clamp, Cable Mounting 1 - ---- --- Collar 1 - ---- --- Grommet 1 - ---- --- Screw, Bracket Clamping 3 - 107 261 Screw, Bracket Mounting 1 - ---- --- Spacer 1 - ---- --- Spotlight
	1-88-51 COVER PACKAGE, MOTOR DRIVEN RADIO ANTENNA SHIELD HOLE Part No. 1838 090 Consists of: 1 - ---- --- Cover		SPOTLIGHT PACKAGE . Part No. 1971 047 Consists of: 1 - ---- --- Bushing 1 - ---- --- Clamp, Cable Mounting 1 - ---- --- Collar 1 - ---- --- Grommet 1 - ---- --- Screw, Bracket Clamping 3 - 107 261 Screw, Bracket Mounting 1 - ---- --- Spacer 1 - ---- --- Spotlight
	1-88-180 SHIELD PACKAGE, RADIO ANTENNA Part No. 1688 944 Consists of: 3 - 122 159 Screw 1 - ---- --- Shield	1-108-2	BRACKET and GASKET PACKAGE, SPOTLIGHT MOUNTING . Part No. 1818 917 Consists of: 1 - ---- --- Bracket 1 - ---- --- Gasket
	1-108-1 SPOTLIGHT PACKAGE . Part No. 1818 916 Consists of: 1 - ---- --- Bushing 1 - ---- --- Clamp, Cable Mounting 1 - ---- --- Clip, Conduit Mounting 1 - ---- --- Collar 1 - ---- --- Conduit 1 - ---- --- Grommet 1 - ---- --- Screw, Bracket Clamping 3 - 107 261 Screw, Bracket Mounting 1 - 125 978 Screw, Conduit Mounting Clip 1 - ---- --- Spacer 1 - ---- --- Spotlight		BRACKET and GASKET PACKAGE, SPOTLIGHT MOUNTING . Part No. 1818 918 Consists of: 1 - ---- --- Bracket 1 - ---- --- Gasket
		2-07-1	END PACKAGE, TIE ROD OUTER Part No. 1692 688 Consists of: 1 - ---- --- Bolt, Tie Rod End Clamp 1 - ---- --- Clamp, Tie Rod End 1 - ---- --- End, Tie Rod Outer 1 - ---- --- Nipple, Lubricant 1 - ---- --- Nut, Tie Rod End 1 - ---- --- Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter 1 - 1673 045 Seal, Tie Rod End Dust
			END PACKAGE, TIE ROD OUTER Part No. 1818 998 Consists of: 1 - ---- --- Bolt, Tie Rod End Clamp 1 - ---- --- Clamp, Tie Rod End 1 - ---- --- End, Tie Rod Outer 1 - ---- --- Nipple, Lubricant 1 - ---- --- Nut, Tie Rod End 1 - ---- --- Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter 1 - 1735 470 Seal, Tie Rod End Dust

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.
 May 25, 1959 Supersedes Oct. 27, 1958.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	END PACKAGE, TIE ROD INNER Part No. 1818 999 Consists of: 1 - ---- Bolt, Tie Rod End Clamp 1 - ---- Clamp, Tie Rod End 1 - ---- End, Tie Rod Inner 1 - ---- Nipple, Lubricant 1 - ---- Nut, Tie Rod End 1 - ---- Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter 1 - 1735 470 Seal, Tie Rod End Dust	2-10-55	BALL JOINT PACKAGE, FRONT SUSPENSION LOWER . . Part No. 1843 247 Consists of: 1 - ---- Ball Joint, Assembly 1 - 128 027 Nut, Ball Joint Stud 1 - ---- Pin, Ball Joint Stud Nut Cotter 1 - 1825 009 Seal, Ball Joint 1 - 1672 960 Washer, Ball Joint Stud Nut
	END PACKAGE, TIE ROD INNER Part No. 1881 820 Consists of: 1 - ---- Bolt, Tie Rod End Clamp 1 - ---- Clamp, Tie Rod End 1 - ---- End, Tie Rod Inner 1 - ---- Nipple, Lubricant 1 - ---- Nut, Tie Rod End 1 - ---- Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter 1 - 1673 045 Seal, Tie Rod End Dust		BALL JOINT PACKAGE, FRONT SUSPENSION LOWER . . Part No. 1843 248 Consists of: 1 - ---- Ball Joint, Assembly 1 - 1671 405 Nut, Ball Joint Stud 1 - 119 209 Pin, Ball Joint Stud Nut Cotter 1 - 1825 303 Seal, Ball Joint 1 - 1672 961 Washer, Ball Joint Stud Nut
	END PACKAGE, TIE ROD INNER Part No. 1881 821 Consists of: 1 - ---- Bolt, Tie Rod End Clamp 1 - ---- Clamp, Tie Rod End 1 - ---- End, Tie Rod Inner 1 - ---- Nipple, Lubricant 1 - ---- Nut, Tie Rod End 1 - ---- Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter 1 - 1673 045 Seal, Tie Rod End Dust	2-10-57	BUSHING and RETAINER PACKAGE, SUSPENSION LOWER CONTROL ARM STRUT FRONT Part No. *2084 045 Consists of: 1 - 1734 321 Bushing, Control Arm Strut 1 - 1825 432 Nut, Control Arm Strut Bushing 2 - 1734 341 Retainer, Control Arm Strut
2-08-57	BALL JOINT PACKAGE, Front SUSPENSION UPPER . . Part No. 1843 245 Consists of: 1 - ---- Ball Joint, Assembly 1 - 128 025 Nut, Ball Joint Stud 1 - ---- Pin, Ball Joint Stud Nut Cotter 1 - ---- Retainer, Ball Joint Outer Seat 1 - 1731 435 Seal, Ball Joint Inner 1 - ---- Seal, Ball Joint Outer 1 - 1672 960 Washer, Ball Joint Stud Nut		BUSHING and RETAINER PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM STRUT FRONT . . Part No. *2084 214 Consists of: 1 - ---- Bushing, Control Arm Strut 1 - 1825 432 Nut, Control Arm Strut Bushing 2 - 1734 341 Retainer, Control Arm Strut
	BALL JOINT PACKAGE, FRONT SUSPENSION UPPER . . Part No. 1843 246 Consists of: 1 - ---- Ball Joint, Assembly 1 - 128 027 Nut, Ball Joint Stud 1 - ---- Pin, Ball Joint Stud Nut Cotter 1 - 1734 267 Retainer, Ball Joint Outer Seat 1 - 1731 264 Seal, Ball Joint Inner 1 - 1734 266 Seal, Ball Joint Outer 1 - 1672 960 Washer, Ball Joint Stud Nut	2-10-61	SHAFT and BUSHING PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM Part No. 1881 647 Consists of: 1 - 1636 010 Bushing, Shaft 1 - ---- Nut, Bushing 1 - 128 213 Nut, Shaft 1 - 137 214 Pin, Arm 1 - 119 209 Pin, Bushing Nut Cotter 1 - ---- Shaft, Arm 1 - ---- Washer, Bushing 1 - ---- Washer, Shaft Nut
2-08-59	BRACKET, CAM and BUSHING PACKAGE, FRONT SUSPENSION UPPER CONTROL ARM SUPPORT Part No. 1881 652 Consists of: 2 - ---- Bracket, Cam, Assembly 2 - 1825 317 Bushing, Arm 2 - ---- Cam, Bracket - Slotted 2 - ---- Washer, Bracket Cam Lock 2 - 1825 449 Nut, Bracket Cam		SHAFT and BUSHING PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM Part No. 1881 650 Consists of: 1 - 1636 017 Bushing, Shaft 1 - ---- Nut, Bushing 1 - ---- Nut, Shaft 1 - ---- Pin, Arm 1 - 119 209 Pin, Bushing 1 - ---- Shaft Arm 1 - 1636 019 Washer, Bushing 1 - ---- Washer, Shaft Nut
		2-14-1	BOLT AND SWIVEL PACKAGE, FRONT SUSPENSION TORSION BAR OR SPRING REAR END ANCHOR ADJUSTING Part No. B2196 770 Consists of: 1 - ---- Bolt, Torsion Bar Anchor 1 - ---- Swivel, Torsion Bar Anchor

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

1959 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	BOLT and SWIVEL PACKAGE, FRONT SUSPENSION TORSION BAR OR SPRING REAR END ANCHOR ADJUSTING Part No. E2196 771 Consists of: 1 - ---- Bolt, Torsion Bar Anchor 1 - ---- Swivel, Torsion Bar Anchor		ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING REAR END RIGHT Part No. 2084 022 Consists of: 1 - 1825 120 Anchor, End 1 - ---- Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1613 388 Seal, End Anchor 1 - 1735 464 Seat, End Anchor Adjusting Bolt 1 - ---- Swivel, End Anchor Adjusting Bolt
2-14-8	ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING REAR END LEFT Part No. 2084 017 Consists of: 1 - 1825 615 Anchor, End 1 - ---- Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1613 388 Seal, End Anchor 1 - 1735 460 Seat, End Anchor Adjusting Bolt 1 - ---- Swivel, End Anchor Adjusting Bolt	2-14-17	SEAL PACKAGE, FRONT SUSPENSION TORSION BAR OR SPRING REAR END ANCHOR . . Part No. E2196 067 Consists of: 2 - ---- Lock, End Anchor Seal 2 - ---- Seal, End Anchor
	ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING REAR END RIGHT Part No. 2084 018 Consists of: 1 - 1825 614 Anchor, End 1 - ---- Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1613 388 Seal, End Anchor 1 - 1735 460 Seat, End Anchor Adjusting Bolt 1 - ---- Swivel, End Anchor Adjusting Bolt	2-15-4	BUSHING PACKAGE, FRONT SUSPENSION UPPER and LOWER CONTROL ARM Part No. 1881 653 Consists of: 1 - 1636 010 Bushing, Lower 2 - 1825 317 Bushing, Upper
	ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING REAR END LEFT Part No. 2084 019 Consists of: 1 - 1825 615 Anchor, End 1 - ---- Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1613 388 Seal, End Anchor 1 - 1735 464 Seat, End Anchor Adjusting Bolt 1 - ---- Swivel, End Anchor Adjusting Bolt	4-03-5	BUSHING PACKAGE, FRONT SUSPENSION UPPER and LOWER CONTROL ARM Part No. 1881 654 Consists of: 1 - 1636 017 Bushing, Lower 2 - 1825 317 Bushing, Upper
	ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING REAR END RIGHT Part No. 2084 020 Consists of: 1 - 1825 614 Anchor, End 1 - ---- Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1613 388 Seal, End Anchor 1 - 1735 464 Seat, End Anchor Adjusting Bolt 1 - ---- Swivel, End Anchor Adjusting Bolt	5-03-1	LINING PACKAGE, PARKING BRAKE Part No. 1843 178 Consists of: 10' - ---- Lining 78' - ---- Rivets 30' - ---- Rivets
	ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING REAR END LEFT Part No. 2084 021 Consists of: 1 - 1825 614 Anchor, End 1 - ---- Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1613 388 Seal, End Anchor 1 - 1735 464 Seat, End Anchor Adjusting Bolt 1 - ---- Swivel, End Anchor Adjusting Bolt		LINING PACKAGE, WHEEL BRAKE SHOE Part No. 1843 028 Consists of: 8 - ---- Lining
	ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING REAR END LEFT Part No. 2084 022 Consists of: 1 - 1825 121 Anchor, End 1 - ---- Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1613 388 Seal, End Anchor 1 - 1735 464 Seat, End Anchor Adjusting Bolt 1 - ---- Swivel, End Anchor Adjusting Bolt		LINING PACKAGE, WHEEL BRAKE SHOE Part No. 1879 396 Consists of: 8 - ---- Lining
			LINING PACKAGE, WHEEL BRAKE SHOE Part No. 1879 398 Consists of: 4 - ---- Lining 4 - ---- Lining
			LINING PACKAGE, WHEEL BRAKE SHOE Part No. 1879 399 Consists of: 8 - ---- Lining
			LINING PACKAGE, WHEEL BRAKE SHOE Part No. 1879 401 Consists of: 8 - ---- Lining
			LINING PACKAGE, WHEEL BRAKE SHOE Part No. 1879 404 Consists of: 4 - ---- Lining 4 - ---- Lining

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.
 Feb. 15, 1960 Supersedes May 25, 1959.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
5-39-1	SERVICE PACKAGE, MASTER CYLINDER Part No. 1603 235 Consists of: 1 - 1316 628 Boot 1 - ---- --- Cup, Piston 1 - 958 659 Cup, Secondary 1 - 1617 379 Seal, Valve 1 - 1318 446 Valve 1 - 857 443 Washer, Piston Cup	(Cont'd)	1 - 1674 989 "O" Ring, Valve Operat- ing Rod 1 - 1674 991 "O" Ring, Valve Housing to Cover
	SERVICE PACKAGE, MASTER CYLINDER Part No. 1879 303 Consists of: 1 - 1828 388 Boot 1 - ---- --- Cup, Piston 1 - 958 659 Cup, Secondary 1 - 1617 379 Seal, Valve 1 - 1318 446 Valve 1 - 857 443 Washer, Piston Cup		REPAIR PACKAGE, POWER BRAKE Part No. 1940 788 Consists of: 1 - 1940 790 Bearing, Piston Rod 1 - 1675 112 Diaphragm, Valve Applying 1 - 1675 123 Diaphragm, Poppet Valve Seat 1 - 1675 137 Gasket, Inspection Hole Screw 1 - 1675 124 Hose, Vacuum 1 - 1673 620 Retainer, Valve Stem Spring 2 - 1675 104 Ring, Valve Stem Snap 1 - 1940 787 Seal, Piston Rod 1 - 1675 128 Seal, Valve Stem 1 - 1739 853 Seal, Shell 1 - 1675 118 Seat, Poppet Valve, Assy. 1 - 1675 099 Washer, Piston Rod Stop Cushion
	SERVICE PACKAGE, MASTER CYLINDER Part No. 1881 645 Consists of: 1 - 1316 628 Boot 1 - ---- --- Cup, Piston 1 - 958 659 Cup, Secondary 1 - 1316 627 Collar, Boot 1 - 1828 659 Piston 1 - 1617 379 Seal, Valve 1 - 1738 268 Spring, Piston Return 1 - 1554 664 Stop 1 - 1318 446 Valve 1 - 857 443 Washer, Piston Cup	5-100-3	SEAL PACKAGE, POWER BRAKE CYLINDER Part No. 1940 787 Consists of: 1 - 1940 790 Bearing, Piston Rod 1 - ---- --- Seal, Piston Rod
	SERVICE PACKAGE, MASTER CYLINDER Part No. 1881 987 Consists of: 1 - 1828 388 Boot 1 - ---- --- Cup, Piston 1 - 958 659 Cup, Secondary 1 - ---- --- Piston 1 - 1617 379 Seal, Valve 1 - 1318 446 Valve 1 - 857 443 Washer, Piston Cup	5-100-152	PACKING PACKAGE, POWER BRAKE PISTON Part No. 1820 003 Consists of: 1 - 1739 834 Packing, Piston 1 - 1739 835 Ring, Piston Packing 1 - 1675 013 Wick, Piston Packing
5-39-4	COVER PACKAGE, MASTER CYLINDER Part No. 1752 470 Consists of: 1 - 1731 226 Baffle 1 - 1731 225 Cover 1 - 1737 171 Gasket, Cover 1 - 1731 227 Screw, Cover	6-01-3	SET PACKAGE, CLUTCH . Part No. 1818 774 Consists of: 1 - 1730 055 Cover, w/Pressure Plate 1 - 1820 226 Disc, Driving
5-63-1	SERVICE PACKAGE, WHEEL CYLINDER Part No. 1818 639 Consists of: 2 - 1136 872 Boot 2 - 1674 080 Cup, Piston	6-17-3	LEVER PACKAGE, CLUTCH RELEASE Part No. 1879 682 Consists of: 1 - ---- --- Lever, Release 1 - ---- --- Pin, Lever 1 - ---- --- Strut, Lever 1 - ---- --- Spring, Lever 1 - ---- --- Eyebolt, w/Nut
5-63-3	SERVICE PACKAGE, WHEEL CYLINDER PISTON . . Part No. 1818 834 Consists of: 2 - 1136 872 Boot 2 - 1674 080 Cup, Piston 2 - 1674 081 Expander, Piston Cup 2 - 1312 830 Piston 2 - 1614 894 Spring, Piston Return 1 - 1633 106 Spring, Piston Return		LEVER PACKAGE, CLUTCH RELEASE Part No. 1879 652 Consists of: 1 - ---- --- Lever, Release 1 - ---- --- Pin, Lever 1 - ---- --- Strut, Lever 1 - ---- --- Spring, Lever 1 - ---- --- Eyebolt, w/Nut
5-100-1	REPAIR PACKAGE POWER BRAKE Part No. 1675 001 Consists of: 1 - 1674 949 Seal, Air Valve 1 - 1674 949 Seal, Vacuum Valve 1 - 1674 952 Valve, Vacuum 1 - 1674 957 "O" Ring, Housing to Guide 1 - 1674 972 Seal, Bearing to Sleeve 1 - 1674 974 "O" Ring, Bearing to Mounting Plate (Pkg. Cont'd)	7-14-10	CLAMP PACKAGE, RADIATOR HOSE Part No. 1450 499 Consists of: 50 - ---- --- Clamps, Small
		7-42-1	CLAMP PACKAGE, RADIATOR HOSE Part No. 1450 500 Consists of: 50 - ---- --- Clamps, Large
			PUMP PACKAGE, WATER. Part No. 1692 686 Consists of: 1 - 1674 702 Gasket 1 - ---- --- Pump
			PUMP PACKAGE, WATER. Part No. 1752 422 Consists of: 1 - 1676 031 Gasket 1 - ---- --- Pump

★ Indicates use as required.

⊞ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

1959 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	PUMP PACKAGE, WATER. Part No. 1818 610 Consists of: 1 - 1737 705 Gasket 1 - ---- --- Pump		SPRING AND HINGE PACKAGE, DIS- TRIBUTOR CAP CLAMP Part No. 1881 756 Consists of: 2 - ---- --- Spring and Hinge
	PUMP PACKAGE, WATER. Part No. 1879 526 Consists of: 1 - 1737 705 Gasket 1 - ---- --- Pump	8-27-85	CONTACT AND SPRING PACKAGE, DISTRIBUTOR. Part No. 1879 594 Consists of: 1 - 1195 772 Contact 1 - 1308 183 Spring
	PUMP PACKAGE, WATER. Part No. 1879 536 Consists of: 1 - 1737 705 Gasket 1 - ---- --- Pump	8-27-133	BEARING PACKAGE, DISTRIBUTOR DRIVE SHAFT Part No. 1879 596 Consists of: 1 - ---- --- Bearing, Upper 1 - ---- --- Bearing, Lower 1 - 643 904 Collar 1 - 1689 763 Pin 1 - 1195 769 Washer, Upper, Inner 1 - 1195 770 Washer, Upper, Outer 1 - 643 892 Washer, Lower
7-42-4	REPAIR KIT, WATER PUMP Part No. 1752 435 Consists of: 1 - 1618 645 Gasket, Pump Body 1 - 1676 031 Gasket, Pump Body 1 - 1635 783 Impeller 1 - ---- --- Seal 1 - ---- --- Shaft 1 - ---- --- Thrower 1 - 1674 679 Washer		BEARING PACKAGE, DISTRIBUTOR DRIVE SHAFT. Part No. 1881 753 Consists of: 2 - ---- --- Bearing 1 - ---- --- Collar 1 - ---- --- Pin 1 - ---- --- Washer, Inner 1 - ---- --- Washer, Outer 1 - ---- --- Washer, Lower
	REPAIR KIT, WATER PUMP Part No. 1752 622 Consists of: 1 - 1673 782 Gasket, Body 1 - 1671 894 Gasket, Body 1 - 1737 705 Gasket, Mounting 1 - 1859 151 Impeller 1 - ---- --- Seal 1 - ---- --- Shaft 1 - ---- --- Thrower 1 - 1674 679 Washer		BEARING PACKAGE, DISTRIBUTOR DRIVE SHAFT. Part No. 1881 947 Consists of: 1 - ---- --- Collar 2 - ---- --- Bearing, Upper and Lower 1 - 1838 503 Pin, Collar 1 - 1195 769 Washer, Upper, Inner 1 - 1195 770 Washer, Upper, Outer 1 - ---- --- Washer, Lower Thrust
	REPAIR KIT, WATER PUMP Part No. 1843 447 Consists of: 1 - 1671 191 Gasket, Body 1 - 1673 782 Gasket, Body 1 - 1671 894 Gasket, Body 1 - 1737 705 Gasket, Mounting 1 - 1637 724 Impeller 1 - ---- --- Seal 1 - ---- --- Shaft 1 - ---- --- Thrower 1 - 1674 679 Washer	8-27-208	LEAD PACKAGE, DISTRIBUTOR BREAKER and GROUND. Part No. 1881 768 Consists of: 1 - ---- --- Lead, Breaker Arm 1 - ---- --- Lead, Ground
	REPAIR KIT, WATER PUMP Part No. 1879 410 Consists of: 1 - 1674 702 Gasket, Body 1 - 1852 594 Impeller 1 - ---- --- Seal 1 - ---- --- Shaft 1 - ---- --- Thrower 1 - 1674 679 Washer	8-27-218	TERMINAL and MOUNTING PACKAGE DISTRIBUTOR Part No. 1881 751 Consists of: 1 - ---- --- Bushing 1 - ---- --- Insulation 1 - ---- --- Nut 1 - ---- --- Stud 1 - ---- --- Washer, Insulating 1 - ---- --- Washer, Lock 1 - ---- --- Washer, Plain
7-46-1	SEAL PACKAGE, WATER PUMP Part No. 1243 631 Consists of: 1 - 600 811 Lock Ring 1 - ---- --- Seal 1 - 1123 841 Washer, Grease Retaining 1 - 1674 679 Washer, Seal Retaining	8-27-278	WEIGHT PACKAGE, DISTRIBUTOR GOVERNOR Part No. 1879 595 Consists of: 2 - ---- --- Weight WEIGHT PACKAGE, DISTRIBUTOR GOVERNOR Part No. 1881 746 Consists of: 2 - 1271 768 Weight WEIGHT PACKAGE, DISTRIBUTOR GOVERNOR Part No. 1881 945 Consists of: 2 - ---- --- Weight WEIGHT PACKAGE, DISTRIBUTOR GOVERNOR Part No. 1881 955 Consists of: 2 - ---- --- Weight
8-27-77	SPRING and HINGE PACKAGE, DISTRIBUTOR CAP CLAMP Part No. 1879 606 Consists of: 1 - ---- --- Clamp 1 - 1383 948 Spring and Hinge 2 - ---- --- Lockwasher 2 - 121 832 Screw		

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.
 Feb. 15, 1960 Supersedes May 25, 1959.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
8-27-297	FELT and SNAP RING PACKAGE, DISTRIB- UTOR CAM SLEEVE . . Part No. 1879 607 Consists of:		CHAMBER PACKAGE, VACUUM Part No. 1881 950 Consists of:
	1 - 643 899 Felt Disc 1 - 643 893 Snap Ring		1 - ---- Lock Ring 1 - ---- Vacuum Control
8-27-308	CHAMBER PACKAGE, VACUUM, w/ATTACHING PARTS . Part No. 1881 752 Consists of:		CHAMBER PACKAGE, VACUUM. Part No. 1881 954 Consists of:
	1 - 643 901 Lock Ring 1 - 1818 569 Vacuum Chamber		1 - ---- Lock Ring 1 - ---- Vacuum Control
	1 - 218 322 Washer, Plain VACUUM CHAMBER AND ATTACH- ING PARTS PACKAGE, DISTRIBUTOR Part No. 1881 754 Consists of:	8-27-315	PLUG and GASKET PACKAGE, VACUUM CHAMBER . . Part No. 1879 597 Consist of:
	1 - ---- Vacuum Chamber 1 - ---- Ring 1 - ---- Washer, Plain		1 - 1383 641 Gasket 1 - 1345 705 Plug
	VACUUM CHAMBER AND ATTACH- ING PARTS PACKAGE, DISTRIBUTOR Part No. 1881 767 Consists of:	8-27-316	SPRING and WASHER PACKAGE, DISTRIBUTOR VACUUM CHAMBER Part No. 1879 604 Consists of:
	1 - ---- Vacuum Chamber 1 - ---- Ring 2 - ---- Screw 2 - ---- Washer, Lock		1 - ---- Spring 2 - 691 709 Washer .032 3 - 691 708 Washer .010 2 - 691 710 Washer .065
	VACUUM CHAMBER AND ATTACH- ING PARTS PACKAGE, DISTRIBUTOR Part No. 1881 738 Consists of:		SPRING and WASHER PACKAGE, VACUUM CHAMBER . . Part No. 1881 737 Consists of:
	1 - ---- Vacuum Chamber 1 - ---- Ring 2 - ---- Screw 2 - ---- Washer, Lock		1 - 1879 286 Spring 2 - 691 709 Washer .032 2 - 691 708 Washer .010 2 - 691 710 Washer .065
	VACUUM CHAMBER AND ATTACH- ING PARTS PACKAGE, DISTRIBUTOR Part No. 1881 748 Consists of:		SPRING and WASHER PACKAGE, VACUUM CHAMBER . . Part No. 1881 742 Consists of:
	1 - ---- Vacuum Chamber 1 - ---- Ring 2 - ---- Screw 2 - ---- Washer, Lock 1 - ---- Washer, Plain		1 - ---- Spring 2 - 691 709 Washer .032 3 - 691 708 Washer .010 2 - 691 710 Washer .065
	CHAMBER PACKAGE, VACUUM, w/ATTACHING PARTS . Part No. 1881 748 Consists of:		SPRING and WASHER PACKAGE, VACUUM CHAMBER . . Part No. 1881 747 Consists of:
	2 - ---- Lockwasher 1 - 643 901 Lock Ring 2 - 132 096 Screw 1 - ---- Vacuum Chamber 1 - 218 322 Washer, Plain		1 - 1818 572 Spring 2 - 691 709 Washer .032 3 - 691 708 Washer .010 2 - 691 710 Washer .065
	VACUUM CHAMBER and ATTACHING PARTS PACKAGE, DIS- TRIBUTOR Part No. 1881 749 Consists of:		SPRING and WASHER PACKAGE, DISTRIBUTOR VACUUM CHAMBER Part No. 1881 755 Consists of:
	1 - ---- Vacuum Chamber 1 - ---- Ring 1 - ---- Washer, Plain		1 - ---- Spring 2 - ---- Washer .032" thk. 3 - ---- Washer .010" thk. 2 - ---- Washer .065" thk.
	CHAMBER PACKAGE, VACUUM, w/ATTACHING PARTS . Part No. 1881 929 Consists of:		SPRING and WASHER PACKAGE, DISTRIBUTOR VACUUM CHAMBER Part No. 1881 766 Consists of:
	2 - ---- Lockwasher 1 - 643 901 Lock Ring 2 - 132 096 Screw 1 - ---- Vacuum Chamber 1 - 218 322 Washer, Plain		1 - ---- Spring 2 - ---- Washer .032" thk. 3 - ---- Washer .010" thk. 2 - ---- Washer .065" thk.
	VACUUM CHAMBER and ATTACHING PARTS PACKAGE, DIS- TRIBUTOR Part No. 1881 749 Consists of:		SPRING and WASHER PACKAGE, DISTRIBUTOR VACUUM CHAMBER Part No. 1881 755 Consists of:
	1 - ---- Vacuum Chamber 1 - ---- Ring 1 - ---- Washer, Plain		1 - ---- Spring 2 - ---- Washer .032" thk. 3 - ---- Washer .010" thk. 2 - ---- Washer .065" thk.
	CHAMBER PACKAGE, VACUUM, w/ATTACHING PARTS . Part No. 1881 929 Consists of:		SPRING and WASHER PACKAGE, DISTRIBUTOR VACUUM CHAMBER Part No. 1881 766 Consists of:
	2 - ---- Lockwasher 1 - 643 901 Lock Ring 2 - 132 096 Screw 1 - ---- Vacuum Chamber 1 - 218 322 Washer, Plain		1 - ---- Spring 2 - ---- Washer .032" thk. 3 - ---- Washer .010" thk. 2 - ---- Washer .065" thk.
	VACUUM CHAMBER and ATTACHING PARTS PACKAGE, DIS- TRIBUTOR Part No. 1881 749 Consists of:		SPRING and WASHER PACKAGE, DISTRIBUTOR VACUUM CHAMBER Part No. 1881 755 Consists of:
	1 - ---- Vacuum Chamber 1 - ---- Ring 1 - ---- Washer, Plain		1 - ---- Spring 2 - ---- Washer .032" thk. 3 - ---- Washer .010" thk. 2 - ---- Washer .065" thk.
	CHAMBER PACKAGE, VACUUM, w/ATTACHING PARTS . Part No. 1881 929 Consists of:	8-29-13	NUT and LOCKWASHER PACKAGE, ARMATURE Part No. 1881 722 Consists of:
	2 - ---- Lockwasher 1 - 643 901 Lock Ring 2 - 132 096 Screw 1 - ---- Vacuum Chamber 1 - 218 322 Washer, Plain		1 - 40 654 Nut 1 - ---- Washer, Lock
	VACUUM CHAMBER and ATTACHING PARTS PACKAGE, DIS- TRIBUTOR Part No. 1881 944 Consists of:		
	1 - ---- Lock Ring 1 - ---- Vacuum Control		
	CHAMBER PACKAGE, VACUUM Part No. 1881 948 Consists of:		
	1 - ---- Lock Ring 1 - ---- Vacuum Control		

★ Indicates use as required.
 □ Indicates parts not listed in any previous parts book.
 * Indicates change or addition.

1959 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
8-29-14	STUD and MOUNTING PACKAGE, ARMATURE TERMINAL Part No. 1881 744 Consists of: 1 - 960 162 Bushing 2 - 120 367 Nut 1 - 1267 793 Stud 1 - 671 477 Washer, Insulator 2 - 131 098 Washer, Lock 1 - 120 392 Washer, Plain STUD and MOUNTING PACKAGE, ARMATURE TERMINAL Part No. 1881 740 Consists of: 2 - 120 367 Nut 1 - ---- Stud 1 - 1138 481 Washer, Insulator 2 - 131 098 Washer, Lock 1 - 120 392 Washer, Plain	8-36-1	CABLE SET, IGNITION, RESISTOR TYPE Part No. 2084 023 Consists of: 8 - ---- Cable 1 - ---- Cable, 8"long 10 - 1658 838 Nipple, Distributor 1 - 1665 085 Sleeve CABLE PACKAGE, IGNITION, RESISTOR TYPE Part No. 2084 064 Consists of: 1 - ---- Cable 1 - 1658 838 Nipple 1 - ---- Terminal, Straight CABLE PACKAGE, IGNITION, RESISTOR TYPE Part No. 2084 065 Consists of: 1 - ---- Cable 1 - 1658 838 Nipple 1 - ---- Terminal, Elbow Type
8-29-19	ARM and SPRING PACKAGE, GENERATOR BRUSH . . Part No. 1881 741 Consists of: 1 - 673 014 Arm 1 - 671 490 Spring ARM and SPRING PACKAGE, GENERATOR BRUSH . . Part No. 1881 721 Consists of: 2 - 1627 277 Arm 2 - 1627 279 Spring ARM and SPRING PACKAGE, GENERATOR BRUSH . . Part No. 1881 745 Consists of: 1 - 674 936 Arm 1 - 960 173 Spring	8-37-72	ORNAMENT AND BEZEL PACKAGE, FUEL GAUGE LENS . . Part No. E2084 463 Consists of: 1 - ---- Bezel 1 - ---- Gasket 1 - ---- Lens, w/Ornament 3 - 1626 973 Nut 1 - ---- Retainer 3 - ---- Washer 8-37-94 LENS AND BEZEL PACKAGE, OIL AND AMMETER INDICATOR LAMP Part No. E2084 464 Consists of: 1 - ---- Bezel 1 - ---- Gasket 1 - ---- Lens, Low Oil Pressure 1 - ---- Lens, Ammeter 3 - 1626 973 Nut 3 - ---- Washer
8-29-41	HOLDER and TERMINAL PACKAGE, GENERATOR BRUSH . . Part No. 1881 720 Consists of: 1 - ---- Bushing, Insulator 1 - ---- Bushing, Rivet 1 - ---- Holder, Brush 1 - ---- Holder, Insulator, w/Terminal 1 - ---- Insulator, Holder 2 - 120 367 Nut 2 - ---- Rivet, Ground Brush Holder 1 - ---- Rivet, Insulated Brush Holder 2 - 131 098 Washer, Lock 1 - 446 188 Washer, Plain	8-37-137	ORNAMENT AND BEZEL PACKAGE, TEMPERATURE GAUGE LENS Part No. E2084 462 Consists of: 1 - ---- Bezel 1 - ---- Gasket 1 - ---- Lens, w/Ornament 3 - 1626 973 Nut 1 - ---- Retainer 3 - ---- Washer
8-29-193	STUD and MOUNTING PACKAGE, GENERATOR FIELD TERMINAL Part No. 1881 719 Consists of: 1 - 1253 346 Bushing 2 - ---- Nut 1 - 1253 348 Stud 1 - 1253 344 Washer 2 - ---- Washer, Lock 1 - 1253 345 Washer, Plain STUD and MOUNTING PACKAGE, GENERATOR FIELD TERMINAL Part No. 1881 743 Consists of: 1 - 960 161 Bushing 1 - ---- Insulation 1 - 1253 332 Insulator 2 - ---- Nut 1 - ---- Stud 2 - ---- Washer, Lock 1 - ---- Washer, Plain 1 - 671 481 Washer	8-42-14	STUD and MOUNTING PACKAGE, GENERATOR ARMATURE TERMINAL Part No. 1881 740 Consists of: 1 - ---- Insulator 2 - ---- Nut 1 - ---- Stud 1 - ---- Washer, Insulator 1 - ---- Washer, Lock 1 - ---- Washer, Plain STUD and MOUNTING PACKAGE, GENERATOR ARMATURE TERMINAL Part No. 1841 744 Consists of: 1 - ---- Bushing 2 - ---- Nut 1 - ---- Stud 1 - ---- Washer, Insulator 2 - ---- Washer, Lock 1 - ---- Washer, Plain

★ Indicates use as required.

⊠ Indicates parts not listed in any previous parts book.
 Feb. 15, 1960 Supersedes May 25, 1959.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
8-50-103	ARM PACKAGE, DIRECTIONAL SIGNAL SWITCH Part No. 2084 288 Consists of: 1 - ---- --- Arm, Operating 1 - ---- --- Detent, Switch 1 - ---- --- Spring, Operating Arm		THRUST WASHER PACKAGE, STARTER COMMUTATOR and DRIVE END HEAD . . . Part No. 1881 725 Consists of: 1 - 1369 645 Washer, Commutator 2 - 641 446 Washer, Commutator, 1/32" 2 - 672 641 Washer, Commutator, 3/64" 1 - 1752 367 Washer, Drive End
8-50-303	LAMP PACKAGE, PARKING, RT. Part No. 1879 588 Consists of: 1 - 151 567 Bulb 1 - ---- --- Housing, Socket and Gasket 1 - 1879 590 Lens and Gasket 2 - ---- --- Nut 2 - 128 058 Screw 2 - 161 453 Screw LAMP PACKAGE, PARKING, LT. Part No. 1879 589 Consists of: 1 - 151 567 Bulb 1 - ---- --- Housing, Socket and Gasket 1 - 1879 591 Lens and Gasket 2 - ---- --- Nut 2 - ---- --- Screw 2 - 161 453 Screw	8-52-275	STUD PACKAGE, STARTER TERMINAL Part No. 1879 612 Consists of: 1 - 1818 777 Bushing 1 - 1879 612 Stud 1 - 1752 383 Washer, Inner 1 - 1818 751 Washer, Outer 1 - ---- --- Stud 1 - ---- --- Washer, Inner 1 - ---- --- Washer, Outer
8-50-334	LENS and GASKET PACKAGE, PARKING LAMP, RT. . . Part No. 1879 590 Consists of: 1 - ---- --- Gasket 1 - ---- --- Lens LENS and GASKET PACKAGE, PARKING LAMP, LT. . . Part No. 1879 591 Consists of: 1 - ---- --- Gasket 1 - ---- --- Lens	8-52-302	CONNECTOR and GROMMET, STARTER SWITCH . . . Part No. 1881 724 Consists of: 1 - ---- --- Connector 1 - ---- --- Grommet
8-52-75	YOKE and ATTACHING PACKAGE, STARTER . . Part No. 1881 726 Consists of: 1 - 1527 947 Clamp 1 - ---- --- Pin, Cotter 1 - ---- --- Pin, Link 1 - 1527 946 Pin Yoke 1 - 1752 373 Yoke	8-52-311	PLUNGER PACKAGE. . . Part No. 1881 728 Consists of: 1 - ---- --- Gasket 1 - ---- --- Plunger
8-52-82	STOP and LOCK RING PACKAGE, STARTER PINION. . . . Part No. 1881 727 Consists of: 1 - 1752 375 Lock Ring 1 - 1752 376 Stop	8-52-344	COVER PACKAGE, SOLENOID SWITCH. . . Part No. 1879 603 Consists of: 1 - ---- --- Cover 1 - ---- --- Gasket 1 - ---- --- Nut 1 - 120 614 Nut 1 - ---- --- Stud 1 - 1527 971 Stud 1 - 120 214 Washer, Lock, 5/16" 1 - 1135 614 Washer, Stud, 5/16" 1 - ---- --- Washer, No. 10 1 - ---- --- Washer, No. 10 1 - ---- --- Washer, Lock 1 - ---- --- Washer, 5/16"
8-52-150	HOLDER PACKAGE, STARTER BRUSH Part No. 1879 611 Consists of: 2 - 1752 361 Holder, Grounded Brush 2 - 1752 360 Holder, Insulated Brush 2 - 1752 363 Pin 4 - ---- --- Screw 2 - 1752 362 Spring	8-55-219	REFLECTOR PACKAGE, TAIL, STOP AND BACK-UP LAMP Part No. 1881 736 Consists of: 1 - ---- --- Gasket 1 - ---- --- Reflector 1 - ---- --- Retainer
8-52-180	THRUST WASHER PACKAGE, STARTER COMMUTATOR and DRIVE END HEAD . . . Part No. 1879 613 Consists of: 2 - 641 446 Washer, Commutator, 1/32" 2 - 672 641 Washer, Commutator, 3/64" 2 - ---- --- Washer, Commutator, .080" 2 - ---- --- Washer, Commutator, 1/16" 1 - 641 446 Washer, Intermediate, 1/32"	8-57-54	LENS and GASKET PACKAGE, LICENSE LAMP. Part No. 1879 566 Consists of: 1 - ---- --- Gasket 1 - ---- --- Lens
		9-01-5	GASKET SET, ENGINE. . . Part No. 1752 440 Consists of: 1 - 952 062 Gasket, Air Cleaner to Carburetor 1 - 1326 847 Gasket, Air Cleaner to Carburetor 1 - 622 772 Gasket, By-Pass Elbow 1 - 637 191 Gasket, Carburetor Flange 1 - 1552 874 Gasket, Carburetor Flange 1 - 1615 860 Gasket, Carburetor Flange 1 - 1630 472 Gasket, Carburetor Flange 1 - 1122 450 Gasket, Chain Case Cover 1 - 695 441 Gasket, Chain Case Cover Plate 1 - 1326 319 Gasket, Cylinder Head

(Pkg. Cont'd)

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

1959 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER
(Cont'd)	
	1 - 1636 571 Gasket, Exhaust Pipe Flange
	1 - 688 482 Gasket, Fuel Pump Flange
	1 - 1313 836 Gasket, Fuel Pump Flange
	1 - 1313 837 Gasket, Fuel Pump Flange
	1 - ---- --- Gasket, Manifold Center
	1 - ---- --- Gasket, Manifold End
	1 - 866 680 Gasket, Oil Pan Frt. and Rr.
	1 - ---- --- Gasket, Oil Pan, Left
	1 - ---- --- Gasket, Oil Pan, Right
	1 - 618 622 Gasket, Oil Pressure Relief Valve Cap
	1 - 695 442 Gasket, Oil Pump Body
	1 - 1124 984 Gasket, Oil Pump Cover
	2 - 980 583 Gasket, Valve Spring Cover
	4 - ---- --- Gasket, Valve Spring Cover Screw
	1 - 50 082 Gasket, Water Outlet Elbow
	1 - 1674 602 Gasket, Water Pump Body
	1 - 1735 036 Gasket, Water Pump Housing to Cylinder Block
	1 - 1326 325 Gasket, Water Pump to Block
	GASKET SET, ENGINE . . Part No. 1879 530
	Consists of:
	1 - 1618 685 Gasket, Chain Case Cover
	2 - 1731 552 Gasket, Cylinder Head
	2 - 1827 403 Gasket, Cylinder Head Cover
	1 - 50 082 Gasket, Cylinder Water Outlet
	2 - 1636 570 Gasket, Exhaust Pipe Flange
	1 - 1400 185 Gasket, Fuel Pump Flange
	1 - 1326 836 Gasket, Ignition Distributor
	2 - 1828 052 Gasket, Intake Manifold
	1 - 1637 570 Gasket, Intake Manifold, Frt.
	1 - 1637 571 Gasket, Intake Manifold, Rr.
	2 - ---- --- Gasket, Oil Pan
	2 - ---- --- Gasket, Oil Pan, End
	1 - 1676 031 Gasket, Water Pump Body
	GASKET SET, ENGINE . . Part No. 1879 701
	Consists of:
	1 - 1737 763 Gasket, Chain Case Cover
	2 - 1851 579 Gasket, Cylinder Head
	2 - 1821 440 Gasket, Cylinder Head Cover
	1 - 50 082 Gasket, Cylinder Water Outlet Elbow
	2 - 1855 029 Gasket, Exhaust Pipe Flange
	2 - 1821 640 Gasket, Exhaust Pipe Flange
	1 - 1400 185 Gasket, Fuel Pump Flange
	1 - 1326 836 Gasket, Ignition Distributor
	1 - 1737 709 Gasket, Intake Manifold
	1 - 1737 770 Gasket, Oil Pan
	1 - 618 622 Gasket, Oil Pressure Relief Valve Cap
	1 - 1737 705 Gasket, Water Pump Body
	2 - 1737 761 Gasket, Water Pump to Cylinder Block
	GASKET SET, ENGINE . . Part No. 1879 702
	Consists of:
	1 - 1737 763 Gasket, Chain Case Cover
	2 - 1851 579 Gasket, Cylinder Head
	2 - 1821 440 Gasket, Cylinder Head Cover
	1 - 50 082 Gasket, Cylinder Water Outlet Elbow
	2 - 1821 640 Gasket, Exhaust Pipe Flange
	2 - 1855 029 Gasket, Exhaust Pipe Flange
	1 - 1400 185 Gasket, Fuel Pump Flange
	1 - 1326 836 Gasket, Ignition Distributor
	1 - 1851 664 Gasket, Intake Manifold
	1 - 1737 770 Gasket, Oil Pan

(Pkg. Cont'd)

CODE	PART NAME AND PART NUMBER
(Cont'd)	
	1 - 618 622 Gasket, Oil Pressure Relief Valve Cap
	1 - 1737 705 Gasket, Water Pump Body
	2 - 1737 761 Gasket, Water Pump to Cylinder Block
9-10-2	OIL SEAL PACKAGE, CRANKSHAFT BEARING NO. 5 CAP . . Part No. 1326 091
	Consists of:
	1 - ---- --- Oil Seal, Left
	1 - ---- --- Oil Seal, Right
9-11-1	OIL SEAL PACKAGE, CRANKSHAFT REAR BEARING Part No. 1326 093
	Consists of:
	2 - ---- --- Oil Seal, Bearing
	1 - ---- --- Oil Seal, Bearing Cap, Left
	1 - ---- --- Oil Seal, Bearing Cap, Right
	OIL SEAL PACKAGE, CRANKSHAFT REAR BEARING Part No. 1450 866
	Consists of:
	1 - ---- --- Gasket, Cap, Left
	1 - ---- --- Gasket, Cap, Right
	2 - ---- --- Oil Seal
	OIL SEAL PACKAGE, CRANKSHAFT REAR BEARING Part No. 1818 781
	Consists of:
	2 - ---- --- Oil Seal, Crankshaft Rear Bearing
	2 - ---- --- Oil Seal, Crankshaft Rear Bearing Retainer
9-39-1	GASKET PACKAGE, VALVE GRIND Part No. 1325 976
	Consists of:
	1 - 1326 319 Gasket, Cylinder Head
	1 - 863 220 Gasket, Thermostat
	2 - ---- --- Gasket, Valve Spring Cover
	4 - ---- --- Gasket, Valve Spring Cover Screw
	1 - 50 082 Gasket, Water Outlet Connection
	1 - 622 772 Gasket, Water Pump By-Pass Elbow
	GASKET PACKAGE, VALVE GRIND Part No. 1752 444
	Consists of:
	2 - 1731 552 Gasket, Cylinder Head
	2 - 1827 403 Gasket, Cylinder Head Cover
	2 - 1636 570 Gasket, Exhaust Pipe Flange
	2 - 1828 052 Gasket, Intake Manifold
	1 - 1637 570 Gasket, Intake Mainfold, Front
	1 - 1637 571 Gasket, Intake Manifold, Rear
	GASKET PACKAGE, VALVE GRIND Part No. 1879 703
	Consists of:
	2 - 1851 579 Gasket, Cylinder Head
	2 - 1821 440 Gasket, Cylinder Head Cover
	2 - 1821 640 Gasket, Exhaust Pipe Flange
	2 - 1855 029 Gasket, Exhaust Pipe Flange
	1 - 1737 709 Gasket, Intake Manifold
	2 - 1737 761 Gasket, Water Pump to Cylinder Block

★ Indicates use as required.

⊠ Indicates parts not listed in any previous parts book.
Feb. 15, 1960 Supersedes May 25, 1959.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	GASKET PACKAGE, VALVE GRIND Part No. 1879 704 Consists of: 2 - 1851 579 Gasket, Cylinder Head 2 - 1821 440 Gasket, Cylinder Head Cover 2 - 1821 640 Gasket, Exhaust Pipe Flange 2 - 1855 029 Gasket, Exhaust Pipe Flange 1 - 1851 664 Gasket, Intake Manifold 2 - 1737 761 Gasket, Water Pump to Cylinder Block	10-24-2	SEAL and PLATE PACKAGE, OIL PAN FRONT END OIL Part No. 1115 100 Consists of: 1 - ---- Plate, Oil Pan Front End Oil Seal 2 - 1066 873 Seal, Oil Pan Front End Oil
9-40-1	GASKET SET, VALVE SPRING COVER Part No. 980 583 Consists of: 2 - ---- Gasket, Cover 4 - ---- Stud Nut	10-26-1	OIL FILTER KIT Part No. 1123 152 Consists of: 1 - ---- Filter, Oil
9-50-1	GASKET SET, MANIFOLD Part No. 780 460 Consists of: 1 - ---- Gasket, Center 4 - ---- Gasket, End	10-26-2	ADAPTER PACKAGE, OIL FILTER Part No. 1450 553 Consists of: 1 - 1320 517 Bracket, w/Clamp 1 - 137 420 Elbow 1 - 431 537 Nipple 2 - ---- Screw, Oil Filter Attaching 1 - ---- Tube, Engine to Oil Filter 1 - ---- Tube, Oil Filter to Engine 2 - 120 382 Washer, Lock 1 - 120 394 Washer, Plain
9-58-1	HEAT CONTRL PACKAGE, MANIFOLD Part No. 1752 418 Consists of: 1 - 1736 012 Bolt 2 - 651 251 Bushing 1 - 601 420 Gasket 1 - 1409 594 Lock 1 - ---- Nut 1 - 604 504 Plate 1 - 604 505 Shaft 1 - 1670 514 Shield 1 - 644 876 Spacer 1 - 683 057 Stop 1 - 960 003 Thermostat	10-26-8	CARTRIDGE, OIL FILTER Part No. 1634 447 Consists of: 1 - ---- Cartridge, Oil Filter 1 - ---- Gasket, Cover 1 - ---- Gasket, Retainer CARTRIDGE, OIL FILTER Part No. 1821 552 Consists of: 1 - ---- Cartridge, Oil Filter 1 - ---- Gasket, Cover
10-07-2	GASKET and SEAL PACKAGE, OIL PUMP Part No. 2084 355 Consists of: 1 - 1737 727 Gasket, Oil Pump Cover, Large 1 - 1737 726 Gasket, Oil Pump Cover, Small 1 - ---- Gasket, Oil Pump Body 1 - 1855 328 Seal, Oil Pump Body	11-02-1	CLAMP PACKAGE, INTER- MEDIATE TAIL PIPE . Part No. 1843 008 Consists of: 2 - 120 376 Nut 1 - ---- Saddle 1 - ---- U-Bolt 2 - 120 214 Washer, Lock CLAMP PACKAGE, INTER- MEDIATE TAIL PIPE . Part No. 1843 009 Consists of: 2 - 120 376 Nut 1 - ---- Saddle 1 - ---- U-Bolt 2 - 120 214 Washer, Lock
10-07-3	SHAFT and ROTOR PACKAGE, OIL PUMP DRIVE . . . Part No. 1316 143 Consists of: 1 - ---- Rotor, Outer 1 - ---- Shaft, Drive, Assembly	11-08-1	CLAMP PACKAGE, EXHAUST PIPE Part No. 1603 364 Consists of: 2 - 120 376 Nut 1 - ---- Saddle 1 - ---- U-Bolt 2 - 120 214 Washer, Lock CLAMP PACKAGE, EXHAUST PIPE Part No. 1843 008 Consists of: 2 - 120 376 Nut 1 - ---- Saddle 1 - ---- U-Bolt 2 - 120 214 Washer, Lock CLAMP PACKAGE, EXHAUST PIPE Part No. 1843 010 Consists of: 2 - 120 368 Nut 1 - ---- Saddle 1 - ---- U-Bolt 2 - 120 214 Washer, Lock
10-24-1	SHAFT and ROTOR PACKAGE, OIL PUMP DRIVE . . . Part No. 2084 354 Consists of: 1 - 1737 722 Rotor, Outer 1 - 1737 719 Shaft, Drive Assy.		
	GASKET PACKAGE, OIL PAN Part No. 933 438 Consists of: 2 - 866 680 Gasket, Oil Pan Front and Rear 1 - ---- Gasket, Oil Pan Left 1 - ---- Gasket, Oil Pan Right		
	GASKET PACKAGE, OIL PAN Part No. 1879 520 Consists of: 2 - ---- Gasket, Oil Pan 2 - ---- Gasket, Oil Pan End		

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

1959 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	CLAMP PACKAGE, EXHAUST PIPE Part No. 1843 407 Consists of: 2 - 120 376 Nut 1 - ---- Saddle 1 - ---- U-Bolt 2 - 120 214 Washer, Lock 2 - 120 387 Washer, Plain	(Cont'd)	1 - ---- Support, w/Clamp 2 - ---- Washer, Lock 2 - ---- Washer, Plain
11-09-1	CLAMP PACKAGE, TAIL PIPE Part No. 1843 008 Consists of: 2 - 120 376 Nut 1 - ---- Saddle 1 - ---- U-Bolt 2 - 120 214 Washer, Lock	14-02-49	CAP PACKAGE, AUTO. PILOT DRIVE MECHANISM SPRING COMPRESSOR Part No. 1881 967 Consists of: 1 - ---- Cap, w/Rod 1 - ---- Collar, Adjusting 1 - ---- Fitting, Guide Clamp 1 - ---- Guide, Compressor Rod 2 - ---- Washer
	CLAMP PACKAGE, TAIL PIPE Part No. 1843 009 Consists of: 2 - 120 376 Nut 1 - ---- Saddle 1 - ---- U-Bolt 2 - 120 214 Washer, Lock	14-02-50	ARM PACKAGE, AUTO. PILOT DRIVE MECHANISM CONTACT. Part No. 1881 968 Consists of: 1 - ---- Arm, Contact 2 - ---- Nut 2 - ---- Point, Contact 2 - ---- Washer, Lock
11-10-1	CLAMP PACKAGE, TAIL PIPE SUPPORT . Part No.*1321 109 Consists of: 1 - ---- Clamp, Tail Pipe 1 - 181 639 Bolt, Tail Pipe Clamp 1 - 120 369 Nut, Tailpipe Clamp Bolt 1 - 120 382 Washer, Tail Pipe Clamp Bolt Lock	14-02-51	PINTLE and ARM PACKAGE, AUTO. PILOT DRIVE MECHANISM . . Part No. 1881 969 Consists of: 1 - ---- Arm, Locking 1 - ---- Bolt, Gauge 1 - ---- Pintle 2 - ---- Screw, Pintle 3 - ---- Washer, Lock
	CLAMP PACKAGE, TAIL PIPE SUPPORT Part No. 1843 008 Consists of: 2 - 120 376 Nut 1 - ---- Saddle 1 - ---- U-Bolt 2 - 120 214 Washer, Lock	14-02-52	GEAR PACKAGE, AUTO. PILOT DRIVE MECHANISM SPEEDOMETER Part No. 1881 970 Consists of: 1 - ---- Adapter, Gear 3 - ---- Bolt 1 - ---- Gear
	CLAMP PACKAGE, TAIL PIPE SUPPORT Part No. 1843 009 Consists of: 2 - 120 376 Nut 1 - ---- Saddle 1 - ---- U-Bolt 2 - 120 214 Washer, Lock	14-02-53	DRIVE SCREW and BEARING PACKAGE, AUTO. PILOT DRIVE MECHANISM Part No. 1881 971 Consists of: 1 - ---- Bearing, Ball 1 - ---- Locknut 1 - ---- Screw, w/Nut 3 - ---- Screw 1 - ---- Washer, Retainer
	CLAMP PACKAGE, TAIL PIPE SUPPORT Part No. 1843 408 Consists of: 1 - 181 614 Bolt 1 - ---- Clamp 1 - 120 368 Nut 1 - 120 214 Washer, Lock 1 - 120 387 Washer, Plain	14-02-54	RING PACKAGE, AUTO. PILOT DRIVE MECHANISM FELT . . . Part No. 1881 972 Consists of: 2 - ---- Ring, Felt 4 - ---- Screw 1 - ---- Strip, Sealing
	SUPPORT PACKAGE, TAIL PIPE Part No. 1881 685 Consists of: 1 - ---- Bolt, Hexagon Head 1 - ---- Bolt, Square Neck Carriage 2 - ---- Nut, Bolt 1 - ---- Support, w/Clamp 2 - ---- Washer, Lock 2 - ---- Washer, Plain	14-02-55	HOUSING PACKAGE, AUTO. PILOT DRIVE MECHANISM GOVERNOR Part No. 1881 973 Consists of: 1 - ---- Housing 1 - ---- Ring, Felt 1 - ---- Stud
	SUPPORT PACKAGE, TAIL PIPE Part No. 1881 688 Consists of: 1 - ---- Bolt, Hexagon Head 1 - ---- Bolt, Square Neck Carriage 2 - ---- Nut, Bolt	14-02-56	BLOCK PACKAGE, AUTO. PILOT DRIVE MECHANISM Part No. 1881 974 Consist of: 1 - ---- Block, Terminal 1 - ---- Screw
		14-02-57	SCREW PACKAGE, AUTO. PILOT DRIVE MECHANISM COVER . . Part No. 1881 975 Consists of: 4 - ---- Screw, Cover

(Pkg. Cont'd)

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

Feb. 15, 1960 Supersedes May 25, 1959.

* Indicates change or addition.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
14-11-8	ROD PACKAGE, ACCELERATOR SHAFT TO ENGINE CROSS SHAFT Part No. 1603 200 Consists of: 1 - 1401 687 Ball Joint 2 - 120 367 Nut 1 - ---- Rod 1 - 120 380 Washer, Lock	(Cont'd)	2 - ---- Gasket, Metering Jet 1 - ---- Gasket, By-Pass Jet 1 - ---- Gasket, Pump Discharge Nozzle Screw 1 - ---- Gasket, Pump Discharge Nozzle 2 - ---- Jet, Main Metering 1 - ---- Jet, Power By-Pass 1 - ---- Needle, w/Seat, Float 1 - ---- Pin, Cotter 2 - ---- Plug, Channel 1 - ---- Pump, w/Rod 1 - ---- Retainer, Pump Link 1 - ---- Spring, Pump 1 - ---- Spring, Float 2 - ---- Valve, Idle Needle
	ROD PACKAGE, ENGINE BELL CRANK TO CARBURETOR Part No. 1603 200 Consists of: 1 - 1401 687 Ball Joint 2 - 120 367 Nut 1 - ---- Rod 1 - 120 380 Washer, Lock		REPAIR PACKAGE, CARBURETOR Part No. 1826 471 Consists of: 1 - ---- Gasket, Air Horn to Body 1 - ---- Gasket, Body to Flange 1 - ---- Gasket, Choke Coil Housing 1 - ---- Gasket, Flange 1 - ---- Gasket, Step-Up Piston 1 - ---- Jet, Main Metering 1 - ---- Needle, w/Seat, Float 1 - ---- Plug, Passage 1 - ---- Pump, w/Rod 1 - ---- Spring, Step-Up Piston 1 - ---- Tube, Idle Orifice 1 - ---- Tube, Main Vent
14-30-4	REPAIR PACKAGE, CARBURETOR Part No. 1826 471 Consists of: 1 - ---- Gasket, Air Horn to Body 1 - ---- Gasket, Body to Flange 1 - ---- Gasket, Choke Coil Housing 1 - ---- Gasket, Flange 1 - ---- Gasket, Step-Up Piston 1 - ---- Jet, Main Metering 1 - ---- Needle, w/Seat, Float 1 - ---- Plug, Passage 1 - ---- Pump, w/Rod 1 - ---- Spring, Step-Up Piston 1 - ---- Tube, Idle Orifice 1 - ---- Tube, Main Vent		REPAIR PACKAGE, CARBURETOR Part No. 1826 540 Consists of: 1 - ---- Ball, Discharge Check Valve 1 - ---- Ball, Inlet Check Valve 1 - ---- Gasket, Air Horn to Body 1 - ---- Gasket, Body to Flange 2 - ---- Gasket, Metering Jet 1 - ---- Gasket, By-Pass Jet 1 - ---- Gasket, Pump Dis- charge Nozzle 1 - ---- Gasket, Pump Dis- charge Nozzle Screw 2 - ---- Jet, Main Metering 1 - ---- Jet, Power By-Pass 1 - ---- Needle, w/Seat, Float 2 - ---- Pin, Cotter 2 - ---- Plug, Channel 1 - ---- Pump, w/Rod 1 - ---- Retainer, Pump Link 1 - ---- Spring, Float Pin 1 - ---- Spring, Pump 2 - ---- Valve, Idle Needle
	REPAIR PACKAGE, CARBURETOR Part No. 1826 477 Consists of: 1 - ---- Gasket, Air Horn to Body 1 - ---- Gasket, Body to Flange 1 - ---- Gasket, Choke Coil Housing 1 - ---- Gasket, Flange 1 - ---- Gasket, Step-Up Piston 1 - ---- Jet, Main Metering 1 - ---- Needle, w/Seat, Float 1 - ---- Plug, Passage 1 - ---- Pump, w/Rod 1 - ---- Spring, Step-Up Piston 1 - ---- Tube, Idle Orifice 1 - ---- Tube, Main Vent		REPAIR PACKAGE, CARBURETOR Part No. 1826 541 Consists of: 1 - ---- Ball, Inlet Check 1 - ---- Ball, Discharge Check 1 - ---- Gasket, Air Horn 1 - ---- Gasket, Main Body 2 - ---- Gasket, Metering Jet 1 - ---- Gasket, Power By-Pass Jet 1 - ---- Gasket, Discharge Nozzle 1 - ---- Gasket, Discharge Nozzle Screw 2 - ---- Jet, Main Metering 1 - ---- Jet, Power By-Pass 1 - ---- Needle, w/Seat, Float 2 - ---- Pin, Cotter
	REPAIR PACKAGE, CARBURETOR Part No. 1826 539 Consists of: 1 - ---- Ball, Intake Check 1 - ---- Ball, Discharge Check 1 - ---- Gasket, Air Horn 1 - ---- Gasket, Main Body		
	(Pkg. Cont'd)		(Pkg. Cont'd)

★ Indicates use as required.

⊠ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)			
	2 - ---- Plug, Channel		REPAIR PACKAGE,
	1 - ---- Pump, w/Rod		CARBURETOR Part No. 1826 612
	1 - ---- Retainer, Pump Link		Consists of:
	1 - ---- Spring, Float Lever		1 - ---- Gasket, Air Horn
	1 - ---- Spring, Pump		to Body
	2 - ---- Valve, Idle Needle		1 - ---- Gasket, Body
	REPAIR PACKAGE,		to Flange
	CARBURETOR Part No. 1826 555		1 - ---- Gasket, Flange
	Consists of:		2 - ---- Gasket, Step-Up
	1 - ---- Gasket, Air Horn		Piston
	1 - ---- Gasket, Flange		1 - ---- Gasket, Venturi
	1 - ---- Gasket, Pump Jet		Cover
	2 - ---- Gasket, Secondary		1 - ---- Gasket, Venturi
	Cluster		Housing
	2 - ---- Gasket, Primary		2 - ---- Jet, Main Metering
	Cluster		1 - ---- Needle, w/Seat,
	2 - ---- Jet, Metering		Float
	2 - ---- Needle, w/Seat,		1 - ---- Pump, w/Rod
	Float		1 - ---- Spring, Step-Up
	1 - ---- Pump, w/Rod		Piston
	2 - ---- Rod, Step-Up		REPAIR PACKAGE,
	2 - ---- Spring, Vacuum		CARBURETOR Part No. 1826 613
	Piston		Consists of:
	REPAIR PACKAGE,		1 - ---- Gasket, Air Horn
	CARBURETOR Part No. 1826 563		to Body
	Consists of:		1 - ---- Gasket, Body
	1 - ---- Gasket, Air Horn		to Flange
	1 - ---- Gasket, Flange		1 - ---- Gasket, Flange
	1 - ---- Gasket, Pump Jet		1 - ---- Gasket, Step-Up
	2 - ---- Gasket, Primary		Piston
	Cluster		1 - ---- Gasket, Venturi
	2 - ---- Gasket, Secondary		Cover
	Cluster		1 - ---- Gasket, Venturi
	2 - ---- Jet, Metering Rod		Housing
	1 - ---- Needle, w/Seat,		2 - ---- Jet, Main Metering
	Float		1 - ---- Needle, w/Seat,
	1 - ---- Pump, w/Rod		Float
	2 - ---- Rod, Step-Up		1 - ---- Pump, w/Rod
	2 - ---- Spring, Vacuum		1 - ---- Spring, Step-Up
	Piston		Piston
	REPAIR PACKAGE,		REPAIR PACKAGE,
	CARBURETOR Part No. 1826 564		CARBURETOR Part No. 1826 617
	Consists of:		Consists of:
	1 - ---- Gasket, Air Horn		1 - ---- Gasket, Air Horn
	1 - ---- Gasket, Choke		to Body
	Housing		1 - ---- Gasket, Flange
	1 - ---- Gasket, Choke Heat		1 - ---- Gasket, Pump Jet
	Tube Cap		2 - ---- Gasket, Primary
	1 - ---- Gasket, Flange		Cluster
	1 - ---- Gasket, Pump Jet		REPAIR PACKAGE,
	2 - ---- Gasket, Primary		CARBURETOR Part No. 1826 620
	Cluster		Consists of:
	2 - ---- Gasket, Secondary		1 - ---- Gasket, Air Horn
	Cluster		to Body
	2 - ---- Jet, Primary		1 - ---- Gasket, Flange
	Metering Rod		1 - ---- Gasket, Pump Jet
	2 - ---- Needle, w/Seat,		2 - ---- Gasket, Primary
	Float		Cluster
	1 - ---- Pump, w/Rod		2 - ---- Gasket, Secondary
	2 - ---- Rod, Step-Up		Cluster
	2 - ---- Spring, Vacuum		2 - ---- Jet, Primary Metering
	Piston		2 - ---- Needle, w/Seat,
			Float
			1 - ---- Pump, w/Rod
			2 - ---- Rod, Step-Up
			2 - ---- Spring, Vacuum Piston
			2 - ---- Gasket, Secondary
			Cluster
			2 - ---- Jet, Primary Metering

(Pkg. Cont'd)

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.
Feb. 15, 1960 Supersedes May 25, 1959.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)			
	2 - ---- --- Needle, w/Seat, Float	14-30-7	GASKET PACKAGE, CARBURETOR Part No. 1631 368 Consists of:
	1 - ---- --- Pump, w/Rod		1 - ---- --- Gasket, Air Horn to Body
	2 - ---- --- Rod, Step-Up		1 - ---- --- Gasket, Body to Flange
	2 - ---- --- Spring, Vacuum Piston		1 - ---- --- Gasket, Float Needle Seat
	REPAIR PACKAGE, CARBURETOR Part No. 1826 854 Consists of:		2 - ---- --- Gasket, Metering Jet
	1 - ---- --- Gasket, Air Horn to Body		1 - ---- --- Gasket, Power By-Pass Jet
	1 - ---- --- Gasket, Air Cleaner		1 - ---- --- Gasket, Pump Discharge Nozzle
	1 - ---- --- Gasket, Choke Housing		1 - ---- --- Gasket, Pump Discharge Nozzle Screw
	1 - ---- --- Gasket, Flange		1 - ---- --- Gasket, Thermostat Cover
	1 - ---- --- Gasket, Heat Tube Cap		GASKET PACKAGE, CARBURETOR Part No. 1826 441 Consists of:
	1 - ---- --- Gasket, Pump Jet		1 - ---- --- Gasket, Air Horn to Body
	2 - ---- --- Gasket, Primary Cluster		1 - ---- --- Gasket, Body to Flange
	2 - ---- --- Gasket, Secondary Cluster		1 - ---- --- Gasket, Choke Housing
	2 - ---- --- Jet, Metering Rod		1 - ---- --- Gasket, Flange
	2 - ---- --- Needle, w/Seat, Float		1 - ---- --- Gasket, Needle Seat
	1 - ---- --- Pump, w/Rod		1 - ---- --- Gasket, Step-Up Jet
	2 - ---- --- Rod, Step-Up		1 - ---- --- Gasket, Step-Up Piston
	2 - ---- --- Spring, Vacuum Piston		GASKET PACKAGE, CARBURETOR Part No. 1826 511 Consists of:
	REPAIR PACKAGE, CARBURETOR Part No. 1826 855 Consists of:		1 - ---- --- Gasket, Air Horn to Body
	1 - ---- --- Gasket, Air Horn to Body		1 - ---- --- Gasket, Body to Flange
	1 - ---- --- Gasket, Air Cleaner		1 - ---- --- Gasket, Flange
	1 - ---- --- Gasket, Flange		2 - ---- --- Gasket, Metering Jet
	1 - ---- --- Gasket, Pump Jet		1 - ---- --- Gasket, Needle Seat
	2 - ---- --- Gasket, Primary Cluster		1 - ---- --- Gasket, Step-Up Piston
	2 - ---- --- Gasket, Secondary Cluster		1 - ---- --- Gasket, Venturi Cover
	2 - ---- --- Jet, Metering Rod		1 - ---- --- Gasket, Venturi Housing
	2 - ---- --- Needle, w/Seat, Float		GASKET PACKAGE, CARBURETOR Part No. 1826 552 Consists of:
	1 - ---- --- Pump, w/Rod		1 - ---- --- Gasket, Air Horn to Body
	2 - ---- --- Rod, Step-Up		1 - ---- --- Gasket, Flange
	2 - ---- --- Spring, Vacuum Piston		2 - ---- --- Gasket, Primary Cluster
	REPAIR PACKAGE, CARBURETOR Part No. 1826 878 Consists of:		2 - ---- --- Gasket, Secondary Cluster
	1 - ---- --- Gasket, Air Horn to Body		1 - ---- --- Gasket, Pump Jet
	1 - ---- --- Gasket, Body to Flange		GASKET PACKAGE, CARBURETOR Part No. 1826 554 Consists of:
	1 - ---- --- Gasket, Flange		1 - ---- --- Gasket, Air Horn to Body
	1 - ---- --- Gasket, Step-Up Piston		1 - ---- --- Gasket, Flange
	1 - ---- --- Gasket, Venturi Cover		2 - ---- --- Gasket, Primary Cluster
	1 - ---- --- Gasket, Venturi Housing		2 - ---- --- Gasket, Secondary Cluster
	2 - ---- --- Jet, Main Metering		1 - ---- --- Gasket, Pump Jet
	1 - ---- --- Needle, w/Seat, Float		
	1 - ---- --- Pump, w/Rod		
	1 - ---- --- Spring, Step-Up Piston		

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

1959 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
	GASKET PACKAGE, CARBURETOR Part No. 1826 561 Consists of: 1 - ---- Gasket, Air Cleaner 1 - ---- Gasket, Air Horn to Body 1 - ---- Gasket, Flange 2 - ---- Gasket, Primary Cluster 2 - ---- Gasket, Secondary Cluster 1 - ---- Gasket, Pump Jet	14-73-1	PUMP PACKAGE, FUEL. Part No. 1752 463 Consists of: 1 - 1400 185 Gasket 1 - ---- Pump
	GASKET PACKAGE, CARBURETOR Part No. 1826 562 Consists of: 1 - ---- Gasket, Air Cleaner 1 - ---- Gasket, Air Horn to Body 1 - ---- Gasket, Choke Heat Tube Cap 1 - ---- Gasket, Choke Housing 1 - ---- Gasket, Flange 2 - ---- Gasket, Primary Cluster 2 - ---- Gasket, Secondary Cluster 1 - ---- Gasket, Pump Jet		PUMP PACKAGE, FUEL. Part No. 1843 287 Consists of: 1 - 1400 185 Gasket 1 - ---- Pump
	GASKET PACKAGE, CARBURETOR Part No. 1826 615 Consists of: 1 - ---- Gasket, Air Cleaner 1 - ---- Gasket, Air Horn to Body 1 - ---- Gasket, Body to Flange 1 - ---- Gasket, Flange 1 - ---- Gasket, Step-Up Piston 1 - ---- Gasket, Venturi Cover 1 - ---- Gasket, Venturi Housing		PUMP PACKAGE, FUEL. Part No. 1843 399 Consists of: 1 - 1400 185 Gasket 1 - ---- Pump
	GASKET PACKAGE, CARBURETOR Part No. 1826 616 Consists of: 1 - ---- Gasket, Air Cleaner 1 - ---- Gasket, Air Horn to Body 1 - ---- Gasket, Flange 2 - ---- Gasket, Primary Cluster 2 - ---- Gasket, Secondary Cluster 1 - ---- Gasket, Pump Jet	14-86-35	PUMP PACKAGE, FUEL. Part No. 1843 400 Consists of: 1 - 1400 185 Gasket 1 - ---- Pump
14-67-1	FILTER PACKAGE, FUEL Part No. 1879 513 Consists of: 4 - 274 461 Clamp 1 - 1263 079 Clip 1 - ---- Filter 2 - ---- Hose 1 - 1826 835 Nut, Strainer		PUMP PACKAGE, FUEL. Part No. 1879 296 Consists of: 1 - 1400 185 Gasket 1 - ---- Pump
14-67-5	ELEMENT PACKAGE, FUEL FILTER Part No. 1879 458 Consists of: 1 - ---- Element 1 - ---- Gasket	16-03-1	CAP PACKAGE, FILLER TUBE Part No. 1879 488 Consists of: 1 - ---- Bar, Cap 1 - ---- Cap 1 - ---- Nut, w/Washer
14-67-8	BOWL PACKAGE, FUEL FILTER Part No. 1879 294 Consists of: 1 - ---- Bowl 1 - ---- Gasket, Bowl		JOINT PACKAGE, UNIVERSAL, FRONT Part No. 1603 398 Consists of: 1 - 579 445 Pin, Centering 1 - 602 820 Cover, Grease 2 - 629 768 Button, Centering 1 - 639 973 Spring 1 - 870 539 Clamp, Large 1 - 870 540 Clamp, Small 1 - ---- Cover 2 - 1550 466 Ball and Roller 2 - 605 004 Washer, Thrust 1 - 1616 185 Gasket, Cover
			JOINT PACKAGE, UNIVERSAL, REAR Part No. 1752 624 Consists of: 1 - ---- Cross Assy. 4 - 858 006 Retainer, Roller and Bushing 4 - 1739 913 Roller and Bushing
			JOINT PACKAGE, UNIVERSAL, FRONT Part No. 1752 680 Consists of: 1 - 1635 092 Cover, Grease 2 - 605 004 Washer, Thrust 1 - 1635 098 Gasket, Cover 1 - 870 540 Clamp, Small 1 - 1739 923 Pin, Centering 1 - 1532 943 Clamp, Large 2 - 1739 924 Button, Centering 1 - ---- Cover 2 - 1739 927 Ball and Roller
			JOINT PACKAGE, UNIVERSAL, CENTER BRG. Part No. 1752 623 Consists of: 1 - ---- Cross Assy. 2 - 1739 914 Block, Roller and Bearing 2 - 858 006 Retainer, Roller and Bushing 2 - 1739 913 Roller and Bushing

★ Indicates use as required.

⊠ Indicates parts not listed in any previous parts book.
Feb. 15, 1960 Supersedes May 25, 1959.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER	
16-07-4	DUST COVER PACKAGE, UNIVERSAL JOINT . . . Part No. 1603 397 Consists of: 1 - ---- --- Cover, Dust 1 - 870 539 Clamp, Large 1 - 870 540 Clamp, Small DUST COVER PACKAGE, UNIVERSAL JOINT . . . Part No. 1450 448 Consists of: 1 - ---- --- Cover, Dust 1 - 1532 943 Clamp, Large 1 - 870 540 Clamp, Small		ABSORBER and BUSHING PACKAGE, FRONT SHOCK Part No. 1881 774 Consists of: 1 - ---- --- Absorber 1 - 1614 385 Bushing, Upper Mounting 1 - 1635 588 Bushing, Lower Mounting ABSORBER and BUSHING PACKAGE, FRONT SHOCK Part No. 1881 775 Consists of: 1 - ---- --- Absorber 1 - 1614 385 Bushing, Upper Mounting 1 - 1635 588 Bushing, Lower Mounting	
17-11-1	BUSHING PACKAGE, REAR SPRING Part No. 1450 089 Consists of: 4 - ---- --- Bushing	19-01-3	OVERHAUL PACKAGE, STEERING GEAR Part No. 1879 395 Consists of: 1 - 1615 679 Bushing, Shaft-Lower 1 - 1673 962 Bushing, Shaft-Upper 2 - 640 086 Cage, w/Roller, Worm Thrust Bearing 1 - 376 751 Cup, Worm Upper Thrust Bearing 1 - 637 539 Cup, Worm Lower Thrust Bearing 1 - 1738 206 Gasket, Shaft Cover 1 - 1730 985 Seal, Shaft Oil 1 - 1829 134 Seal, Tube Oil 1 - 661 117 Seal, Column Jacket Oil 10 - 1123 313 Shim, Housing Cover	
17-12-2	BOOSTER PACKAGE, LEAF SPRING Part No. E2201 550 Consists of: 2 - 1944 361 Bolt 2 - 2122 359 Interliner, Front End 2 - 1616 921 Interliner, Rear End 2 - ---- --- Leaf 2 - ---- --- Nut		OVERHAUL PACKAGE, STEERING GEAR Part No. 1879 737 Consists of: 1 - 1615 679 Bushing, Shaft-Lower 1 - 1673 962 Bushing, Shaft-Upper 2 - 669 077 Cage, w/Roller, Worm Thrust Bearing 1 - 618 311 Cup, Worm Upper Thrust Bearing 1 - 632 685 Cup, Worm Lower Thrust Bearing 1 - 1142 262 Gasket, Shaft Cover 1 - 1738 204 Gasket, Shaft Cover 1 - 1730 985 Seal, Shaft Oil 1 - 653 194 Seal, Tube Oil 1 - 661 117 Seal, Column Jacket Oil 10 - 1142 261 Shim, Housing Cover	
17-16-1	SHACKLE and BUSHING PACKAGE, REAR SPRING Part No. 1450 087 Consists of: 4 - ---- --- Bushing 2 - 126 022 Nut 2 - ---- --- Shackle SHACKLE and BUSHING PACKAGE, REAR SPRING Part No. 1450 961 Consists of: 4 - ---- --- Bushing 2 - 126 022 Nut 2 - ---- --- Shackle		19-01-4	"O"RING and SEAL PACKAGE, POWER STEERING GEAR Part No. *1881 715 Consists of: 1 - ---- --- Gasket, Valve Housing Plug 1 - 1733 615 "O" Ring, Shaft Cover 1 - 1316 849 "O" Ring, Housing 2 - 1556 385 "O" Ring, Housing Port 1 - 1486 205 "O" Ring, Cylinder Head Ferrule 2 - 1733 562 "O" Ring, Cylinder Head 1 - 1822 149 "O" Ring, Reaction-Lower 1 - 1733 602 "O" Ring, Column Support 1 - 1536 268 "O" Ring, Pressure Control Valve 1 - 1733 612 "O" Ring, Valve Housing 1 - 1822 203 Seal, Shaft Adjusting Screw 1 - 1822 324 Seal, Worm Shaft Inner 1 - 1822 151 Seal, Reaction-Upper 1 - 1730 985 Seal, Shaft Oil
17-23-3	ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 1752 511 Consists of: 1 - ---- --- Absorber 2 - 1319 902 Bushing ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 1843 132 Consists of: 1 - ---- --- Absorber 2 - 1319 902 Bushing ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 1879 305 Consists of: 1 - ---- --- Absorber 2 - 1319 902 Bushing ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 1879 306 Consists of: 1 - ---- --- Absorber 2 - 1319 902 Bushing ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 1879 307 Consists of: 1 - ---- --- Absorber 2 - 1319 902 Bushing ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 1881 877 Consists of: 1 - ---- --- Absorber 2 - 1319 902 Bushing			

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

1959 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
19-02-6	PIVOT PACKAGE, STEERING GEAR HOUSING, w/o POWER STEERING Part No. E2084 336 Consists of: 1 - 1945 894 Pivot, Housing 1 - 1671 587 Wedge, Housing to Frame 3 - 2122 980 Spacer, Housing to Frame 3 - 272 406 Bolt, Housing		GASKET SET, STD. TRANSMISSION Part No. 1752 479 Consists of: 2 - 865 180 Gasket, Bearing Retainer 1 - 1635 273 Gasket, Case to Adapter 1 - 1853 856 Gasket, Gearshift Housing
19-14-7	BEARING and COLLAR PACKAGE, POWER STEERING GEAR COLUMN JACKET . . . Part No. 1879 708 Consists of: 1 - ---- --- Bearing 1 - ---- --- Collar 1 - ---- --- Spring 2 - ---- --- Washer		GASKET and SEAL PACKAGE, POWERFLITE TRANSMISSION, COMPLETE Part No. *2084 617 Consists of: 1 - 1408 254 Gasket, Extension 1 - 1408 255 Gasket, Output Shaft Support 1 - 1408 282 Gasket, Oil Pan 1 - 1672 066 Gasket, Valve Body 1 - 1117 819 Gasket, Regulator Valve Spring Retainer 1 - 1408 375 Gasket, Torque Converter Valve Spring Retainer 1 - 1316 864 "O" Ring, Control Cable 1 - 1736 376 Ring, Output Shaft Seal 1 - 1738 262 Ring, Clutch Piston Retainer Seal 1 - 1537 149 Ring, Reaction Shaft Seal 1 - 1672 358 Ring, Throttle Cam Shaft Sleeve Seal 1 - 1408 245 Seal, Frt. Oil Pump Housing 1 - 1486 536 Seal, Reaction Shaft 1 - 1738 265 Seal, Reaction Shaft 1 - 1738 263 Seal, Hub 1 - 1738 261 Seal, Direct Clutch Piston Ring 1 - 1671 763 Seal, Output Shaft Rear Bearing 2 - 1401 256 Seal, Oil Strainer Tube 1 - 863 987 Seal, Drain Plug 1 - 1738 264 Seal, Front Oil Pump Drive Sleeve
19-14-10	SUPPORT and INSULATOR PACKAGE, POWER STEERING GEAR COLUMN JACKET . . . Part No. 1879 713 Consists of: 1 - 1850 547 Insulator 1 - ---- --- Support		GASKET SET, AUTO. 3 SPEED TRANSMISSION Part No. 1879 507 Consists of: 1 - 1853 888 Gasket, Shaft Support 1 - 1853 891 Gasket, Extension 1 - 1636 448 Gasket, Oil Pan 1 - 1824 553 Ring, Shaft Seal 1 - 1408 245 Seal, Oil Pump Housing
19-15-2	BALL PACKAGE, POWER STEERING GEAR WORM CONNECTOR Part No. 1450 995 Consists of: 40 - ---- --- Ball		GASKET, PLATE AND DISC PACKAGE, TRANSMISSION COMPLETE OVERHAUL, POWERFLITE Part No. E2240 194 Consists of: 6 - 1633 843 Disc, Clutch Driving 1 - 1117 819 Gasket, Valve Spring Retainer 1 - 1672 066 Gasket, Regulator Valve Body 1 - 1408 254 Gasket, Extension 1 - 1408 255 Gasket, Output Shaft Support 1 - 1408 282 Gasket, Oil Pan 1 - 1408 375 Gasket, Valve Spring Retainer 1 - 1408 232 Plate, Direct Clutch 1 - 1316 864 "O" Ring, Control Cable 1 - 1329 638 Ring, Reverse Servo Piston 1 - 1736 376 Ring, Output Shaft Seal 1 - 863 987 Seal, Drain Plug 2 - 1401 256 Seal, Oil Strainer Tube 1 - 1408 245 Seal, Frt. Oil Pump Housing 1 - 1486 536 Seal, Reaction Shaft 1 - 1671 763 Seal, Output Shaft Bearing Oil 1 - 1738 261 Seal, Direct Clutch Piston Ring (Pkg. Cont'd)
19-15-5	TUBE PACKAGE, POWER STEERING GEAR Part No. 1879 715 Consists of: 2 - 1822 667 Insert 1 - 1822 668 Insulator 1 - ---- --- Tube TUBE PACKAGE, POWER STEERING GEAR Part No. 1879 716 Consists of: 2 - 1822 667 Insert 1 - 1822 668 Insulator 1 - ---- --- Tube		
19-15-39	SPRING PACKAGE, POWER STEERING BALL GUIDE Part No. 2084 215 Consists of: 2 - ---- --- Plug 2 - ---- --- Spring		
19-54-128	FLOW CONTROL VALVE PLUG and SNAP RING PACKAGE, POWER STEERING GEAR PUMP. Part No. 1879 353 Consists of: 1 - ---- --- Plug 1 - ---- --- Ring		
19-57-2	PISTON AND SPRING PACKAGE, HYDRAULIC STEERING GEAR PRESSURE CONTROL VALVE . . . Part No. *1879 509 Consists of: 1 - ---- --- Piston 1 - 1822 442 Spring		
21-01-3	GASKET and SEAL PACKAGE, POWERFLITE TRANSMISSION, PARTIAL Part No. 1603 251 Consists of: 1 - 1408 254 Gasket, Extension 1 - 1408 255 Gasket, Output Shaft Support 1 - 1408 282 Gasket, Oil Pan 1 - 1408 245 Seal, Front Oil Pump Housing 1 - 1486 536 Seal, Reaction Shaft 1 - 1738 265 Seal, Reaction Shaft		

★ Indicates use as required.

⊠ Indicates parts not listed in any previous parts book.
Feb. 15, 1960 Supersedes May 25, 1959.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
(Cont'd)		(Cont'd)	
	1 - 1738 263 Seal, Impeller Hub		1 - 1738 263 Oil Seal, Impeller Hub
	1 - 1738 265 Seal, Reaction Shaft		1 - 1824 553 Ring, Reaction Shaft Seal
	1 - 1638 462 Washer, Carrier Front Thrust		1 - 1408 245 Seal, Frt. Oil Pump Housing
	GASKET AND SEAL PACKAGE, TRANSMISSION COMPLETE OVERHAUL, AUTO. 3 SPEED Part No. E2240 192		1 - 1738 264 Seal, Frt. Oil Pump Drive Sleeve
	Consists of:		GASKET SET, AUTO. 3 SPEED TRANSMISSION REAR OIL PUMP and EXTENSION Part No. 1879 508
	1 - 1117 819 Gasket, Spring Retainer		Consists of:
	1 - 1408 375 Gasket, Spring Retainer		1 - 1853 888 Gasket, Output Shaft Support
	1 - 1636 303 Gasket, Regulator Valve Body		1 - 1853 891 Gasket, Extension
	1 - 1636 448 Gasket, Oil Pan		2 - 1636 470 Ring, Support Seal
	1 - 1672 074 Gasket, Cable Adapter Housing	21-131-1	BODY PACKAGE, POWERFLITE TRANSMISSION REGULATOR VALVE Part No. 1643 243
	1 - 1853 891 Gasket, Extension		Consists of:
	1 - 1853 888 Gasket, Output Shaft Support		1 - ---- --- Body, Regulator Valve
	1 - 1638 667 Plate, Carrier Thrust		1 - 1630 812 Spring, Torque Converter Control Valve
	2 - 1314 249 Ring, Kickdown Piston Seal		1 - 2124 247 Valve, Torque Converter Control
	1 - 1322 363 Ring, Kickdown Piston Seal	21-133-3	GASKET and SEAL PACKAGE, AUTO. 3 SPEED TRANSMISSION FRONT and REAR CLUTCH and INPUT SHAFT Part No. 1843 229
	1 - 1323 593 Ring, Input Shaft Oil Seal		Consists of:
	1 - 1329 638 Ring, Reverse Servo Piston		1 - 1636 448 Gasket, Oil Pan
	2 - 1636 324 Ring, Shaft Seal		1 - 1672 074 Gasket, Cable Adapter Seal, Inner
	2 - 1636 469 Ring, Sun Gear Rr. Clutch Seal		1 - 1824 551 Ring, Frt. Clutch Piston Seal, Inner
	2 - 1636 470 Ring, Governor Support Seal		1 - 1824 549 Ring, Frt. Clutch Piston Seal, Outer
	4 - 1672 287 Ring, Intermediate Shaft Seal		1 - 1323 593 Ring, Input Shaft, Large
	1 - 1736 224 Ring, Kickdown Piston Seal		1 - 1941 831 Ring, Input Shaft, Small
	1 - 1736 233 Ring, Accumulator Piston		1 - 1824 550 Ring, Rear Clutch Piston Seal, Outer
	1 - 1736 376 Ring, Output Shaft Seal		1 - 1824 552 Ring, Rear Clutch Piston Seal, Inner
	1 - 1854 304 Ring, Frt. Oil Pump Drive Sleeve Seal		1 - 1314 249 Ring, Output Shaft Seal, Large
	1 - 1824 549 Ring, Frt. Clutch Piston Seal		1 - 1736 376 Ring, Output Shaft Seal, Small
	1 - 1824 550 Ring, Rear Clutch Piston Seal		2 - 1636 324 Ring, Intermediate Shaft Seal, Small
	1 - 1824 551 Ring, Frt. Clutch Piston Seal		4 - 1672 287 Ring, Intermediate Shaft Seal, Large
	1 - 1824 552 Ring, Rear Clutch Piston Seal		2 - 1636 469 Ring, Rear Clutch Seal
	1 - 1824 553 Ring, Reaction Shaft Seal		2 - 1401 256 Seal, Oil Strainer Tube
	1 - 1941 831 Ring, Input Shaft Oil Seal	21-133-37	PLATE and DISC PACKAGE, POWERFLITE TRANSMISSION DIRECT CLUTCH DRIVING Part No. 1643 259
	2 - 1401 256 Seal, Oil Strainer Tube		Consists of:
	1 - 1408 245 Seal, Frt. Oil Pump Housing		7 - ---- --- Disc
	1 - 1738 263 Seal, Impeller Hub Oil		7 - ---- --- Plate
	1 - 1738 264 Seal, Frt. Oil Pump Drive Sleeve	21-136-31	BAND PACKAGE, POWERFLITE TRANSMISSION REVERSE Part No. 1881 799
	2 - 1636 290 Washer, Frt. Clutch and Sun Gear Thrust		Consists of:
	1 - 1636 314 Washer, Sun Gear Thrust		1 - 1854 170 Band, Reverse
	1 - 1636 376 Washer, Carrier Thrust		1 - 1854 171 Link, Reverse Band
	1 - 1638 669 Washer, Input Shaft Thrust		1 - 1854 172 Strut, Reverse Band
	1 - 1638 670 Washer, Input Shaft Thrust		
	1 - 1638 671 Washer, Input Shaft Thrust		
21-113-24	SWITCH PACKAGE, TRANSMISSION NEUTRAL STARTER . . Part No. 1704 283		
	Consists of:		
	1 - 1316 849 "O" Ring, Mounting		
	1 - ---- --- Switch, Neutral Starter		
	1 - 1704 482 Washer, Mounting		
21-118-1	GASKET SET, AUTO. 3 SPEED TRANSMISSION FRONT OIL PUMP Part No. 1843 230		
	Consists of:		
	1 - 1636 303 Gasket, Regulator Valve Body		
	1 - 1117 819 Gasket, Regulator Valve Spring Retainer		
	1 - 1408 375 Gasket, Torque Converter Control Valve Spring Retainer (Pkg. Cont'd)		

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

1959 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
21-138-2	REPAIR PACKAGE, POWERFLITE TRANSMISSION GOVERNOR Part No. 1653 464 Consists of: 1 - ---- --- Body, Governor 1 - 1329 702 Ring, Weight 2 - 1638 461 Ring, Shaft 1 - 1630 708 Ring, Outer Weight 1 - 1556 082 Shaft, Valve 1 - 1736 468 Screw, Locating 1 - 1559 498 Spring, Weight 1 - 1315 155 Valve, Governor 1 - 1559 501 Weight, Governor, Outer 1 - 1559 502 Weight, Governor, Inner 1 - 1559 503 Weight, Governor, Intermediate	21-139-94	VALVE PACKAGE, SHUTTLE POWERFLITE TRANSMISSION Part No. *1643 118 Consists of: 1 - ---- --- Plug, Shuttle Valve 1 - ---- --- Ring, Shuttle Valve Stop 1 - ---- --- Screw, Plug Adjusting 1 - ---- --- Spring, Shuttle Valve 1 - ---- --- Valve, Shuttle
	REPAIR PACKAGE, POWERFLITE TRANSMISSION GOVERNOR Part No. 1653 463 Consists of: 1 - ---- --- Body, Governor 1 - 1329 702 Ring, Weight 1 - 1559 495 Ring, Weight 1 - 1736 468 Screw, Locating 1 - 1556 082 Shaft, Valve 2 - 1638 461 Snap Ring, Shaft 1 - 1559 498 Spring, Weight 1 - 1315 155 Valve, Governor 1 - 1559 494 Weight, Governor, Outer 1 - 1559 496 Weight, Governor Intermediate 1 - 1559 497 Weight, Governor, Inner	23-06-19	PLATE PACKAGE, GLOVE BOX DOOR OWNER IDENTIFICATION Part No. 1902 323 Consists of: 2 - ---- --- Nuts 1 - ---- --- Plate 1 - ---- --- Template
	REPAIR PACKAGE, AUTO. 3 SPEED TRANSMISSION GOVERNOR Part No. 1752 684 Consists of: 1 - ---- --- Body, Governor 1 - 1736 468 Screw, Locating 1 - 1556 082 Shaft, Valve 1 - 1636 463 Spring, Weight 1 - 1636 464 Snap Ring, Inner Weight 1 - 1636 465 Snap Ring, Outer Weight 2 - 1638 461 Snap Ring, Valve Shaft 1 - 1736 424 Valve, Governor 1 - 1636 461 Weight, Governor, Outer 1 - 1636 462 Weight, Governor, Inner	23-14-53	HANDLE PACKAGE, DOOR VENT WING, RIGHT Part No. 1833 481 Consists of: 1 - ---- --- Button 1 - ---- --- Handle 1 - ---- --- Pin 1 - ---- --- Spring 1 - ---- --- Washer HANDLE PACKAGE, DOOR VENT WING, RIGHT Part No. 1833 503 Consists of: 1 - ---- --- Handle 1 - ---- --- Key 1 - ---- --- Pin 1 - ---- --- Spring 1 - ---- --- Washer HANDLE PACKAGE, DOOR VENT WING, LEFT Part No. 1833 674 Consists of: 1 - ---- --- Handle 1 - ---- --- Key 1 - ---- --- Pin 1 - ---- --- Spring 1 - ---- --- Washer HANDLE PACKAGE, FRONT VENT WING, LEFT Part No. 1833 675 Consists of: 1 - ---- --- Button 1 - ---- --- Handle 1 - ---- --- Pin 1 - ---- --- Spring 1 - ---- --- Washer
	REPAIR PACKAGE, AUTO. 3 SPEED TRANSMISSION GOVERNOR Part No. 1843 499 Consists of: 1 - ---- --- Body, Governor 1 - 1736 468 Screw, Locating 1 - 1556 082 Shaft, Valve 1 - 1636 464 Snap Ring, Inner Weight 1 - 1636 465 Snap Ring, Outer Weight 2 - 1638 461 Snap Ring, Valve Shaft 1 - 1823 709 Spring, Weight 1 - 1736 424 Valve, Governor 1 - 1823 726 Weight, Governor, Outer 1 - 1636 462 Weight, Governor, Inner	23-17-2	CYLINDER and KEYS PACKAGE, DOOR and IGNITION LOCK Part No. 1698 638 Consists of: 1 - ---- --- Cylinder, Door, Right 1 - ---- --- Cylinder, Door, Left 1 - ---- --- Cylinder, Ignition 2 - ---- --- Keys CYLINDER and KEYS PACKAGE, DOOR and IGNITION LOCK Part No. 1698 668 Consists of: 1 - ---- --- Cylinder, Door, Right 1 - ---- --- Cylinder, Door, Left 1 - ---- --- Cylinder, Ignition 2 - ---- --- Keys CYLINDER and KEYS PACKAGE, DOOR and IGNITION LOCK Part No. 1698 986 Consists of: 1 - ---- --- Cylinder, Door, Right 1 - ---- --- Cylinder, Door, Left 1 - ---- --- Cylinder, Ignition 2 - ---- --- Keys
21-139-28	VALVE AND SPRING PACKAGE, POWERFLITE TRANSMISSION THROTTLE Part No. *1879 506 Consists of: 1 - ---- --- Valve, Throttle 1 - ---- --- Spring, Throttle Valve		

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.
 Feb. 15, 1960 Supersedes May 25, 1959.

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
23-17-5	CYLINDER and KEYS PACKAGE, DECK LID LOCK Part No. 1698 992 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys	23-21-3	MIRROR PACKAGE, REAR VIEW INSIDE MIRROR MATIC Part No. *2161 079 Consists of: 1 - ---- --- Cable 1 - ---- --- Instruction Sheet 1 - ---- --- Mirror 1 - ---- --- Terminal
	CYLINDER and KEYS PACKAGE, DECK LID LOCK Part No. 1839 604 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys		MIRROR PACKAGE, REAR VIEW INSIDE REMOTE CONTROL . . Part No. B2084 545 Consists of: 1 - ---- --- Bracket 1 - ---- --- Instruction Sheet 1 - ---- --- Mirror 4 - ---- --- Screws
	CYLINDER and KEYS PACKAGE, DECK LID LOCK Part No. 1900 388 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys	23-34-261	HINGE and SPRING PACKAGE, QUARTER PANEL FUEL TANK OPENING COVER Part No. 1879 538 Consists of: 1 - ---- --- Hinge, Assembly 1 - 1707 504 Spring
23-17-24	CYLINDER and KEYS PACKAGE, DOOR LOCK, RIGHT . . Part No. 1698 988 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys	23-34-333	ORNAMENT PACKAGE, QUARTER PANEL OUTSIDE Part No. 1881 868 Consists of: 1 - 1954 062 Ornament, Right 1 - 1954 063 Ornament, Left 10 - 6006 215 Nut and Washer 1 - 1909 344 Moulding, Lower End, Right 1 - 1909 345 Moulding, Lower End, Left 4 - 168 904 Screw, 10 - 32 x 3/4" 2 - ---- --- Nut and Washer, 10-24 2 - 9411 584 Screw, 10 - 24 x 3/8" 2 - ---- --- Washer, No. 10 2 - ---- --- Sealing/washer 2 - 443 868 Screw, 10 - 24 x 1/2" 1 - ---- --- Instruction Sheet
	CYLINDER and KEYS PACKAGE, DOOR LOCK, LEFT . . Part No. 1698 989 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys	23-47-414	COIL PACKAGE, ELECTRIC SEAT ADJUSTER SOLENOID Part No. 1830 290 Consists of: 1 - ---- --- Cap 1 - ---- --- Coil 1 - ---- --- Cover
	CYLINDER and KEYS PACKAGE, DOOR LOCK, RIGHT . . Part No. 1698 990 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys	23-58-381	ROTOR PACKAGE, FOLDING TOP LIFT PUMP Part No. 1641 650 Consists of: 1 - ---- --- Rotor, Inner 1 - ---- --- Rotor, Outer
	CYLINDER and KEYS PACKAGE, DOOR LOCK, LEFT . . Part No. 1698 991 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys	23-67-10	GEAR and GASKET PACKAGE, WINDSHIELD WIPER MOTOR, for SINGLE SPEED AUTOLITE MOTORS Part No. 1879 601 Consists of: 1 - 1605 572 Gasket 1 - 1594 973 Gear
	CYLINDER and KEYS PACKAGE, DOOR LOCK, RIGHT . . Part No. 1772 432 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys		GEAR and GASKET PACKAGE, WINDSHIELD WIPER MOTOR, for VARIABLE SPEED WIPERS Part No. 1879 598 Consists of: 1 - 1752 513 Gasket 1 - 1818 685 Gear
	CYLINDER and KEYS PACKAGE, DOOR LOCK, LEFT . . Part No. 1772 433 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys		
23-17-49	CYLINDER and KEYS PACKAGE, TAILGATE LOCK Part No. 1819 404 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys		
	CYLINDER and KEYS PACKAGE, TAILGATE LOCK Part No. 1830 041 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys		
23-17-72	CYLINDER and KEYS PACKAGE, TIRE WELL COVER LOCK Part No. 1830 044 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys		
23-18-120	TERMINAL and INSULATOR PACKAGE, ELECTRIC DOOR LOCK SOLENOID Part No. 1843 226 Consists of: 10 - ---- --- Insulators 10 - ---- --- Terminals, Female 10 - ---- --- Terminals, Male		

★ Indicates use as required.

□ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

1959 PASSENGER CAR PARTS LIST

CODE	PART NAME AND PART NUMBER	CODE	PART NAME AND PART NUMBER
23-67-164	SWITCH CONTACT, END PLATE and GASKET PACKAGE, WINDSHIELD WIPER MOTOR, for SINGLE SPEED AUTOLITE MOTORS Part No. 1879 602 Consists of: 1 - 1818 890 Contact and Plate 1 - 1605 572 Gasket	24-25-162	HOUSING PACKAGE, CRANKSHAFT BEARING Part No.E2196 315 Consists of: 1 - ---- Housing, Crankshaft Bearing 1 - ---- Seal, Bearing Housing
	SWITCH, END PLATE, and GASKET PACKAGE, WINDSHIELD WIPER MOTOR, for VARIABLE SPEED MOTORS. Part No. 1879 599 Consists of: 1 - 1752 513 Gasket 1 - ---- Switch and Plate		HOUSING PACKAGE, CRANKSHAFT BEARING Part No.E2196 303 Consists of: 1 - ---- Housing, Crankshaft Bearing 1 - 1377 831 Seal, Bearing Housing 1 - 1377 832 Seal, Seal Seat
24-25-2	PISTON RING PACKAGE, COMPRESSOR Part No.E2196 301 Consists of: 1 - 1377 904 Gasket, Cylinder Head 1 - 1378 313 Gasket, Valve Plate 1 - 1377 825 Gasket, Oil Pump 1 - ---- Ring, Piston	24-25-246	PUMP PACKAGE, COMPRESSOR OIL . . . Part No.E2196 306 Consists of: 1 - ---- Cover, Oil Pump 1 - 1747 988 Seal, Oil Pump Cover 1 - ---- Rotor, Oil Pump Inner 1 - ---- Rotor, Oil Pump Outer 1 - ---- Shaft, Oil Pump Drive
24-25-3	PISTON AND CONNECTING ROD PACKAGE, COMPRESSOR Part No.*1426 500 Consists of: 1 - ---- Ball, Oil Pressure Relief 1 - 1377 904 Gasket, Cylinder Head 1 - 1377 825 Gasket, Oil Sump 1 - 1378 313 Gasket 1 - ---- Piston and Rod 1 - ---- Spring, Oil Pressure		PUMP PACKAGE, COMPRESSOR OIL . . . Part No.E2196 302 Consists of: 1 - ---- Cover, Oil Pump 1 - 1747 988 Seal, Oil Pump Cover 1 - ---- Rotor, Oil Pump 1 - ---- Rotor, Oil Pump 1 - ---- Shaft, Oil Pump Drive
	PISTON PACKAGE Part No.E1818 922 Consists of: 1 - ---- Bearing, Connecting Rod 1 - 1377 825 Gasket, Oil Sump 1 - ---- Pin, Piston 1 - ---- Piston 1 - ---- Retainer, Piston Pin 1 - ---- Ring, Piston 1 - ---- Rod, Connecting	24-25-249	BALL PACKAGE, OIL PUMP RELIEF VALVE Part No.*1843 474 Consists of: 1 - ---- Ball, Relief Valve 1 - 1982 508 Gasket, Discharge Service Valve 1 - 1377 825 Gasket, Oil Sump 1 - 1378 081 Gasket, Suction Service Valve 1 - ---- Plug, Oil Pump Pressure 1 - 1378 318 Spring, Relief Valve
24-25-70	SEAL PACKAGE, COMPRESSOR CRANKSHAFT Part No.*1426 501 Consists of: 1 - ---- Seal, Compressor Crankshaft 1 - 1377 831 Seal, Crankshaft Bearing Housing	24-28-27	HOUSING PACKAGE, EVAPORATOR Part No.E2096 665 Consists of: 1 - ---- Grommet, Tube 1 - ---- Housing, Evaporator 2 - ---- Nut 1 - ---- Retainer, Grommet 2 - ---- Screw
	SEAL PACKAGE, COMPRESSOR CRANKSHAFT Part No.*1734 836 Consists of: 4 - 1015 859 Bolt, Seal Seat 1 - 1730 504 Seal, Oil 1 - 1377 832 Seal, Seal Seat 1 - 1377 831 Seal, Bearing Housing	25-01-3	COMPRESSOR, CYLINDER HEAD and GASKET PACKAGE, AIR SUSPENSION Part No. 1944 593 Consists of: 1 - 1944 574 Gasket, Cylinder Head 1 - 1944 595 Gasket, Valve Plate 1 - ---- Head, Cylinder
24-25-93	PLATE PACKAGE, COMPRESSOR VALVE Part No.*1734 837 Consists of: 1 - 1377 904 Gasket, Cylinder Head 1 - 1378 313 Gasket, Valve Plate 1 - ---- Plate, Valve 1 - ---- Valve, Suction	25-01-5	COMPRESSOR, VALVE PLATE and GASKET PACKAGE, AIR SUSPENSION Part No. 1944 596 Consists of: 1 - 1944 574 Gasket, Cylinder Head 1 - 1944 595 Gasket, Valve Plate 1 - ---- Plate, Valve
24-25-154	CRANKSHAFT PACKAGE Part No.E2196 304 Consists of: 1 - ---- Crankshaft 2 - 1377 904 Gasket, Cylinder Head 1 - 1377 825 Gasket, Oil Sump 2 - 1378 313 Gasket, Valve Plate 1 - 1377 831 Seal, Bearing Housing 1 - ---- Seal, Crankshaft Gas 1 - ---- Washer, Crankshaft Thrust		

★ Indicates use as required.

⊠ Indicates parts not listed in any previous parts book.

Feb. 15, 1960 Supersedes May 25, 1959.

