

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|------|---------------------------|------|---------------------------|
|------|---------------------------|------|---------------------------|

PARTS PACKAGES

1-01-1 GUARD PACKAGE, FRONT
 BUMPER TIE BAR . . . Part No. 2240 382
 Consists of:
 2 - 180 147 Bolt
 2 - 120 383 Lockwasher
 2 - 271 501 Nut
 2 - 120 395 Plainwasher
 1 - ---- Tie Bar
 BUMPER TIE BAR . . . Part No.*2196 449
 Consists of:
 2 - ---- Bolt
 2 - 2074 235 Guard
 2 - 120 382 Washer, Lock
 2 - 120 394 Washer

1-06-1 FLASHER PACKAGE,
 EMERGENCY Part No. 2256 968
 Consists of:
 1 - 2097 161 Bracket, Switch
 1 - ---- Flasher
 1 - ---- Screw
 1 - 220 480 Screw
 1 - ---- Washer and Nut

FLASHER PACKAGE
 EMERGENCY Part No.*2097 278
 Consists of:
 1 - ---- Bracket, Mounting
 1 - ---- Nut
 1 - 133 781 Screw
 1 - ---- Screw
 1 - ---- Wiring

LAMP PACKAGE, HAND
 BRAKE SIGNAL Part No. 2076 719
 Consists of:
 1 - ---- Bracket, Lamp Switch
 1 - 142 453 Bulb, Lamp
 1 - ---- Lamp, Indicator
 1 - ---- Nut, Lamp Mounting
 1 - 9414 586 Screw, Bracket Mounting
 1 - ---- Socket and Cables
 1 - 1972 426 Switch

LAMP PACKAGE, HAND
 BRAKE SIGNAL Part No.*2096 797
 Consists of:
 1 - ---- Bracket
 1 - 127 934 Bulb
 1 - 2096 529 Lamp
 1 - ---- Socket and Cable
 1 - 1971 931 Switch

1-10-1 LAMP PACKAGE,
 BACK-UP Part No. 2076 724
 Consists of:
 2 - 142 454 Bulb
 1 - 2188 664 Lamp, Right
 1 - 2188 665 Lamp, Left
 2 - ---- Screw, Switch Mounting
 4 - 9414 111 Screw, Lamp Mounting
 2 - 2198 388 Socket
 1 - ---- Switch

LAMP PACKAGE,
 BACK-UP Part No. 2257 286
 Consists of:
 2 - 151 576 Bulb
 1 - 1302 807 Gasket, Switch
 1 - 2094 338 Lamp, Right

(Pkg. Cont'd)

(Cont'd)

1 - 2094 339 Lamp, Left
 4 - 134 530 Nut
 2 - 6006 464 Washer, Cup
 1 - ---- Wiring, Switch
 1 - ---- Wiring, Lamp
 1 - 1343 998 Switch

LAMP PACKAGE,
 BACK-UP Part No. 2257 287
 Consists of:
 1 - 1676 629 Activator, Switch
 2 - 151 576 Bulb
 1 - 2094 338 Lamp, Right
 1 - 2094 339 Lamp, Left
 4 - 134 530 Nut
 2 - ---- Rivet
 1 - 1972 052 Switch
 2 - 6006 464 Washer, Cup
 1 - ---- Wiring, Lamp
 1 - ---- Wiring, Switch

LAMP PACKAGE,
 BACK-UP Part No. 2257 288
 Consists of:
 2 - 151 576 Bulb
 1 - 1302 807 Gasket
 2 - ---- Socket and Cable
 1 - 1343 998 Switch
 1 - ---- Wiring, Lamp
 1 - ---- Wiring, Switch

LAMP PACKAGE,
 BACK-UP Part No. 2257 289
 Consists of:
 1 - 1676 629 Activator, Switch
 2 - 151 576 Bulb
 2 - ---- Rivet
 2 - ---- Socket and Cable
 1 - 1972 052 Switch
 1 - ---- Wiring, Lamp
 1 - ---- Wiring, Switch

LAMP PACKAGE,
 BACK-UP Part No. 2257 586
 Consists of:
 2 - 142 454 Bulb
 1 - 1302 807 Gasket, Switch
 1 - 2188 664 Lamp, Right
 1 - 2188 665 Lamp, Left
 4 - 9414 111 Screw
 2 - 2198 388 Socket, Lamp
 1 - 1343 998 Switch
 1 - ---- Wiring, Lamp
 1 - ---- Wiring, Switch

LAMP PACKAGE,
 BACK-UP Part No. 2257 701
 Consists of:
 2 - 142 454 Bulb
 1 - 1302 807 Gasket, Switch
 1 - 2188 664 Lamp, Right
 1 - 2188 665 Lamp, Left
 4 - 9414 111 Screw
 2 - 2198 388 Socket, Lamp
 1 - 1343 998 Switch
 1 - ---- Wiring, Switch

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|----------|---|----------|--|
| (Cont'd) | LAMP PACKAGE BACK-UP Part No. 2290 106 Consists of: 2 - 151 576 Bulb 1 - 1302 807 Gasket 1 - ---- Switch 1 - ---- Wiring | (Cont'd) | 2 - 142 453 Bulb 2 - 161 895 Screw 1 - ---- Socket, w/Wires 2 - ---- Speed Nut 2 - 1972 329 Switch |
| 1-10-1 | LAMP PACKAGE, BACK-UP Part No. *2076 723 Consists of: 1 - ---- Bracket, w/Switch 2 - 142 454 Bulb 1 - 2188 664 Lamp, Rt. 1 - 2188 665 Lamp, Lt. 4 - ---- Screw 2 - 172 335 Screw, Mounting 1 - 2198 388 Socket 1 - ---- Wiring | 1-19-1 | LAMP PACKAGE, GLOVE COMPARTMENT Part No. 2096 926 Consists of: 1 - 131 282 Bulb 1 - ---- Socket and Switch |
| 1-12-1 | CIGAR LIGHTER PACKAGE Part No. *2076 538 Consists of: 1 - ---- Cable, Feed 1 - ---- Knob, w/Element 1 - 2096 599 Shell, w/Clamp | 1-21-1 | CLOCK PACKAGE, INSTRUMENT PANEL. . . Part No. 2257 404 Consists of: 1 - 152 240 Bulb 1 - ---- Clock 1 - ---- Wiring, Clock Feed |
| 1-13-1 | LAMP PACKAGE, UNDERHOOD Part No. 1972 690 Consists of: 1 - ---- Bracket 1 - 151 578 Bulb 1 - ---- Lamp 2 - ---- Screw LAMP PACKAGE, UNDERHOOD Part No. 2076 445 Consists of: 1 - 151 578 Bulb 1 - ---- Bracket, Switch 3 - 444 267 Screw 1 - ---- Socket and Bracket 1 - 1972 426 Switch LAMP PACKAGE, UNDERHOOD Part No. 2258 799 Consists of: 1 - 151 578 Bulb 1 - ---- Grommet 1 - ---- Lamp 1 - ---- Switch and Bracket 1 - ---- Terminal | 1-30-1 | LAMP PACKAGE, TRUNK COMPARTMENT Part No. 2076 451 Consists of: 1 - 151 578 Bulb 1 - ---- Lamp 2 - 444 267 Screw, Mounting 1 - ---- Switch |
| 1-14-4 | LAMP PACKAGE, MAP . . . Part No. 2257 726 Consists of: 1 - 1887 789 Bezel 1 - 151 578 Bulb 1 - 1887 955 Housing and Lens 1 - 2257 478 Knob, Switch 1 - ---- Socket and Cables 2 - ---- Screw 1 - 2257 691 Switch | 1-44-1 | BRAKE SELF ADJUSTING PACKAGE Part No. *2275 430 Consists of: 4 - ---- Cable 4 - ---- Guide, Cable 2 - ---- Lever 2 - ---- Lever 2 - ---- Nut 2 - ---- Nut 2 - ---- Screw, Adjusting 2 - ---- Screw, Adjusting 4 - ---- Socket 4 - ---- Spring, Lever Return |
| 1-14-40 | COURTESY LIGHT PACKAGE Part No. *2258 507 Consists of: 2 - ---- Bracket 2 - 142 453 Bulb 2 - 161 895 Screw 1 - ---- Socket, w/Wires 2 - ---- Speed Nut COURTESY LIGHT PACKAGE Part No. *2096 386 Consists of: 2 - ---- Bracket | 1-48-1 | HEATER PACKAGE Part No. 2219 291 Consists of: 1 - ---- Bracket 1 - 127 934 Bulb 1 - ---- Cable, Switch Feed 1 - ---- Cable and Housing 6 - 870 469 Clamp, Hose 1 - ---- Clip 1 - 6015 143 Clip 1 - ---- Clip 1 - ---- Clip 1 - ---- Clip, Hose Mounting 1 - ---- Clip, Hose Mounting 1 - ---- Clip, Hose Mounting 1 - ---- Controls, Instrument Panel 1 - ---- Deflector, Fresh Air 1 - ---- Duct, Distribution 1 - ---- Hose 1 - 2197 011 Hose 1 - ---- Hose, Valve to Heater 1 - ---- Hose and Connector 1 - ---- Housing and Core 1 - 1971 061 Nipple, Inlet 1 - 1971 061 Nipple, Return 1 - 1971 841 Nozzle, Defroster, Right 1 - 1971 842 Nozzle, Defroster, Left 4 - ---- Nut, w/Washer, Nozzle 1 - 1622 064 Plug 14 - 274 888 Screw, Housing 3 - 9416 053 Screw, Duct Mounting 2 - ---- Screw, Valve 2 - ---- Screw, Bracket |

(Pkg. Cont'd)

(Pkg. Cont'd)

★ Indicates use as required.

⊠ Indicates parts not listed in any previous parts book.
March 1, 1962 Supersedes May 31, 1961.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|----------|--|----------|---|
| (Cont'd) | | (Cont'd) | |
| | 1 - ---- --- Screw, Bracket | | 1 - 2076 389 Seal, Duct to Dash |
| | 1 - ---- --- Seal, Duct Inlet | | 3 - ---- --- Spacer, Duct Mounting |
| | 1 - ---- --- Socket and Cable, Controls | | 1 - ---- --- Tube, Defroster Duct |
| | 1 - ---- --- Spacer, Duct Mounting | | 1 - 2076 532 Tube, Defroster Duct |
| | 1 - ---- --- Tube, Defroster, Right | | 1 - 2074 934 Valve, Vacuum Check |
| | 1 - 2096 989 Tube, Defroster, Left | | 1 - ---- --- Wiring, Switch to Motor |
| | 1 - ---- --- Valve, Control | | |
| | 2 - ---- --- Washer, Valve Mounting | | |
| | HEATER PACKAGE . . . Part No. 2219 294 | 1-48-137 | DEFROSTER PACKAGE, REAR WINDOW Part No. 2076 552 |
| | Consists of: | | Consists of: |
| | 1 - 1829 748 Cable and Housing | | 1 - 1819 014 Bezel, Inlet |
| | 6 - 870 469 Clamp, Hose | | 1 - ---- --- Blower |
| | 1 - ---- --- Clip, Tube Retainer | | 1 - ---- --- Duct and Seal |
| | 1 - 6015 143 Clip, Cable Mounting | | 1 - ---- --- Grille and Gasket |
| | 1 - ---- --- Clip, Hose Mounting | | 1 - 1971 091 Grille, Inlet |
| | 1 - ---- --- Clip, Bracket | | 3 - ---- --- Lockwasher |
| | 1 - ---- --- Clip, Cable Retainer | | 7 - ---- --- Nut, w/Washer |
| | 1 - ---- --- Clip, Vacuum Hose | | 1 - 1887 582 Plate |
| | 1 - 2097 095 Controls, Instrument Panel | | 1 - ---- --- Screw, Duct Mounting |
| | 1 - 2197 768 Deflector, Fresh Air | | 3 - ---- --- Screw, Plate to Blower |
| | 1 - ---- --- Duct, Distribution | | 1 - 1972 596 Switch |
| | 1 - 106 653 Fuse, Wiring | | 1 - ---- --- Wiring, Front |
| | 1 - ---- --- Hose | | 1 - ---- --- Wiring, Rear |
| | 1 - ---- --- Hose | 1-48-299 | DEFROSTER SWITCH PACKAGE, REAR |
| | 1 - ---- --- Hose | | WINDOW Part No.*2197 442 |
| | 1 - 2257 197 Hose and Connector | | Consists of: |
| | 1 - ---- --- Housing and Core | | 1 - 2097 388 Bezel |
| | 1 - 1971 061 Nipple, Inlet | | 1 - 1887 591 Knob |
| | 1 - 1971 061 Nipple, Return | | 1 - 1887 603 Nut |
| | 1 - 1971 836 Nozzle, Defroster | | 1 - 1972 772 Switch |
| | 1 - 1971 693 Nozzle, Defroster | 1-50-1 | SWITCH PACKAGE, ELECTRIC WINDOW |
| | 4 - ---- --- Nut, w/Washer, Nozzle | | LIFT SAFETY Part No. 2197 405 |
| | 1 - 1622 064 Plug | | Consists of: |
| | 14 - 274 888 Screw, Housing Mounting | | 3 - 1264 933 Sleeve |
| | 3 - 9416 053 Screw, Duct Mounting | | 1 - 2197 404 Switch |
| | 2 - ---- --- Screw, Valve Mounting | | 4 - 903 895 Terminal |
| | 1 - ---- --- Screw, Fresh Air Deflector | | 1 - ---- --- Terminal |
| | 2 - ---- --- Screw, Vacuum Hose | | 2 - ---- --- Terminal |
| | 1 - 1887 757 Seal, Duct Inlet | | 1 - 1786 009 Wire, 48" Long |
| | 1 - ---- --- Spacer, Duct Mounting | | 1 - 1345 871 Connector |
| | 1 - ---- --- Tube, Defroster, Right | 1-76-1 | MIRROR PACKAGE, OUTSIDE REAR VIEW, REMOTE CONTROL . . . Part No. 2275 014 |
| | 1 - 2096 989 Tube, Defroster, Left | | Consists of: |
| | 1 - ---- --- Valve, Control | | 1 - 2161 931 Anti-Squeak |
| | 2 - ---- --- Washer, Valve Mounting | | 1 - 2161 932 Anti-Squeak |
| | HEATER PACKAGE . . . Part No. 2219 852 | | 1 - ---- --- Bracket |
| | Consists of: | | 1 - ---- --- Mirror, w/Remote Control |
| | 1 - ---- --- Cable | | 1 - 2080 541 Nut |
| | 1 - ---- --- Cable and Housing | | 2 - ---- --- Screw, Tapping |
| | 1 - ---- --- Clamp, Valve Cover | | 2 - 9411 860 Screw |
| | 4 - 870 469 Clamp, Hose | | MIRROR PACKAGE, OUTSIDE REAR VIEW . . Part No. 2275 015 |
| | 1 - 6015 143 Clip, Cable Mounting | | Consists of: |
| | 1 - 1858 955 Connector, Vacuum Control | | 1 - ---- --- Anti-Squeak |
| | 1 - 2209 029 Controls, Instrument Panel | | 1 - ---- --- Anti-Squeak |
| | 1 - 2209 323 Control Tubes and Connector | | 1 - ---- --- Mirror |
| | 1 - ---- --- Duct Distribution | | 2 - 274 791 Screw |
| | 1 - 2209 038 Face Plate, Push Button | | MIRROR PACKAGE, OUTSIDE REAR VIEW . . Part No. 2275 020 |
| | 1 - 2076 322 Gasket, Housing to Dash | | Consists of: |
| | 1 - 2076 217 Gasket, Face Plate | | 1 - 2161 931 Anti-Squeak |
| | 1 - ---- --- Hose, to Pump | | 1 - 2161 932 Anti-Squeak |
| | 1 - ---- --- Hose, to Valve | | 1 - ---- --- Mirror |
| | 1 - ---- --- Housing and Core | | 2 - 274 791 Screws |
| | 1 - 2209 042 Knob, Temperature Control | | |
| | 1 - 1971 061 Nipple, Hose Inlet | | |
| | 3 - ---- --- Screw, Control Mounting | | |
| | 3 - ---- --- Screw, Duct Mounting | | |
| | 10 - 274 888 Screw, Housing Mounting | | |
| | (Pkg. Cont'd) | | |

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|--------|---|---|--|
| 1-76-3 | MIRROR PACKAGE, INSIDE REAR VIEW. . . Part No. 2161 079 Consists of: 1 - ---- --- Feed Cable 1 - ---- --- Mirror-Matic 1 - ---- --- Terminal | (Cont'd) | 1 - 1971 239 Collar 1 - 1971 238 Gasket 1 - ---- --- Nut, Cap 1 - 1658 328 Nut, Hex 1 - ---- --- Screw |
| 1-82-2 | WASHER PACKAGE, WINDSHIELD Part No. 2257 692 Consists of: 1 - ---- --- Bracket, Reservoir 1 - 1838 001 Cap 1 - 1880 222 Check Valve 1 - 1838 000 Clip, Valve Mounting 2 - ---- --- Clip, Nozzle 1 - ---- --- Hose, Tee to Nozzle 1 - ---- --- Hose, Tee to Nozzle 1 - ---- --- Hose, Check Valve to Tee 1 - ---- --- Hose, Check Valve to Pump 1 - ---- --- Hose, Check Valve to Reservoir 1 - 138 557 L/Washer 1 - ---- --- Nut, Pump Mounting 1 - 2198 211 Nozzle 1 - 1887 148 Pump 1 - 1972 368 Reservoir 2 - 444 267 Screw, Reservoir Mounting 1 - 444 267 Screw, Check Valve 1 - 1571 028 Strainer 1 - 1523 160 Tee | ANTENNA PACKAGE, RADIO Part No. 2198 229 Consists of: 1 - 2198 127 Adapter, Upper, Right 1 - 2198 292 Adapter, Upper, Left 1 - 2198 128 Adapter, Lower, Right 1 - 2198 293 Adapter, Lower, Left 1 - ---- --- Body and Mast, Right 1 - ---- --- Body and Mast, Left 1 - ---- --- Clip, Antenna Lead 1 - 2198 134 Collar, Grounding 2 - 2198 133 Gasket, Upper Adapter 2 - ---- --- Gasket, Dome Nut 2 - ---- --- Nut, Cap 2 - 1658 328 Nut, Hex 1 - 1779 072 Y-Connector and Lead-In Wire | |
| 1-87-2 | RADIO SPEAKER PACKAGE, REAR SHELF Part No. 2198 514 Consists of: 1 - ---- --- Bezel 1 - ---- --- Grille 4 - 120 614 Nut, Speaker Mounting 1 - ---- --- Speaker and Cover 1 - ---- --- Wiring, Speaker | ANTENNA PACKAGE, RADIO Part No. 2198 530 Consists of: 1 - 2198 519 Adapter, Mounting, Upper 1 - 2198 521 Adapter, Mounting, Lower 1 - ---- --- Body, Mast and Shield 1 - 2198 134 Collar, Grounding 1 - 2097 550 Extension, Lead-In 1 - 2198 523 Gasket, Upper Adapter 1 - ---- --- Gasket, Dome Nut 1 - ---- --- Nut, Cap 1 - 1658 328 Nut, Hex | |
| | RADIO SPEAKER PACKAGE, REAR SHELF Part No. 2198 515 Consists of: 1 - ---- --- Bezel 1 - ---- --- Cable 1 - ---- --- Cable 1 - ---- --- Grille 1 - 1971 644 Knob 1 - ---- --- Plate, Name 1 - ---- --- Nut, Switch 4 - ---- --- Nut, Speaker 1 - ---- --- Speaker and Cover | ANTENNA, PACKAGE, RADIO FRONT Part No. *2076 578 Consists of: 1 - 2076 250 Adapter, Mounting 1 - ---- --- Body, w/Lead 1 - 2096 052 Cap, Nut Mounting 1 - 2076 249 Collar, Adapter 1 - 2076 251 Gasket, Adapter | |
| 1-88-1 | ANTENNA PACKAGE, RADIO Part No. 2197 180 Consists of: 1 - 2197 181 Adapter, Upper 1 - 2197 182 Adapter, Lower 1 - 1886 713 Antenna 1 - 2197 870 Collar 1 - 2197 448 Gasket 1 - ---- --- Nut, Cap 1 - 1658 328 Nut, Hex | ANTENNA PACKAGE, RADIO Part No. 2198 532 Consists of: 1 - 2198 520 Adapter, Upper 1 - 2198 522 Adapter, Lower 1 - ---- --- Body, Mast and Shield 1 - 2198 134 Collar, Grounding 1 - 2097 550 Extension, Lead-In 1 - ---- --- Gasket, Dome Nut 1 - 2198 524 Gasket, Upper Adapter 1 - ---- --- Nut, Cap 1 - 1658 328 Nut, Hex | |
| | ANTENNA PACKAGE, RADIO Part No. 2197 641 Consists of: 1 - 1971 242 Adapter, Upper 1 - 1971 241 Adapter, Lower 1 - 1886 713 Body and Mast 1 - ---- --- Cover | ANTENNA PACKAGE, RADIO Part No. 2198 737 Consists of: 1 - 1838 162 Body and Mast, Rear Right 1 - 1838 163 Body and Mast, Rear Left 4 - ---- --- Clip 4 - ---- --- Cup, Washer 2 - 1841 057 Gasket 4 - ---- --- Nut and Washer 1 - 1779 072 Y-Connector and Lead-In Wire | |

(Pkg. Cont'd)

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.
 March 1, 1962 Supersedes May 31, 1961.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|---------|--|----------|---|
| 1-135-1 | DOOR EDGE PROTECTOR PACKAGE Part No.*1964 380 Consists of: 14 - - - - - Clip, Moulding 1 - - - - - Strip, Frt. Door, Rt. 1 - - - - - Strip, Frt. Door, Lt. 1 - - - - - Strip, Rr. Door, Rt. 1 - - - - - Strip, Rr. Door, Lt. | (Cont'd) | 1 - - - - - Clamp, Tie Rod End 1 - - - - - End, Tie Rod Inner 1 - - - - - Nipple, Lubricant 1 - - - - - Nut, Tie Rod End 1 - - - - - Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter |
| | DOOR EDGE PROTECTOR PACKAGE Part No.*1964 515 Consists of: 8 - - - - - Clip, Moulding 1 - - - - - Strip, Rt. 1 - - - - - Strip, Lt. | | END PACKAGE, TIE ROD OUTER Part No. 2084 352 Consists of: 1 - - - - - Bolt, Tie Rod End Clamp 1 - - - - - Clamp, Tie Rod End 1 - - - - - End, Tie Rod Outer 1 - - - - - Nipple, Lubricant 1 - - - - - Nut, Tie Rod End 1 - - - - - Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter 1 - 1735 470 Seal, Tie Rod End Dust 1 - - - - - Spacer, Tie Rod End Ball |
| | DOOR EDGE PROTECTOR PACKAGE Part No.*2094 921 Consists of: 14 - - - - - Clip, Moulding 1 - - - - - Strip, Frt. Door, Rt. 1 - - - - - Strip, Frt. Door, Lt. 1 - - - - - Strip 1 - - - - - Strip | | END PACKAGE, TIE ROD INNER Part No. 1881 821 Consists of: 1 - - - - - Bolt, Tie Rod End Clamp 1 - - - - - Clamp, Tie Rod End 1 - - - - - End, Tie Rod Inner 1 - - - - - Nipple, Lubricant 1 - - - - - Nut, Tie Rod End 1 - - - - - Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter 1 - 1673 045 Seal, Tie Rod End Dust |
| | DOOR EDGE PROTECTOR PACKAGE Part No.*2094 926 Consists of: 8 - - - - - Clip, Moulding 1 - - - - - Strip, Rt. 1 - - - - - Strip, Lt. | | END PACKAGE, TIE ROD INNER Part No. 1881 820 Consists of: 1 - - - - - Bolt, Tie Rod End Clamp 1 - - - - - Clamp, Tie Rod End 1 - - - - - End, Tie Rod Inner 1 - - - - - Nipple, Lubricant 1 - - - - - Nut, Tie Rod End 1 - - - - - Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter 1 - 1673 045 Seal, Tie Rod End Dust |
| | DOOR EDGE PROTECTOR PACKAGE Part No.*1964 379 Consists of: 8 - - - - - Clip, Moulding 1 - - - - - Strip, Rt. 1 - - - - - Strip, Lt. | | END PACKAGE, TIE ROD OUTER Part No. 2084 353 Consists of: 1 - - - - - Bolt, Tie Rod End Clamp 1 - - - - - Clamp, Tie Rod End 1 - - - - - End, Tie Rod Outer 1 - - - - - Nipple, Lubricant 1 - - - - - Nut, Tie Rod End 1 - - - - - Nut, Tie Rod End Clamp 1 - 108 636 Pin, Tie Rod End Nut Cotter 1 - 1673 045 Seal, Tie Rod End Dust 1 - - - - - Spacer, Tie Rod End Ball |
| | DOOR EDGE PROTECTOR PACKAGE Part No.*1964 528 Consists of: 14 - - - - - Clip, Moulding 1 - - - - - Strip, Frt. Door, Rt. 1 - - - - - Strip, Frt. Door, Lt. 1 - - - - - Strip, Rr. Door, Rt. 1 - - - - - Strip, Rr. Door, Lt. | | 2-08-57 BALL JOINT PACKAGE, FRONT SUSPENSION . UPPER Part No. 2084 837 Consists of: 1 - - - - - Ball Joint 1 - 273 705 Nut, Ball Joint Stud 1 - 108 636 Pin, Ball Joint Stud Nut Cotter 1 - 2071 255 Seal, Ball Joint |
| 2-07-1 | END PACKAGE, TIE ROD INNER Part No. 2240 381 Consists of: 1 - - - - - Bolt, Tie Rod End Clamp 1 - - - - - Clamp, Tie Rod End 1 - - - - - End, Tie Rod Inner 1 - - - - - Nut, Tie Rod End Lock 1 - 128 014 Nut, Tie Rod 1 - - - - - Oiler, Tie Rod End 1 - 108 636 Pin, Tie Rod Nut Cotter 1 - 1735 470 Seal, Tie Rod End | | BALL JOINT PACKAGE, FRONT SUSPENSION . UPPER Part No. 2196 056 Consists of: 1 - - - - - Ball Joint 1 - 128 025 Nut, Ball Joint Stud 1 - - - - - Pin, Ball Joint Stud Nut Cotter 1 - 1825 487 Seal, Ball Joint 1 - 1672 960 Washer, Ball Joint Stud Nut |
| | END PACKAGE, TIE ROD OUTER Part No. 2240 380 Consists of: 1 - - - - - Bolt, Tie Rod End Clamp 1 - - - - - Clamp, Tie Rod End 1 - - - - - End, Tie Rod Outer 1 - - - - - Nut, Tie Rod End Lock 1 - 128 014 Nut, Tie Rod 1 - - - - - Oiler, Tie Rod End 1 - 108 636 Pin, Tie Rod Nut Cotter 1 - 1735 470 Seal, Tie Rod End | | |
| | END PACKAGE, TIE ROD INNER Part No. 1818 999 Consists of: 1 - - - - - Bolt, Tie Rod End Clamp | | |

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.
 * Indicates change or addition.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|---------|---|----------|--|
| | BALL JOINT PACKAGE, FRONT SUSPENSION UPPER Part No. 2084 252 Consists of: 1 - ---- Ball Joint 1 - 128 027 Nut, Ball Joint Stud 1 - ---- Pin, Ball Joint Stud Nut Cotter 1 - ---- Retainer, Ball Joint Outer Seal 1 - 1731 264 Seal, Ball Joint Inner 1 - 1734 266 Seal, Ball Joint Outer 1 - 1672 960 Washer, Ball Joint Stud Nut | (Cont'd) | 1 - 1825 432 Nut, Control Arm Strut Bushing 2 - 1734 341 Retainer, Control Arm Strut Bushing |
| 2-08-59 | CAM and BUSHING PACKAGE, FRONT SUSPENSION UPPER CONTROL ARM Part No. 2084 920 Consists of: 2 - 2071 204 Bushing, Arm 2 - ---- Cam, Arm, Slotted 2 - ---- Cam, Arm 2 - 1825 449 Nut, Arm Bolt 2 - 120 384 Washer, Arm Cam Lock | | BUSHING and RETAINER PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM, STRUT Part No. *2084 918 Consists of: 1 - 2071 167 Bushing, Front Suspension Strut 1 - 124 634 Nut, Front Suspension Strut Bushing Retainer 2 - 2071 211 Retainer, Front Suspension Strut Bushing |
| | BRACKET, CAM and BUSHING PACKAGE, FRONT SUSPENSION UPPER CONTROL ARM SUPPORT Part No. 1881 652 Consists of: 2 - ---- Bracket, Cam 2 - 1825 317 Bushing, Arm 2 - ---- Cam, Bracket Slotted 2 - 1825 449 Nut, Bracket Cam 2 - ---- Washer, Bracket Cam Lock | 2-10-61 | SHAFT and BUSHING PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM Part No. 2084 919 Consists of: 1 - 2071 206 Bushing, Shaft 1 - 128 178 Nut, Bushing 1 - 128 027 Nut, Shaft 1 - 119 209 Pin, Bushing Nut Cotter 1 - 119 209 Pin, Shaft Nut Cotter 1 - ---- Shaft, Arm 1 - 2071 205 Washer, Bushing Nut 1 - 2071 245 Washer, Shaft Nut |
| 2-10-55 | BALL JOINT PACKAGE, FRONT SUSPENSION LOWER Part No. 2084 838 Consists of: 1 - ---- Ball Joint 1 - 128 178 Nut, Ball Joint Stud 1 - 119 209 Pin, Ball Joint Stud Nut Cotter 1 - 2071 246 Seal, Ball Joint | | SHAFT and BUSHING PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM Part No. 1881 650 Consists of: 1 - 1636 017 Bushing, Shaft 1 - ---- Nut, Bushing 1 - ---- Nut, Shaft 1 - ---- Pin, Arm 1 - 119 209 Pin, Bushing 1 - ---- Shaft, Arm 1 - ---- Washer, Bushing 1 - ---- Washer, Shaft Nut |
| | BALL JOINT PACKAGE, FRONT SUSPENSION LOWER Part No. 2196 059 Consists of: 1 - ---- Ball Joint 1 - ---- Pin, Ball Joint Stud Nut Cotter 1 - 128 027 Nut, Ball Joint Stud 1 - 1825 488 Seal, Ball Joint 1 - 1672 960 Washer, Ball Joint Stud Nut Cotter | | SHAFT and BUSHING PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM Part No. 1881 647 Consists of: 1 - 1636 010 Bushing, Shaft 1 - ---- Nut, Bushing 1 - 128 213 Nut, Shaft 1 - 137 214 Pin, Arm 1 - 119 209 Pin, Bushing Nut Cotter 1 - ---- Shaft, Arm 1 - ---- Washer, Bushing 1 - ---- Washer, Shaft Nut |
| | BALL JOINT PACKAGE, FRONT SUSPENSION LOWER Part No. 2084 253 Consists of: 1 - ---- Ball Joint 1 - ---- Nut, Ball Joint Stud 1 - 119 209 Pin, Ball Joint Stud Nut 1 - 1825 303 Seal, Ball Joint Cotter 1 - 1672 961 Washer, Ball Joint Stud Nut | 2-14-1 | BOLT and SWIVEL PACKAGE, TORSION BAR or SPRING REAR END ANCHOR Part No. 2196 773 Consists of: 1 - ---- Bolt, Torsion Bar Anchor 1 - ---- Swivel, Torsion Bar Anchor |
| 2-10-57 | BUSHING and RETAINER PACKAGE, FRONT SUSPENSION LOWER CONTROL ARM STRUT Part No. 2084 045 Consists of: 1 - 1734 321 Bushing, Control Arm Strut (Pkg. Cont'd) | | BOLT and SWIVEL PACKAGE, TORSION BAR or SPRING REAR END ANCHOR ADJUSTING . . Part No. 2196 774 Consists of: 1 - ---- Bolt, Torsion Bar Anchor 1 - ---- Swivel, Torsion Bar Anchor |

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.
 March 1, 1962 Supersedes May 31, 1961.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|--------|--|----------|---|
| 2-14-8 | ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING REAR END RIGHT . . . Part No. 2196 750 Consists of: 1 - ---- --- Anchor, End 1 - ---- --- Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1857 580 Plug, End Anchor 1 - 1613 388 Seal, End Anchor 1 - 1857 549 Seat, End Anchor Adjusting 1 - ---- --- Swivel, End Anchor Adjusting | (Cont'd) | 1 - 1825 582 Plug, End Anchor 1 - 1613 388 Seal, End Anchor 1 - 1857 549 Seat, End Anchor Adjusting 1 - ---- --- Swivel, End Anchor Adjusting |
| | ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING REAR END LEFT Part No. 2196 751 Consists of: 1 - ---- --- Anchor, End 1 - ---- --- Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1857 580 Plug, End Anchor 1 - 1613 388 Seal, End Anchor 1 - 1857 549 Seat, End Anchor Adjusting 1 - ---- --- Swivel, End Anchor Adjusting | 3-09-3 | REPAIR KIT, REAR AXLE DIFFERENTIAL Part No. 2070 845 Consists of: 2 - ---- --- Disc 2 - ---- --- Disc 2 - ---- --- Plate 2 - ---- --- Plate 2 - ---- --- Plate |
| | ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING REAR END RIGHT . . . Part No. 2196 752 Consists of: 1 - ---- --- Anchor, End 1 - ---- --- Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1825 582 Plug, End Anchor 1 - 1613 388 Seal, End Anchor 1 - 1857 549 Seat, End Anchor Adjusting 1 - ---- --- Swivel, End Anchor Adjusting | 4-03-5 | LINING PACKAGE, PARKING BRAKE Part No. 1843 179 Consists of: 10 - ---- --- Lining 78 - ---- --- Rivets 30 - ---- --- Rivets |
| | ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING REAR END LEFT Part No. 2196 753 Consists of: 1 - ---- --- Anchor, End 1 - ---- --- Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1825 582 Plug, End Anchor 1 - 1613 388 Seal, End Anchor 1 - 1857 549 Seat, End Anchor Adjusting 1 - ---- --- Swivel, End Anchor Adjusting | 4-03-6 | SHOE AND LINING PACKAGE, PARKING BRAKE Part No. 2084 230 Consists of: 2 - ---- --- Shoe and Lining |
| | ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING REAR END RIGHT Part No. 2196 754 Consists of: 1 - ---- --- Anchor, End 1 - ---- --- Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1825 582 Plug, End Anchor 1 - 1613 388 Seal, End Anchor 1 - 1857 549 Seat, End Anchor Adjusting 1 - ---- --- Swivel, End Anchor Adjusting | 5-03-1 | LINING PACKAGE, WHEEL BRAKE SHOE Part No. 1879 398 Consists of: 4 - ---- --- Lining 4 - ---- --- Lining LINING PACKAGE, WHEEL BRAKE SHOE Part No. 1879 401 Consists of: 8 - ---- --- Lining LINING PACKAGE, WHEEL BRAKE SHOE Part No. 1879 404 Consists of: 4 - ---- --- Lining 4 - ---- --- Lining LINING PACKAGE, WHEEL BRAKE SHOE Part No. 2196 077 Consists of: 2 - ---- --- Lining 2 - ---- --- Lining 2 - ---- --- Lining 2 - ---- --- Lining 80 - ---- --- Rivets LINING PACKAGE, WHEEL BRAKE SHOE Part No. 2196 092 Consists of: 8 - ---- --- Lining LINING PACKAGE, WHEEL BRAKE SHOE Part No. 2240 387 Consists of: 8 - ---- --- Lining |
| | ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING REAR END LEFT Part No. 2196 755 Consists of: 1 - ---- --- Anchor, End 1 - ---- --- Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor 1 - 1825 582 Plug, End Anchor 1 - 1613 388 Seal, End Anchor 1 - 1857 549 Seat, End Anchor Adjusting 1 - ---- --- Swivel, End Anchor Adjusting | 5-03-9 | DAMPENER PACKAGE, WHEEL BRAKE Part No. 2084 257 Consists of: 1 - 600 071 Spring 1 - 600 072 Retainer 1 - 600 073 Retainer 1 - ---- --- Rod |
| | ANCHOR PACKAGE, FRONT SUSPENSION TORSION BAR or SPRING REAR END LEFT Part No. 2196 755 Consists of: 1 - ---- --- Anchor, End 1 - ---- --- Bolt, End Anchor Adjusting 1 - 1639 171 Lock, End Anchor | 5-39-1 | SERVICE PACKAGE, MASTER CYLINDER . . Part No. 1879 303 Consists of: 1 - 1828 388 Boot 1 - 958 659 Cup, Secondary 1 - 857 443 Washer, Piston Cup 1 - 1318 446 Valve 1 - 1617 379 Seal, Valve 1 - ---- --- Cup, Piston |

(Pkg. Cont'd)

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.
 * Indicates change or addition.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|--------|---|---------|---|
| | SERVICE PACKAGE, MASTER CYLINDER . . Part No. 1881 985 Consists of: 1 - 857 443 Washer, Piston Cup 1 - 958 659 Cup, Secondary 1 - 1316 628 Boot 1 - 1318 446 Valve 1 - 1617 379 Seal, Valve 1 - 1828 659 Piston 1 - ---- Cup, Piston | | SERVICE PACKAGE, REAR WHEEL CYLINDER . . . Part No. 2084 789 Consists of: 2 - 2072 636 Cup, Piston 2 - 2072 679 Boot |
| | SERVICE PACKAGE, MASTER CYLINDER . . Part No. 1881 987 Consists of: 1 - 857 443 Washer, Piston Cup 1 - 958 659 Cup, Secondary 1 - 1318 446 Valve 1 - 1617 379 Seal, Valve 1 - 1828 388 Boot 1 - ---- Piston 1 - ---- Cup, Piston | 5-63-3 | PISTON PACKAGE, FRONT WHEEL CYLINDER . . . Part No. 2084 255 Consists of: 2 - 1312 830 Piston 2 - 1614 894 Spring 2 - 1674 080 Cup 2 - 1674 081 Expander 2 - 1943 690 Boot |
| | SERVICE PACKAGE, MASTER CYLINDER . . Part No. 2196 904 Consists of: 1 - ---- Washer 1 - ---- Cup 1 - 1318 446 Valve 1 - 1617 379 Seal 1 - 1828 388 Boot 1 - ---- Piston 1 - ---- Cup | | PISTON PACKAGE, REAR WHEEL CYLINDER . . . Part No. *1818 834 Consists of: 2 - 1136 872 Boot 2 - 1312 830 Piston 1 - 1633 106 Spring 2 - 1674 080 Cup 2 - 1674 081 Expander 2 - 1614 894 Spring |
| | SERVICE PACKAGE, MASTER CYLINDER . . Part No. 2196 905 Consists of: 1 - ---- Washer 1 - ---- Cup 1 - 1318 446 Valve 1 - 1617 379 Seal 1 - 1828 388 Boot 1 - ---- Cup | | PISTON PACKAGE, FRONT WHEEL CYLINDER . . . Part No. 2084 790 Consists of: 2 - 1669 337 Cup 1 - 1799 634 Spring 2 - 2072 625 Boot 2 - 2072 655 Piston |
| | SERVICE PACKAGE, MASTER CYLINDER . . Part No. 2196 906 Consists of: 1 - ---- Washer 1 - ---- Cup 1 - 1318 446 Valve 1 - 1617 379 Seal 1 - ---- Piston 1 - ---- Cup | | PISTON PACKAGE, REAR WHEEL CYLINDER . . . Part No. 2084 791 Consists of: 2 - 2072 636 Cup 1 - 2072 637 Spring 2 - 2072 656 Piston 2 - 2072 679 Boot |
| 5-39-4 | COVER PACKAGE, MASTER CYLINDER . . Part No. 1752 470 Consists of: 1 - 1731 225 Cover 1 - 1731 227 Screw 1 - 2122 276 Gasket | 5-100-1 | REPAIR PACKAGE, POWER BRAKE Part No. 1675 001 Consists of: 1 - 1674 949 Seal, Air Valve 1 - 1674 949 Seal, Vacuum Valve 1 - 1674 952 Valve, Vacuum 1 - 1674 957 "O" Ring 1 - 1674 972 Seal 1 - 1674 974 "O" Ring 1 - 1674 989 "O" Ring 1 - 1674 991 "O" Ring |
| 5-63-1 | SERVICE PACKAGE, REAR WHEEL CYLINDER . . . Part No. 1818 639 Consists of: 2 - 1136 872 Boot 2 - 1674 080 Cup, Piston | | REPAIR PACKAGE, POWER BRAKE Part No. 1940 788 Consists of: 1 - 1940 790 Bearing 1 - 1675 112 Diaphragm 1 - 1675 123 Diaphragm 1 - 1675 137 Gasket 1 - 1675 124 Hose 1 - 1673 620 Retainer 2 - 1675 104 Ring 1 - 1940 787 Seal 1 - 1675 128 Seal 1 - 1739 853 Seal 1 - 1675 118 Seat 1 - 1675 099 Washer |
| | SERVICE PACKAGE, FRONT WHEEL CYLINDER . . . Part No. 2084 254 Consists of: 2 - 1674 080 Cup, Piston 2 - 1943 690 Boot | | REPAIR PACKAGE, POWER BRAKE Part No. 2075 001 Consists of: 1 - ---- Diaphragm 1 - ---- Disc 1 - ---- Filter |
| | SERVICE PACKAGE, FRONT WHEEL CYLINDER . . . Part No. 2084 788 Consists of: 2 - 1669 337 Cup, Piston 2 - 2072 625 Boot | | |

(Pkg. Cont'd)

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.
March 1, 1962 Supersedes May 31, 1961.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|-----------|---|-----------|---|
| (Cont'd) | 1 - ---- Guard | | PACKING PACKAGE, POWER |
| | 1 - ---- Poppet | | BRAKE PISTON Part No. 2075 000 |
| | 1 - ---- Seal | | Consists of: |
| | REPAIR PACKAGE, | | 1 - ---- Packing |
| | POWER BRAKE Part No. 2084 916 | | 1 - ---- Expander |
| | Consists of: | | 1 - ---- Felt |
| | 1 - ---- Piston | 5-100-157 | 1 - ---- Tube |
| | 1 - ---- Diaphragm and Plate | | PLATE PACKAGE, POWER |
| | 1 - ---- "O" Ring | | BRAKE DIAPHRAGM and |
| | 1 - ---- "O" Ring | | PISTON Part No. 2240 625 |
| | 1 - ---- "O" Ring | | Consists of: |
| | 2 - ---- Block, Vee | | 1 - ---- Plate, Diaphragm |
| | 2 - ---- Block, Vee | 5-100-166 | 1 - ---- Plate, Piston |
| | 1 - ---- Ring | | RETAINER PACKAGE, |
| | 1 - ---- Cup | | POWER BRAKE PLUNGER and |
| | 1 - ---- Diaphragm | | PUSH ROD Part No. *2421 084 |
| | 1 - ---- Seal | | Consists of: |
| | 1 - ---- Spring | | 1 - 2401 166 Retainer, Push Rod |
| | 1 - ---- Spring | 5-105-1 | 1 - ---- Plunger |
| | 1 - ---- Spring | | VALVE and WASHER PACKAGE, |
| | 1 - ---- Nut | | POWER BRAKE CHECK, Part No. *2421 083 |
| | 1 - ---- Washer | | Consist of: |
| | REPAIR PACKAGE, | | 1 - ---- Valve, Check |
| | POWER BRAKE Part No. 2084 917 | 6-01-1 | 1 - 2401 857 Washer, to Front Housing |
| | Consists of: | | CLUTCH PACKAGE . . . Part No. 2084 413 |
| | 1 - ---- "O" Ring | | Consists of: |
| | 1 - ---- "O" Ring | | 1 - 2073 606 Cover, w/Pressure Plate |
| | 1 - ---- "O" Ring | | 1 - 2073 676 Disc, Driving |
| | 2 - ---- Block, Vee | | CLUTCH PACKAGE . . . Part No. 2240 304 |
| | 2 - ---- Block, Vee | | Consists of: |
| | 1 - ---- Cap | | 1 - 2200 031 Cover, w/Pressure Plate |
| | 1 - ---- Diaphragm | 6-17-3 | 1 - 2200 068 Disc, Driving |
| | 1 - ---- Seal | | LEVER PACKAGE, CLUTCH |
| | 1 - ---- Gasket | | RELEASE Part No. 2084 250 |
| | 1 - ---- Nut | | Consists of: |
| | 1 - ---- Washer | | 1 - ---- Eye Bolt, w/Nut |
| | REPAIR PACKAGE, | | 1 - ---- Lever Release |
| | POWER BRAKE Part No. *2421 082 | | 1 - ---- Pin, Lever |
| | Consists of: | | 1 - ---- Spring, Lever |
| | 1 - ---- Diaphragm | | 1 - ---- Strut, Lever |
| | 1 - 2401 163 Seal, Valve Body | | LEVER PACKAGE, CLUTCH |
| | 1 - 2401 163 Seal, Adaptor | | RELEASE Part No. 1879 652 |
| | 1 - 2401 166 Retainer, Push Rod | | Consists of: |
| | 1 - ---- Ring, Plunger Cushion | | 1 - ---- Eye Bolt, w/Nut |
| | 1 - ---- Seal, Plunger | | 1 - ---- Lever, Release |
| | 1 - ---- Seal, Adaptor | | 1 - ---- Pin, Lever |
| | 1 - 2401 172 Seal, Plunger | | 1 - ---- Spring, Lever |
| | 1 - ---- Valve | | 1 - ---- Strut, Lever |
| | 1 - ---- Seal, Valve | | LEVER PACKAGE, CLUTCH |
| | 1 - ---- Ring, Plunger Retainer | | RELEASE Part No. 1879 655 |
| | 1 - ---- Bellows, Front Housing to Valve Body | | Consists of: |
| | 1 - 2401 855 Filter | | 1 - ---- Lever, Clutch Release |
| | 1 - 2401 858 Ring, Lever Retaining | | 1 - ---- Nut |
| 5-100-3 | SEAL PACKAGE, POWER | | 1 - ---- Pin |
| | BRAKE CYLINDER . . . Part No. 1940 787 | | 1 - ---- Spring |
| | Consists of: | | 1 - ---- Screw |
| | 1 - 1940 790 Bearing | | 1 - ---- Washer |
| | 1 - ---- Seal | 7-14-10 | CLAMP PACKAGE, |
| 5-100-152 | PACKING PACKAGE, POWER | | RADIATOR HOSE Part No. 1450 499 |
| | BRAKE PISTON Part No. 1820 003 | | Consists of: |
| | Consists of: | | 50 - ---- Clamps, Small |
| | 1 - 1739 834 Packing | | CLAMP PACKAGE, |
| | 1 - 1739 835 Ring | | RADIATOR HOSE Part No. 1450 500 |
| | 1 - 1679 013 Wick | | Consists of: |
| | | | 50 - ---- Clamps, Large |

1961 PASSENGER CAR PARTS CATALOG

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|--------|---|--------|---|
| 7-42-1 | <p>PUMP PACKAGE, WATER Part No. 1752 422 Consists of: 1 - 1676 031 Gasket 1 - ---- --- Pump</p> <p>PUMP PACKAGE, WATER Part No. 1879 526 Consists of: 1 - 1737 705 Gasket 1 - ---- --- Pump</p> <p>PUMP PACKAGE, WATER Part No. 1879 536 Consists of: 1 - 1737 705 Gasket 1 - ---- --- Pump</p> <p>PUMP PACKAGE, WATER Part No. 2196 035 Consists of: 1 - 1947 521 Gasket 1 - ---- --- Pump</p> | 7-42-4 | <p>REPAIR PACKAGE, WATER PUMP Part No. 1752 435 Consists of: 1 - 1618 645 Gasket 1 - 1635 783 Impeller 1 - 1674 679 Washer 1 - 1676 031 Gasket 1 - ---- --- Seal 1 - ---- --- Shaft 1 - ---- --- Thrower</p> |

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.
 March 1, 1962.

Printed in U.S.A.
 Prices and specifications subject to change without notice.
 * Indicates change or addition.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|----------|---|----------|--|
| | REPAIR PACKAGE, WATER PUMP Part No. 1752 622 Consists of: 1 - 1671 894 Gasket 1 - 1673 782 Gasket 1 - 1674 679 Washer 1 - 1737 705 Gasket 1 - 1859 151 Impeller 1 - ---- Seal 1 - ---- Shaft 1 - ---- Thrower | (Cont'd) | 1 - ---- Bearing, Shaft, Upper 1 - ---- Collar 1 - 9414 181 Pin, Collar 1 - 1195 770 Washer, Upper Thrust Outer 1 - 1195 769 Washer, Upper Thrust Inner 1 - ---- Washer, Lower Thrust |
| | REPAIR PACKAGE, WATER PUMP Part No. 1843 447 Consists of: 1 - 1637 724 Impeller 1 - 1671 191 Gasket 1 - 1671 894 Gasket 1 - 1673 782 Gasket 1 - 1674 679 Washer 1 - 1737 705 Gasket 1 - ---- Seal 1 - ---- Shaft 1 - ---- Thrower | | BEARING PACKAGE, DRIVE SHAFT Part No. 2084 867 Consists of: 2 - ---- Bearing, Bronze 1 - ---- Collar 1 - ---- Pin, Collar 2 - ---- Washer, Thrust |
| 7-46-1 | SEAL PACKAGE, WATER PUMP Part No. 1243 631 Consists of: 1 - 600 811 Lock Ring 1 - 1123 841 Washer 1 - 1674 679 Washer 1 - ---- Seal | | BEARING and THRUST WASHER PACKAGE, DRIVE SHAFT Part No. 2240 746 Consists of: 1 - ---- Bearing, Shaft, Upper 1 - ---- Bearing, Shaft, Lower 1 - ---- Gear 1 - 9414 181 Pin, Gear 1 - 1195 769 Washer, Upper Thrust, Inner 1 - 1195 770 Washer, Upper Thrust, Outer 1 - ---- Washer, Lower Thrust |
| 8-27-18 | GEAR PACKAGE, FOLLOWER Part No. 2084 870 Consists of: 1 - ---- Cover, Housing 1 - ---- Gear 1 - ---- Shaft, Drive 1 - ---- Washer, Thrust | 8-27-137 | COLLAR and PIN PACKAGE, DRIVE SHAFT Part No. 2084 448 Consists of: 1 - ---- Collar 1 - 9414 181 Pin |
| 8-27-77 | SPRING and HINGE PACKAGE, DISTRIBUTOR CAP Part No. 1879 606 Consists of: 1 - ---- Spring, w/Hinge, Locating Clamp 1 - ---- Spring, w/Hinge, Clamp | 8-27-190 | CONDENSER and BRACKET PACKAGE Part No. 1818 757 Consists of: 1 - ---- Bracket 1 - ---- Condenser |
| 8-27-85 | CONTACT and SPRING PACKAGE, DISTRIBUTOR CAP Part No. 2084 655 Consists of: 1 - ---- Contact 1 - ---- Spring | 8-27-208 | BREAKER and GROUND LEAD PACKAGE, DISTRIBUTOR Part No. 1881 768 Consists of: 1 - ---- Lead, Breaker Arm 1 - ---- Lead, Ground |
| 8-27-133 | BEARING PACKAGE, DISTRIBUTOR DRIVE SHAFT Part No. 1879 596 Consists of: 1 - ---- Bearing 1 - ---- Bearing 1 - ---- Collar 1 - ---- Pin, Collar 1 - ---- Washer, Thrust, Lower 1 - ---- Washer, Upper Thrust, Inner 1 - ---- Washer, Upper Thrust, Outer | 8-27-218 | STUD and MOUNTING PACKAGE, DISTRIBUTOR TERMINAL Part No. 1881 751 Consists of: 1 - ---- Nut 1 - ---- Stud 1 - ---- Stud, Insulation 1 - ---- Stud, Insulation Bushing 1 - ---- Stud, Insulation Washer 1 - ---- Washer, Lock 1 - ---- Washer, Plain |
| | BEARING and THRUST WASHER PACKAGE, DRIVE SHAFT Part No. 1881 947 Consists of: 1 - ---- Bearing, Shaft, Lower | 8-27-278 | GOVERNOR WEIGHT PACKAGE, DISTRIBUTOR Part No. 1881 746 Consists of: 2 - ---- Weight GOVERNOR WEIGHT PACKAGE, DISTRIBUTOR Part No. 1881 945 Consists of: 2 - ---- Weight GOVERNOR WEIGHT PACKAGE, DISTRIBUTOR Part No. 1881 955 Consists of: 2 - ---- Weight |

(Pkg. Cont'd)

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.
 May 31, 1961 Supersedes Oct. 3, 1960.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|----------|--|----------|---|
| 8-27-279 | GOVERNOR WEIGHT SPRING SET PACKAGE Part No. 1818 571 Consists of: 1 - ---- --- Spring, Short 1 - ---- --- Spring, Long | | VACUUM CHAMBER PACKAGE, DISTRIBUTOR. Part No. 2084 652 Consists of: 1 - ---- --- Chamber, Vacuum 1 - ---- --- Ring, Lock |
| | GOVERNOR WEIGHT SPRING SET PACKAGE Part No. 1881 946 Consists of: 1 - ---- --- Spring, Short 1 - ---- --- Spring, Long | | VACUUM CHAMBER PACKAGE, DISTRIBUTOR Part No. 2084 857 Consists of: 1 - ---- --- Chamber, Vacuum 1 - ---- --- Washer, Nylon 1 - ---- --- Washer, Plain |
| | GOVERNOR WEIGHT SPRING SET PACKAGE Part No. 1881 956 Consists of: 1 - ---- --- Spring, Short 1 - ---- --- Spring, Long | | VACUUM CHAMBER PACKAGE, DISTRIBUTOR Part No. 2084 868 Consists of: 1 - ---- --- Chamber, Vacuum 1 - ---- --- Ring, Lock 1 - ---- --- Washer, Plain |
| | GOVERNOR WEIGHT SPRING SET PACKAGE Part No. 2084 866 Consists of: 1 - ---- --- Spring, Short 1 - ---- --- Spring, Long | | VACUUM CHAMBER PACKAGE, DISTRIBUTOR Part No. 2084 893 Consists of: 1 - ---- --- Chamber, Vacuum 1 - ---- --- Ring, Lock |
| | GOVERNOR WEIGHT SPRING SET PACKAGE Part No. 2084 891 Consists of: 1 - ---- --- Spring, Short 1 - ---- --- Spring, Long | | VACUUM CHAMBER PACKAGE, DISTRIBUTOR Part No. 2240 715 Consists of: 1 - ---- --- Chamber, Vacuum 1 - ---- --- Ring, Lock |
| | GOVERNOR WEIGHT SPRING SET PACKAGE Part No. 2084 892 Consists of: 1 - ---- --- Spring, Short 1 - ---- --- Spring, Long | | VACUUM CHAMBER PACKAGE, DISTRIBUTOR Part No. 2275 226 Consists of: 1 - ---- --- Chamber, Vacuum 1 - ---- --- Washer, Nylon 1 - ---- --- Washer, Plain |
| | GOVERNOR WEIGHT SPRING SET PACKAGE Part No. 2240 747 Consists of: 1 - ---- --- Spring, Short 1 - ---- --- Spring, Long | 8-27-315 | PLUG and GASKET PACKAGE, DISTRIBUTOR VACUUM CHAMBER . . Part No. 1879 597 Consists of: 1 - ---- --- Gasket 1 - ---- --- Plug |
| | GOVERNOR WEIGHT SPRING SET PACKAGE Part No. 2275 227 Consists of: 1 - ---- --- Spring, Short 1 - ---- --- Spring, Long | 8-27-316 | SPRING and WASHER PACKAGE, DISTRIBUTOR VACUUM CHAMBER . . Part No. 1881 766 Consists of: 1 - ---- --- Spring 2 - ---- --- Washer, .032 3 - ---- --- Washer, .010 2 - ---- --- Washer, .065 |
| | FELT and SNAP RING PACKAGE, DISTRIBUTOR CAM SLEEVE Part No. 1879 607 Consists of: 1 - ---- --- Disc, Felt 1 - ---- --- Ring, Snap | | SPRING and WASHER PACKAGE, DISTRIBUTOR VACUUM CHAMBER . . Part No. 2275 225 Consists of: 1 - ---- --- Spring 2 - ---- --- Washer, .010 3 - ---- --- Washer, .032 2 - ---- --- Washer, .065 |
| 8-27-308 | VACUUM CHAMBER PACKAGE, DISTRIBUTOR Part No. 1881 944 Consists of: 1 - ---- --- Chamber, Vacuum 1 - ---- --- Ring, Lock | 8-27-352 | GEAR and PIN PACKAGE, DISTRIBUTOR DRIVE. . Part No. 2084 653 Consists of: 1 - ---- --- Gear 1 - ---- --- Pin |
| | VACUUM CHAMBER PACKAGE, DISTRIBUTOR. Part No. 1881 948 Consists of: 1 - ---- --- Chamber, Vacuum 1 - ---- --- Ring, Lock | | |

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

1961 PASSENGER CAR PARTS CATALOG

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|----------|--|---------|---|
| | GEAR and PIN PACKAGE, DISTRIBUTOR DRIVE. . . Part No. 2084 869 Consists of: 1 - ---- --- Gear 1 - ---- --- Pin | | CABLE SET, MOPAR IGNITION, RESISTOR TYPE Part No.*2084 219 Consists of: ★ - ---- --- Cable 9 - 2095 766 Nipple, Distributor Terminal 1 - 2095 768 Nipple, Coil Tower Terminal 10 - 1717 314 Terminal, Distributor |
| 8-29-17 | BRUSHES, WASHER AND TERMINAL PACKAGE Part No. 2084 673 Consists of: 2 - ---- --- Brush, Assembly 1 - ---- --- Terminal, Field 1 - ---- --- Washer, Insulator | | CABLE SET, MOPAR IGNITION, RESISTOR TYPE Part No.*2084 368 Consists of: ★ - ---- --- Cable 9 - 2095 766 Nipple, Distributor Terminal 1 - 2095 768 Nipple, Coil Tower Terminal 10 - 1717 314 Terminal, Distributor |
| 8-29-129 | CAPACITOR and BOLT PACKAGE Part No. 2084 675 Consists of: 1 - ---- --- Capicitor and Bolt 2 - ---- --- Insulator 1 - ---- --- Washer | | CABLE and TERMINAL PACKAGE, RESISTOR IGNITION Part No. 2084 456 Consists of: 1 - ---- --- Cable, 37 1/2" Long 1 - 2095 766 Nipple 1 - 1717 314 Terminal |
| 8-29-135 | RECTIFIER, HEAT SINK PACKAGE Part No. 2084 674 Consists of: 1 - ---- --- Sink, Heat 1 - ---- --- Spacer, Heat Sink | | CABLE and TERMINAL PACKAGE, RESISTOR IGNITION Part No. 2084 458 Consists of: 1 - ---- --- Cable 1 - 2095 766 Nipple 1 - 1717 314 Terminal |
| 8-35-111 | CYLINDER PACKAGE, IGNITION and DOOR LOCK Part No. 2161 192 Consists of: 1 - ---- --- Cylinder, Front Door, Right 1 - ---- --- Cylinder, Front Door, Left 1 - ---- --- Cylinder, Ignition Lock 1 - ---- --- Key CYLINDER PACKAGE, IGNITION and DOOR LOCK Part No. 2161 503 Consists of: 1 - ---- --- Cylinder, Right 1 - ---- --- Cylinder, Left 1 - ---- --- Cylinder, Ignition Lock 1 - ---- --- Key | | CABLE SET, MOPAR IGNITION, RESISTOR TYPE Part No.*2084 606 Consists of: ★ - ---- --- Cable 5 - 2095 766 Nipple, Distributor Terminal 1 - 2095 768 Nipple, Coil Tower Terminal 8 - 1717 314 Terminal |
| 8-35-115 | CYLINDER and KEY PACKAGE, IGNITION LOCK Part No. 2086 047 Consists of: 1 - ---- --- Cylinder 1 - ---- --- Key | | CABLE SET, MOPAR IGNITION, RESISTOR TYPE Part No.*2196 052 Consists of: ★ - ---- --- Cable 7 - 2095 766 Nipple, Distributor Terminal 1 - 2095 768 Nipple, Coil Tower Terminal 8 - 1717 314 Terminal, Distributor |
| 8-36-1 | CABLE and TERMINAL PACKAGE, RESISTOR IGNITION Part No. 2084 064 Consists of: 1 - ---- --- Cable 1 - 2095 766 Nipple 1 - 1717 314 Terminal CABLE and TERMINAL PACKAGE, RESISTOR IGNITION Part No. 2084 065 Consists of: 1 - ---- --- Cable 1 - 2095 766 Nipple 1 - 1717 314 Terminal CABLE SET, MOPAR IGNITION, RESISTOR TYPE Part No.*2084 217 Consists of: ★ - ---- --- Cable 9 - 2095 766 Nipple, Distributor Terminal 1 - 2095 768 Nipple, Coil Tower Terminal 10 - 1717 314 Terminal, Distributor | 8-36-49 | CABLE PACKAGE, COIL SECONDARY, 15" CABLE Part No.*2084 427 Consists of: 1 - ---- --- Cable, 15" Long 1 - 2095 766 Nipple 1 - 2095 768 Nipple 2 - 1717 314 Terminal CABLE PACKAGE, COIL SECONDARY, EXCEPT 15" CABLE Part No. B2084 428 Consists of: 1 - ---- --- Cable 1 - 2095 766 Nipple 1 - 2095 768 Nipple 2 - 1717 314 Terminal |

★ Indicates use as required.

⊞ Indicates parts not listed in any previous parts book.
May 31, 1961 Supersedes Oct. 3, 1960.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|----------|--|----------|--|
| 8-50-103 | ARM PACKAGE, TURN SIGNAL SWITCH OPERATING Part No. 2084 304 Consists of: 1 - ---- --- Arm 1 - 1972 207 Pivot 1 - ---- --- Spring | | WASHER PACKAGE, COMMUTATOR END THRUST Part No. 2240 529 Consists of: 2 - ---- --- Washer, .020 2 - ---- --- Washer, .080 2 - ---- --- Washer, 1/32 2 - 1383 663 Washer, 1/16 2 - 672 641 Washer, 3/64 |
| | ARM PACKAGE, TURN SIGNAL SWITCH OPERATING Part No. 2084 863 Consists of: 1 - ---- --- Arm 1 - 1972 207 Pivot 1 - ---- --- Spring | 8-52-214 | FIELD SERIES and SHUNT COIL PACKAGE Part No. 2084 088 Consists of: 1 - ---- --- Coil, Field Series 1 - ---- --- Coil, Field Shunt |
| | ARM PACKAGE, TURN SIGNAL SWITCH OPERATING Part No. 2240 250 Consists of: 1 - ---- --- Arm 1 - 1972 207 Pivot 1 - ---- --- Spring | 8-52-275 | STUD PACKAGE, STARTER TERMINAL Part No. 2084 667 Consists of: 1 - ---- --- Bushing, Insulating 1 - ---- --- Lockwasher 1 - ---- --- Nut 1 - ---- --- Stud, Terminal 1 - ---- --- Washer, Inner Insulating 1 - ---- --- Washer, Outer Insulating 1 - ---- --- Washer, Plain |
| 8-50-334 | LENS and GASKET PACKAGE, PARK and TURN SIGNAL LAMP, RIGHT Part No. 2240 742 Consists of: 1 - 2188 864 Gasket 1 - ---- --- Lens | 8-52-341 | COVER and GASKET PACKAGE, SOLENOID Part No. 2084 091 Consists of: 1 - ---- --- Contact, Solenoid 1 - ---- --- Gasket, Cover 1 - ---- --- Spring, Return |
| | LENS and GASKET PACKAGE, PARK and TURN SIGNAL LAMP, LEFT Part No. 2240 743 Consists of: 1 - 2188 864 Gasket 1 - ---- --- Lens | 8-52-344 | COVER and GASKET PACKAGE, SOLENOID Part No. 2084 090 Consists of: 1 - ---- --- Cover 1 - ---- --- Gasket, Cover |
| 8-52-49 | FORK and PIN PACKAGE, SHIFTING Part No. 2084 093 Consists of: 1 - ---- --- Fork, Shifting 1 - ---- --- Pin, Roll | 8-52-354 | STUD PACKAGE, SOLENOID TERMINAL RELAY Part No. 2084 094 Consists of: 1 - ---- --- Insulator, Relay Stud 1 - 120 622 Nut, Hex 1 - ---- --- Stud 1 - ---- --- Washer, Lock 1 - ---- --- Washer, Relay Stud Spacing |
| 8-52-82 | STOP and LOCK RING PACKAGE, STARTER PINION Part No. 1881 727 Consists of: 1 - 1752 375 Ring 1 - 1752 376 Stop | 8-53-265 | RHEOSTAT REPLACEMENT PACKAGE, HEADLAMP SWITCH . . Part No. B2275 238 Consists of: 1 - ---- --- Rheostat 1 - ---- --- Spring |
| 8-52-135 | BRUSH PACKAGE Part No. 2240 749 Consists of: 2 - ---- --- Brush | | RHEOSTAT REPLACEMENT PACKAGE, HEADLAMP SWITCH . Part No. B2275 231 Consists of: 1 - ---- --- Rheostat 1 - ---- --- Spring |
| 8-52-140 | SPRING PACKAGE, BRUSH Part No. 2084 095 Consists of: 4 - 636 841 Spring, Brush | | RHEOSTAT REPLACEMENT PACKAGE, HEADLAMP SWITCH . Part No. B2275 234 Consists of: 1 - ---- --- Driver 1 - ---- --- Rheostat 1 - ---- --- Spring |
| | SPRING PACKAGE, STARTER BRUSH Part No. 2084 666 Consists of: 4 - ---- --- Spring | 8-55-1 | LAMP PACKAGE, STOP and TURN SIGNAL, RIGHT Part No. 2240 261 Consists of: 1 - ---- --- Housing, Socket and Gaskets (Pkg. Cont'd) |
| 8-52-180 | WASHER PACKAGE, COMMUTATOR END THRUST Part No. 1879 613 Consists of: 3 - ---- --- Washer 2 - 1383 663 Washer 2 - 672 641 Washer 2 - ---- --- Washer | | |

★ Indicates use as required.

□ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|----------|--|--|---------------------------|
| (Cont'd) | 1 - 2093 550 Lens, Eyelet and Wick 2 - ---- --- Screw and Washer, Lamp to Quarter Panel 2 - 9414 814 Screw, Lens to Housing LAMP PACKAGE, STOP and TURN SIGNAL, LEFT Part No. 2240 262 Consists of: 1 - ---- --- Housing, Socket and Gaskets 1 - 2093 551 Lens, Eyelet and Wick 2 - ---- --- Screw and Washer, Lamp to Quarter Panel 2 - 9414 814 Screw, Lens to Housing LAMP PACKAGE, QUARTER PANEL TAIL, STOP and TURN SIGNAL, RIGHT Part No. 2240 738 Consists of: 1 - ---- --- Button, Reflector 1 - 2094 682 Housing 1 - 2094 674 Lamp 1 - ---- --- Nut and Washer, Button 4 - ---- --- Nut and Washer 3 - ---- --- Screw 4 - ---- --- Washer, Sealing LAMP PACKAGE, QUARTER PANEL TAIL, STOP and TURN SIGNAL, LEFT Part No. 2240 739 Consists of: 1 - ---- --- Button, Reflector 1 - 2094 683 Housing 1 - 2094 675 Lamp 1 - ---- --- Nut and Washer, Button 4 - ---- --- Nut and Washer 3 - ---- --- Screw 4 - ---- --- Washer, Sealing | LAMP and GASKET PACKAGE, BACK-UP, LEFT Part No. 2084 053 Consists of: 1 - 1961 256 Gasket 1 - ---- --- Lamp 2 - 1961 349 Screw 2 - 1961 352 Washer 8-56-8 LENS and GASKET PACKAGE, BACK-UP LAMP Part No. 2240 741 Consists of: 1 - 2094 343 Gasket 1 - ---- --- Lens 8-56-27 SPRING, INSULATOR and CONTACT PACKAGE, BACK-UP LAMP SOCKET Part No. 2257 100 Consists of: 1 - ---- --- Contact 1 - ---- --- Insulator 1 - ---- --- Spring 8-56-36 BEZEL and GASKET PACKAGE, REAR BUMPER BACK-UP LAMP, RIGHT Part No. 2240 731 Consists of: 1 - ---- --- Bezel 1 - 1961 448 Gasket BEZEL and GASKET PACKAGE, REAR BUMPER BACK-UP LAMP, LEFT Part No. 2240 732 Consists of: 1 - ---- --- Bezel 1 - 1961 448 Gasket 8-57-54 LENS and GASKET PACKAGE, LICENSE LAMP Part No. 1679 566 Consists of: 1 - ---- --- Gasket 1 - ---- --- Lens 8-57-89 SPRING, INSULATOR and CONTACT PACKAGE, LICENSE LAMP SOCKET Part No. 2257 100 Consists of: 1 - ---- --- Contact 1 - ---- --- Insulator 1 - ---- --- Spring 9-01-5 GASKET SET ENGINE Part No. 2196 045 Consists of: 1 - 1945 561 Gasket, Air Cleaner Cover 1 - 1947 797 Gasket, Air Cleaner to Carburetor 1 - 637 191 Gasket, Carburetor Flange 1 - 1947 554 Gasket, Chain Case Cover 1 - 1947 578 Gasket, Cylinder Head 1 - 2121 244 Gasket, Cylinder Head Cover 1 - 1947 671 Gasket, Cylinder Water Outlet Elbow 1 - 2073 792 Gasket, Exhaust Pipe Flange 1 - 1400 185 Gasket, Fuel Pump Flange 1 - ---- --- Gasket, Intake and Exhaust Manifold 1 - ---- --- Gasket, Oil Pan, Front 1 - ---- --- Gasket, Oil Pan, Left 1 - ---- --- Gasket, Oil Pan, Rear 1 - ---- --- Gasket, Oil Pan, Right (Pkg. Cont'd) | |
| 8-55-63 | CONTACT, INSULATOR and SPRING PACKAGE, TAIL, STOP and TURN SIGNAL LAMP SOCKET Part No. 2198 860 Consists of: 1 - ---- --- Contact 1 - ---- --- Insulator 1 - ---- --- Spring CONTACT, INSULATOR and SPRING PACKAGE, TAIL LAMP Part No. 2257 100 Consists of: 1 - ---- --- Contact 1 - ---- --- Insulator 1 - ---- --- Spring | | |
| 8-55-194 | LENS and GASKET PACKAGE, QUARTER PANEL TAIL, STOP and TURN SIGNAL. Part No. 2240 740 Consists of: 1 - 2094 368 Gasket 1 - ---- --- Lens | | |
| 8-56-3 | LAMP and GASKET PACKAGE, BACK-UP, RIGHT Part No. 2084 052 Consists of: 1 - 1961 256 Gasket 1 - ---- --- Lamp 2 - 1961 349 Screw 2 - 1961 352 Washer | | |

★ Indicates use as required.

⊞ Indicates parts not listed in any previous parts book.
 May 31, 1961 Supersedes Oct. 3, 1960.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|----------|---|--------|--|
| (Cont'd) | | | |
| | 1 - 618 622 Gasket, Oil Pressure Relief Valve Cap | | GASKET SET, ENGINE . . Part No. 1879 702 Consists of: |
| | 1 - 2121 404 Gasket, Oil Pump Body | | 1 - 1737 763 Gasket, Chain Case Cover |
| | 1 - 1947 521 Gasket, Water Pump Body | | 2 - 1851 579 Gasket, Cylinder Head |
| | 1 - 1947 523 Gasket, Water Pump Body Intermediate Plate | | 2 - 1821 440 Gasket, Cylinder Head Cover |
| | GASKET SET, ENGINE, w/ALUMINUM ENGINE Part No.*2240 628 | | 1 - 50 082 Gasket, Cylinder Water Outlet Elbow |
| | Consists of: | | 2 - 1821 640 Gasket, Exhaust Pipe Flange |
| | 1 - 1947 797 Gasket, Air Cleaner to Carburetor | | 2 - 1855 029 Gasket, Exhaust Pipe Flange |
| | 1 - 1947 554 Gasket, Chain Case Cover | | 1 - 1400 185 Gasket, Fuel Pump Flange |
| | 1 - 2128 279 Gasket, Cylinder Head | | 1 - 1326 836 Gasket, Ignition Distributor |
| | 1 - 2121 244 Gasket, Cylinder Head Cover | | 1 - 1851 664 Gasket, Intake Manifold |
| | 1 - 1947 671 Gasket, Cylinder Water Outlet Elbow | | 1 - 1737 770 Gasket, Oil Pan |
| | 1 - 2073 792 Gasket, Exhaust Pipe Flange | | 1 - 618 622 Gasket, Oil Pressure Relief Valve Cap |
| | 1 - 1400 185 Gasket, Fuel Pump Flange | | 1 - 1737 705 Gasket, Water Pump Body |
| | 1 - 1947 762 Gasket, Intake and Exhaust Manifold | 9-10-2 | 2 - 1737 761 Gasket, Water Pump to Cylinder Block |
| | 1 - 2288 264 Gasket, Intake to Exhaust Manifold | | OIL SEAL PACKAGE, CRANKSHAFT BEARING |
| | 1 - ---- Gasket, Oil Pan, Front | | NO. 5 Cap Part No. 1326 091 |
| | 1 - ---- Gasket, Oil Pan, Left | | Consists of: |
| | 1 - ---- Gasket, Oil Pan, Rear | | 1 - ---- Oil Seal, Left |
| | 1 - ---- Gasket, Oil Pan, Right | 9-11-1 | 1 - ---- Oil Seal, Right |
| | 1 - 618 622 Gasket, Oil Pressure Relief Valve Cap | | OIL SEAL PACKAGE, CRANKSHAFT REAR |
| | 1 - 2121 404 Gasket, Oil Pump Body | | BEARING Part No. 1326 093 |
| | 1 - 1947 521 Gasket, Water Pump Body | | Consists of: |
| | 1 - 1947 523 Gasket, Water Pump Body Intermediate Plate | | 2 - ---- Oil Seal, Bearing |
| | GASKET SET, ENGINE . . Part No. 2196 087 | | 1 - ---- Oil Seal, Bearing Cap, Right |
| | Consists of: | | 1 - ---- Oil Seal, Bearing Cap, Left |
| | 1 - 2129 012 Gasket, Chain Case Cover | | 2 - ---- Oil Seal |
| | 2 - 2129 655 Gasket, Cylinder Head | | OIL SEAL PACKAGE, CRANKSHAFT REAR |
| | 2 - 2128 407 Gasket, Cylinder Head Cover | | BEARING Part No. 1818 781 |
| | 1 - 50 826 Gasket, Cylinder Water Outlet | | Consists of: |
| | 2 - 1636 570 Gasket, Exhaust Pipe Flange | | 2 - ---- Oil Seal, Crankshaft Rear Bearing |
| | 1 - 1400 185 Gasket, Fuel Pump Flange | | 2 - ---- Oil Seal, Crankshaft Rear Bearing Retainer |
| | 1 - 1326 836 Gasket, Ignition Distributor | 9-39-1 | GASKET PACKAGE, VALVE |
| | 2 - ---- Gasket, Intake Manifold | | GRIND Part No. 2196 046 |
| | 1 - ---- Gasket, Intake Manifold-Front | | Consists of: |
| | 1 - ---- Gasket, Intake Manifold-Rear | | 1 - 1947 578 Gasket, Cylinder Head |
| | 2 - ---- Gasket, Oil Pan | | 1 - 2121 244 Gasket, Cylinder Head Cover |
| | 2 - ---- Gasket, Oil Pan-End | | 1 - 2073 792 Gasket, Exhaust Pipe Flange |
| | 1 - 2129 013 Gasket, Water Pump Body | | GASKET PACKAGE, VALVE |
| | GASKET SET, ENGINE . . Part No. 1879 701 | | GRIND Part No. 2196 086 |
| | Consists of: | | Consists of: |
| | 1 - 1737 763 Gasket, Chain Case Cover | | 2 - 2129 655 Gasket, Cylinder Head |
| | 2 - 1851 579 Gasket, Cylinder Head | | 2 - 2128 407 Gasket, Cylinder Head Cover |
| | 2 - 1821 440 Gasket, Cylinder Head Cover | | 2 - ---- Gasket, Exhaust Pipe Flange |
| | 1 - 50 082 Gasket, Cylinder Water Outlet Elbow | | 2 - ---- Gasket, Intake Manifold |
| | 2 - 1855 029 Gasket, Exhaust Pipe Flange | | 1 - ---- Gasket, Intake Manifold Front |
| | 2 - 1821 640 Gasket, Exhaust Pipe Flange | | 1 - ---- Gasket, Intake Manifold Rear |
| | 1 - 1400 185 Gasket, Fuel Pump Flange | | GASKET PACKAGE, VALVE |
| | 1 - 1326 836 Gasket, Ignition Distributor | | GRIND Part No. 1879 703 |
| | 1 - 1737 709 Gasket, Intake Manifold | | Consists of: |
| | 1 - 1737 770 Gasket, Oil Pan | | 2 - 1851 579 Gasket, Cylinder Head |
| | 1 - 618 622 Gasket, Oil Pressure Relief Valve Cap | | 2 - 1821 440 Gasket, Cylinder Head Cover |
| | 1 - 1737 705 Gasket, Water Pump Body | | (Pkg. Cont'd) |
| | 2 - 1737 761 Gasket, Water Pump to Cylinder Block | | |

★ Indicates use as required.
 □ Indicates parts not listed in any previous parts book.
 * Indicates change or addition.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|----------|---|----------|--|
| (Cont'd) | 2 - 1821 640 Gasket, Exhaust Pipe Flange 2 - 1855 029 Gasket, Exhaust Pipe Flange 1 - 1737 709 Gasket, Intake Manifold 2 - 1737 761 Gasket, Water Pump to Cyl. Block GASKET PACKAGE, VALVE GRIND Part No. 1879 704 Consists of: 2 - 1851 579 Gasket, Cylinder Head 2 - 1821 440 Gasket, Cylinder Head Cover 2 - 1821 640 Gasket, Exhaust Pipe Flange 2 - 1855 029 Gasket, Exhaust Pipe Flange 2 - 1851 664 Gasket, Intake Manifold 2 - 1737 761 Gasket, Water Pump to Cylinder Block | (Cont'd) | 1 - 1670 515 Shield, Thermostat 1 - 1558 897 Spring, Valve 1 - 683 057 Stop 1 - 2128 933 Thermostat HEAT CONTROL PACKAGE, MANIFOLD . Part No. 2084 795 Consists of: 1 - 1736 012 Bolt, Shield Clamp 2 - ---- --- Bushing 1 - 1409 594 Lock, Shield 1 - 120 614 Nut, Shield Clamp Bolt 1 - ---- --- Plate 2 - 148 148 Retainer, Shaft 1 - ---- --- Shaft 1 - 1944 616 Shield, Thermostat 1 - 1558 897 Spring, Valve 1 - 683 057 Stop 1 - 2128 933 Thermostat |
| 9-50-1 | GASKET SET, MANIFOLD Part No. 2084 416 Consists of: 1 - ---- --- Gasket, Intake and Exhaust Manifold 1 - ---- --- Gasket, Intake to Exhaust Manifold GASKET SET, MANIFOLD Part No. 2084 347 Consists of: 2 - ---- --- Gasket, Intake Manifold 1 - ---- --- Gasket, Intake Manifold, Front 1 - ---- --- Gasket, Intake Manifold, Rear | 10-07-2 | GASKET and SEAL PACKAGE, OIL PUMP Part No. 2084 355 Consists of: 3 - ---- --- Gasket 1 - ---- --- Seal |
| 9-58-1 | HEAT CONTROL PACKAGE, MANIFOLD . Part No. 2084 797 Consists of: 1 - 1736 012 Bolt, Valve Clamp 2 - ---- --- Bushing 1 - 2121 430 Counterweight 1 - 1409 594 Lock, Counterweight 1 - 120 614 Nut, Valve Clamp 1 - ---- --- Plate 2 - 148 148 Retainer, Shaft 1 - ---- --- Shaft 1 - 1558 897 Spring, Valve 1 - 2121 455 Stop 1 - 2121 554 Thermostat HEAT CONTROL PACKAGE, MANIFOLD . Part No. 2084 794 Consists of: 1 - 1736 012 Bolt, Shield Clamp 2 - ---- --- Bushing 1 - 1409 594 Lock, Shield 1 - 120 614 Nut, Shield Clamp Bolt 1 - ---- --- Plate 2 - 148 148 Retainer, Shaft 1 - ---- --- Shaft 1 - 1670 515 Shield, Thermostat 1 - 1558 897 Spring, Valve 1 - 683 057 Stop 1 - 960 003 Thermostat HEAT CONTROL PACKAGE, MANIFOLD . Part No. 2196 074 Consists of: 1 - 1736 012 Bolt, Shield Clamp 2 - ---- --- Bushing 1 - 1409 594 Lock, Shield 1 - 120 614 Nut, Shield Clamp Bolt 1 - ---- --- Plate 2 - 148 148 Retainer, Shaft 1 - ---- --- Shaft | 10-07-3 | SHAFT and ROTOR PACKAGE, OIL PUMP DRIVE Part No. 2084 415 Consists of: 1 - ---- --- Rotor, Outer 1 - ---- --- Shaft, Drive SHAFT and ROTOR PACKAGE, OIL PUMP DRIVE Part No. 2084 354 Consists of: 1 - ---- --- Rotor, Outer 1 - ---- --- Shaft, Drive, Assembly |
| | | 10-24-1 | GASKET PACKAGE, OIL PAN Part No. 1879 520 Consists of: 2 - ---- --- Gasket, Oil Pan Side 2 - ---- --- Gasket, Oil Pan End GASKET PACKAGE, OIL PAN Part No. 2240 647 Consists of: 1 - ---- --- Gasket, Oil Pan Right 1 - ---- --- Gasket, Oil Pan Left 1 - ---- --- Gasket, Oil Pan Front 1 - ---- --- Gasket, Oil Pan Rear |
| | | 10-26-8 | CARTRIDGE, OIL FILTER Part No. 2129 023 Consists of: 1 - ---- --- Cartridge, Oil Filter 5 - ---- --- Gasket |
| | | 11-08-1 | CLAMP PACKAGE, EXHAUST PIPE Part No. 1603 364 Consists of: 2 - 120 376 Nut 1 - ---- --- Saddle 1 - ---- --- U-Bolt 2 - 120 214 Washer, Lock CLAMP PACKAGE, EXHAUST PIPE Part No. 1843 009 Consists of: 2 - 120 376 Nut 1 - ---- --- Saddle 1 - ---- --- U-Bolt 2 - 120 214 Washer, Lock |

(Pkg. Cont'd)

★ Indicates use as required.
 ☐ Indicates parts not listed in any previous parts book.
 March 1, 1962 Supersedes May 31, 1961.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|---------|--|--|---|
| | CLAMP PACKAGE, EXHAUST | (Cont'd) | |
| | PIPE Part No. 1843 008 | 1 - ---- | Gasket, Pump Jet Housing |
| | Consists of: | 2 - ---- | Gasket, Primary Venturi Cluster |
| | 1 - 181 614 Bolt | 2 - ---- | Gasket, Secondary Venturi Cluster |
| | 1 - ---- Clamp | 2 - ---- | Jet, Primary Metering |
| | 1 - 120 368 Nut | 2 - ---- | Needle, w/Seat, Float |
| | 1 - 120 214 Washer | 1 - ---- | Plunger, w/Rod, Pump |
| 11-09-1 | CLAMP PACKAGE, TAIL | 2 - ---- | Rod, Step-Up |
| | PIPE Part No. 2240 312 | 2 - ---- | Spring, Vacuum Piston |
| | Consists of: | REPAIR PACKAGE, | |
| | 1 - 181 614 Bolt | CARBURETOR Part No. 2084 725 | |
| | 1 - ---- Clamp | Consists of: | |
| | 1 - 120 368 Nut | 1 - ---- | Ball, Pump Discharge Check Valve, 1/8" Dia. |
| | 1 - 120 214 Washer, Lock | 1 - ---- | Ball, Pump Inlet Check Valve, 3/16" Dia. |
| 13-72-4 | BAR and BASE PACKAGE, | 1 - ---- | Cotter Pin, Choke Piston Link |
| | BUMPER JACK RACK . Part No. 2275 450 | 1 - ---- | Gasket, Air Horn |
| | Consists of: | 1 - ---- | Gasket, Main Body |
| | 1 - ---- Bar, Rack | 1 - ---- | Gasket, Power By-Pass Jet |
| | 1 - ---- Base | 1 - ---- | Gasket, Venturi Cluster |
| 14-30-4 | REPAIR PACKAGE, | 2 - ---- | Jet, Main Metering |
| | CARBURETOR Part No. 2084 164 | 1 - ---- | Jet, Power By-Pass |
| | Consists of: | 3 - ---- | Plug, Drive, 1/8" Dia. |
| | 1 - ---- Gasket, Air Cleaner | 2 - ---- | Plug, Drive, 3/16" Dia. |
| | 1 - ---- Gasket, Body | 1 - ---- | Plunger, w/Rod, Pump |
| | 1 - ---- Gasket, Body Flange | 1 - ---- | Valve, Idle Needle |
| | 1 - ---- Gasket, Flange | 1 - ---- | Valve, w/Seat, Float |
| | 1 - ---- Gasket, Step-Up Piston | REPAIR PACKAGE, | |
| | 1 - ---- Gasket, Venturi Cover | CARBURETOR Part No. 2196 216 | |
| | 1 - ---- Gasket, Venturi Housing | Consists of: | |
| | 2 - ---- Jet, Main Metering | 1 - ---- | Gasket, Flange |
| | 1 - ---- Needle, w/Seat, Float | 1 - ---- | Gasket, Body |
| | 1 - ---- Plunger, w/Rod, Pump | 1 - ---- | Gasket, Body Flange |
| | 1 - ---- Spring, Step-Up Piston | 1 - ---- | Gasket, Step-Up Piston |
| | REPAIR PACKAGE, | 1 - ---- | Jet, Main Metering |
| | CARBURETOR Part No. 2084 188 | 1 - ---- | Needle, w/Seat, Float |
| | Consists of: | 1 - ---- | Plug, High Speed Passage |
| | 1 - ---- Gasket, Air Cleaner | 1 - ---- | Plunger, w/Rod, Pump |
| | 1 - ---- Gasket, Body | 1 - ---- | Spring, Step-Up Piston |
| | 1 - ---- Gasket, Body Flange | 1 - ---- | Tube, w/Plug, Idle Orifice |
| | 1 - ---- Gasket, Flange | 1 - ---- | Tube, Main Vent |
| | 1 - ---- Gasket, Step-Up Piston | REPAIR PACKAGE, | |
| | 1 - ---- Gasket, Venturi Cover | CARBURETOR Part No. 2196 217 | |
| | 1 - ---- Gasket, Venturi Housing | Consists of: | |
| | 2 - ---- Jet, Main Metering | 1 - ---- | Gasket, Body |
| | 1 - ---- Needle, w/Seat, Float | 1 - ---- | Gasket, Body Flange |
| | 1 - ---- Plunger, w/Rod, Pump | 1 - ---- | Gasket, Flange |
| | 1 - ---- Spring, Step-Up Piston | 1 - ---- | Gasket, Step-Up Piston |
| | REPAIR PACKAGE, | 1 - ---- | Jet, Main Metering |
| | CARBURETOR Part No. 2084 196 | 1 - ---- | Needle, w/Seat, Float |
| | Consists of: | 1 - ---- | Plug, High Speed Passage |
| | 1 - ---- Gasket, Air Cleaner | 1 - ---- | Plunger, w/Rod, Pump |
| | 1 - ---- Gasket, Air Horn | 1 - ---- | Spring, Step-Up Piston |
| | 1 - ---- Gasket, Flange | 1 - ---- | Tube, w/Plug, Idle Orifice |
| | 1 - ---- Gasket, Pump Jet Housing | 1 - ---- | Tube, Main Vent |
| | 2 - ---- Gasket, Primary Venturi Cluster | REPAIR PACKAGE, | |
| | 2 - ---- Gasket, Secondary Venturi Cluster | CARBURETOR Part No. 2196 219 | |
| | 2 - ---- Jet, Primary Metering | Consists of: | |
| | 2 - ---- Needle, w/Seat, Float | 1 - ---- | Gasket, Body |
| | 1 - ---- Plunger, w/Rod, Pump | 1 - ---- | Gasket, Body Flange |
| | 2 - ---- Rod, Step-Up | 1 - ---- | Gasket, Flange |
| | 2 - ---- Spring, Vacuum Piston | 1 - ---- | Gasket, Step-Up Piston |
| | REPAIR PACKAGE, | 1 - ---- | Jet, Main Metering |
| | CARBURETOR Part No. 2084 198 | 1 - ---- | Needle, w/Seat, Float |
| | Consists of: | 1 - ---- | Plug, High Speed Passage |
| | 1 - ---- Gasket, Air Cleaner | 1 - ---- | Plunger, w/Rod, Pump |
| | 1 - ---- Gasket, Flange | | |

(Pkg. Cont'd)

(Pkg. Cont'd)

★ Indicates use as required.

☐ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|----------|--|----------|--|
| (Cont'd) | | (Cont'd) | |
| | 1 - ---- Spring, Step-Up Piston | | 1 - ---- Gasket, Main Discharge Nozzle |
| | 1 - ---- Tube, w/Plug, Idle Orifice | | 1 - ---- Gasket, Pump Discharge Nozzle Screw |
| | 1 - ---- Tube, Main Vent | | |
| | REPAIR PACKAGE, | | GASKET PACKAGE, |
| | CARBURETOR Part No. 2196 246 | | CARBURETOR Part No. 1826 511 |
| | Consists of: | | Consists of: |
| | 1 - ---- Gasket, Body | | 1 - ---- Gasket, Body |
| | 1 - ---- Gasket, Body Flange | | 1 - ---- Gasket, Body Flange |
| | 1 - ---- Gasket, Flange | | 1 - ---- Gasket, Flange |
| | 1 - ---- Gasket, Step-Up Piston | | 2 - ---- Gasket, Main Metering Jet |
| | 1 - ---- Jet, Main Metering | | 1 - ---- Gasket, Float Needle Seat |
| | 1 - ---- Needle, w/Seat, Float | | 1 - ---- Gasket, Step-Up Piston |
| | 1 - ---- Plug, High Speed Passage | | 1 - ---- Gasket, Venturi Cover |
| | 1 - ---- Plunger, w/Rod, Pump | | 1 - ---- Gasket, Venturi Housing |
| | 1 - ---- Spring, Step-Up Piston | | |
| | 1 - ---- Tube, w/Plug, Idle Orifice | | GASKET PACKAGE, |
| | 1 - ---- Tube, Main Vent | | CARBURETOR Part No. 2084 192 |
| | REPAIR PACKAGE, | | Consists of: |
| | CARBURETOR Part No. 2240 468 | | 1 - ---- Gasket, Air Cleaner |
| | Consists of: | | 1 - ---- Gasket, Body |
| | 1 - ---- Gasket, Body | | 1 - ---- Gasket, Body Flange |
| | 1 - ---- Gasket, Body Flange | | 1 - ---- Gasket, Flange |
| | 1 - ---- Gasket, Flange | | 1 - ---- Gasket, Step-Up Piston |
| | 1 - ---- Gasket, Step-Up Piston | | 1 - ---- Gasket, Venturi Cover |
| | 1 - ---- Jet, Main Metering | | 1 - ---- Gasket, Venturi Housing |
| | 1 - ---- Needle, w/Seat, Float | | |
| | 1 - ---- Plunger, w/Rod, Pump | | GASKET PACKAGE, |
| | 1 - ---- Plug, High Speed Passage | | CARBURETOR Part No. 2084 200 |
| | 1 - ---- Spring, Step-Up Piston | | Consists of: |
| | 1 - ---- Tube, w/Plug, Idle Orifice | | 1 - ---- Gasket, Air Cleaner |
| | 1 - ---- Tube, Main Vent | | 1 - ---- Gasket, Air Horn |
| | REPAIR PACKAGE, | | 1 - ---- Gasket, Flange |
| | CARBURETOR Part No. 2240 469 | | 2 - ---- Gasket, Primary Venturi Cluster |
| | Consists of: | | 2 - ---- Gasket, Secondary Venturi Cluster |
| | 1 - ---- Gasket, Body | | 1 - ---- Gasket, Pump Jet Housing |
| | 1 - ---- Gasket, Body Flange | | |
| | 1 - ---- Gasket, Flange | | GASKET PACKAGE, |
| | 1 - ---- Gasket, Step-Up Piston | | CARBURETOR Part No. 2084 728 |
| | 1 - ---- Jet, Main Metering | | Consists of: |
| | 1 - ---- Needle, w/Seat, Float | | 1 - ---- Gasket, Air Horn |
| | 1 - ---- Plunger, w/Rod, Pump | | 1 - ---- Gasket, Float Needle Seat |
| | 1 - ---- Plug, High Speed Passage | | 1 - ---- Gasket, Power By-Pass Jet |
| | 1 - ---- Spring, Step-Up Piston | | 1 - ---- Gasket, Main Body |
| | 1 - ---- Tube, w/Plug, Idle Orifice | | 1 - ---- Gasket, Venturi Cluster |
| | 1 - ---- Tube, Main Vent | | |
| | REPAIR PACKAGE, | | GASKET PACKAGE, |
| | CARBURETOR Part No. 2240 471 | | CARBURETOR Part No. 2196 209 |
| | Consists of: | | Consists of: |
| | 1 - ---- Gasket, Body | | 1 - ---- Gasket, Air Cleaner |
| | 1 - ---- Gasket, Body Flange | | 1 - ---- Gasket, Air Horn |
| | 1 - ---- Gasket, Flange | | 1 - ---- Gasket, Flange |
| | 1 - ---- Gasket, Step-Up Piston | | 1 - ---- Gasket, Pump Jet Housing |
| | 1 - ---- Jet, Main Metering | | 2 - ---- Gasket, Primary Venturi Cluster |
| | 1 - ---- Needle, w/Seat, Float | | 2 - ---- Gasket, Secondary Venturi Cluster |
| | 1 - ---- Plunger, w/Rod, Pump | | |
| | 1 - ---- Plug, High Speed Passage | | GASKET PACKAGE, |
| | 1 - ---- Spring, Step-Up Piston | | CARBURETOR Part No. 2196 221 |
| | 1 - ---- Tube, w/Plug, Idle Orifice | | Consists of: |
| | 1 - ---- Tube, Main Vent | | 1 - ---- Gasket, Body |
| 14-30-7 | GASKET PACKAGE, | | 1 - ---- Gasket, Body Flange |
| | CARBURETOR Part No. 1631 368 | | 1 - ---- Gasket, Flange |
| | Consists of: | | 1 - ---- Gasket, Float Needle Seat |
| | 1 - ---- Gasket, Air Horn | | 1 - ---- Gasket, Step-Up Piston |
| | 1 - ---- Gasket, Float Needle Valve | | 1 - ---- Gasket, Step-Up Jet |
| | 1 - ---- Gasket, Main Body | | |
| | 2 - ---- Gasket, Metering Jet Plug | | 15-06-3 |
| | 1 - ---- Gasket, Power By-Pass Jet | | NAME PLATE PACKAGE, |
| | (Pkg. Cont'd) | | HOOD Part No. 2275 125 |
| | | | Consists of: |
| | | | 1 - ---- Name Plate |
| | | | 5 - 445 150 Nut |

★ Indicates use as required.

⊠ Indicates parts not listed in any previous parts book.
 March 1, 1962 Supersedes May 31, 1961.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|---------|---|---------|---|
| 15-25-2 | MOULDING PACKAGE, HOOD TOP Part No. 2240 933 Consists of: 1 - ---- Moulding 7 - 9415 250 Nut | | SHACKLE and BUSHING PACKAGE, REAR SPRING Part No. 2084 236 Consists of: 4 - ---- Bushing, Shackle 1 - ---- Insert, Shackle Bushing 2 - ---- Nut, Bolt 1 - ---- Plate, Shackle, Outer 1 - ---- Shackle |
| 16-03-1 | JOINT PACKAGE UNIVERSAL, FRONT . . Part No. 1603 398 Consists of: 2 - 1550 466 Ball and Roller 2 - ---- Button, Centering 1 - 870 539 Clamp, Large 1 - 870 540 Clamp, Small 1 - ---- Cover, Dust 1 - 602 820 Cover, Grease 1 - 1616 185 Gasket 1 - ---- Pin, Centering 1 - 1639 973 Spring 2 - 605 004 Washer, Thrust | | SHACKLE and BUSHING PACKAGE, REAR SPRING Part No. 2196 009 Consists of: 4 - ---- Bushing 1 - ---- Insert, Bushing 2 - 120 369 Nut 1 - ---- Plate 1 - ---- Shackle, w/Bolt |
| | JOINT PACKAGE, UNIVERSAL, FRONT . . Part No. 1752 680 Consists of: 2 - 1739 927 Ball and Roller 2 - ---- Button, Centering 1 - 870 540 Clamp, Small 1 - 1532 943 Clamp, Large 1 - ---- Cover, Dust 1 - 1635 092 Cover, Grease 1 - 1635 098 Gasket 1 - 1739 923 Pin, Centering 1 - 605 004 Washer, Thrust | | SHACKLE and BUSHING PACKAGE, REAR SPRING Part No. 2196 010 Consists of: 4 - ---- Bushing 1 - ---- Plate 1 - ---- Shackle, w/Bolt |
| | JOINT PACKAGE, UNIVERSAL, REAR . . . Part No. 1752 624 Consists of: 1 - ---- Cross, Assy. 4 - 858 006 Retainer, Roller and Bushing 4 - 1739 913 Roller and Bushing | 17-23-3 | ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 2240 317 Consists of: 1 - ---- Absorber 2 - 1319 902 Bushing |
| 16-07-4 | DUST COVER PACKAGE, UNIVERSAL JOINT . . . Part No. 1603 397 Consists of: 1 - 870 539 Clamp 1 - 870 540 Clamp 1 - ---- Cover, Dust | | ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 2240 358 Consists of: 1 - ---- Absorber 2 - 1319 902 Bushing |
| | DUST COVER PACKAGE, UNIVERSAL JOINT . . . Part No. 1450 448 Consists of: 1 - 1637 317 Clamp, Large 1 - 1637 316 Clamp, Small 1 - ---- Cover, Dust | | ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 2240 359 Consists of: 1 - ---- Absorber 2 - 1319 902 Bushing |
| 17-11-1 | BUSHING PACKAGE, REAR SPRING Part No. 2196 011 Consists of: 4 - ---- Bushing | | ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 2240 360 Consists of: 1 - ---- Absorber 2 - 1319 902 Bushing |
| 17-16-1 | SHACKLE AND BUSHING PACKAGE, REAR SPRING Part No. 1450 087 Consists of: 4 - ---- Bushing 2 - ---- Nut 2 - ---- Shackle | | ABSORBER and BUSHING PACKAGE, REAR SHOCK Part No. 2240 361 Consists of: 1 - ---- Absorber 2 - 1319 902 Bushing |
| | SHACKLE and BUSHING PACKAGE, REAR SPRING Part No. 1450 961 Consists of: 4 - ---- Bushing 2 - ---- Nut 2 - ---- Shackle | | ABSORBER and BUSHING PACKAGE, FRONT SHOCK Part No. 2240 316 Consists of: 1 - ---- Absorber 1 - 1635 588 Bushing, Lower Mounting 1 - 1614 385 Bushing, Upper Mounting |

★ Indicates use as required.
 ☒ Indicates parts not listed in any previous parts book.
 * Indicates change or addition.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|---------|--|----------|---|
| | <p>ABSORBER and BUSHING PACKAGE, FRONT</p> <p>SHOCK Part No. 2240 353</p> <p>Consists of:</p> <p>1 - ---- --- Absorber</p> <p>1 - 1635 588 Bushing, Lower Mounting</p> <p>1 - 1614 385 Bushing, Upper Mounting</p> <p>ABSORBER and BUSHING PACKAGE, FRONT</p> <p>SHOCK Part No. 2240 355</p> <p>Consists of:</p> <p>1 - ---- --- Absorber</p> <p>1 - 1635 588 Bushing, Lower Mounting</p> <p>1 - 1614 385 Bushing, Upper Mounting</p> <p>ABSORBER and BUSHING PACKAGE, FRONT</p> <p>SHOCK Part No. 2240 356</p> <p>Consists of:</p> <p>1 - ---- --- Absorber</p> <p>1 - 1635 588 Bushing, Lower Mounting</p> <p>1 - 1614 385 Bushing, Upper Mounting</p> <p>ABSORBER and BUSHING PACKAGE, FRONT</p> <p>SHOCK Part No. 2240 362</p> <p>Consists of:</p> <p>1 - ---- --- Absorber</p> <p>1 - 1635 588 Bushing, Lower Mounting</p> <p>1 - 1614 385 Bushing, Upper Mounting</p> <p>ABSORBER and BUSHING PACKAGE, FRONT</p> <p>SHOCK Part No. 2240 364</p> <p>Consists of:</p> <p>1 - ---- --- Absorber</p> <p>1 - 1635 588 Bushing, Lower Mounting</p> <p>1 - 1614 385 Bushing, Upper Mounting</p> | (Cont'd) | <p>1 - 1730 985 Seal, Shaft Oil</p> <p>1 - 2200 730 Seal, Worm Shaft Oil</p> <p>10 - 1123 313 Shim, Housing Cover</p> <p>19-01-4 "O" RING and SEAL PACKAGE, POWER</p> <p>STEERING GEAR Part No. 2084 839</p> <p>Consists of:</p> <p>1 - ---- --- Gasket, Valve Housing Plug</p> <p>1 - 1733 602 "O" Ring, Column Support</p> <p>2 - 1733 562 "O" Ring, Cylinder Head</p> <p>1 - 1486 205 "O" Ring, Cylinder Head Ferrule</p> <p>1 - 1316 849 "O" Ring, Housing</p> <p>2 - 1556 385 "O" Ring, Housing Port</p> <p>1 - 1536 268 "O" Ring, Pressure Control Valve Body</p> <p>1 - 1822 149 "O" Ring, Reaction, Upper</p> <p>1 - 1733 615 "O" Ring, Shaft Cover</p> <p>1 - 1733 612 "O" Ring, Valve Housing</p> <p>1 - 1822 151 Seal, Reaction, Lower</p> <p>1 - 1822 203 Seal, Shaft Adjusting Screw</p> <p>1 - 1730 985 Seal, Shaft Oil</p> <p>1 - 1822 324 Seal, Worm Sleeve</p> <p>"O" RING and SEAL PACKAGE, POWER</p> <p>STEERING GEAR Part No. 2084 840</p> <p>Consists of:</p> <p>1 - ---- --- Gasket, Valve Housing Plug</p> <p>1 - 1733 602 "O" Ring, Column Support</p> <p>2 - 1733 562 "O" Ring, Cylinder Head</p> <p>1 - 1486 205 "O" Ring, Cylinder Head Ferrule</p> <p>1 - 1823 150 "O" Ring, Housing</p> <p>2 - 1556 385 "O" Ring, Housing Port</p> <p>1 - 1536 268 "O" Ring, Pressure Control Valve</p> <p>1 - 1823 091 "O" Ring, Reaction, Lower</p> <p>1 - 1733 615 "O" Ring, Shaft Cover</p> <p>1 - 1733 612 "O" Ring, Valve Housing</p> <p>1 - 1733 593 Seal, Reaction, Upper</p> <p>1 - 1822 203 Seal, Shaft Adjusting Screw</p> <p>1 - 1730 985 Seal, Shaft Oil</p> <p>1 - 1822 324 Seal, Worm Shaft Inner</p> <p>"O" RING and SEAL PACKAGE, POWER</p> <p>STEERING GEAR Part No. 2196 032</p> <p>Consists of:</p> <p>1 - ---- --- Gasket, Valve Housing Plug</p> <p>1 - 1733 602 "O" Ring, Column Support</p> <p>2 - 1733 562 "O" Ring, Cylinder Head</p> <p>1 - 1486 205 "O" Ring, Cylinder Head Ferrule</p> <p>1 - 1316 849 "O" Ring, Housing</p> <p>2 - 1556 385 "O" Ring, Housing Port</p> <p>1 - 1536 268 "O" Ring, Pressure Control Valve Body</p> <p>1 - 1822 149 "O" Ring, Reaction, Upper</p> <p>1 - 1733 615 "O" Ring, Shaft Cover</p> <p>1 - 1733 612 "O" Ring, Valve Housing</p> <p>1 - 1822 151 Seal, Reaction, Lower</p> <p>1 - 1822 203 Seal, Shaft Adjusting Screw</p> <p>1 - 2072 039 Seal, Shaft Oil</p> <p>1 - 1822 324 Seal, Worm Sleeve</p> |
| 19-01-3 | <p>OVERHAUL PACKAGE, STEERING GEAR Part No. 2196 033</p> <p>Consists of:</p> <p>2 - 2072 038 Bearing, Shaft</p> <p>2 - 2072 060 Bearing, Worm Thrust</p> <p>2 - 2207 835 Bushing, Jacket to Shaft Seal</p> <p>2 - 2072 062 Cup, Worm Thrust Bearing</p> <p>1 - 2072 048 Gasket, Shaft Cover</p> <p>1 - 2073 675 Seal, Column Jacket to Shaft</p> <p>1 - 2072 056 Seal, Shaft</p> <p>1 - 2072 055 Seal, Worm Shaft</p> <p>1 - 2072 051 Shim, Shaft Adjusting Screw</p> <p>1 - 2072 052 Shim, Shaft Adjusting Screw</p> <p>1 - 2072 053 Shim, Shaft Adjusting Screw</p> <p>1 - 2072 054 Shim, Shaft Adjusting Screw</p> <p>OVERHAUL PACKAGE, STEERING GEAR Part No. 2196 995</p> <p>Consists of:</p> <p>1 - 2123 169 Bearing, Shaft Housing, Lower</p> <p>1 - 2123 170 Bearing, Shaft Housing, Upper</p> <p>2 - 2201 624 Bushing, Column Jacket Seal</p> <p>2 - 640 086 Cage and Roller, Worm Thrust Bearing</p> <p>1 - 637 539 Cup, Worm Lower Thrust Bearing</p> <p>1 - 376 751 Cup, Worm Upper Thrust Bearing</p> <p>1 - 1738 206 Gasket, Shaft Cover</p> <p>1 - 2201 234 Seal, Column Jacket Oil</p> <p>(Pkg. Cont'd)</p> | | |

★ Indicates use as required.

⊠ Indicates parts not listed in any previous parts book. May 31, 1961 Supersedes Oct. 3, 1960.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|----------|---|-----------|---|
| 19-02-4 | HOUSING PACKAGE, STEERING GEAR . . . Part No. *2240 602 Consists of: 1 - ---- --- Housing 1 - 1823 150 "O" Ring 1 - 1823 151 Spring | 19-54-55 | SEAL PACKAGE, POWER STEERING PUMP . . . Part No. B2279 997 Consists of: 1 - 1732 946 Oil Seal, Oil Reservoir 1 - 1738 662 Seal, Oil Reservoir Mounting 1 - 1734 913 Seal, Pump Shaft |
| | HOUSING PACKAGE, STEERING GEAR Part No. *2240 615 Consists of: 1 - ---- --- Housing 1 - 1823 150 "O" Ring 1 - 1823 151 Spring | | SEAL PACKAGE, POWER STEERING PUMP Part No. B2279 998 Consists of: 1 - 2120 018 Oil Seal, Oil Reservoir 1 - 2120 019 Seal, Oil Reservoir Mounting 1 - 2120 527 Seal, Pump Shaft |
| 19-15-39 | SPRING PACKAGE, POWER STEERING GEAR BALL GUIDE Part No. 2084 215 Consists of: 2 - ---- --- Plug 2 - ---- --- Spring | 19-54-128 | PLUG and SNAP RING PACKAGE, POWER STEERING FLOW CONTROL VALVE . . . Part No. 1879 353 Consists of: 1 - ---- --- Plug 1 - ---- --- Ring |
| 19-19-1 | SEAL PACKAGE, POWER STEERING CROSS SHAFT COVER Part No. B2279 986 Consists of: 1 - 1733 615 "O" Ring 1 - 1822 203 Seal, Shaft Adjusting Screw | 19-57-1 | SEAL PACKAGE, POWER STEERING GEAR VALVE Part No. B2279 985 Consists of: 1 - 1733 724 Gasket, Plug Valve Housing 1 - 1316 849 "O" Ring, Housing 1 - 1823 150 "O" Ring, Housing 1 - 1556 385 "O" Ring, Housing Port 1 - 1536 268 "O" Ring, Pressure Control Valve Body 1 - 1733 612 "O" Ring, Valve Housing |
| 19-27-2 | ARM PACKAGE, STEERING LINKAGE GEAR ARM. . Part No. 2084 613 Consists of: 1 - ---- --- Arm 1 - ---- --- Nut 1 - 108 636 Pin 1 - 1670 299 Seal | 19-57-2 | PISTON and SPRING PACKAGE, POWER STEERING GEAR PRESSURE CONTROL VALVE Part No. 1879 509 Consists of: 1 - ---- --- Piston 1 - 1822 442 Spring |
| 19-27-31 | IDLER ARM PACKAGE, STEERING LINKAGE . . Part No. 2084 614 Consists of: 1 - ---- --- Arm 1 - 2072 490 Bolt, Arm 1 - 1734 327 Bushing, Arm 1 - ---- --- Nut, Arm Bolt 1 - 128 014 Nut, Arm End 1 - ---- --- Oiler, Arm End 1 - 108 636 Pin, Arm End Nut Cotter 1 - 2072 455 Seal, Arm End | 21-01-3 | GASKET and SEAL PACKAGE POWERFLITE TRANSMISSION, PARTIAL Part No. 2084 616 Consists of: 1 - 1408 254 Gasket, Extension 1 - 1408 255 Gasket, Output Shaft Support 1 - 1408 282 Gasket, Oil Pan 1 - 1408 245 Seal, Frt. Oil Pump Housing 1 - 1738 265 Seal, Reaction Shaft 1 - 1486 536 Seal, Reaction Shaft 1 - 1738 264 Seal, Frt. Pump Drive Sleeve 1 - 1738 263 Seal, Hub |
| 19-48-7 | SMALL PARTS PACKAGE, GEARSHIFT CONTROL (W/STD. TRANS.) . . . Part No. 2240 631 Consists of: 2 - 1676 200 Bushing, Transmission Gearshift Operating Lever Grommet 2 - 1137 669 Clip, Rod Cotter 2 - 148 148 Clip, Rod Swivel 2 - 1941 699 Grommet, Transmission Gearshift Operating Lever 4 - 631 217 Washer, Rod, Plain 2 - 632 258 Washer, Rod Swivel, Plain 2 - 6012 072 Washer, Rod Swivel Spring | | GASKET and SEAL PACKAGE, COMPLETE POWERFLITE TRANSMISSION Part No. 2084 617 Consists of: 1 - 1408 254 Gasket, Extension 1 - 1408 255 Gasket, Output Shaft Support 1 - 1408 282 Gasket, Oil Pan 1 - 1672 066 Gasket, Valve Body 1 - 1117 819 Gasket, Regulator Valve Spring Retainer 1 - 1408 375 Gasket, Torque Converter Valve Spring Retainer 1 - 1316 864 "O" Ring, Control Cable 1 - 1736 376 Ring, Output Shaft Seal (Pkg. Cont'd) |
| 19-54-2 | PUMP PACKAGE, POWER STEERING GEAR Part No. 2196 082 Consists of: 1 - ---- --- Pump 1 - 2120 019 Seal, Oil Reservoir Mounting 1 - 2120 018 Seal, Oil Reservoir Oil | | |
| | PUMP PACKAGE, POWER STEERING Part No. *2240 620 Consists of: 1 - ---- --- Pump 1 - 1738 662 Seal, Oil Reservoir Mounting 1 - 1732 946 Seal, Oil Reservoir Oil | | |

★ Indicates use as required.

□ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|----------|---|----------|--|
| (Cont'd) | <p>1 - 1738 262 Ring, Direct Clutch Piston Retainer Seal</p> <p>1 - 1537 149 Ring, Reaction Shaft Seal</p> <p>1 - 1672 358 Ring, Throttle Cam Shaft Sleeve Seal</p> <p>1 - 1408 245 Seal, Frt. Oil Pump Housing</p> <p>1 - 1486 536 Seal, Reaction Shaft</p> <p>1 - 1738 265 Seal, Reaction Shaft</p> <p>1 - 1738 263 Seal, Hub</p> <p>1 - 1738 261 Seal, Direct Clutch Piston Ring</p> <p>1 - 1671 763 Seal, Output Shaft Rr. Bearing</p> <p>2 - 1401 256 Seal, Oil Strainer Tube</p> <p>1 - 863 987 Seal, Oil Pan Drain Plug</p> <p>1 - 1738 264 Seal, Frt. Oil Pump Sleeve</p> <p>GASKET SET, AUTO. 3 SPEED TRANSMISSION Part No. 1879 507 Consists of:</p> <p>1 - 1853 888 Gasket, Shaft Support</p> <p>1 - 1853 891 Gasket, Extension</p> <p>1 - 1636 448 Gasket, Oil Pan</p> <p>1 - 1636 303 Gasket, Valve Body</p> <p>1 - 1824 553 Ring, Shaft Seal</p> <p>1 - 1408 245 Seal, Oil Pump Housing</p> <p>SEAL and GASKET PACKAGE, STANDARD TRANSMISSION Part No. 2196 069 Consists of:</p> <p>1 - 1949 346 Gasket, Case Cover</p> <p>2 - 865 180 Gasket, Bearing Retainer</p> <p>1 - 865 181 Gasket, Bearing Retainer</p> <p>1 - 1949 361 Gasket, Extension</p> <p>1 - 1949 933 Seal, Pinion Retainer</p> <p>1 - 1854 449 Seal, Main Shaft Oil</p> <p>SEAL and GASKET PACKAGE, STANDARD TRANSMISSION Part No. 2240 320 Consists of:</p> <p>1 - 2124 466 Gasket, Case Cover</p> <p>1 - 2124 519 Gasket, Extension</p> <p>1 - 2124 499 Gasket, Bearing Retainer</p> <p>1 - 1949 933 Seal, Drive Pinion</p> <p>1 - 2205 080 Seal, Main Shaft</p> <p>1 - 2124 461 Seal, Main Shaft</p> <p>SEAL and GASKET PACKAGE, AUTO TRANSMISSION . Part No.*2275 422 Consists of:</p> <p>1 - 1942 390 Gasket, Reaction Shaft Support</p> <p>1 - 2205 299 Gasket, Oil Pan, After</p> <p>1 - 1942 165 Gasket, Parking Lock Cover, Up-To</p> <p>1 - ---- --- Gasket, Parking Lock Cover, After</p> <p>1 - 2205 322 Gasket, Extension</p> <p>1 - 863 987 Gasket, Drain Plug</p> <p>1 - 1942 516 Gasket, Oil Pan, Up-To</p> <p>2 - 1942 109 Ring, Governor Support Seal</p> <p>2 - 1941 831 Ring, Input Shaft Seal</p> <p>2 - 1942 389 Ring, Reaction Shaft Support Seal</p> <p>1 - 6022 859 Ring, Output Shaft</p> <p>1 - 1942 396 Seal, Front Clutch Piston, Inner</p> <p style="text-align: right;">(Pkg. Cont'd)</p> | (Cont'd) | <p>1 - 1942 397 Seal, Front Clutch Piston, Outer</p> <p>1 - 1942 384 Seal, Front Oil Pump Housing, Up-To</p> <p>1 - 2204 709 Seal, Front Oil Pump Housing, After</p> <p>1 - 1942 412 Seal, Rear Clutch Piston, Inner, Up-To</p> <p>1 - 2125 187 Seal, Rear Clutch Piston, Inner, After</p> <p>1 - 1942 397 Seal, Rear Clutch Piston, Outer</p> <p>1 - 2124 705 Seal, Impeller Hub</p> <p>1 - 1942 401 Seal, Output Shaft</p> <p>1 - 2205 300 Seal, Throttle Lever Shaft</p> <p>1 - 1942 454 Washer Output Shaft Thrust .052"</p> <p>1 - 1942 455 Washer, Output Shaft Thrust .068"</p> <p>1 - 1942 456 Washer, Output Shaft Thrust .083"</p> <p>SEAL and GASKET PACKAGE, STANDARD TRANSMISSION Part No. 2196 062 Consists of:</p> <p>1 - 1949 346 Gasket, Case Cover</p> <p>3 - 672 709 Gasket, Bearing Retainer</p> <p>1 - 1949 361 Gasket, Extension</p> <p>1 - 1949 343 Seal, Drive Pinion Oil</p> <p>1 - 1942 401 Seal, Main Shaft</p> <p>GASKET and SEAL PACKAGE, TRANSMISSION COMPLETE OVERHAUL, AUTO. 3 SPEED Part No. 2240 192 Consists of:</p> <p>1 - 1117 819 Gasket, Spring Retainer</p> <p>1 - 1408 375 Gasket, Spring Retainer</p> <p>1 - 1636 303 Gasket, Regulator Valve Body</p> <p>1 - 1636 448 Gasket, Oil Pan</p> <p>1 - 1672 074 Gasket, Cable Adapter Housing</p> <p>1 - 1853 891 Gasket, Extension</p> <p>1 - 1853 888 Gasket, Output Shaft Support</p> <p>1 - 1638 667 Plate, Carrier Thrust</p> <p>2 - 1314 249 Ring, Kickdown Piston Seal</p> <p>1 - 1322 363 Ring, Kickdown Piston Seal</p> <p>1 - 1323 593 Ring, Input Shaft Oil Seal</p> <p>1 - 1329 638 Ring, Reverse Servo Piston</p> <p>2 - 1636 324 Ring, Shaft Seal</p> <p>2 - 1636 469 Ring, Sun Gear Rear Clutch Seal</p> <p>2 - 1636 470 Ring, Governor Support Seal</p> <p>4 - 1672 287 Ring, Intermediate Shaft Seal</p> <p>1 - 1736 224 Ring, Kickdown Piston Seal</p> <p>1 - 1736 233 Ring, Accumulator Piston</p> <p>1 - 1736 376 Ring, Output Shaft Seal</p> <p>1 - 1854 304 Ring, Front Oil Pump Drive Sleeve Seal</p> <p>1 - 1824 549 Ring, Front Clutch Piston Seal</p> <p>1 - 1824 550 Ring, Rear Clutch Piston Seal</p> <p style="text-align: right;">(Pkg. Cont'd)</p> |

★ Indicates use as required.

⊠ Indicates parts not listed in any previous parts book.
March 1, 1962 Supersedes May 31, 1961.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|----------|---|----------|---|
| (Cont'd) | | (Cont'd) | |
| | 1 - 1824 551 Ring, Front Clutch Piston Seal | | 1 - 1636 376 Washer, Carrier Thrust |
| | 1 - 1824 552 Ring, Rear Clutch Piston Seal | | 1 - 1638 669 Washer, Input Shaft Thrust |
| | 1 - 1824 553 Ring, Reaction Shaft Seal | | 1 - 1638 670 Washer, Input Shaft Thrust |
| | 1 - 1941 831 Ring, Input Shaft Oil Seal | | 1 - 1638 671 Washer, Input Shaft Thrust |
| | 2 - 1401 256 Seal, Oil Strainer Tube | | 1 - 1823 872 Washer, Input Shaft Thrust |
| | 1 - 1408 245 Seal, Front Oil Pump Housing | | GASKET, PLATE and DISC PACKAGE, |
| | 1 - 1738 263 Seal, Impeller Hub Oil | | TRANSMISSION COMPLETE |
| | 1 - 1738 264 Seal, Front Oil Pump Drive Sleeve | | OVERHAUL, POWER- |
| | 1 - 1824 075 Seal, Output Shaft Oil | | FLITE Part No. 2240 194 |
| | 2 - 1636 290 Washer, Front Clutch and Sun Gear Thrust | | Consists of: |
| | 1 - 1636 314 Washer, Sun Gear Thrust | | 7 - 1633 843 Disc, Clutch Driving |
| | 1 - 1636 376 Washer, Carrier Thrust | | 1 - 1117 819 Gasket, Valve Spring Retainer |
| | 1 - 1638 669 Washer, Input Shaft Thrust | | 1 - 1672 066 Gasket, Regulator Valve Body |
| | 1 - 1638 670 Washer, Input Shaft Thrust | | 1 - 1408 254 Gasket, Extension |
| | 1 - 1638 671 Washer, Input Shaft Thrust | | 1 - 1408 255 Gasket, Output Shaft |
| | 1 - 1823 872 Washer, Input Shaft Thrust | | 1 - 1408 282 Gasket, Oil Pan |
| | GASKET and SEAL PACKAGE, | | 1 - 1408 375 Gasket, Valve Spring Retainer |
| | TRANSMISSION COMPLETE | | 7 - 1408 232 Plate, Direct Clutch |
| | OVERHAUL, AUTO. 3 | | 1 - 1316 864 "O" Ring, Control Cable |
| | SPEED Part No.*2298 927 | | 1 - 1329 638 Ring, Reverse Servo Piston |
| | Consists of: | | 1 - 1736 376 Ring, Output Shaft Seal |
| | 1 - 1117 819 Gasket, Spring Retainer | | 1 - 1738 262 Ring, Piston Retainer Seal |
| | 1 - 1408 375 Gasket, Spring Retainer | | 2 - 1537 149 Ring, Reaction Shaft Seal |
| | 1 - 1636 303 Gasket, Regulator Valve Body | | 1 - 1672 358 Ring, Shaft Sleeve Seal |
| | 1 - 1636 448 Gasket, Oil Pan | | 1 - 1738 264 Ring, Drive Sleeve |
| | 1 - 1672 074 Gasket, Cable Adapter Housing | | 1 - 863 987 Seal, Drain Plug |
| | 1 - 1853 891 Gasket, Extension | | 2 - 1401 256 Seal, Oil Strainer Tube |
| | 1 - 1853 888 Gasket, Output Shaft Support | | 1 - 1408 245 Seal, Front Oil Pump Housing |
| | 1 - 1638 667 Plate, Carrier Thrust | | 1 - 1486 536 Seal, Reaction Shaft |
| | 2 - 1314 249 Ring, Kickdown Piston Seal | | 1 - 1671 763 Seal, Output Shaft Bearing Oil |
| | 1 - 1322 363 Ring, Kickdown Piston Seal | | 1 - 1738 261 Seal, Direct Clutch Piston Ring |
| | 1 - 1323 593 Ring, Input Shaft Oil Seal | | 1 - 1738 263 Seal, Impeller Hub |
| | 1 - 1329 638 Ring, Reverse Servo Piston | | 1 - 1738 265 Seal, Reaction Shaft |
| | 2 - 1636 324 Ring, Shaft Seal | | 1 - 1638 462 Washer, Carrier Front Thrust |
| | 2 - 1636 469 Ring, Sun Gear Rear Clutch Seal | | 21-113-24 SWITCH PACKAGE, TRANSMISSION |
| | 2 - 1636 470 Ring, Governor Support Seal | | NEUTRAL STARTER . . Part No. 1704 283 |
| | 4 - 1672 287 Ring, Intermediate Shaft Seal | | Consists of: |
| | 1 - 1736 224 Ring, Kickdown Piston Seal | | 1 - 1316 849 "O" Ring, Mounting |
| | 1 - 1736 233 Ring, Accumulator Piston | | 1 - ---- --- Switch, Neutral Starter |
| | 1 - 1736 376 Ring, Output Shaft Seal | | 1 - 1704 482 Washer, Mounting |
| | 1 - 1854 304 Ring, Front Oil Pump Drive Sleeve Seal | | 21-117-1 FILTER PACKAGE, |
| | 1 - 1824 549 Ring, Front Clutch Piston Seal | | TRANSMISSION OIL . . Part No.*2298 944 |
| | 1 - 1824 550 Ring, Rear Clutch Piston Seal | | Consists of: |
| | 1 - 1824 551 Ring, Front Clutch Piston Seal | | 1 - 2400 126 Bracket, Filter |
| | 1 - 1824 552 Ring, Rear Clutch Piston Seal | | 1 - 2268 908 Clamp, Filter |
| | 1 - 1941 831 Ring, Input Shaft Oil Seal | | 1 - 2400 124 Filter, Oil |
| | 1 - 1824 553 Ring, Reaction Shaft Seal | | 1 - 137 398 Nut, Tube, Inlet |
| | 2 - 1401 256 Seal, Oil Strainer Tube | | 1 - 1941 667 Nut, Tube, Outlet |
| | 1 - 1408 245 Seal, Front Oil Pump Housing | | FILTER PACKAGE, |
| | 1 - 2400 084 Seal, Impeller Hub Oil | | TRANSMISSION OIL . . Part No.*2298 945 |
| | 1 - 1738 264 Seal, Front Oil Pump Drive Sleeve | | Consists of: |
| | 1 - 1824 075 Seal, Output Shaft Oil | | 1 - 2400 078 Bracket, Filter |
| | 2 - 1636 290 Washer, Front Clutch and Sun Gear Thrust | | 1 - 2268 908 Clamp, Filter |
| | 1 - 1636 314 Washer, Sun Gear Thrust | | 1 - 2400 124 Filter, Oil |
| | (Pkg. Cont'd) | | 1 - 137 398 Nut, Tube, Inlet |
| | | | 1 - 1941 667 Nut, Tube, Outlet |

★ Indicates use as required.

□ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|----------|---|------------|---|
| 21-118-1 | GASKET SET, AUTO. 3 SPEED TRANSMISSION FRONT OIL PUMP Part No. 1843 230 Consists of: 1 - 1636 303 Gasket, Regulator Valve Body 1 - 1117 819 Gasket, Regulator Valve Spring Retainer 1 - 1408 375 Gasket, Torque Converter Control Valve Spring Retainer 1 - 1738 263 Oil Seal, Impeller Hub 1 - 1824 553 Ring, Reaction Shaft Seal 1 - 1854 304 Ring, Drive Seal 1 - 1408 245 Seal, Frt. Oil Pump Housing 1 - 1738 264 Seal, Frt. Oil Pump Drive Sleeve GASKET SET, AUTO. 3 SPEED TRANSMISSION EXTENSION and REAR OIL PUMP . . Part No. 2240 332 Consists of: 1 - 1853 888 Gasket, Output Shaft Support 1 - 1853 891 Gasket, Extension 1 - 1636 470 Ring, Governor Support Seal 1 - 1824 075 Seal, Output Shaft Oil GASKET SET, AUTO. 3 SPEED TRANSMISSION FRONT OIL PUMP Part No. *2298 926 Consists of: 1 - 1636 303 Gasket, Regulator Valve Body 1 - 1117 819 Gasket, Regulator Valve Spring Retainer 1 - 1408 375 Gasket, Torque Converter Control Valve Spring Retainer 1 - 2400 084 Oil Seal, Impeller Hub 1 - 1824 553 Ring, Reaction Shaft Seal 1 - 1854 304 Ring, Drive Seal 1 - 1408 245 Seal, Frt. Oil Pump Housing 1 - 1738 264 Seal, Frt. Oil Pump Drive Sleeve | 21-133-3 | GASKET and SEAL PACKAGE, AUTO. 3 SPEED TRANSMISSION FRONT and REAR CLUTCH and INPUT SHAFT Part No. 1843 229 Consists of: 1 - 1636 448 Gasket, Oil Pan 1 - 1672 074 Gasket, Cable Adapter 1 - 1824 551 Ring, Frt. Clutch Piston Seal, Inner 1 - 1824 549 Ring, Frt. Clutch Piston Seal, Outer 1 - 1323 593 Ring, Input Shaft, Large 1 - 1941 831 Ring, Input Shaft, Small 1 - 1824 550 Ring, Rear Clutch Piston Seal, Outer 1 - 1824 552 Ring, Rear Clutch Piston Seal, Inner 1 - 1314 249 Ring, Output Shaft Seal, Large 1 - 1736 376 Ring, Output Shaft Seal, Small 1 - 1636 324 Ring, Intermediate Shaft Seal, Small 4 - 1672 287 Ring, Intermediate Shaft Seal, Large 2 - 1636 469 Ring, Rear Clutch Seal 2 - 1401 256 Seal, Oil Strainer Tube |
| | | 21-133-37 | PLATE and DISC PACKAGE, POWERFLITE TRANSMISSION DIRECT CLUTCH DRIVING Part No. 1643 259 Consists of: 7 - ---- Disc 7 - ---- Plate |
| | | 21-136-228 | CAM and RETAINER PACKAGE, OVERRUNNING CLUTCH Part No. 2279 000 Consists of: 1 ---- Cam, Overrunning 1 - ---- Retainer, Spring 5 - ---- Screw 5 - 1823 543 Washer |
| 21-118-6 | ROTOR PACKAGE, AUTO. 3 SPEED TRANSMISSION FRONT OIL PUMP Part No. 2240 302 Consists of: 1 - ---- Rotor, Front Oil Pump, Inner 1 - ---- Rotor, Front Oil Pump, Outer ROTOR PACKAGE, REAR OIL PUMP, AUTO. TRANS- MISSION Part No. 2196 795 Consists of: 1 - 1672 296 Rotor, Outer 1 - ---- Rotor, Inner | 21-138-2 | REPAIR PACKAGE, POWERFLITE TRANSMISSION GOVERNOR Part No. 1653 463 Consists of: 1 - ---- Body, Governor 1 - 1329 702 Ring, Weight 1 - 1559 495 Ring, Weight 1 - 1736 468 Screw, Locating 1 - 1556 082 Shaft, Valve 2 - 1638 461 Snap Ring, Shaft 1 - 1559 498 Spring, Weight 1 - 1315 155 Valve, Governor 1 - 1559 494 Weight, Governor, Outer 1 - 1559 496 Weight, Governor, Intermediate 1 - 1559 497 Weight, Governor, Inner |
| 21-131-1 | BODY PACKAGE, POWERFLITE TRANSMISSION REGULATOR VALVE Part No. 1643 243 Consists of: 1 - ---- Body, Regulator Valve 1 - 1630 812 Spring, Torque Converter Control Valve 1 - 2124 247 Valve, Torque Converter Control | | REPAIR PACKAGE, AUTO. 3 SPEED TRANSMISSION GOVERNOR Part No. 2084 602 Consists of: 1 - ---- Body, Governor 1 - 1736 468 Screw, Locating 1 - 1556 082 Shaft, Valve |

(Pkg. Cont'd)

★ Indicates use as required.

⊠ Indicates parts not listed in any previous parts book.
March 1, 1962 Supersedes May 31, 1961.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|----------|--|----------|--|
| (Cont'd) | 1 - 1949 858 Spring, Weight 1 - 1636 464 Snap Ring, Inner Weight 1 - 1636 465 Snap Ring, Outer Weight 2 - 1638 461 Snap Ring, Valve Shaft 1 - 1736 424 Valve, Governor 1 - 1636 461 Weight, Governor, Outer 1 - 1636 462 Weight, Governor, Inner REPAIR PACKAGE, AUTO. 3 SPEED TRANSMISSION GOVERNOR Part No. 2084 603 Consists of: 1 - ---- --- Body, Governor 1 - 1736 468 Screw, Locating 1 - 1556 082 Shaft, Valve 1 - 1636 464 Snap Ring, Inner Weight 1 - 1636 465 Snap Ring, Outer Weight 2 - 1638 461 Snap Ring, Valve Shaft 1 - 1949 859 Spring, Weight 1 - 1736 424 Valve, Governor 1 - 1636 461 Weight, Governor, Outer 1 - 1636 462 Weight, Governor, Inner REPAIR PACKAGE, AUTO. TRANS- MISSION GOVERNOR . . Part No. 2196 998 Consists of: 1 - ---- --- Body, Governor 2 - 2125 024 Lock, Body Bolt 4 - 180 019 Bolt, Body 2 - 1942 109 Ring, Support Seal or Piston 1 - 1636 464 Snap Ring, Weight, Inner 1 - 1636 465 Snap Ring, Weight, Outer 2 - 1638 461 Snap Ring, Valve Shaft 1 - 1942 471 Snap Ring, Body 1 - 2124 662 Spring, Governor 1 - 1556 082 Shaft, Valve 1 - 2124 663 Valve, Governor 1 - 1636 461 Weight, Governor, Outer 1 - 1636 462 Weight, Governor, Inner REPAIR PACKAGE, AUTO. 3 SPEED TRANSMISSION GOVERNOR Part No. 1843 403 Consists of: 1 - ---- --- Body, Governor 1 - 1736 468 Screw, Locating 1 - 1556 082 Shaft, Valve 1 - 2124 252 Spring, Weight 1 - 1636 464 Snap Ring, Inner Weight 1 - 1636 465 Snap Ring, Outer Weight 2 - 1638 461 Snap Ring, Valve Shaft 1 - 1736 424 Valve, Governor 1 - 1823 726 Weight, Governor Outer 1 - 1636 462 Weight, Governor Inner 23-14-53 HANDLE PACKAGE, FRONT DOOR VENT WING . . . Part No. 1954 110 Consists of: 1 - ---- --- Handle, Right 1 - ---- --- Key 1 - ---- --- Pin 1 - 6000 110 Washer 1 - ---- --- Spring HANDLE PACKAGE, FRONT DOOR VENT WING . . . Part No. 1954 111 Consists of: 1 - ---- --- Handle, Left 1 - ---- --- Key (Pkg. Cont'd) | (Cont'd) | 1 - 6000 116 Pin 1 - 6000 110 Washer 1 - ---- --- Spring DOOR VENT WING . . Part No. 2167 916 Consists of: 1 - ---- --- Handle, Right 1 - 6000 116 Pin 1 - 6000 110 Washer HANDLE PACKAGE, FRONT DOOR VENT WING . . . Part No. 2167 917 Consists of: 1 - ---- --- Handle, Left 1 - 6000 116 Pin 1 - 6000 110 Washer DOOR VENT WING . . . Part No. 2259 214 Consists of: 1 - ---- --- Handle, Right 1 - 6000 110 Washer 1 - 6000 116 Pin HANDLE PACKAGE, FRONT DOOR VENT WING . . . Part No. 2259 215 Consists of: 1 - ---- --- Handle, Left 1 - 6000 110 Washer 1 - 6000 116 Pin 23-17-2 CYLINDER and KEYS PACKAGE, DOOR and IGNITION LOCK Part No. 2080 227 Consists of: 1 - ---- --- Cylinder, Ignition 1 - ---- --- Cylinder, Door, Right 1 - ---- --- Cylinder, Door, Left 2 - ---- --- Keys CYLINDER and KEYS PACKAGE, DOOR and IGNITION LOCK Part No. 2161 192 Consists of: 1 - ---- --- Cylinder, Ignition 1 - ---- --- Cylinder, Door, Right 1 - ---- --- Cylinder, Door, Left 2 - ---- --- Keys CYLINDER and KEYS PACKAGE, DOOR and IGNITION LOCK Part No. 2161 503 Consists of: 1 - ---- --- Cylinder, Ignition 1 - ---- --- Cylinder, Door, Right 1 - ---- --- Cylinder, Door, Left 2 - ---- --- Keys 23-17-5 CYLINDER and KEYS PACKAGE, DECK LID LOCK Part No. 2086 049 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys CYLINDER and KEYS PACKAGE, DECK LID LOCK Part No. 2161 424 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys CYLINDER and KEYS PACKAGE, DECK LID LOCK Part No. 2161 865 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys |

★ Indicates use as required.

☒ Indicates parts not listed in any previous parts book.

* Indicates change or addition.

| CODE | PART NAME AND PART NUMBER | CODE | PART NAME AND PART NUMBER |
|-----------|--|-----------|--|
| 23-17-24 | CYLINDER and KEYS PACKAGE, DOOR LOCK Part No. 2086 048 Consists of: 1 - ---- --- Cylinder, Right 1 - ---- --- Cylinder, Left 2 - ---- --- Keys CYLINDER and KEYS PACKAGE, DOOR LOCK Part No. 2161 356 Consists of: 1 - ---- --- Cylinder, Right 1 - ---- --- Cylinder, Left 2 - ---- --- Keys | 24-25-93 | VALVE PLATE PACKAGE Part No. 2275 204 Consists of: 1 - 1990 584 Gasket, Cylinder Head 1 - 1990 598 Gasket, Valve Plate 1 - 1994 395 Plate, Valve VALVE PLATE PACKAGE Part No. 2275 205 Consists of: 1 - 1990 584 Gasket, Cylinder Head 1 - 1990 598 Gasket, Valve Plate 1 - 1994 396 Plate, Valve |
| 23-17-49 | CYLINDER and KEYS PACKAGE, TAILGATE LOCK Part No. 2161 423 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys CYLINDER and KEYS PACKAGE, TAILGATE LOCK Part No. 2161 599 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys | 24-25-154 | CRANKSHAFT PACKAGE Part No. 2275 206 Consists of: 1 - ---- --- Crankshaft 1 - 1990 584 Gasket, Cylinder Head 1 - 1377 825 Gasket, Oil Sump 2 - 1990 598 Gasket, Valve Plate 1 - 1377 831 Seal, Bearing Housing 1 - ---- --- Seal, Crankshaft Gas 1 - ---- --- Washer, Thrust |
| 23-17-72 | CYLINDER and KEYS PACKAGE, TIREWELL COVER LOCK Part No. 2161 615 Consists of: 1 - ---- --- Cylinder 2 - ---- --- Keys | 24-25-162 | BEARING HOUSING PACKAGE Part No. 2196 315 Consists of: 1 - ---- --- Housing 1 - ---- --- 1877 831 Seal |
| 23-18-120 | TERMINAL and INSULATOR PACKAGE, ELECTRIC DOOR LOCK SOLENOID Part No. 1843 226 Consists of: 10 - ---- --- Insulators 10 - ---- --- Terminals, Male 10 - ---- --- Terminals, Female | 24-25-246 | OIL PUMP PACKAGE . . Part No. 2196 306 Consists of: 1 - ---- --- Cover, Oil Pump 1 - 1747 988 Seal, Cover 1 - ---- --- Rotor, Outer 1 - ---- --- Rotor, Inner 1 - ---- --- Shaft |
| 24-24-23 | BLOWER SWITCH ADAPTER PACKAGE Part No. 2196 336 Consists of: 1 - ---- --- Spring, Control Arm 2 - ---- --- Bushing, Control Arm | 24-26-20 | RECEIVER DRIER PACKAGE Part No. 1880 658 Consists of: 1 - ---- --- Gasket 1 - ---- --- Receiver Drier |
| 24-25-2 | PISTON RING PACKAGE Part No. 2275 207 Consists of: 1 - 1990 584 Gasket, Cylinder Head 1 - 1377 825 Gasket, Oil Sump 1 - 1990 598 Gasket, Valve Plate | 24-28-36 | TUBING SEALING WASHER PACKAGE Part No. 2196 341 Consists of: 6 - ---- --- Seal, 5/8" O. D. 2 - ---- --- Seal, 1/2" O. D. 1 - ---- --- Seal, 3/8" O. D. |
| 24-25-3 | PISTON and CONNECTING ROD PACKAGE Part No. 2275 203 Consists of: 1 - ---- --- Ball, Oil Pressure 1 - 1990 584 Gasket, Cylinder Head 1 - 1990 598 Gasket, Valve Plate 1 - 1377 825 Gasket, Oil Sump 1 - ---- --- Piston, w/Connecting Rod 1 - ---- --- Spring, Oil Pressure | 24-28-322 | INDICATOR PACKAGE . . Part No. 1880 657 Consists of: 1 - ---- --- Gasket, Receiver Drier 1 - ---- --- Indicator |
| 24-25-70 | SEAL PACKAGE, CRANKSHAFT GAS . . . Part No. 1426 501 Consists of: 1 - ---- --- Seal, Crankshaft Gas 1 - 1377 831 Seal, Bearing Housing | 24-28-379 | DEFROSTER DOOR PACKAGE Part No. 2084 295 Consists of: 1 - ---- --- Clip, Outlet Rod Lever 1 - ---- --- Clip, Outlet Rod 1 - ---- --- Door, w/Seal 1 - ---- --- Lever, Door 1 - ---- --- Nut, Shaft 1 - ---- --- Rod, Door 1 - ---- --- Shaft, w/Lever 1 - ---- --- Spacer, Shaft |

NOTES

★ Indicates use as required.
 ☒ Indicates parts not listed in any previous parts book.
 March 1, 1962 Supersedes May 31, 1961.