

GROUP-FIGURE/KEY NO.	GROUP-FIGURE/KEY NO.
	ADAPTER, Distributor 8-200/14
	ADAPTER, Except 4000 lb. Front Axle 5-100/13
	ADAPTER, Rect. H/Lamp Rad. Grille Supt. Rt. or Lt.(Not Shown) 8-2700/40
	ADAPTER, Rect. H/Lp. Support RT.& LT. 8-2900/12
	ADAPTER, Trans. Case to Eng., w/I.H.C. 446 Eng. 21A-100/3
	ADAPTER, Trans. To Transfer Case, w/A727 Trans. 21M-1150/62
	ADAPTER, Trans. to Transfer Case (Use w/3820722 Trans. Assy.) 21M-100/42
	ADAPTER, Trans. to Transfer Case, w/A727 Trans. 21M-1125/10
	ADAPTER, Trans. to Transfer Case, W1,2,3,4-AW1 21A-100/17
	ADAPTER, Transfer Case 21M-1125/6
	ADAPTER, Transfer Case, Use w/A727 Trans. 21M-1000/1
	ADAPTER, w/3500 lb. Front Axle 5-200/5
	ADAPTOR or FITTING, Oil Press. & Elect. Choke Switch & Oil Press. Sending Unit (6 Cyl. Eng.) (Not S 8-5900/29
	ADAPTOR or FITTING, Oil Press. & Elect. Choke Switch & Oil Press. Sending Unit (6 Cyl. Eng.) (Not S 8-6100/41
	ADAPTOR, Oil Gauge Sending Unit, w/225 Eng. - 1978 8-6100/38
	ADJUSTER ASSY., Seat - Up To 12-1-78 23-3625/11
	ADJUSTER, Bucket Seat, Outer - Up To 4-3-78 23-5500/2
	ADJUSTER, Seat Lt. - Up To 4-3-78 23-3600/4
	ADJUSTER, Frt. Seat Club Cab & Sport Utility, RT. 23-8900/1
	AIR CLEANER 14-125
	AIR CLEANER 14-135
	AIR CLEANER 14-150
	AIR CLEANER 14-185
	AIR CLEANER 14-197
	AIR CLEANER & FRESH AIR INTAKE SYSTEM 14-175
	AIR CLEANER - 225 ENGINE 14-100
	AIR CLEANER 360-3 - 440-3 ENGINE 14-195
	AIR CLEANER, Booster 5-1600/10
	AIR PUMP 25-20
	AIR PUMP 25-25
	AIR PUMP 25-50
	AIR PUMP 25-60
	AIR PUMP 25-65
	AIR PUMP 25-80
	AIR PUMP 25-83
	AIR PUMP & DIVERTER VALVE 25-86
	AIR PUMP TUBING 25-55
	AIR PUMP TUBING 25-57
	AIR PUMP TUBING 25-61
	AIR PUMP TUBING 25-63
	AIR PUMP TUBING w/AIR SWITCHING VALVE 25-30
	AIR PUMP TUBING w/o AIR SWITCHING VALVE 25-40
	ALTERNATOR (100 AMP) 8-1100
	ALTERNATOR (41-63 AMPS) 8-800
	ALTERNATOR MTG. 8-1800
	ALTERNATOR MTG. 8-1900
	ALTERNATOR MTG. 8-2000
	ALTERNATOR MTG. 8-2100
	ALTERNATOR MTG. (100 AMP.) 8-1700
	ALTERNATOR MTG.(100 AMP.) 8-1300
	ALTERNATOR MTG.(100 AMP.) 8-1500
ACCELERATOR PEDAL MOUNTING 14-860	
ACCELERATOR PEDAL MOUNTING 14-955	
ACCELERATOR PEDAL MOUNTING 14-990	
ACTUATOR ASSY., Recliner - Up To 12-4-78 23-3550/6	
ACTUATOR and READOUT, Trip Computer Approx. After 10/1/79 8-8900/1	
ACTUATOR and Retaining RING PACKAGE, Starter Clutch Shifting 8-400/7	
ACTUATOR, A/C Recirc. Door 24-425/3	
ACTUATOR, A/C and Htr. A/C Door Vac. 24-425/12	
ACTUATOR, A/C and Htr. Defr. Door Vac. 24-425/13	
ACTUATOR, Ignition Switch (Not Shown) 8-6800/14	
ACTUATOR, Latch 23-4400/29	
ACTUATOR, Ignition Switch 19-500/27	
ADAPTER PLATE, M/Cylinder to Dash 5-1800/2	
ADAPTER PLATE, M/Cylinder to Dash 5-1825/3	
ADAPTER, Case (Use w/Trans. Service Assy. No. 3822278) 21M-500/9	
ADAPTER, Case (Use w/Trans. Service Assy. No. 4210628) 21M-500/9	
ADAPTER, Case to Transfer Case (Use w/Trans. Assy.No. 3822550) 21M-700/50	
ADAPTER, Disc Brake, 1978 5-300/3	

1978-81 LIGHT DUTY TRUCK PARTS CATALOG

	GROUP-FIGURE/KEY NO.
ALTERNATOR MTG.(100 AMP.)	8-1600
ALTERNATOR MTG.(EXC.100 AMP.)	8-1200
ALTERNATOR MTG.(EXC.100 AMP.)	8-1400
ALTERNATOR(65 AMPS.) 446-Engine	8-1000/A
ALTERNATOR-(65 AMPS.)	8-1000
AM-CB w/Fader 1978	1-500/1
AMMETER	8-2200/6
ANCHOR, P/Brake	4-1000/28
ANCHOR, Table Leg, Lower	23-3750/3
ANNULUS And CLUTCH ASSY., Complete	21M-1150/79
ANTENNA Pkg. CB Radio	1-500/30
APPLIQUE - H/Gate Center w/o N/Plate	23-5425/3
APPLIQUE - T/Gate Center w/o N/Plate	23-5425/12
APPLIQUE ASSY., "Dodge Ram" - 1981	23-5000/18
APPLIQUE ASSY., Tailgate "Dodge Ram"- 1981	23-7200/12
APPLIQUE ASSY., Tailgate "Dodge Ram"- 1981	23-7300/20
ARM & STRG.KNUCKLE,FRONT SUSP. UPPER CONTROL	17-52
ARM ASSY.,Upper Control-With 3300 Lb. Axle	17-52/7
ARM ASSY.,Upper Control-With 3600 Lb. Axle	17-52/7
ARM ASSY.,Upper Control-With 4000 Lb. Axle	17-52/7
ARM ASSY.,lower control	17-53/19
ARM ASSY.,lower control-(complete)	17-53/19
ARM ASSY.,lower control-with 3300 lb.axle-after approx.5-21-79	17-53/19
ARM ASSY.,lower control-with 3600 lb. axle	17-53/19
ARM ASSY.,lower control-with 4000 lb. axle	17-53/19
ARM KIT,Steering Knuckle	2-100/8
ARM KIT,Steering Knuckle	2-200/8
ARM REST, (Hi-Line) Drivers, Blue - Up To 12-4-78	23-3500/4
ARM REST, Black	23-8400/3
ARM REST, Blue, 1978-9	23-3700/2
ARM REST, Hi-Back, Blue - Up To 12-4-78	23-5600/1A
ARM REST, Rear Seat, Black	23-6200/4
ARM REST, Seat	23-3625/10
ARM RESTS,RISERS AND SUPPORTS, REAR SEATS	23-3710
ARM, Distributor w/3874876	8-100/16
ARM, Tailgate Check, Swepline	23-5400/1
ARM,COIL SPRG.,SHOCK & SWAY BAR,FRT.SUSP.LOWER CONTROL-B100-200-300,CB-MB-1979-80-81	17-53
ARM,Drag Link-Left	2-1450/7
ARM,Drag Link-Refer To Figure 2-1475-1979-80	2-1500/27
ARM,Lower Control-With 3300 Lb. Axle-Up TO Approx.5-21-79	17-53/19
ARM,Steering Gear	2-1150/11
ARM,Steering Idler	2-1150/16
ARM,Steering Knuckle Tie Rod-Right	2-1450/1
ARM,Steering Knuckle Tie Rod-Left	2-1450/1
ARM,Steering Knuckle-With 4000 Lb. Axle	17-52/16
ARM,Steering-Refer To Steering Arm Kit-Item 8	2-200/1
ARM,Tie Rod -Refer To Figure 2-1475-1979-80	2-1500/27
ARM,drag link-left 1979-80	2-1475/3
ARM,steering knuckle tie rod-1979-80	2-1475/7
ARM,strg.knuckle-With 3300,3600 Lb.Axle-up to approx.12-1-80	17-52/16
ARM,strg.knuckle-With 3300,3600 Lb.Axle-after approx.12-1-80	

	GROUP-FIGURE/KEY NO.
ARM,tie rod-1979-80	2-1475/7
ARMATURE PKG. Wiper Motor 2-Spd.	23-7800/5
ARMATURE, Motor, w/Intermittent Wipe	23-2200/1
ARMATURE, Starter	8-400/13
ARMATURE, Starter	8-600/6
ASH REC. & FACE PLATE	23-6700/4
ASH RECEIVER	23-5800
ASH RECEIVER, Eng. Housing	23-2400/10
ASH RECEIVER, Int. & Rear Seats	23-3700/3
ASPIRATOR	25-90
ATTACHING PARTS, Arm Rest	23-3500/--
ATTACHING PARTS, Arm Rest	23-3600/--
ATTACHING PARTS, Arm Rest	23-5500/--
AUTOMATIC SPEED CONTROL	14-205
AUTOMATIC SPEED CONTROL	14-210
AUTOMATIC SPEED CONTROL	14-215
AUTOMATIC SPEED CONTROL	14-220
AUTOMATIC SPEED CONTROL	14-230
AXLE COMPONENTS,FRONT	2-1500
AXLE, FRONT	2-270
AXLE, w/o Drive Shafts, 6200 lb., 4.10 Ratio-1978	3-500
AXLE,FRONT	2-100
AXLE,FRONT	2-200
AXLE,FRONT	2-300
AXLE,FRONT	2-1475
AXLE,REAR	3-100
AXLE,REAR	3-300
AXLE,REAR	3-1500
BACK ASSEMBLY, 3 Pass., Low and Mid-Line	23-3650/2
BACK ASSY., Exc. Club Frt. & Rr.(Sales Code KL1)	23-5450/2
BACK COVER, (Hi-Line) Blue, 1978-9	23-3500/1
BACK COVER, 3 Pass., Low and Mid-Line	23-3650/2
BACK COVER, Deluxe (Sales Code KA5)	23-5500/1
BACK COVER, Deluxe (Sales Code KA5)	23-5600/1
BACK COVER, Deluxe Vinyl (Sales Code KCA)	23-6200/1
BACK, Jump Seat, Black	23-9300/5
BACK, Plate Htr. 1978	1-150/12
BAFFLE, Radiator Lower Lt	7-810/12
BAFFLE, Radiator Lower Rt	7-810/30
BAFFLE, Radiator Upper	7-810/18
BAFFLE, Rear Cross Sill To T/Gate	23-5400/--
BAFFLE,Side And Rear Cargo Doors	23-1300/2
BALANCER ASSEMBLY, 70" Door (Not Shown)	23-4400/42
BALL JOINT PACKAGE,Lower Control Arm-Without H.D.Package	17-50/26
BALL JOINT PACKAGE,Lower Control Arm-With H.D.Package	17-50/26
BALL JOINT PACKAGE,Upper Control Arm-Without H.D. Package	17-50/8
BALL JOINT PACKAGE,Upper Control Arm-With H.D. Package	17-50/8
BALL JOINT PKG.,Upper Control Arm-With 3000,3300,3600 Lb. Axle	17-55/10
BALL JOINT, Lift Gate Lift Rod	23-5300/8
BALL JOINT,Upper-With 3300,3600 Lb. Axle	17-52/9
BALL JOINT,Upper-With 4000 Lb. Axle	17-52/9

	GROUP-FIGURE/KEY NO.		GROUP-FIGURE/KEY NO.
BALL JT.PKG.,Lower Control Arm-With 3300,3600 Lb.Axle	17-53/17	BEARING, Starter Housing	8-400/6
BALL JT.PKG.,Lower Control Arm-With 4000 Lb.Axle	17-53/17	BEARING,Column Jacket Gearshift Housing	19-100/55
BAND, Kickdown, A727	21A-600/24	BEARING,Column Shaft	19-700/6
BAND, Kickdown, A904,A999	21A-600/23	BEARING,Column Shaft	19-3700/38
BAND, Reverse, A727	21A-600/7	BEARING,Column Shaft Lower	19-1200/3
BASE, Frt. Dr. Medallion Ram - 1981	23-400/37	BEARING,Lower Thrust-In 4037635 Repair Kit	19-2100/27
BASE, Frt. Fndr. Plymouth N/Plate - 1981	23-5000/27	BEARING,Strg.Column Gearshift Tube	19-100/55
BATTERY (See Battery Catalog)	8-3300/16	BEARING,adjuster plug-in 3633527 repair kit	19-2200/34
BATTERY TERMINAL and Positive Heat Sink PACKAGE, Alternator	8-900/13	BEARING,drive shaft	3-100/3
BEAM, Side Impact	12-150/2	BELLCRANK, 1978	5-1825/12
BEARING w/SLEEVE, Cl. Release, Up To 3-1-1979	6-400/4	BELT ASSY, Shoulder Tip Half, Drivers	23-3800/1
BEARING w/SLEEVE, Cl. Release, UP to 3-1-1979	6-700/4	BELT ASSY., 3 Pass., Tip Half, Blue, 1978-9	23-3900/1
BEARING w/SLEEVE, Clutch Release	6-100/5	BELT ASSY., 4 Pass.,Buckle Half, Blue, 1978-9	23-3900/4
BEARING w/SNAP RING, M/Shaft Rear	21M-500/41	BELT ASSY., Buckle Half	23-3625/3
BEARING, A/C Compr. Clutch	24-1400/12	BELT ASSY., Shoulder Tip Half, Drivers	23-3625/2
BEARING, Alternator Drive End	8-800/4	BELT ASSY., Swivel Seat Retr. Tip Half, Rt. Rr. (Black) - 1981	23-3625/1
BEARING, Alternator Drive End Shield	8-900/4	BELT ASSY., Tip Half, w/o Shoulder Belt	23-3625/1
BEARING, Alternator Rectifier End Shield	8-800/10	BELT Air Cond. Compressor Drive 1979-80-81	7-925/C
BEARING, Alternator Rectifier End Shield	8-900/10	BELT, Seat, Tip Half, Blue, 1978-9	23-3750/6
BEARING, Alternator Rectifier End Shield	8-1000/10	BELT,SHOULDER,FRONT & REAR	23-9100
BEARING, Alternator Rectifier End Shield	8-1100/17	BELTS SEAT - REAR	23-6300
BEARING, Case Input, Needle Roller, 2-9/32 O.D.	21M-1150/64	BELTS, SEAT - BUCKET SEAT	23-3800
BEARING, Cl. Torque Shaft Pivot - 1978-79-80	6-400/17	BELTS,SEAT	23-3900
BEARING, Cl. Torque Shaft Pivot - 1978-79-80	6-700/16	BELTS,SEAT-JUMP SEAT	23-9200
BEARING, Clutch Release	6-100/3	BENCH SEAT & ATTACHING PARTS W/STORAGE COMP.	23-8900
BEARING, Co/Shaft Front	21M-700/27	BEZEL & ASH RECEIVER - 1981	23-3300/19
BEARING, Co/Shaft Rear	21M-500/51	BEZEL and HOOD, w/Warning Indicator Lamp LENS, Inst. Cluster, w/o Radio Opening Black, 1978	8-2200/24
BEARING, Co/Shaft Rear	21M-700/42	BEZEL, A/C Outlet, RT.	24-425/18
BEARING, Co/Shaft Rear Thrust	21M-500/49	BEZEL, A/C Outlet, center	24-425/19
BEARING, Co/Shaft, Front, Needle	21M-500/19	BEZEL, A/C Outlet, w/Wiper and Washer	24-425/20
BEARING, Drive End Shield	8-1100/6	BEZEL, Cargo Lamp Indicator Switch Mtg., after 6-1-78	8-7400/33
BEARING, Drive Gear Pilot, Needle Roller, 1-1/2" O.D.	21M-1150/74	BEZEL, H/Lamp Switch	8-7800/24
BEARING, Ext., w/Short Extension	21A-100/23	BEZEL, Heater Control Omission (Not Shown)	1-300/23
BEARING, Front Input Shaft	21M-1125/1	BEZEL, Rear Corner Panel Tail Lamp, Sweptline (Not Shown)	8-4600/20
BEARING, Front Output Shaft	21M-1000/66	BEZEL, Recliner Release Handle - Up To 12-4-78	23-3550/4
BEARING, Front Output Shaft, Rear Needle Roller, 1-7/8" O.D.	21M-1150/7	BEZEL, s/Pnl. Fuel Filler Opening (In White)	23-485/3
BEARING, Frt. Output Shaft, Rear	21M-1000/70	BEZEL, w/Shield Wiper Switch With Air/Cond.	23-2200/11
BEARING, Frt. Output Shaft, Rear	21M-1130/21	BLOCK, Fuse ,1978-79-80	8-5300/3
BEARING, Inner	22-600/8	BOARD, Floor Center - 6 1/2' Box, 1978-79-80	23-7600/12
BEARING, Input Drive Gear	21M-1000/9	BOARD, Printed Circuit, w/CAPACITOR and CLIP	8-2200/11
BEARING, Input Gear, Thrust, 1-31/32" I.D.	21M-1150/70	BOARD, Printed Circuit, w/CLIPS	8-2200/15
BEARING, Input Shaft	21M-1000/47	BOARD,CIRCUIT,w/Capacitor	8-2300/2
BEARING, M/Drive Gear	21M-200/51	BODY & FLANGE-Refer To Figure 19-1200-see insert	19-1200/1
BEARING, M/Drive Gear, 3.54 O.D., 13/16" Width	21M-300/44	BODY ASSEMBLY, KARY VAN	23-4000
BEARING, Main Drive Gear	21M-100/38	BODY ASSEMBLY, KARY VAN	23-4100
BEARING, Mainshaft	21M-100/11	BODY HOLD DOWN	23-5100
BEARING, Mainshaft, Rear	21M-300/9	BODY PACKAGE>manual steering column coupling	19-300/49
BEARING, Mainshaft, Thrust	21M-1150/73	BODY PACKAGE,power steering column coupling	19-300/49
BEARING, Outer	22-600/4	BODY PANELS - D1-2-3, W1-2	23-9700
BEARING, Output Shaft	21M-200/12	BODY PANELS - D2-3, W2	23-9800
BEARING, Output Shaft (Refer To Illus. 500)	21A-850/13	BODY PANELS - REAR	23-5175
BEARING, Output Shaft, w/Long Extension, A727	21A-500/25	BODY PANELS, REAR - AD, AW	23-5150
BEARING, Rear Wheel Output Shaft	21M-1100/33		

1978-81 LIGHT DUTY TRUCK PARTS CATALOG

	GROUP-FIGURE/KEY NO.
BODY PANELS-CONVENTIONAL CAB	23-9600
BODY PLUGS	23-225
BODY,Strg. Col.Shaft Coupling-Up To Approx.6-1-79	19-1600/30
BOLSTER ASSY. Frt. Dr. Trim Pnl., Blue, 1978-9	23-2900/12
BOLT OR SHAFT, Brake Pedal Pivot, 1978	5-800/11
BOLT SET, Starter	8-600/12
BOLT w/"O" Ring, Brake Pedal	5-800/23
BOLT, Adapter to Knuckle, w/3500 lb. Front Axle	5-200/13
BOLT, Adapter to Knuckle, 1978	5-300/8
BOLT, Exhaust Pipe Flange (3/-16x1 3/4)	11-560/9
BOLT, Master Cylinder Mounting	5-1825/21
BOLT, P/Brake Drum	4-1000/18
BOLT, P/Brake Shoe Lever, Up to 1-15-1979	4-1000/32
BOLT, Parking Brake Lever Anchor	4-600/5
BOLT, Shield to Hub, w/3500 lb. Front Axle	5-200/6
BOLT, Support to Axle, Long	5-700/11
BOLT, Support to Axle, w/12x2.5 Brakes	5-600/4
BOLT, Wheel Retaining, 9"	22-1400/2
BOLT, w/"O" Ring	5-1800/5
BOLT, w/"O" Ring	5-1825/6
BOLT,Control Arm Pivot Bar-Up To 11-1-79	17-52/11
BOLT,Control Arm Pivot Bar-After 11-1-79	17-52/11
BOLT,Intermediate Shaft Coupling Clamp	19-900/18
BOLT,Knuckle To Arm-With 3300,3600 Lb.Axle	17-52/21
BOLT,Knuckle To Arm-With 4000 Lb. Axle	17-52/21
BOLT,s/gear mounting bracket to frame	2-1350/3
BOOT AND SEAL PACKAGE	5-100/9
BOOT AND SEAL PACKAGE, 1978	5-300/10
BOOT, Adjustable Stop Lp. Switch Terminal	8-5800/22
BOOT, Booster Cylinder Push Rod	5-1825/37
BOOT, Cl. Release Fork	6-700/11
BOOT, Clutch Pedal Rod	6-300/7
BOOT, Clutch Pedal Rod	6-600/12
BOOT, Cylinder	5-600/27
BOOT, Cylinder	5-700/24
BOOT, G/Shift Lever	21M-400/21
BOOT, G/Shift Lever, Rubber 3" Dia.	21M-600/3
BOOT, G/Shift Lever, Rubber 3" Dia.	21M-800/3
BOOT, Push Rod	5-1800/19
BOOT, Push Rod	5-1800/39
BOOT, Push Rod	5-1825/17
BOOT, Push Rod	5-1850/13
BOOT, Push Rod, 1978	5-1825/35
BOOT, Shift Control Lever, Vinyl - 1978	21M-900/36
BOOT, Transfer Case Shift Control Lever, Vinyl	21M-1175/40
BOOT, Under Body Trans. Cover Shift Lever, Rubber 6-1/2" x 7-1/2"	21M-600/34
BOOT, Under Body Trans. Cover G/Shift Lever, Rubber 6-1/2 x 7-1/2	21M-1175/39
BOOT, Wheel Cylinder	5-500/30
BOOT, Wheel Cylinder	5-650/24
BOOT,Pot Joint Body-Serviced In Item 16	19-900/21
BORG WARNER AUTOMATIC LOCKING HUB	2-25
BOW,Roof Front & Center	23-3000/9
BOWL,Gearshift Lever-Refer To Item 55	19-1700/41

	GROUP-FIGURE/KEY NO.
BOWL,gearshift lever-in item A	19-500/41
BOX,Glove	23-2800/4
BRACE, Radiator Support	7-810/20
BRACKET	8-4350/3
BRACKET	8-9900/6
BRACKET & ARM, W/Shield Visor - 1978	23-6500/1
BRACKET & LEVER LINK, Door Switch to Latch Elect. Lock	8-9200/3
BRACKET & LEVER LINK, Door Elect. Lock Switch to Lock	8-9700/7
BRACKET AND STUDS, Hydro-Booster Mounting	5-1800/32
BRACKET AND STUDS, Hydro-Booster Mounting	5-1825/22
BRACKET ASSEMBLY, Bumper	23-4100/15
BRACKET ASSEMBLY, Spare Tire Carrier	22-1000/5
BRACKET ASSY., U/Body Seat Anchor	23-3700/18
BRACKET ASSY.,I-Beam Damper Mounting-1978	2-1600/6
BRACKET ASSY.,I-Beam Damper Mounting-1979	2-1600/6
BRACKET ASSY.,I-Beam Damper Mounting	2-1600/6
BRACKET Ash Receiver Light Mtg.	8-5000/13
BRACKET and ARM,Visor	23-2300/1
BRACKET, "J" Bolt	22-1100/8
BRACKET, ALL Mtg., Rear - 1979	8-1900/5
BRACKET, Air Cleaner Mounting	5-1850/8
BRACKET, Alt. Mtg., Frt.	8-1900/3
BRACKET, Altr. Idler (wo A/Cond.)	8-1700/9
BRACKET, Altr. Mtg.	8-1700/2
BRACKET, Altr. and Ign. Coil Mtg.	8-1300/1
BRACKET, Booster Mounting, Except 163" W.B., 1978	5-1825/10
BRACKET, Brake Pedal, 1978	5-800/12
BRACKET, Cable Anchor, Front	4-1100/2
BRACKET, Center Bearing Mounting	16-200/23
BRACKET, Clock Mtg. (Not Shown)	8-2200/24
BRACKET, Cowl Panel - 1978	4-100/15
BRACKET, Cowl Panel - 1978	4-200/16
BRACKET, Diagnostic Conn. Mtg.(Not Shown) - 1979-80-81	8-6100/41
BRACKET, Diagnostic Connector Mtg.	8-3000/16
BRACKET, Diagnostic Connector Mtg. - 1979-80-81 Not Shown	8-5900/29
BRACKET, Dome Lamp, Club Cab, w/Headliner - 1979-80-81	8-4200/18
BRACKET, Dome Lp. Switch	8-10000/5
BRACKET, Door Electric Locks Relay and C/Breaker Mtg.	8-9600/2
BRACKET, Extension to Instrument Panel	23-550/3
BRACKET, Floor	22-1100/9
BRACKET, Front Cable Anchor - 1978	4-100/19
BRACKET, Front Cable Anchor - 1978	4-200/17
BRACKET, Front Cable Anchor - 1978-79-80	4-300/8
BRACKET, Front Cable Anchor	4-400/12
BRACKET, Front Hose Anchor, Right	5-1300/5
BRACKET, Guide, Up to Approx. 11-20-1978	4-300/23
BRACKET, Hose Anchor, w/Hose, 1978	5-1600/4
BRACKET, Hose, Rear	5-1400/4
BRACKET, Housing to Header	8-8900/3
BRACKET, Idler Pulley w/Air Cond.	7-900/13
BRACKET, Inner	5-1400/9
BRACKET, Lever Mounting	4-1000/9
BRACKET, Lever Mounting	4-1050/9

	GROUP-FIGURE/KEY NO.		GROUP-FIGURE/KEY NO.
BRACKET, Lever Mounting	4-1100/12	BRUSH and INSULATOR PACKAGE, Alternator	8-1100/27
BRACKET, Master Cylinder Mounting	5-1825/2	BRUSH and WASHER PACKAGE, Alternator	8-800/11
BRACKET, Muffler Support	11-550/12	BRUSH and WASHER PACKAGE, Alternator	8-900/11
BRACKET, On C/Member	5-1400/10	BUCKLE, Frt. Seat Back & Cush. Cvr. Trim - Cashmere	23-5450/--
BRACKET, Rear	4-100/13	BULB (#158), H/Lamp Switch	8-7800/22
BRACKET, Rear Anchor	4-1100/26	BULB (#330), Eng. Oil Level (Not Shown)	8-2400/21
BRACKET, Rear Bumper, Inner	13-800/27	BULB, #158 - Htr. Control Illumination, w/o Integral A/C (Not Shown)	8-5200/43
BRACKET, Rear Bumper, Outer	13-800/26	BULB, #158 - Htr. and Aux. Htr. Control Illumination (Not Shown)	8-5200/43
BRACKET, Rear Cable	4-300/19	BULB, #158 - Radio Illumination (Not Shown)	8-5200/43
BRACKET, Rear Cable Anchor	4-200/15	BULB, A/C and Heater Control Illumination Lamp (Not Shown)	8-5200/43
BRACKET, Rear Cable Guide	4-400/26	BULB, Control Illum. Socket	24-425/26
BRACKET, Rear Cable Mounting	4-400/21	BULB, Dome Lamp, Club Cab, w/Headliner - 1979-80	8-4200/20
BRACKET, Rear, Step Bumper Supt.	13-800/32	BULB, Heated Rear Window Inst. Panel Wiring	8-9100/2
BRACKET, Rr. Splash Shield To Dash, Left (Not Shown)	12-100/1	BULB, Ign. Sw. Lamp (Not Shown)	8-7800/32
BRACKET, Shift Lever Mtg. - 1980	21M-1175/3	BULB, Pk. and Turn Sig. Lp. (Clear) (Not Shown)	8-2700/40
BRACKET, Shift Lever Mtg.	21M-1175/26	BULB, Pk. and Turn Sig. Lp. (Clear)	8-7000/4
BRACKET, Side & RR. C/Dr. Hge. Plr. Lower (Not Shown)	23-700/--	BULB, Printed Circuit Board Lights	8-2200/14
BRACKET, Side Pnl. I/Side Spare Whl. Mtg.	23-5175/13	BULB, Rd. H/Lp. (Riteway Shift)	8-2700/10
BRACKET, Spare Tire Bolt	23-4100/12	BULB, Rect. H/Lp., Hi Beam (Riteway Shift) -1979-80	8-2700/11
BRACKET, Spring, 1978	5-800/30	BULB, Rect. H/Lp., Hi and Lo Beam (Riteway Shift)	8-2700/12
BRACKET, Starter Center	8-600/5	BULB, Riteway Shift, Rd. H/Lp.	8-2900/20
BRACKET, Starter Front	8-600/7	BULB, Side Marker (Clear)	8-2700/23
BRACKET, Starter Rear	8-600/11	BULB, T/Sig. Indic. Light (Not Shown) - 1980	8-6800/14
BRACKET, Starter Relay Mtg.	8-3300/5	BULB, Tail Lamp Sidemarker -1979 (Not Shown)	8-4700/15
BRACKET, Step Bumper Styled Outer 1980-81	13-800/26	BUMPER ASSEMBLY, "A" Body	23-4100/14
BRACKET, Stop Lp. Switch Actuating	8-5800/22	BUMPER OR STOP, Pedal	5-1000/10
BRACKET, Stop, 1978	5-800/20	BUMPER, Brake Pedal	5-1100/7
BRACKET, Support Mounting - Rear	25-86/1	BUMPER, Frt. Chrome w/Guards and w/Nerf Strip Holes 1979-80-81	13-800/3
BRACKET, T/Case Mtg.	21M-1175/46	BUMPER, Frt. Chrome w/o Guards or Nerf Strip Holes	13-800/13
BRACKET, Tire Carrier	22-1100/3	BUMPER, Frt. Painted	13-800/13
BRACKET, Tube	5-1300/14	BUMPER, Prime w/Winch	13-800/10
BRACKET, Tube (Shield)	5-1300/3	BUMPER, Rear Chrome w/Nerf Strip Holes 1979-80	13-800/21
BRACKET, Tube Support	5-1400/13	BUMPER, Rear Chrome w/o Nerf Strip Holes	13-800/20
BRACKET, Tube and Hose Union, 1978	5-1700/4	BUMPER, Rear, Step Type 1978	13-800/31
BRACKET, Valve Mounting, w/Frame Reinforcement, 1979-80	5-1400/17	BUMPER, Rr. C.Dr., License Plate	23-1900/--
BRACKET, W/Wiper and Washer Switch and Lamp Mtg. (Not Shown)	8-5200/43	BUMPER, Rubber Track	23-4300/17
BRACKET, w/Wiper & Washer Switch	23-2200/27	BUMPER,Front Door	23-1400/24
BRACKET,Dome Lamp Switch 70-3615 (Not Serv)	8-10000/24	BUMPER,Front Door Glass	23-1400/22
BRACKET,E.M.R.,Module Mtg.	8-2200/26	BUMPER,Lock Control Housing	19-100/4
BRACKET,Idler Mtg. 1978-79	7-850/23	BUMPER,Upper Control Arm	17-52/13
BRACKET,POWER STEERING PUMP ENGINE	19-4100	BUMPER-With 3300 Lb. Axle	17-53/9
BRACKET,POWERSTEERING PUMP MOUNTING	19-3200	BUMPER-With 3600,4000 Lb. Axle	17-53/9
BRACKET,Tie Rod Damper Mounting	2-1600/9	BUSHING PACKAGE	16-400/15
BRACKET,steering gear	2-1350/2	BUSHING, A/C Motor Mtg.	24-425/6
BRACKETS,POWER STEERING PUMP MOUNTING	19-3300	BUSHING, Alternator Drive End	8-1000/4
BRAKE, REAR HYDRAULIC - 15 x 4	5-700	BUSHING, Bellcrank	5-1825/11
BRAKE, REAR, 13 X 3.5	5-650	BUSHING, Bolt	4-600/7
BRAKES, REAR, HYDRAULIC	5-500	BUSHING, Brake Pedal, 1979-80	5-800/34
BRAKES, REAR, HYDRAULIC	5-600	BUSHING, Lever Bolt	4-1100/35
BREATHER	10-600	BUSHING, Low Speed Gear	21M-1000/44
BRUSH & WA PKG., Alternator	8-1000/11	BUSHING, P/Brake Cable	4-1000/16
BRUSH HOLDER, Alternator	8-900/12		
BRUSH HOLDER, Starter	8-600/10		

1978-81 LIGHT DUTY TRUCK PARTS CATALOG

	GROUP-FIGURE/KEY NO.
BUSHING, Pedal Shaft	5-1000/9
BUSHING, Pedal Shaft	5-1100/4
BUSHING, Ratio Lever	4-300/12
BUSHING, Ratio Lever	4-400/16
BUSHING, Shift Lever	21M-1175/12
BUSHING, Shift Lever	21M-1175/19
BUSHING, w/ROLLER (Serv. in Cross Pkg.)	16-400/4
BUSHING,Camshaft #1	9B-500/11
BUSHING,Col.G/Shift Tube Seal-With A727 Trans.-Up To Approx.6-1-79	19-1300/2
BUSHING,Col.Gearshift Tube Seal	19-800/5
BUSHING,G/shift Tube Lever Grommet-With A727 Trans	19-1300/8
BUSHING,G/shift Tube Seal-Except A230,A390 Trans.	19-1300/10
BUSHING,Upper Control Arm-with 3300 lb.axle-up to approx.1-15-80	17-52/4
BUSHING,Upper Control Arm-with 3300 lb.axle-after approx.1-15-80	17-52/4
BUSHING,Upper Control Arm-With 3600,4000 Lb. Axle-up to approx.1-15-80	17-52/4
BUSHING,Upper Control Arm-With 3600,4000 Lb. Axle-after approx.1-15-80	17-52/4
BUTTON ASSY, Rr. Seat, Blue - 1979	23-6200/—
BUTTON, Deluxe Bucket, Blue	23-3400/3
BUTTON, Inst. Pnl. Ash Rec. Spring Stop	23-5800/6
BUTTON, Seat Back (Hi-Line), Blue	23-3500/3
BUTTON, Seat Back - Blue	23-5500/8
BUTTON, Seat Back, Blue	23-5600/25
BUZZER & WIRING,SEAT BELT	8-7500
Ball Joint Package,Lower Control Arm-With 4000 Lb. Axle	17-55/23
C/MBR Eng. Rear Support 1979-80	13-550/2
CAB, FRONT - B, CB, MB	23-550
CAB, FRONT - B, CB, MB - 1978	23-500
CABLE SET, Complete, Spark Plug, 225 Eng. - 1978	8-4100/3
CABLE and Spool, Eng. Wiring Fusible Link (# 16 Ga. x 25 Ft.) (Not Shown)	8-6500/30
CABLE, (Neg.), Dual Batt., 225,318 and 360 Eng. (Not Shown)	8-6100/41
CABLE, Adjusting	5-600/20
CABLE, Alternator Ground (Not Shown)	8-1100/32
CABLE, Automatic Adjusting	5-500/11
CABLE, Automatic Adjusting	5-650/10
CABLE, Battery (Neg.)	8-6300/10
CABLE, Battery (Pos.)	8-7200/3
CABLE, Battery Ground, w/Single Battery -1978	8-6100/21
CABLE, Battery Ground, w/Single Battery	8-6400/26
CABLE, Battery to Starter Relay - 1978	8-3200/1
CABLE, Battery to Starter and to Starter Relay - 1978	8-6100/22
CABLE, Battery to Starter and Starter Relay - 1978	8-6400/28
CABLE, Battery to Stirr. Relay	8-3300/14
CABLE, Battery to Trans. Grd.	8-3300/15
CABLE, Coil Secondary, 225 Eng. - 1978	8-4100/2
CABLE, Double Conductor, No. 14, Green and Black (100 Ft. Spool) (Order by Spool)	8-5100
CABLE, Front	4-1100/6
CABLE, Front 109"-127" W.B., 91" Lg.	4-100/1

	GROUP-FIGURE/KEY NO.
CABLE, Front, 53.50" Lg. - 1978-79	4-300/24
CABLE, Front, w/109" W.B., 119.50" Lg. - 1978-79	4-200/1
CABLE, Front, w/o Frame Reinforcement, 53.50" Lg. - 1978-79	4-400/28
CABLE, Grd.	8-3300/21
CABLE, Heater and Defroster	1-300/24
CABLE, Intermediate, 10.65" Lg. - 1978-79	4-300/25
CABLE, Intermediate, w/109" W.B., 76.96" Lg.	4-100/8
CABLE, Intermediate, w/115" W.B., 19.65 Lg. -1978-79	4-400/29
CABLE, Neoprene Jacketed (Serviced by the Inch) 10 Ga., Two Conductor	8-5100
CABLE, Parking Brake, 100" Lg. - 1978	4-1000/1
CABLE, Parking Brake, 107.33" Lg.	4-1050/1
CABLE, Plastic Jacketed (Serviced by the Inch) 16 Ga., Two Conductor	8-5100
CABLE, Rear, Left w/10 x 2.5 Brakes, 40.62" Lg.	4-300/27
CABLE, Rear, Left, 44" Lg.	4-1100/27
CABLE, Rear, Left, Except School Bus, 44" Lg.	4-200/8
CABLE, Rear, Left, w/10 x 2.5 Brakes, 40.62 Lg.	4-400/31
CABLE, Rear, Right w/10 x 2.5 Brakes, 81.62" Lg.	4-300/27
CABLE, Rear, Right, 44" Lg.	4-1100/20
CABLE, Rear, Right, w/10 x 2.5 Brakes, 81.62 Lg.	4-400/32
CABLE, Rear, w/10 x 2.5 Brakes	4-100/12
CABLE, Recliner Release - Up To 12-4-78	23-3550/3
CABLE, Single Battery (Negative)	8-6200/5
CABLE, Spark Plug, 225 Eng., No. 1,2,5, and 6	8-4100/1
CABLE, Starter Relay to Starter	8-400/25
CABLE, Starter Relay to Starter Relay	8-7200/4
CABLE, Starter to Starter Relay, Diesel Eng.	8-6200/7
CABLE, Starter to Starter Relay	8-7200/6
CABLE, Temp. Control	24-425/27
CABLE, Temperature Control (Up TO 4-1-1978)	1-300/23
CABLE,Heater Temp.Cont.1979-80-81	1-200/33
CABLE,ROLL STOCK	8-5100
CABLES, SPARK PLUGS & COIL	8-4100
CAM, w/Horn Contact RING, Tilt Strg. Turn Sig. Cancelling (Not Shown)	8-6800/14
CAMSHAFT & VALVE MECHANISM (MMC DIESEL)	9B-800
CAMSHAFT, VALVES, ROCKER SHAFT, TIMING CHAIN	9C-500
CAMSHAFT, VALVES, ROCKER, CHAIN, SPROCKET	9B-225
CAP ASSY., Header, Inner	23-5200/8
CAP ASSY., Rear Seat Rr. Mtg. Brkt. w/Nut (Not Shown)	23-3700/—
CAP, Center, Sport Chrome	22-300/9
CAP, Center, Sport Chrome 1980-81	22-300/9
CAP, Distributor - 1978-79	8-100/7
CAP, Distributor - 1978-9	8-200/1
CAP, Distributor,Approx. After 5/15/79 -1979-80	8-300/1
CAP, Dome, Styled	22-300/6
CAP, Grease	22-350/1
CAP, Grease	22-400/1
CAP, Grease	22-600/1
CAP, Grease, 1978	22-450/1
CAP, Hub, w/15" Wheels	22-100/5
CAP, Hub, w/16" and 16.5" Wheels	22-100/4
CAP, Lockstrip or Retainer - 1978	23-1100/12

	GROUP-FIGURE/KEY NO.		GROUP-FIGURE/KEY NO.
CAP, Muffler 79-80-81	24-250/5	CB-300 - POST OFFICE - 1980	23-4530
CAP, Radiator	7-200/10	CB-300 - POST OFFICE - 1980	23-4540
CAP, Radiator Pressure	7-810/1	CB-300 - POST OFFICE - 1980	23-4550
CAP, Reservoir	5-1800/33	CB-300 - POST OFFICE - 1980	23-4560
CAP, Reservoir	5-1825/29	CB-300 - POST OFFICE - 1980	23-4570
CAP, Valve Stem	22-300/10	CB-300 - POST OFFICE - 1980	23-4580
CAP, Wheel Cover Dome	22-100/8	CENTER BEARING PACKAGE, w/Support and Insulator	16-200/10
CAP, Yoke Oil Seal	16-100/5	CENTER BEARING PACKAGE, w/Support and Insulator - 1978-79	
CAP, Yoke Oil Seal	16-400/9		16-600/12
CAP, Yoke Oil Seal, Up To 11-15-1978	16-200/14	CHAIN, Drive 3/8 Pitch, Use w/Transfer Case As Purchased Assy. No. 3898654	21M-1100/13
CAPACITOR, Stud, Insulator Pkg., Alternator	8-1000/14	CHAIN, Sprocket Drive, 72 Links 1-1/4" Wide	21M-1150/21
CAPACITOR, Alternator (Serviced in 3838978 Pkg.)	8-1100/19	CHAIN, Tailgate (Up to 10-6-80)	23-5400/10
CAPACITOR, STUD and INSULATOR PACKAGE, Alternator	8-900/14	CHANNEL & FRAME, Vent Wing	23-1400/9
CAPACITOR, STUD and INSULATOR PACKAGE, Alternator	8-800/14	CHANNEL, Floor Mount	22-1400/7
CAPS AND COVERS, WHEEL	22-100	CHANNEL, Side Mount	22-1400/1
CARPET, Frt. drivers side, (Hi-Line), Blue-1978	23-2500/3	CHANNEL, Spare Wheel Mounting, Up To 3-24-81	23-800/12
CARPET, Fuel Filler Cover, Blue - 1978	23-6800/8	CHANNEL, Frt. Door Glass Lwr., 1978-9	23-1400/35
CARPET, Fuel Tank, Black- 1978	23-9300/2	CHECK ARM	23-2000
CARPET, Rr. Fr. w/127" W.B. - w/Hge. c/ Drs.	23-2600/5	CHECK VALVE, A/C & Htr. Vacuum Hose Extension (Not Shown)	
CARPETS & SCUFF PLATES, FLOOR	23-6800		24-425/29
CARPETS, MATS & SCUFF PLATES - D-W1,2,3	23-6850	CIRCUIT BREAKER, 15 Amp. (Not Shown)	8-5300/14
CARRIER & TUBE, drive pinion	3-300/7	CIRCUIT BREAKER, Dr. Elect. Locks 15 Amp.	8-9600/8
CARRIER w/BOLTS, Diff., Partial w/o Spider Gear	21M-1100/24	CIRCUIT BREAKER, Dr. Elect. Locks 30 Amp.	8-9600/8
CARRIER, Sprocket, 32 Teeth	21M-1150/34	CIRCUIT BREAKER, Elect. Door Locks	8-9000/5
CARRIER, w/PINION and WASHER, Frt., Planet Pinion	21A-800/2	CIRCUIT BREAKER, Fuel Control Mtr. (8 Amp) (Not Shown)	8-8700/14
CARRIER, w/PINIONS, SHAFTS, ROLLERS and WASHERS, Rr. Planet Pinion	21A-850/14	CLAMP ASSY., tie rod-1979-80	2-1475/11
		CLAMP PACKAGE, Tie Rod Tube	2-1150/35
CARRIER, w/TUBES PACKAGE (Includes Diff. BEARINGS)	3-100/15	CLAMP PKG., Exhaust Pipe (2.25 Dia.)	11-550/11
CARRIER, w/TUBES, Drive Pinion	3-100/14	CLAMP PKG., Exhaust Pipe Support	11-560/11
CARTER 1BBL CARBURETOR AND COMPONENT PARTS	14-790	CLAMP PKG., Front to Rear Exhaust (2 1/4")	11-560/12
CARTER 2BBL CARBURETOR AND COMPONENT PARTS	14-795	CLAMP, A/C Wheel to Motor	24-425/7
CARTER 4BBL CARBURETOR AND COMPONENT PARTS	14-797	CLAMP, Cover, w/4089212 & 223 M/Cyl.	5-1825/25
CASE	3-1500/21	CLAMP, Distributor Mounting	8-200/14
CASE ASSY. KIT, differential-3.54, 4.10 ratio	3-400/30	CLAMP, M/Cylinder	5-1800/30
CASE ASSY. KIT, differential-3.54, 3.73, 4.10 ratio	3-400/30	CLAMP, Master Cylinder Cover	5-1850/17
CASE KIT, DIFFERENTIAL	2-280	CLAMP, Shift Lever Rod Swivel	21M-1175/23
CASE KIT, differential-3.54, 3.73, 4.10 ratio	3-400/30	CLAMP, Tail Pipe Support	11-550/20
CASE Kit, Differential	2-250	CLAMP, U/Joint Cross Yoke	16-100/8
CASE PKG., Consists of: CASE Alum., LEVER G/S Rev., SEAL Lvr. Shaft, RETAINER Lvr. Seal, Use w/Tran	21M-300/48	CLAMP, Coupling	19-900/20
CASE, Partial, w/Magnetic Chip Collector - 1980	21M-1125/16	CLAMP, Distributor	8-100/20
CASE, Rear Half	21M-1150/9	CLAMP, Starter Heat Shield	8-400/25
CASE, Trans.	21M-200/29	CLAMP, steering column	19-600/3
CASE, Trans. - 1978	21M-100/56	CLEANER, Booster Air	5-1850/4
CASE, Transfer Case Front Half	21M-1150/67	CLIP CHART, BRAKE	5-6000
CASE, w/225 Eng., A727 - 1978	21A-100/2	CLIP, Adjusting Screw Spring	5-700/18
CASE, w/Magnet, Use w/Transfer Case As Purchased Assy. No. 3898654		CLIP, Anti-Rattle	5-200/11
		CLIP, Brake Hose	5-1400/1
CASE, w/Magnetic Chip Collector	21M-1000/50	CLIP, Brake Tube	5-1700/5
CASE, w/Magnetic Chip Collector	21M-700/28	CLIP, Elect. Door Locks Circuit Breaker Mtg.	8-9000/6
CASE, w/o Anti Spin	3-300/13	CLIP, Hub Cap Retaining	22-300/14
CASE, differential	3-100/22	CLIP, Inst. Cluster Hood and Bezel Mtg. (Not Shown) - 1978-9	
CASE-3.54, 4.10 Ratio	3-500/23		8-2200/24
CASE-4.10 ratio	3-1000/4	CLIP, Instruments Cover to Housing - 1978-9	8-2200/24
CB-300 - POST OFFICE - 1980	23-4510	CLIP, Link to Latch	23-1600/29
CB-300 - POST OFFICE - 1980	23-4520		

	GROUP-FIGURE/KEY NO.		GROUP-FIGURE/KEY NO.
CLIP, Link to Lock	23-1800/38	CONE AND ROLLER, Outer	22-400/6
CLIP, Link to Lock	23-1900/28	CONE AND ROLLER, Outer	22-900/12
CLIP, Link to Solenoid, 1979-80-81	23-1900/32	CONE AND ROLLER, Outer, 1978	22-450/6
CLIP, Switch to Door Lock Link, Right, 1979-80-81	23-1400/49	CONE AND ROLLER, Wheel, Inner	22-800/9
CLIP, Valve to Front Axle Tube, w/Frame Reinforcement, 1979-80-81	5-1400/17	CONE w/ROLLERS, Idler Gear Bearing	21M-1130/5
CLIP,Rear Spring	17-1200/11	CONE, Wheel Bearing, Outer	22-800/11
CLIP,Remote Control Lever to Lock Link	23-1400/27	CONE,drive pinion front bearing	3-300/4
CLOCK (Digital) (Not Shown)	8-2200/24	CONNECTOR	8-10800/2B
CLUSTER,INSTRUMENT	8-2200	CONNECTOR ASSY., Discharge Hose w/Muffler w/318-360 Eng. AFTER	4-2-1979
CLUSTER,INSTRUMENT	8-2400		24-250/14
CLUSTER,INSTRUMENT & GAUGES	8-2300	CONNECTOR and TERMINAL PKG.	8-2900/31,32
CLUSTER-INSTRUMENT & GAUGES	8-2350	CONNECTOR and TERMINAL PKG., Sliding Door Electric Lock Wiring (Not	illus.)
CLUTCH COVER w/PLATE, 10" Clutch, w/225 Eng.	6-100/2		8-9500/9-12
CLUTCH DISC, 10" Clutch, w/225 Eng.	6-100/1	CONNECTOR, Cable Adjusting - 1980-81	4-400/13
CLUTCH HOUSING, 10" Clutch, w/225 Eng. - 1978-79-80	6-200/1	CONSOLE ASSY.,Black	23-9050/1
CLUTCH, 10",11",12"	6-100	CONSOLE, Body Frt., (Paint As Required) 1978-79-80	23-6400/1
CLUTCH, First and Second Speed Sliding, w/o Anti-Rattle Springs, Up To		CONSOLE, FRONT	23-6400
Approx. 5-29-1979	21M-700/2	CONTACT and SPRING PACKAGE,Starter Solenoid Switch	8-400/20
CLUTCH, Sliding Lock	21M-1100/11	CONTACT, Parking and Turn Sig. Lamp Wiring (Not Shown)	8-2600/16
CLUTCH, Sliding Rear Output	21M-1140/26	CONTACT, Parking and Turn Sig. Lamp Wiring (Not Shown)	8-2800/31
CLUTCH, Starter	8-400/1	CONTROL Assy, Htr. B-CB-MB 1978	1-100/11
CLUTCH, Third and Fourth Speed Sliding, w/o Inner Rings	21M-500/31	CONTROL UNIT, Ignition - 1979	8-3000/4
COIL, A/C Evaporator	24-425/1A	CONTROL, A/C and Htr.	24-425/23
COIL, Ignition - 1978	8-4100/6	CONTROL, Base w/Air. Cond. And Htr. 1979-80	24-425/23
COIL, Ignition - 1978	8-5900/7	CONTROL, Distributor Vacuum	8-100/14
COIL, Ignition - 1978	8-6100/6	CONTROL, Distributor Vacuum	8-200/10
COIL, Ignition - 1978	8-6500/18	CONTROL, Distributor Vacuum, Approx. After 5/15/79(Not Serviced)	
COLLAR - I/Pnl. Lwr. Trim Pnl. Lt. - 1978	23-2700/12		8-300/7
COLLAR and PIN PACKAGE, Distributor	8-200/9	CONTROL, Heater Temp. (Complete)	1-300/22
COLUMN TO BODY,STEERING	19-1000	CONTROL, Lever Kit	1-1000/1
COLUMN TO BODY,STEERING-NON-TILT	19-600	CONTROL,ENGINE (MMC DIESEL)	9B-2400
COLUMN,STEERING	19-900	CONTROL,IDLE (MMC DIESEL)	9B-2700
COLUMN,STEERING	19-3700	CONTROL,Remote	23-1800/3
COLUMN,STEERING UPPER	19-1100	CONTROL,Remote	23-1900/10
COLUMN,STEERING-NON TILT	19-100	CONTROLS, BRAKE	5-800
COLUMN,STEERING-NON-TILT	19-200	CONVERT-A-BED SEATING SYSTEM	23-3780
COLUMN,STEERING-NON-TILT	19-300	COOLER LINES,TRANS.OIL (MMC DIESEL)	9B-2800
COLUMN,STEERING-NON-TILT	19-700	COOLING SYSTEM (MMC DIESEL)	9B-1300
COLUMN,STEERING-NON-TILT	19-800	CORE and SHIFT FORK PACKAGE, Starter Solen. Moving	8-400/23
COLUMN,STEERING-NON-TILT	19-1200	CORE, Heater	1-150/
COLUMN,STEERING-NON-TILT	19-1300	CORE, Heater Aux. htr. B model	1-200/7
COLUMN,STEERING-NON-TILT	19-1400	COUNTERSHAFT, 11-1/4" Lg. (S43-R25-35-S14T)	21M-500/48
COLUMN,STEERING-TILT	19-400	COUNTERSHAFT, 13-11/32" Lg. (R38-33-25-14T)	21M-700/53
COLUMN,STEERING-TILT	19-500	COUNTERSHAFT, Trans.	21M-200/9
COLUMN,STEERING-TILT	19-1500	COUNTERSHAFT, Trans.	21M-300/25
COLUMN,STEERING-TILT	19-1600	COUNTERSHAFT, Trans. (.9450" x 10-3/16"Lg.)	21M-100/46
COLUMN,STEERING-TILT	19-1700	COUNTERSHAFT, Transfer Case	21M-1000/37
COMPUTER, TRIP	8-8900	COUPLING & FLANGE ASSY.,steering gear	19-600/22
CONE AND ROLLER, Inner	22-400/11	COUPLING & FLANGE ASSY.-refer to figure 19-1600-1978-79	
CONE AND ROLLER, Inner	22-900/10		19-1500/25
CONE AND ROLLER, Inner, 1978	22-450/11	COUPLING or BODY,S/Col. Inter.Shaft Pot Joint	19-900/17
CONE AND ROLLER, Inner, w/3300 lb. Front Axle, 5 Stud Rotor	22-350/11	COUPLING or BODY,strg. column shaft	19-1200/23
	22-350/11	COUPLING or BODY,strg. col. shaft-1978	19-1500/24
CONE AND ROLLER, Outer	22-350/6	COUPLING or INSULATOR,Power Steering Column Shaft	19-100/53
		COUPLING or INSULATOR-Manual Steering Column Shaft	19-100/53

	GROUP-FIGURE/KEY NO.		GROUP-FIGURE/KEY NO.
COUPLING, Intermediate Shaft Lower Flange-1978	19-1500/13	COVER, Dome Light Switch 70-3614	8-10000/26
COVER ASSY., Wheel, 15", 1978 (Use Trim Rings 4026533)	22-100/1	COVER, Inboard Belt Anchor (Not Shown)	23-9075/—
COVER ASSY., Wheel, 15", 1978	22-100/2	COVER, Lock Housing	19-500/12
COVER ASSY., Wheel, 15", 1979 (Note:--Use Trim Rings, Ref. #3, for 16.5" Wheels)	22-100/10	COVER, Lock Housing-(painted)-1981	19-1700/12
COVER KIT, Diff. Carrier-(w/Thd.Pipe Filler Plug)-1978	2-200/15	COVER, Lock Housing-1978-79-80	19-1700/12
COVER KIT, Diff. Carrier-1979	2-100/15	COVER, Shaft Lock-Not Used-(skirt used)	19-1700/24
COVER KIT, Diff. Carrier-1979	2-200/15	COVER, Side Rr.Corner, Filler Tube Inner	23-1000/18
COVER KIT, Diff. Carrier-1979-80	2-300/40	COVER, Strg. Col. Coupling	19-1200/22
COVER KIT, Differential Carrier-1978	2-100/15	COVER, Tachometer	9B-500/28
COVER KIT, differential carrier-except RD2	3-400/32	CRANK ARM ASSY, w/Wiper Delay	23-2200/—
COVER KIT, differential carrier	3-500/33	CRANKCASE	9B-500/1
COVER w/PINS and PLUGS, G/Shift Lever	21M-800/12	CRANKSHAFT, CAMSHAFT & TORQUE CONVERTER	9C-910
COVER, Adjusting Hole	5-500/28	CRANKSHAFT, CONN. RODS, PISTONS, RINGS	9C-930
COVER, Adjusting Hole	5-600/1	CRANKSHAFT, PISTONS AND RINGS	9C-400
COVER, Adjusting Hole	5-700/12	CRANKSHAFT-PISTON-CONNECTING ROD & BEARINGS	9B-700
COVER, Adjusting Screw Hole	5-650/22	CROSS PACKAGE, Universal Joint	16-100/2
COVER, Back Cushion, Hi-Line	23-3750/8	CROSS PACKAGE, Universal Joint (1-5)	16-1700/2
COVER, Back Exc. Club Cab Frt. & Rr. (Sales Code KL1)	23-5450/2	CROSS PACKAGE, Universal Joint	16-200/3
COVER, Brake Tube, (Spring) 25 Ft. Roll, 3/16" O.D.	5-1600/9	CROSSMEMBER, Transfer Case Skid Plate	21M-900/39
COVER, Brake Tube, 25 Ft. Roll, 3/16" O.D.	5-1400/5	CROSSMEMBER, Transfer Case Skid Plate	21M-1175/44
COVER, Clutch Rel. Rod Hole (Not Shown)	23-900/—	CUP W/CONE AND ROLLER, Outer	22-350/7
COVER, Cushion Exc. Club Cab Frt. & Rr.(Sales Code KL1)	23-5450/1	CUP W/CONE, ROLLER AND SEAL, Inner, w/3300 lb. Front Axle	22-350/10
COVER, Diagnostic Connector	8-3000/15	CUP, Bearing, Inner	22-400/10
COVER, Diagnostic Connector - 1979-80-81 Not Shown	8-5900/29	CUP, Bearing, Inner, 1978	22-450/10
COVER, Dome Lp. Switch	8-10000/7	CUP, Bearing, Outer	22-400/7
COVER, Dual Batt. Isolator (Not Shown)-1979-80	8-3200/26	CUP, Bearing, Outer, 1978	22-450/7
COVER, Frt. Seat Belt - Black	23-9375/10	CUP, Cylinder, w/ 7/8" Cylinder	5-600/29
COVER, Fuel Filler Trim Pnl., Blue, 1978-9	23-3300/10	CUP, Cylinder, w/1-3/8" Dia. Cyl.	5-700/26
COVER, Fuse Block (Not Shown)	8-5200/43	CUP, Diff. Bearing	3-500/14
COVER, G/Shift Lever Boot	21M-400/22	CUP, Expander (Serv. in Ref. #28)	5-650/29
COVER, G/Shift Lever w/Pins and Plugs	21M-600/11	CUP, Inner	22-600/7
COVER, Hinge Pillar To Roof Seal	23-5200/9	CUP, Outer	22-600/5
COVER, Master Cylinder	5-1800/13	CUP, Shoe Hold Down Spring	5-650/11
COVER, Master Cylinder, 1978	5-1850/18	CUP, Wheel Bearing, Inner	22-800/8
COVER, P/Brake Support	4-1000/31	CUP, Wheel Bearing, Inner	22-900/9
COVER, Pedestal Stud, Black Only	23-3625/9	CUP, Wheel Bearing, Outer	22-800/10
COVER, Pedestal, Front	23-3625/8	CUP, Wheel Bearing, Outer	22-900/11
COVER, Pedestal, Rear	23-3625/7	CUP, Wheel Cylinder	5-500/32
COVER, SPARE TIRE	23-2650	CUP, Wheel Cylinder	5-650/26
COVER, Seat Cushion, Hi-Line	23-3750/9	CUSHION ASSEMBLY, 3 Pass., Low and Mid-Line	23-3650/3
COVER, Spare Tire, Blue, 1978-9	23-2650/1	CUSHION ASSY., Exc. Club Cab, Frt. & Rr. (Sales Code KL1)	23-5450/1
COVER, Starter Gear Housing	8-400/11	CUSHION COVER, (Hi-Line) Blue, 1978-9	23-3500/1
COVER, Trans. Case	21M-200/1	CUSHION COVER, (Sales Code KA5)	23-5500/1
COVER, Tubing, 25 Ft. Roll, 3/16" O.D.	5-1300/2	CUSHION COVER, 3 Pass., Low and Mid-Line	23-3650/3
COVER, W/Seal Heater Housing 1978	1-150/	CUSHION COVER, Deluxe (Sales Code KA5)	23-5600/1
COVER, Wheel Cylinder	5-700/10	CUSHION COVER, Deluxe Vinyl (Sales Code KCA)	23-6200/1
COVER, Wheel, 15", u/w 15"x7" Wheel Only, 1979	22-100/6	CUSHION, Jump Seat, Black, 1978-79-80	23-9300/1
COVER, Wiring	8-8800/5	CUTTING EDGE, Moldboard w/7 1/2 ft Plow	1-700/31
COVER, w/4089212 & 223 M/Cyl.	5-1825/26	CYL & KEYS PKG. Ignition & Dr. w/o Tilt	23-8200/1
COVER, w/LENS, Speedometer, Fuel and Temp. Gauge, w/o Trip - 1978-79-80-81	8-2200/1	CYLINDER & KEY, Console, 1978-79-80 (Complete)	23-6400/6
COVER, w/Lens, Ammeter and Oil Indicator	8-2200/23	CYLINDER HEAD & RELATED PARTS	9C-920
COVER, Chaincase	9B-600/1	CYLINDER PACKAGE, Wheel	5-700/9
COVER, Col. Shaft Coupling Body	19-300/48	CYLINDER and KEY PKG.	23-1400/31

	GROUP-FIGURE/KEY NO.
CYLINDER, Booster	5-1800/8
CYLINDER, Booster, 1978	5-1825/20
CYLINDER, Booster, 1978	5-1850/9
CYLINDER, Master	5-1800/1
CYLINDER, Master, 1978	5-1850/16
CYLINDER, Master, w/Manual Disc, 1978	5-1825/5
CYLINDER, Wheel	5-500/33
CYLINDER, Wheel (Refer to Item #30)	5-600/6
CYLINDER, Wheel, 1 1/8" Dia.	5-650/19
CYLINDER, Wheel, 7/8" Diameter	5-600/30
CYLINDER, snow plow lift	1-700/41
CYLINDERS, KEYS AND PACKAGES	23-250
Chrysler-refer to figure 19-1900,up to approx.11-14-78	19-1800
Chrysler-refer to figure 19-1900,after approx.11-14-78	19-1800
Chrysler-refer to figure 19-1900,1979-80-81	19-1800
Chrysler-refer to figure 19-2300	19-1800
Consists of: CONNECTOR (10) & TERMINAL (20)	8-11100/1
DAMPER & PARTS PACKAGE,Front Wheel-1979	2-1600/12
DECAL, "4WD"	23-6985/2
DECAL, "Camper" - 1981 (Not Shown)	23-7200/15
DECAL, Dodge Ram - Big Horn	23-7190/5
DECAL, Side - LEAPING RAM	23-7180/1
DECAL, Tailgate (Dodge) White, 1978-79	23-7600/16
DECAL, Tailgate, "Dodge", White, 1978-79-80	23-7200/12
DECAL,1979-80-81	22-100/7
DECAL,Wheel Cover Cap (Chrysler Corporation)(Medallion)	22-100/7
DIAPHRAGM, Cap	5-1800/34
DIAPHRAGM, Cap	5-1825/30
DIFFERENTIAL (Consists of CASE, GEARS, PINIONS, DISCS and PLATES)	3-400/4
DIFFERENTIAL ASSY.-(partial)-with anti-spin	3-300/32
DIFFERENTIAL CASE ASSY.KIT-3.54,3.73,4.10 ratio	3-500/32
DIFFERENTIAL CASE KIT	2-250
DIFFERENTIAL CASE KIT	2-750
DIFFERENTIAL CASE PARTS KIT	3-1400/12
DIFFERENTIAL PARTS KIT	2-285
DIFFERENTIAL PARTS KIT	2-290
DIFFERENTIAL and CARRIER- 4.88 Ratio-1978-79	3-1500
DIFFERENTIAL,FRONT AXLE	2-240
DIFFERENTIAL,FRONT AXLE	2-275
DIFFERENTIAL,FRONT AXLE	2-600
DIFFERENTIAL,REAR AXLE-WITH ANTI-SPIN	3-1000
DIFFUSER, Ash Receiver Lp. (Not Shown)	8-5000/14
DIFFUSER, Cigar Lighter Lp. (Not Shown)	8-5000/14
DIFFUSER, H/Lamp Sw. Ident. Lamp (Not Shown)	8-7800/32
DIFFUSER, Inst. Cluster Hsg. Light (Not Shown)	8-2400/21
DIFFUSER, Lights	8-2200/17
DIFFUSER, W/Wiper and Washer Switch Ident. Lamp (Not Shown)	8-5200/43
DISC BRAKES, FRONT	5-100
DISC BRAKES, FRONT	5-200
DISC BRAKES, FRONT	5-300
DISC, Frt. Clutch, w/225 Eng., A904	21A-300/8
DISC, Rr. Clutch	21A-300/21
DISTRIBUTOR-6 CYL. ENG.	8-100

	GROUP-FIGURE/KEY NO.
DISTRIBUTOR-8 CYL. ENG.	8-200
Differential CASE KIT-3.54,4.10 ratio	3-500/34
DOME, Styled	22-300/5
DOME, Wheel Cover	22-100/9
DOOR, SLIDING	23-1500
DOOR ASSY, Frt. - 1978	23-1400/42
DOOR ASSY, Slidg. w/Window- 1978	23-1500/38
DOOR ASSY,Glove Box, 1978-79-80	23-2800/1
DOOR ASSY., Qtr. Pnl. Fuel Filler	23-5175/24
DOOR CARGO-SIDE & REAR	23-1800
DOOR SHELL FRONT	23-1400
DOOR SHELL, Side Cargo Frt. w/Window (All W.B.)-1978	23-1800/31
DOOR SHELL, Single - 1978	23-1900/23
DOOR SLIDING	23-1600
DOOR SLIDING	23-1700
DOOR w/SEAL w/o SHAFT, Htr, Vent 1979-80-81	1-150/
DOOR w/SEAL, A/C Recirculator	24-425/3
DOOR w/SEAL, w/Shaft Htr, Blend Air	1-150/
DOOR, A/C Blend Air	24-425/11
DOOR, FRT.- REGULATORS & RUNS	23-8200
DOOR, H/Lamp,Includes Turn Signal Lens 1981 BRIGHT	8-2700/39
DOOR, HARDWARE - REAR	23-4500
DOOR, REAR - REGULATORS & RUNS	23-8300
DOOR, ROLL UP - WHITING ALUMINUM	23-4300
DOOR, ROLL UP - WHITING ALUMINUM	23-4400
DOOR, Rad. Grille Rectangular H/Lamp	8-2900/35
DOOR, Radiator Grille Panel Rectangular H/Lamp	8-2700/39
DOOR, w/o Window, Left (A-Body)	23-4500/12
DOOR, w/o Window, Right (A-Body)	23-4500/13
DOOR,CARGO-SINGLE REAR	23-1900
DOOR,Glove Box,Black	23-5700/15
DOWEL, Case Alignment, 1/2" O.D. x 5/8" Lg.	21M-1150/8
DOWEL, Flywheel Hsg. to Clutch Hsg.	9B-1000/5
DOWEL, Trans. Adapter	21M-500/9
DRAINCOCK, radiator	7-200/7
DRIP RAIL	23-9700/15
DRIP RAIL, Cab	23-9800/17
DRUM, Brake	22-800/2
DRUM, Brake, w/10x2.5 Brakes	22-700/1
DRUM, Brake, w/13x3.5 Brakes	22-900/2
DRUM, Lifting Strap	23-4300/15
DRUM, Parking Brake	4-1050/38
DRUM, Reverse	21A-850/16
DRUM, Reverse (Also Specify 1 of 3420100 Race Pkg.)	21A-800/17
DUAL, Rectangular Chrome 1979-80	7-525/2
DUCT ASSY., A/C and Htr. Dist. Comp.	24-425/11
DUCT w/SEAL, A/C Outlet, LT.	24-425/15
DUCT w/SEAL, A/C Outlet, LT. Ext.	24-425/16
DUCT w/SEAL, A/C Outlet, RT.	24-425/17
DWELL, Switch Assy - w/Shield Wpr. Mtr.	23-2200/25
ELBOWS AND CONNECTORS, BRAKE	5-5700
ELECTRIC CHOKE CONTROLS	14-778
ELECTRONIC SPARK ADVANCE	8-6150
ELEMENT, Cigar Lighter	8-7800/5
EMISSION CONTROLS & SWITCHES	25-700

GROUP-FIGURE/KEY NO.	GROUP-FIGURE/KEY NO.
EMISSION WIRING	25-905
END PACKAGE, Drag Link-L.H.Thd.-up to approx.10-1-80	2-1150/34
END PACKAGE, Drag Link-R.H.Thd.-up to approx.10-1-80	2-1150/33
END PACKAGE, Tie Rod-Inner-Right-With H.D. Pkg.	2-1100/4
END PACKAGE, Tie Rod-Inner Left-With H.D. Pkg.	2-1100/4
END PACKAGE, Tie Rod-Inner Right-With 4000 Lb. Axle	2-1150/25
END PACKAGE, Tie Rod-Inner Left-With 4000 Lb. Axle	2-1150/25
END PACKAGE, Tie Rod-L.H.Thd.-W/3300,3600 Lb. Axle	2-1150/24
END PACKAGE, Tie Rod-L.H.Thd.-1978	2-1500/20
END PACKAGE, Tie Rod-Left	2-100/18
END PACKAGE, Tie Rod-Left	2-200/18
END PACKAGE, Tie Rod-R.H. Thd.-1978	2-1500/20
END PACKAGE, Tie Rod-R.H.Thd.-W/3300,3600 Lb.Axle	2-1150/24
END PACKAGE, Tie Rod-Right	2-100/18
END PACKAGE, Tie Rod-Right	2-200/18
END PACKAGE, Tie Rod-Right	2-300/20
END PACKAGE, tie rod-l.h.thd.-1979-80	2-1500/20
END PACKAGE, tie rod-r.h.thd.-1979-80	2-1500/20
END, Push Rod	5-1850/10
ENGINE - (6 CYLINDER)	9B-100
ENGINE ASSEMBLIES	9C-100
ENGINE MOUNTINGS	9C-700
ENGINE MOUNTINGS	9C-725
ENGINE MOUNTINGS	9C-730
ENGINE MOUNTINGS	9C-940
ENGINE MOUNTINGS - 6 CYLINDER	9B-300
ENGINE MOUNTINGS - 6 CYLINDER	9B-325
ENGINE, As Shipped	9B-500/1
ENGINE, Short	9B-500/1
EQUALIZER, Cable	4-100/9
EQUALIZER, Cable - 1978-79	4-200/12
EQUALIZER, Cable - 1978-79	4-1100/22
EQUALIZER, Front to Rear Cable	4-300/17
EQUALIZER, Rear Cable	4-400/23
ESCUTCHEON, Lift Gate Outside Lock Rel.	23-5300/14
ESCUTCHEON, Rear Floor (Not Shown)	23-3700/18
EXHAUST GAS RECIRCULATION SYSTEM (EGR)	25-425
EXHAUST GAS RECIRCULATION SYSTEM (EGR)	25-450
EXHAUST GAS RECIRCULATION SYSTEM (EGR)	25-475
EXHAUST GAS RECIRCULATION SYSTEM (EGR)	25-477
EXHAUST GAS RECIRCULATION SYSTEM (EGR)	25-480
EXPANDER, Piston	5-500/36
EXPRESS BOX	23-7500
EXPRESS BOX - UTILINE	23-7600
EXTENSION w/BUSHING, Trans. Case	21M-200/17
EXTENSION, Case (Use w/Trans. Assy. No. 3633462)	21M-700/50
EXTENSION, Case, Long, w/225, MMC DIESEL and 360 High Perf. Eng., A727	21A-100/17
EXTENSION, Dash Panel to Engine Housing, 1978-79-80	23-550/2
EXTENSION, Fender Panel to Hinge Pillar	12-150/9
EXTENSION, Fndr. Pnl. To H/Lamp Support, 1979-80	12-150/8
EXTENSION, Frame	13-800/12
EXTENSION, Longitudal Rail	23-9700/11
EXTENSION, Otr. Pnl. Rear	23-5175/16
EXTENSION, Rr. Plr. Inr. To Side Inner	23-5175/12
EXTENSION, Short (Use w/3641114 Trans. Assy.)	21M-100/17
EXTENSION, Side Dr. Hge. Plr. Rr.to Step Sill,w/109" W.B., 1978-79-80	23-700/6
EXTENSION, Side Sill Reinforcement	23-9800/14
EXTENSION, Tail Pipe, 1978-79	11-560/5
EXTENSION, Trans. Case	21M-300/13
EXTENSION, U/Body Flr. Rr.	23-900/—
EXTENSION, Valve Stem, w/15" Wheel	22-300/12
EXTENSION, Wheelhouse Panel, Front	23-5150/4
EXTENSION, w/House Inner Upper Rear - Up To 3-1-79	12-150/4
EXTENSION, w/House Pnl. Frt.	23-5175/8
EXTENSION, w/House Pnl. Rear	23-5175/10
EXTENSION, Manual Steering Gear	2-1150/1
EXTERIOR MOULDINGS AND NAME PLATES	23-400
EXTERIOR VIEW - D,W1,2,3	23-7200
EXTERIOR VIEW - D-W1,2,3	23-7300
EXTERNAL ENGINE	9C-200
End Package, tie rod-left	2-270/21
FABRIC, Seat, Hillcrest Pattern	23-5650/1
FABRIC, Trombley Pattern	23-3950/4
FAN 1980-81	7-450/1
FAN and PULLEY	8-1100/1
FAN, Eng. Coolant w/225 Eng. w/o Air Cond. or Inc. Cooling	7-300/1
FASTENER, Cargo Lp. Switch Mtg. Bezel, after 6-1-78	8-7400/34
FASTENER, Housing and Tube, Push On	5-1850/12
FENDER & RUNNING BOARD, REAR	12-300
FENDER, FRONT	12-200
FENDER, FRONT - B, CB, MB - 1978	12-100
FERRULE, Alternator (Serviced in Drive End Shield)	8-1100/8
FILLER - Rear Cargo Dr. Hge Plr. To Hdr. Pnl.	23-700/14
FILLER ASSY., Side Hdr. Frt. Dr. Close Off - Rt. (Not Shown)	23-600/—
FILLER, Plr., Lwr. Inner	23-5175/3
FILLER, Rr. Flr. Carpet to U/Body Rear, w/H.D. Trim Pkg.- Up To 11-1-78	23-2600/5
FILLER, Side Cargo Hge.& Sldg.Dr. Plr. Upr. Rear, All W.B.	23-700/14
FILLER, Side Pnl. To Rr. U/Body Pnl. w/o Ext. Body Rt.,1978-79-80	23-900/1
FILLER, Sill To Reinforcement (Plastic)	23-9300/—
FILLER,Rear Corner Post, "A" Body, 1978-79-80	23-4100/11
FILTER FUEL (MMC DIESEL)	9B-1600
FILTER, Drier 1979-80	24-1100/29
FILTER, Drier 1981	24-250/6
FILTER, Drier 79-80	24-250/6
FILTER, Governor	21A-500/15
FILTER, Oil	10-410/15
FILTER, Push Rod	5-1800/20
FLANGE, Exhaust Pipe	11-560/7
FLANGE, Front Output Shaft	21M-1150/60
FLANGE, T/Case Frt. Output Yoke	21M-1130/33
FLANGE, Transfer Case Front Output Shaft, w/208 T/Case	16-400/21
FLANGE, strg.column shaft coupling-1979	19-1500/26
FLOOR ASSEMBLY, KARY VAN	23-4200
FLOOR MATS - FRONT	1-2000
FLOOR PAN	23-900

1978-81 LIGHT DUTY TRUCK PARTS CATALOG

	GROUP-FIGURE/KEY NO.
FLYWHEEL & HOUSING (MMC DIESEL)	9B-1000
FLYWHEEL,w/Auto.Trans.	9B-1000/1
FORK ASSY., Shift Range	21M-1150/26
FORK w/SPRING, Cl. Release - 1978-79-80	6-700/9
FORK w/SPRING, Clutch Release - 1978-79-80	6-400/9
FORK, First and Second Speed Shift	21M-600/26
FORK, First and Second Speed Shift	21M-800/22
FORK, Frt. Wheel Shift Rail	21M-1125/29
FORK, G/Shift Second and Third	21M-200/33
FORK, Gearshift	21M-100/59
FORK, Gearshift First and Reverse	21M-200/26
FORK, Lockout Shift Rail	21M-1100/3
FORK, Reverse Shift	21M-600/16
FORK, Reverse Shifter, Use w/Trans. Service Assy. No. 4031879	21M-300/63
FORK, Rr. Wheel Shift Rail	21M-1125/22
FORK, Shift Range Box	21M-1000/19
FORK, Third and Overdrive	21M-300/82
FRAME ASSEMBLY, Front, "A" Body	23-4100/4
FRAME ASSEMBLY, Rear, "A" Body, 1978-79-80	23-4100/1
FRAME, Assy. 137" W.B 1979-80-81	13-550/1
FRAME, w/FIELD Starter	8-400/18
FRESH AIR INTAKE SYSTEM 1980-81	14-201
FUEL LINES	14-771
FUEL LINES	14-772
FUEL LINES	14-773
FUEL LINES 1978-79-80	14-770
FUEL PUMP & CARBURETOR HEAT SHIELD	14-775
FUEL SYSTEM (MMC DIESEL)	9B-2500
FUEL TANK & MOUNTING-P3	14-760
FUEL TANK - 22 GALLON	14-300
FUEL TANK - 24 GALLON	14-725
FUEL TANK - 36 GALLON	14-400
FUEL TANK - 36 GALLON	14-730
FUEL TANK - 36 GALLON	14-750
FUEL TANK - 45 GALLON	14-430
FUEL TANK - 45 GALLON	14-758
FUEL TANK - 50 GALLON	14-450
FUEL TANK - IN CAB - 24 GALLON	14-600
FUEL TANK - MID MOUNTED	14-752
FUEL TANK - MID-MOUNTED	14-625
FUEL TANK - REAR MOUNTED - 21 GALLON	14-680
FUEL TANK FILLER TUBES	14-460
FUEL TANK FILLER TUBES	14-740
FUEL TANK FILLER TUBES - MID - MOUNTED	14-635
FUEL TANK FILLER TUBES - MID - MOUNTED	14-645
FUEL TANK FILLER TUBES - REAR MOUNTED	14-685
GASKET AND CLAMP PACKAGE	5-1800/12
GASKET AND CLAMP PACKAGE, Master Cylinder, 1978	5-1850/19
GASKET AND SEAL PACKAGE - A727, w/Long Extension, Complete	21A-100
GASKET AND SEAL PACKAGE - A727, w/Short Extension, Complete	21A-100
GASKET AND SEAL PACKAGE - A904,A999 Complete	21A-100
GASKET SET	10-410/23

	GROUP-FIGURE/KEY NO.
GASKET and SEAL	21M-900
GASKET, Adapter To Transfer Case	21M-1150/62
GASKET, Adapter to Transfer Case	21M-900/21
GASKET, Adapter to Transfer Case	21M-1125/9
GASKET, Brake Hose	5-1300/19
GASKET, Brg. Retainer	21M-1000/5
GASKET, Compr. Muffler and Discharge Fitting Flange	24-250/24
GASKET, Cover	3-400/14
GASKET, Cover, w/4089212 & 223 M/Cyl.	5-1825/24
GASKET, Diff. Carrier to Hsg.	3-1500/36
GASKET, Disch. & Liq. Line Plate to Condenser 225, 318, 360 Eng.	24-250/25
GASKET, Discharge Line Flange to Compr. (Rubber Coated) 1980-81	24-250/26
GASKET, Distributor Mounting	8-200/14
GASKET, Distributor Mtg., 1.068" I.D.	8-100/19
GASKET, Distributor Mtg., Approx. After 5/15/79 (Not Shown) - 1979-80	8-300/14
GASKET, Diverter Valve 1979	25-86/18
GASKET, Drive Shaft	3-1500/33
GASKET, EGR Valve	25-480/5
GASKET, Expansion Valve Mtg. 2 Hole	24-250/22
GASKET, Frt. Output Shaft Brg. Retainer	21M-1130/30
GASKET, Hose Screw	5-1400/15
GASKET, M/Cylinder Cover	5-1800/31
GASKET, Master Cylinder Cover	5-1850/20
GASKET, Mounting Bracket, 1978	5-1825/18
GASKET, Mounting Spacer	5-1800/23
GASKET, Mounting Spacer	5-1850/9
GASKET, Pk. and Turn Sig. Lp. Mtg. (Not Shown)	8-7000/5
GASKET,Breather	9B-550/14
GASKET,Cyl.Head	9B-550/1
GASKET,Exh. Manifold	9B-550/12
GASKET,Front Plate	9B-550/3
GASKET,Handle	23-1400/33
GASKET,Inlet Coupler	9B-550/20
GASKET,Inlet Manifold	9B-550/11
GASKET,Lens	8-4600/22
GASKET,Oil Pan	9B-550/9
GASKET,Oil Strainer	9B-550/19
GASKET,Relief Valve Case	9B-550/13
GASKET,Rocker Case	9B-550/2
GASKET,Thermostat Case	9B-550/17
GASKET,Thermostat Cover	9B-550/18
GASKET,Timing Gear Case	9B-550/7
GASKET,Water Outlet Pipe	9B-550/22
GASKET,Water Pump Assy.	9B-550/16
GASKET,Water Pump Case	9B-550/15
GASKET,carrier cover	3-800/15
GASKET,cover	3-500/12
GASKET,cover-use liquid sealer part #4026070	3-100/36
GASKET,cover-use liquid sealer-part # 4026070	3-300/24
GASKET,drive shaft	3-800/9
GASKET,drive shaft-5500 lb. axle	3-400/28
GASKET,drive shaft-5500 lb.axle	3-500/10

	GROUP-FIGURE/KEY NO.		GROUP-FIGURE/KEY NO.
GATE, Lift - Up To 11-1-77	23-5300/18	GEAR, Low Speed	21M-1000/43
GATE, Gearshift-1981	19-1100/36	GEAR, M/Drive, 10-7/8" Long (S21-L22T)	21M-700/35
GATE, Shift Lever	19-1700/39	GEAR, Main Drive	21M-200/50
GATE, gearshift-1979-80	19-300/36	GEAR, Main Drive 10-7/8" Long (S21-L17T)	21M-500/25
GATE, gearshift-1979-80	19-1100/36	GEAR, Main Drive, 11" Lg. (S36-L18T)	21M-100/39
GATE, gearshift-1981	19-300/36	GEAR, Main Drive, 11" Lg. (23Spl-22T-36T)	21M-300/45
GAUGE, Fuel	8-2200/3	GEAR, Mode Clutch, 16 Int. Teeth	21M-1150/36
GAUGE, Oil Pressure	8-2200/16	GEAR, Overdrive	21M-300/33
GAUGE, Temperature	8-2200/20	GEAR, Rev. Idler	21M-100/53
GEAR & LINKAGE, POWER STEERING	2-1325	GEAR, Rev. Idler (21 Teeth)	21M-700/20
GEAR & LINKAGE, POWER STEERING	2-1350	GEAR, Reverse (S34-L28T)	21M-100/10
GEAR & LINKAGE, STEERING	2-1100	GEAR, Reverse Idler	21M-200/11
GEAR & LINKAGE, STEERING	2-1150	GEAR, Reverse Idler, Use w/Trans. Service Assy. No. 4031879	21M-300/62
GEAR & LINKAGE, STEERING	2-1200	GEAR, Reverse Speed (R28Spl-R33T)	21M-700/14
GEAR & LINKAGE, STEERING	2-1300	GEAR, Second Speed	21M-200/41
GEAR & PINION KIT	2-260	GEAR, Second Speed	21M-300/1
GEAR & PINION KIT	2-950	GEAR, Second Speed (S27-L23T)	21M-500/38
GEAR & PINION KIT, 3.54 ratio	3-400/31	GEAR, Second Speed (S28-L33T)	21M-700/13
GEAR & PINION KIT, Drive-(consists of: gear & pinion, shims, brgs, seal, slinger & baffle)	3-800/19	GEAR, Second Speed (S30-L24T)	21M-100/30
GEAR & PINION KIT, DRIVE	2-285	GEAR, Side	3-1500/22
GEAR & PINION SET PKG. (includes bearings)	3-100/7	GEAR, Speedometer Drive	21M-1150/43
GEAR & PINION SET, drive gear	3-500/31	GEAR, Synch. Clutch	21M-100/6
GEAR APPLICATION, STEERING	19-1800	GEAR, Third Speed (S24-L23T)	21M-500/35
GEAR ASSY., Drive, 31 Spl., 46 Teeth	21M-1150/71	GEAR, Third Speed (S24-L25T)	21M-700/6
GEAR and PIN PACKAGE, Distributor	8-100/15	GEAR, Third and Fourth Speed Clutch	21M-500/33
GEAR and PINION SET (Only), 3.54 to 1 Ratio	3-500/13	GEAR, Third and Fourth Speed Clutch	21M-700/7
GEAR and PINION SET, 3.54 ratio	3-400/3	GEAR, Camshaft	9B-1100/2
GEAR and PINION SET-3.90 Ratio Only	3-300/14	GEAR, Crankshaft	9B-1100/1
GEAR and PINION SET-4.88 Ratio	3-1500/6	GEAR, MANUAL STEERING	19-2400
GEAR and SNAP RING PKG., Starter Pinion Shaft	8-400/9	GEAR, Manual Steering-1978	19-2400
GEAR w/BUSHING, First Speed (37 Teeth)	21M-700/17	GEAR, Power Steering-1978	19-2000
GEAR w/BUSHING, Rev. Idler (S17-21T)	21M-500/52	GEAR, Power Steering-1978	19-2100
GEAR w/BUSHING, Sun	21A-800/7	GEAR, Power Steering-1979	19-2100
GEAR w/BUSHING, Sun	21A-850/10	GEAR, Power Steering-After Approx.-6-1-78	19-1900
GEAR w/SPRING, First and Rev. Sliding (37 Teeth)	21M-500/43	GEAR, Power Steering-After Approx.-6-12-79	19-2000
GEAR w/SUPPORT, Frt. Annulus, 2-1/2" I.D. Center Hole	21A-800/4	GEAR, Power Steering-Up To Approx.-6-1-78	19-1900
GEAR w/SUPPORT, Rear Annulus, 3-1/2" I.D., Center Hole	21A-800/16	GEAR, Power Steering-Up To Approx.-6-12-79	19-2000
GEAR, Co/Shaft	21M-200/38	GEAR, Ring	9B-1000/2
GEAR, Co/Shaft Cluster	21M-100/50	GEAR, power steering-1978	19-2250
GEAR, Countershaft	21M-300/23	GEAR, power steering-1979-80-81	19-1900
GEAR, Countershaft	21M-1000/33	GEAR, power steering-1979-80	19-2250
GEAR, Diff. Pinion	21M-1100/15	GEAR, power steering-1980-81	19-2000
GEAR, Diff. Side	3-500/18	GEAR, power steering-1980-81	19-2100
GEAR, Diff. Side	3-1000/1	GEAR-CHRYSLER POWER STEERING	19-1900
GEAR, Diff. Side	3-1400/9	GEAR-MANUAL STEERING	19-2300
GEAR, First Speed	21M-200/44	GEAR-POWER STEERING	19-2200
GEAR, First Speed (S34-L28T)	21M-100/1	GEAR-POWER STEERING	19-2250
GEAR, First Speed (S36-L35T)	21M-300/7	GEAR-SAGINAW POWER STEERING	19-2000
GEAR, Frt. Wheel, High	21M-1130/15	GEAR-SAGINAW POWER STEERING	19-2100
GEAR, Idler	21M-1130/8	GEARSHIFT CONTROLS, 3-SPEED COLUMN SHIFT	21M-250
GEAR, Input Drive	21M-1000/17	GEARSHIFT CONTROLS, 4 SPEED FLOOR SHIFT	21M-600
GEAR, Low Front Output	21M-1130/26	GEARSHIFT CONTROLS, 4 SPEED FLOOR SHIFT	21M-800
GEAR, Low Rear Output Shaft	21M-1140/22	GEARSHIFT CONTROLS, A727-A904-A999 AUTOMATIC TRANSMISSION, B-D-W-AD-AW-RD-CB-MB	21A-1150

	GROUP-FIGURE/KEY NO.
GEARSHIFT CONTROLS, OVERDRIVE 4-SPEED FLOOR SHIFT N.P.G.	
MODEL A833 MANUAL TRANSMISSION	21M-400
GEARSHIFT CONTROLS, STEERING COLUMN SHIFT	21A-900
GEARSHIFT CONTROLS, STEERING COLUMN SHIFT, WITH	
.....	21A-1000
GEARSHIFT INDICATOR, WITH TILT STEERING COLUMN, ...	21A-1100
GLASS & WEATHERSTRIP, SIDE PANEL	23-9500
GLASS AND WEATHERSTRIPS	23-1100
GLASS, Clear	23-5200/6
GLASS, Front Door, Clear - 1978-9	23-8200/17
GLASS, Lift Gate, Clear	23-5300/1
GLASS, Rear Window, Clear, 1978-9	23-8000/3
GLASS, Rr. Qtr. Wdo.- Tinted	23-5175/22
GLASS, WEATHERSTRIP & STRIKER - H/GATE	23-5350
GLASS, Windshield, Clear, 1978-9	23-8000/1
GLASS, w/Band, Vented, Clear	23-9500/4
GLASS, w/Sliding Cargo Door, 2 Piece	23-1100/13
GLASS, Frt Door Clear, 1978-9	23-1400/3
GLOVE BOX & DOOR	23-2800
GRILLE	7-500/9
GRILLE, Cowl Plenum, 1978	23-9700/13
GRILLE, Cowl Plenum, 1978	23-9800/8
GRILLE, Panel Single Round Painted 1979-80	7-525/1
GRILLE, Radiator w/Round Headlamps (Bright Finish) 1979	7-650/1
GRILLE, defroster, black	1-300/10
GRIP RAIL PACKAGE	23-7300/16
GROMMET	4-1100/29
GROMMET	19-1300/15
GROMMET, Cable	4-1000/43
GROMMET, Check Valve	5-1800/24
GROMMET, Check Valve	5-1850/15
GROMMET, Check Valve, Except Hydro-Booster	5-1825/20
GROMMET, Frt. Floor Carpet Dimmer Switch (Not Shown)	8-5200/43
GROMMET, Knob	23-1800/26
GROMMET, Knob	23-1800/35
GROMMET, Knob	23-1900/27
GROMMET, Locking Knob, 1979-80-81	23-1400/47
GROMMET, Reservoir	5-1800/36
GROMMET, Reservoir	5-1825/32
GROMMET, Shift Lever Rod	21M-1175/21
GROMMET, Side and Rear Cargo Door Pillar Wiring	8-8800/9
GROMMET, Sliding Door Pillar Wiring	8-8800/7
GROMMET, Speedometer Hsg. (Not Shown)	8-2200/24
GROMMET, Col. Jacket-Up To Approx. 10-1-79	19-300/29
GROMMET, G/shift Tube Lever-With A727 Trans.	19-1200/12
GROMMET, G/shift Tube Lever-With A727 Trans.	19-1300/9
GROMMET, Steering Column	19-1300/6
GROMMET, Strg. Column	19-1200/6
GROMMET, Vent Glass	23-1400/6
GSKT. Line Mtg. To Drier	24-250/5
GUARD, Frt. Bumper	13-800/5
GUIDE, Adjusting Cable	5-600/23
GUIDE, Automatic Adjusting Cable	5-500/12
GUIDE, Automatic Adjusting Cable	5-650/8
GUIDE, Cable	4-100/10

	GROUP-FIGURE/KEY NO.
GUIDE, P/Brake Anchor	4-1000/24
GUSSET, Frame Extension	13-800/11
GUSSET, Strainer to U/Body Side Pnl.	23-1000/19
H-VALVE, A/C Expansion 1979-80	24-250/10
H-VALVE, A/C Expansion 1981	24-250/10
H/GATE & T/GATE MOULDINGS	23-5425
HAND THROTTLE CONTROL	14-850
HANDLE ASSY., Dualmatic Lock Hub	2-50/17
HANDLE, Bucket Seat Adjuster - Up To 4-3-78	23-3400/5
HANDLE, Bucket Seat Adjuster - Up To 4-3-78	23-3500/8
HANDLE, Front Door Window Regulator	23-8200/21
HANDLE, Inside Door	23-4500/5
HANDLE, Inside Release	23-4400/28
HANDLE, Locking	23-4400/42
HANDLE, Locking	23-4500/6
HANDLE, Outside	23-1900/6
HANDLE, P/Brake Lever - 1978-79-80	4-300/30
HANDLE, P/Brake Lever - 1978-79-80	4-400/33
HANDLE, Recliner Release	23-3550/5
HANDLE, Seat Adjuster	23-3625/12
HANDLE, Seat Adjuster - Up To 4-3-78	23-5500/3
HANDLE, Slgd. Dr.	23-1600/1
HANDLE, Taigate Lock, 1978-79-80	23-5400/6
HANDLE, Vent Wing, Up To 9-1-80	23-1400/8
HANDLE, Frt. Door Outside	23-1400/32
HANDLE, Inside	23-1800/1
HANDLE, Remote Control - Up To 12-21-78	23-1400/14
HANDLE, Window Regulator - Up To 10-20-78	23-1400/13
HANGER ASSEMBLY, Understung Tire Carrier	22-1300/3
HATCH GATE & ATTACHING PARTS	23-5325
HEAD ASSY., Bright, 1979-80-81	23-350/9
HEAD, Starter End	8-400/17
HEAD, CYLINDER & COVER (MMC DIESEL)	9B-600
HEAD, Cylinder	9B-600/6
HEADER, Rear, "A" Body, 1978-79-80	23-4100/8
HEADLAMP, Auxiliary snow plow	1-700/1
HEADLAMP, Rd. Type (Riteway Shift) - 1979	8-2900/30
HEADLAMP, Riteway Shift, Right - 1978	8-2500
HEADLAMP, Round (Leftway Shift)	8-2700/30
HEADLAMP-SINGLE ROUND	8-2500
HEADLINER-ADV. & S.E.	23-9800
HEADLINING - AD, AW, 1979-80-81	23-5250
HEAT SINK PACKAGE, Alternator Positive	8-1100/18
HEAT SINK and BATT. TERMINAL PACKAGE, Alternator Postive	
.....	8-800/17
HEAT SINK, Alternator Negative	8-800/17
HEAT SINK, Alternator Negative	8-900/17
HEAT SINK, Alternator Negative	8-1000/17
HEAT SINK, Alternator Postive	8-1000/17
HEATER ASSY, Auxiliary, Model 92	1-200
HEATER assy. deluxe A-D-W models	1-300
HEATER, ENGINE BLOCK (MMC DIESEL)	9B-3000
HINGE ASSY, Left - 1978	23-2800/2
HINGE ASSY., w/Dual Vented Wdo. w/o Mldg., 1978-9	23-2100/15
HINGE, Door	23-4500/1

GROUP-FIGURE/KEY NO.	GROUP-FIGURE/KEY NO.
HINGE, Glove Box	23-5700/7
HINGE, Lift Gate - 1978	23-5300/7
HINGE, Upper, Door & Body Half	23-8200/22
HINGE, Assy. Upper Left - Up To 1-2-80	23-1800/30
HINGE, Body Half, w/Mldg., w/Dual Vented Wdo.	23-2100/1
HINGE, Door Half - Up To 2-1-79	23-1500/1
HINGE, Frt Door Lower	23-1400/44
HINGE, Frt Door Upr.	23-1400/43
HINGE, Lower - Up To 1-2-80	23-1900/18
HOLD DOWN & FRONT END MOUNTING	23-7400
HOLDER, Alternator Brush	8-800/12
HOLDER, Alternator Brush	8-1100/26
HOLDER, Alternator Brush, Radial	8-1000/12
HOLDER, Bulb	8-4300/23
HOLLEY 1BBL. CARBURETOR AND COMPONENT PARTS	14-780
HOLLEY 2BBL. CARBURETOR AND COMPONENT PARTS	14-785
HOOD & BEZEL Assy. w/o Radio Black - 1978	23-2700/2
HOOD AND LOCK	15-100
HOOD AND LOCK ASSEMBLY	15-180
HOOD ASSEMBLY	15-200
HOOD LATCH RELEASE ASSEMBLY-IN CAB	15-175
HOOD LATCH RELEASE ASSEMBLY - IN CAB	15-225
HOOK BOLT	22-1100/10
HOOK, Coat	23-3200/9
HOOK, Coat	23-9350/8
HORN & BRACKET	8-3900
HORN, w/Brkt. Low Note	8-3900/11
HOSE ASSY., A/C Liquid, Rear 1979-80	24-550/10
HOSE ASSY., A/C Suction and Liquid (Unified)	24-550/7
HOSE ASSY., A/C Suction, Rear 1979-80	24-550/9
HOSE W/TEE, Front, 1978	5-1400/6
HOSE W/TEE, Rear, 1978	5-1300/15
HOSE W/TEE, Rear, 1978	5-1400/3
HOSE w/CONN., A/C and Htr. Vac. Control	24-425/29
HOSE w/MUFFLER, Discharge	24-250/3
HOSE w/MUFFLER, Discharge w/225 Eng. UP TO 6-2-1979	24-250/5
HOSE w/MUFFLER, Discharge w/225 Eng. AFTER 6-2-1979	24-250/5
HOSE w/MUFFLER, Discharge and Liquid Unified w/318-360 Eng. UP to 4-2-1979	24-250/14
HOSE w/MUFFLER, Discharge and Liquid w/440 Eng. 1979	24-250/14
HOSE w/SWITCH, Suction w/225 Eng. 78-79-80	24-250/1
HOSE w/SWITCH, Suction w/225 Eng. 1981	24-250/1
HOSE, 1 1/16", 50 Ft. Roll	5-1300/9
HOSE, Air Cleaner (5/8" Roll Stock)	5-1850/3
HOSE, Brake, Rear, 1978	5-1700/7
HOSE, Discharge Line w/225 Eng. 1981	24-250/5
HOSE, Discharge and Liquid w/318-360 Eng. 1980	24-250/14
HOSE, Discharge and Liquid w/318-360 Eng. 1981	24-250/14
HOSE, Distributor Vacuum	8-100/20
HOSE, Distributor Vacuum	8-200/14
HOSE, Front, 1978	5-1600/1
HOSE, Front, w/3500 lb. Axle, 1978	5-1400/7
HOSE, Front, w/Bracket, 1978	5-1300/6
HOSE, Heater and A/C	24-250/17
HOSE, Pump to Hydroboost-Pressure-W/360-3 Eng.	19-3400/14
HOSE, Suction & Liquid Unified 318-360 Eng. UP to 4-2-1979	24-250/12
HOSE, Vacuum (Service Roll Stock)	5-1850/1
HOSE, Vacuum 1/8" (Serv. Roll Stock)	24-425/29
HOSE, Hydroboost To Gear-Pressure	19-3400/10
HOSE, Hydroboost To Pump Tube-Return	19-3400/8
HOSE, POWER STEERING PUMP	19-4400
HOSE, POWER STEERING PUMP	19-4500
HOSE, Power Steering-Return-With 440 Eng.-Make From Item A	19-3400/15
HOSE, hydroboost to pump tube-return	19-3500/2
HOSE-50 Foot Roll-	19-3600/B
HOSE-50 Foot Roll-.344 I.D. x .656 O.D.	19-3600/A
HOSES & TUBES	19-4000
HOSES & TUBES, POWER STEERING & HYDROBOOST	19-3400
HOSES & TUBES, POWER STEERING & HYDROBOOST	19-3500
HOSES & TUBES, POWER STEERING & HYDROBOOST	19-3600
HOUSING	3-1500/2
HOUSING & CARPET, 400 & 440 Eng.- 1978	23-2400/6
HOUSING & POINTER KIT, G/shift W/auto. trans.-1979-80-81	19-300/25
HOUSING & POINTER KIT, G/shift-W/A727 Trans. 1979-80	19-1100/25
HOUSING & POINTER KIT, Gearshift	19-200/25
HOUSING AND TUBE, Booster	5-1850/12
HOUSING ASSY., Evaporator Upper	24-300/3
HOUSING ASSY., Ash Rec.	23-5800/2
HOUSING ASSY., Tilt Steering Column-Refer To Figure 19-1700	19-1500/3
HOUSING Assy., steering column-1978-79-80	19-1700/31
HOUSING Assy., steering column-1981	19-1700/31
HOUSING Assy., steering column-1978-79-80	19-1700/31
HOUSING Assy., steering column-1981	19-1700/31
HOUSING and Tube PACKAGE, Front Axle Repair	2-100/7
HOUSING and Tube PACKAGE, Front Axle Repair	2-200/7
HOUSING or BODY, Governor - 1980-81, A727	21A-500/9
HOUSING w/BUSHING and PLUG, Frt. Pump	21A-350/3
HOUSING w/BUSHING, ROTORS AND SEAL, Frt. Pump, A904-A999	21A-350/14
HOUSING w/StUD, A/C Recirculating	24-425/2
HOUSING, Caliper	5-100/1
HOUSING, Caliper, 1978	5-300/7
HOUSING, Caliper, w/3500 lb. Front Axle	5-200/4
HOUSING, Clearance and Identification Lamp - Silver (Argent)	8-4400/3
HOUSING, Differential, Use w/Transfer Case As Purchased Assy. No. 3898654	21M-1100/29
HOUSING, Distributor	8-100/1
HOUSING, Distributor, Serviced in Distributor Partial Assy.	8-300/8
HOUSING, E.G.R. Signal (Not Shown)	8-2400/21
HOUSING, ENGINE	23-2400
HOUSING, G/Shift Lever Boot - 1978	21M-400/23
HOUSING, Gearshift	21M-100/71
HOUSING, Gearshift, Case, Use w/Trans. Service Assy. No. 4031879	21M-300/76
HOUSING, Handle, Adventurer SE & Sportsman	23-5400/6
HOUSING, Heater 1978	1-150/

	GROUP-FIGURE/KEY NO.
HOUSING, Instruments	8-2200/5
HOUSING, Motor, w/Intermittent, Delay	23-2200/26
HOUSING, Oil Pump	21M-1150/42
HOUSING, Parking and Turn Signal Lp.	8-2700/20
HOUSING, Trip Computer	8-8900/2
HOUSING, front htr. housing	1-300/6
HOUSING, htr. rear	1-300/13
HOUSING, w/Amber LENS, Side Marker 1981	8-2700/22
HOUSING, w/Lens, Park., T/Sig. and Side Marker - Round Headlamp	8-2900/1
HOUSING, w/WIRING, Pk. and Turn Sig. Lamp	8-7000/1
HOUSING, Col. Shaft Bearing	19-300/10
HOUSING, Column Gearshift-w/A230,390 Trans.	19-100/30
HOUSING, Column Gearshift-ALL Trans.Except A727	19-100/30
HOUSING, Column Lock Control-w/A833 Trans.	19-100/1
HOUSING, Column Shaft Bearing Upper-With A727 Trans	19-1100/10
HOUSING, Flywheel	98-1000/5
HOUSING, G/shift-W/A230, A390 Trans.	19-300/25
HOUSING, Gearshift-In 3780847 Hsg. & Pointer Kit-Item 25	19-200/25
HOUSING, Gearshift-With A230, A390 Trans.	19-1100/25
HOUSING, Shaft Bearing	19-100/16
HOUSING, Shaft Bearing	19-200/10
HOUSING, Shaft Bearing-Except A727 Trans.	19-1100/10
HOUSING, Starter Pinion or Gear	8-400/5
HOUSING, Steering Column Lock	19-100/29
HOUSING, Steering Column Lock	19-300/22
HOUSING, Steering Column Lock - w/o Auto Trans.-1979-80	19-1100/22
HOUSING, Steering Gear	19-2300/6
HOUSING, Strg. Col. G/shift-With A727 Trans.	19-700/14
HOUSING, Strg. Col. G/shift-With 435,445, A833 Trans.	19-700/14
HOUSING, Strg. Column Lock	19-200/22
HOUSING, col. G/shift-in white, w/Auto Trans.-1981	19-1100/25
HOUSING, column gearshift-w/A833 trans.	19-100/30
HOUSING, except sweptline with dual wheels & D4 ambulance 1978-9	3-800/1
HOUSING, g/shift-w/A833 trans.-1980-81	19-300/25
HOUSING, gearshift-with automatic trans.-1981	19-300/25
HOUSING, w/BEARING, Distributor	8-200/8
HUB AND CUP, Brake Drum	22-800/3
HUB AND CUP, Brake, w/13x3.5 Brakes	22-900/3
HUB AND DRUM, Brake	22-800/1
HUB AND DRUM, Brake	22-900/1
HUB W/DISC, 1978	5-300/6
HUB W/DISC, w/3500 lb. Front Axle	5-200/8
HUB and DISC ASSEMBLY	5-100/6
HUB, Borg Warner Automatic Locking-(Comple)-3500 Lb. Axle ("4WD")	2-25/--
HUB, Dana Manual Locking(Complete)-3500 lb. Axle	2-50/1
HUB, Dualmatic Manual Locking (Complete) - 4500 Lb.	2-50/16
HUBS & COMPONENTS, LOCKING	2-50
HYDRO BOOSTER COMPONENTS, B - D - M	5-900
Housing, steering gear-for 4116205 gear-use 4210539 repair kit	19-2200/11
I-BEAM, front axle-4500,5000 lb. axle	2-1475/2

	GROUP-FIGURE/KEY NO.
I-BEAM, front axle-6000 lb.-1979	2-1475/2
I-BEAM, front axle-6000 lb. axle-1980	2-1475/2
I-BEAM-6000 Lb.	2-1450/8
IMITATION LEATHER, Tacoma	23-3950/1
INDICATOR, Gear Shift (Illustrated), 1978	8-2200/8
INDICATOR, R.V. Sensor	8-2250/2
INDICATOR, Trans. Oil Level, A727	21A-100/12
INLAY, Horn Pad (Wood Grain) (Hi-Line Premier) (Not Shown)	8-3500/7
INSERT, Alternator	8-900/18
INSERT, Alternator Rectifier End	8-800/18
INSERT, Alternator Rectifier End	8-1000/18
INSERT, Frt. Dr. Medallion "Custom 150" - 1981	23-400/38
INSERT, Shift Lever Knob	21M-1175/19
INSTRUMENT PANEL	23-5700
INSTRUMENT PANEL	23-5750
INSULATER	24-425/26
INSULATION, BODY - WITH DIESEL	23-9900
INSULATION, Cargo Door	23-2900/10
INSULATION, Cowl Inside Panel, 36"x72" Flat Stock (Cut to Fit)	23-9900/1
INSULATION, Dash Panel, Right, 1978-79-80	23-9900/2
INSULATION, Front Fender, 1978-79-80	23-9900/5
INSULATION, Roof H/Lining, Trim Pnl.(Not Shown)	23-3000/--
INSULATION, Rr. Carpet Frt., Exc. 109" W.B.	23-2600/5
INSULATION, Trim Panel	23-3300/--
INSULATOR	8-10500/1
INSULATOR - 1978	23-5100/6
INSULATOR PACKAGE, Lower	21M-1175/34
INSULATOR and BEARING ASSY.	19-1700/56
INSULATOR and BEARING, Tilt Steering Column	19-1500/27
INSULATOR, A/C Motor Terminal	24-425/7
INSULATOR, Alternator	8-1100/16
INSULATOR, Alternator Stator Terminal Stud	8-800/16
INSULATOR, Alternator Stator Terminal Stud	8-900/16
INSULATOR, Alternator Stator Terminal Stud	8-1000/16
INSULATOR, Diagnostic Connector Wiring (Not Shown)	8-3000/15
INSULATOR, Diagnostic Connector Wiring Terminal - 1979 (Not Shown)	8-5900/29
INSULATOR, Elect. Door Lk. Wiring to Cab Wiring (Not Shown)	8-8800/11
INSULATOR, Elect. Door Locks Wiring	8-9000/8
INSULATOR, H/Lp. Ext. Wiring to Frt. End Wiring	8-2900/9
INSULATOR, Lamp Wiring Terminal (Not Shown)	8-7300/6
INSULATOR, Muffler Support, Rear	11-550/16
INSULATOR, Muffler Support, Rear, Except 131"-165" W.B., 1978	11-560/15
INSULATOR, Pk. and Turn Sig. Lp. Cable	8-7000/5
INSULATOR, Seat Lap and Shoulder Belt Wiring Terminal-(2 Way-Female) (Not Shown)	8-7500/8
INSULATOR, Shift Lever	21M-1175/19
INSULATOR, Sliding Door ElectricLock Wiring (Sole noid End) (Not Illustrated)	8-9500/9-12
INSULATOR, Sp. Control Inst. Panel Wiring	8-9800/4
INSULATOR, Starter Battery Term., A,D,W1-4	8-400/25
INSULATOR, Tail Pipe Support	11-550/19

	GROUP-FIGURE/KEY NO.		GROUP-FIGURE/KEY NO.
INSULATOR, Turn Sig. Sw. Lever Speed Control Wiring	8-6800/11	KNOB, Locking, 1979-80-81	23-1400/47
INSULATOR, to Body Ext. Wiring (Not Shown)	8-9000/9	KNOB, Shift Lever	21M-1175/16
INSULATOR, to Door Lock Relay (Not Shown)	8-9000/9	KNOB, Shift Lever - 1980	21M-1175/17
INSULATOR, Col. Shaft Bearing	19-300/7	KNOB, Speedometer Trip Reset (Not Shown) - 1978	8-2200/24
INSULATOR, Column Shaft Bearing	19-100/24	KNOB, Trip Reset	8-2350/14
INSULATOR, Column Shaft Bearing	19-200/7	KNOB, W/Shield Wiper Switch	23-2200/13
INSULATOR, Column Shaft Bearing	19-3700/39	KNOB, w/BEZEL, Cigar Lighter	8-7800/5
INSULATOR, Horn Relay Mtg. Screw (Not Shown)	8-3900/15	KNOB, Blower Switch 1981	24-425/32
INSULATOR, Steering Column Coupling	19-600/23	KNOB, Locking	23-1400/34
INSULATOR, Steering Column Coupling	19-1600/23	KNUCKLE KIT, Front Axle Steering-Right	2-100/1
INSULATOR, Steering Column Coupling	19-1600/23	KNUCKLE KIT, Front Axle Steering, Left	2-100/1
INSULATOR, manual strg. column coupling-1979-80-81	19-1000/22	KNUCKLE KIT, Front Axle Steering-Right	2-200/1
INSULATOR, manual strg. column coupling-1979-80-81	19-1200/30	KNUCKLE KIT, Front Axle Steering-Left	2-200/1
INSULATORS, WIRING	8-10500	KNUCKLE KIT, Front Axle Steering-Left	2-200/1
INTAKE & EXHAUST MANIFOLD	9C-935	KNUCKLE, Steering-1978	2-1500/12
INTAKE AND EXHAUST MANIFOLD	9B-250	KNUCKLE, Steering-1978	17-55/21
INTERIOR - REAR	23-9300	KNUCKLE, Steering-5000 Lb. Axle-1978	2-1500/12
INTERMEDIATE & REAR SEAT SUPPORTS,	23-3700	KNUCKLE, Steering-5000 Lb. Axle-1978	2-1500/12
ISOLATOR PACKAGE, Alternator	8-1100/3	KNUCKLE, Steering-With 3300 Lb. Axle-1979-80	17-52/20
ISOLATOR, Dual Battery (60 Amp.)	8-6300/1	KNUCKLE, Steering-With 3300 Lb. Axle-1981	17-52/20
ISOLATOR, Coil Spring Upper	17-53/10	KNUCKLE, Steering-With 3600 Lb. Axle	17-52/20
JACKET & BOWL & Shift Tube, steering column-1979-80	19-1700/55	KNUCKLE, Steering-With 4000 Lb. Axle	17-52/20
JACKET ASSY., steering column-1981	19-1700/55	KNUCKLE, steering-1979-80	2-1500/12
JACKET with BOWL & Shift Tube, Steering Column-1978	19-1700/55	LAMP	8-4350/2
JACKET, Column-With A230, A390 Trans.	19-100/33	LAMP & WIRING COURTESY	8-4350
JACKET, Column-With A833 Trans.	19-100/33	LAMP & WIRING, CLEARANCE REAR	8-4500
JACKET, Steering Column-1980-81	19-1000/1	LAMP & WIRING, DOME	8-7300
JACKET, Steering Column-With A230, A390 Trans.-1979	19-300/28	LAMP, Ash Receiver	23-5800/5
JACKET, Steering Column-With A230, A390 Trans.-1979	19-1000/1	LAMP, Dome, Club Cab, w/H/Liner - 1979-80-81 Consists of-	3488935
JACKET, Steering Column-With A727 Trans.-1979	19-1000/1	Bezel and 1 - 3488936 LENS	8-4200/21
JACKET, steering column-(primed)-1980-81	19-300/28	LAMP, Ign. & Starter Sw. (Not Shown) - 1978-9	8-6800/14
JACKET, steering column-except A727 trans.-1979	19-300/28	LAMP, Turn Signal	8-2700/20
JACKET, steering column-with A833, A727 trans.-1979	19-300/28	LAMP, w/BRACKET, Ign. Time Delay - 1978	8-7800/30
JACKET, strg. col.-(complete)-with auto trans.-1981	19-1000/1	LAMP, w/o License Lens -1978	8-4700/11
JACKET, strg. column-with 435, 445, A833 trans.-1979	19-1000/1	LAMP, CLEARANCE	8-4400
JACKET-All Trans., Except A727	19-100/33	LAMP, LICENSE	8-3100
KING PIN PARTS KIT, steering knuckle	2-300/34	LAMP, Lic., Step Type (Bright Hitch Bmpr.) - 1980-81	8-4800/4
KIT, Bearing and Seal	22-500/11	LAMP, PARKING & TURN SIGNAL	8-7000
KIT, Bushing, Seal & Washers, Approx. After 5/15/79 (Not Serviced)	8-300/13	LAMP, PILLAR MTD.	8-7700
.....	8-300/13	LAMP, REAR VIEW (MIRROR)	8-4900
KIT, Center Ball	16-400/13	LAMP, RELAY & CIRCUIT BREAKER	8-8200
KIT, Drive Gear, Pin & Thrush Washers, Approx. After 5/15/79 (Not Serviced)	8-300/14	LAMP, WIRING & RELAY	8-8700
KIT, Gasket	9B-500/1	LAMPS & SWITCHES, INSTRUMENT PANEL	8-7800
KIT, GASKET	9B-550	LAMPS & WIRING (FRT.END)	8-2600
KNOB	23-5800/3	LAMPS & WIRING (FRT.END)	8-2700
KNOB, /STEM, H/Lamp Switch - 1978 (Not Shown)	8-5300/14	LAMPS & WIRING (FRT.END)	8-2800
KNOB, G/Shift Lever	21M-400/1	LAMPS & WIRING (FRT.END)	8-2900
KNOB, G/Shift Lever	21M-800/1	LAMPS & WIRING (REAR END)	8-4600
KNOB, G/Shift Lever	21M-900/1	LAMPS & WIRING, CARGO & DOME	8-4200
KNOB, G/Shift Lever - 1978-79	21M-600/1	LAMPS & WIRING-DOME	8-4300
KNOB, Locking	23-1600/25	LAMPS, GLOVE BOX & ASH RECIEVER	8-5000
KNOB, Locking	23-1800/34	LAMPS, KARY VAN BOX	8-10000
KNOB, Locking	23-1900/26	LAMPS, LICENSE PLATE	8-4800
KNOB, Locking	23-8200/30	LAMPS, REAR END	8-8400
		LATCH ASSEMBLY, Curbside	23-4400/25

	GROUP-FIGURE/KEY NO.
LATCH ASSEMBLY, Roadside	23-4400/26
LATCH ASSEMBLY, Roadside	23-4400/45
LATCH ASSY., Vented Wdo.	23-2100/7
LATCH, Glove Box	23-5700/14
LATCH, Keeper	23-4400/31
LATCH, Keeper	23-4400/44
LATCH, Sldg. Dr. - 1978	23-1600/4
LATCH, Vented Window	23-9500/5
LATCH, ASSY.	23-2800/7
LEG ASSY., Dinette	23-3750/10
LENS and GASKET PKG., Parking and Turn Signal Lp.	8-2700/20
LENS and GASKET PKG., Pk. and Turn Sig. Lp. (Not Shown)	8-2700/40
LENS and GASKET PKG., Pk. and Turn Sig. Lp. (Amber)	8-7000/2
LENS, Dome Lamp	8-4300/22
LENS, H/Lp. Switch Identification - 1978 (Not Shown)	8-2200/24
LENS, w/ Reset	8-2350/25
LENS, w/o Reset	8-2350/24
LEVER	4-1100/32
LEVER	24-1005/11
LEVER ASSY, Gearshift Tube-First & Reverse	19-1300/13
LEVER ASSY, Gearshift Tube-Second & Third	19-1300/13
LEVER ASSY., Foot - 1978-79-80	4-400/3
LEVER ASSY., P/Brake Foot - 1978-79-80	4-300/2
LEVER ASSY., Parking Brake	4-100/3
LEVER ASSY., Parking Brake	4-150/3
LEVER ASSY., Parking Brake	4-200/3
LEVER ASSY., Parking Brake Hand	4-1000/10
LEVER ASSY., Parking Brake Hand	4-1050/10
LEVER ASSY., Col. Gearshift Hsg. Lock	19-1100/18
LEVER ASSY., G/Shift Tube-2ND & 3RD	19-1200/16
LEVER ASSY., Gearshift Housing Lock	19-300/18
LEVER ASSY., Gearshift Tube-First & Reverse	19-1200/16
LEVER W/PIN, P/Brake, w/10 x 2.5 Brake	4-800/3
LEVER w/BUSHING, Shift Control	21M-1175/12
LEVER w/BUSHING, Shift Control	21M-1175/19
LEVER w/KNOB, Column G/Shift, UP TO 10-1-80 WARREN BUILT	21A-900/2
LEVER w/PIN, A/C Blend Air Door Control	24-425/11
LEVER w/SHAFT, Inner Third and Overdrive, Use w/Trans. Service Assy. No. 4031879	21M-300/81
LEVER, A/C Recirc. Door	24-425/4
LEVER, A/C and Htr. Temp. Control	24-425/24
LEVER, Automatic Adjusting	5-500/14
LEVER, Automatic Adjusting	5-600/14
LEVER, Automatic Adjusting	5-650/13
LEVER, Automatic Adjusting, Right	5-700/6
LEVER, Cl. Release Idler - 1978	6-700/31
LEVER, Clutch Pedal - 1978	6-600/11
LEVER, Column G/Shift	21M-100/76
LEVER, Column G/Shift	21M-200/59
LEVER, G/Shift Operating, First and Reverse - 1978	21M-200/66
LEVER, G/Shift w/Rattle Isolator - 1980	21M-600/7
LEVER, Gearshift	21M-200/28
LEVER, Gearshift, UP TO APPROX. 6-16-1980	21M-400/3

	GROUP-FIGURE/KEY NO.
LEVER, Gearshift, Up To Approx. 4-18-1978	21M-600/7
LEVER, Gearshift, Up To Approx. 4-24-1978	21M-800/7
LEVER, Hurst Gearshift	21M-900/3
LEVER, Operating Reverse	21M-300/68
LEVER, P/Brake Hand	4-1100/14
LEVER, P/Brake Shoe, Up to 1-15-1979	4-1000/33
LEVER, Parking Brake	4-600/3
LEVER, Parking Brake	4-900/1
LEVER, Ratio	4-300/13
LEVER, Ratio	4-400/17
LEVER, Starter	8-600/3
LEVER, Turn Sig., w/o Speed Control	8-3400/5
LEVER, Upper Shift	21M-1175/14
LEVER, Upper Shift	21M-1175/18
LEVER, Col. Shaft Lock	19-1100/19
LEVER, Column Gearshift Tube-1St & Rev.	19-100/41
LEVER, Column Shaft Lock	19-300/19
LEVER, Housing Lock	19-100/8
LEVER, Lock	19-100/10
LEVER, Shift	19-300/24
LEVER, Shoe Release	19-1700/28
LIFT GATE	23-5300
LIFT ROD, Lift Gate	23-5300/9
LIGHT SWITCH--Post Office	8-10000/26
LIGHT, B/Up 70-1910	8-10000/13
LIGHT, Dome, w/BULB	8-10000/3
LIGHT, License	8-10000/9
LIGHT, License 70-1910	8-10000/12
LIGHT, Oil Pressure Signal (Illustrated), 1978	8-2200/16
LIGHT, Side Marker	8-10000/8
LIGHT, Tail	8-10000/11
LIGHT, Dome w/Bulb 70-1916	8-10000/21
LIGHT, Dome--Post Office	8-10000/26
LIGHT, ICC Amber 70-1913	8-10000/20
LIGHT, ICC Red	8-10000/18
LIGHT, Marker 70-1915	8-10000/15
LIGHT, Side Marker--Post Office	8-10000/28
LIGHT, Tail 70-1910	8-10000/14
LIL RED TRUCK	23-7150
LIMITER, Voltage	8-2200/7
LINER, 8 Ft. Box, Mopar Pick-Up (White)	23-7500/20
LINERS - DASH PANEL	23-5900
LINING & RIVET, Kit	4-1050/16
LINING PACKAGE	5-700/20
LINING PACKAGE, Standard	5-650/20
LINK & BUSHING ASSY., w/Wiper Mtr. Drive - 1981	23-7800/4
LINK with ENDS, drag-without diesel eng.-up to approx.10-1-80	2-1150/23
LINK with ENDS, drag-without diesel eng.-after approx.10-1-80	2-1150/23
LINK, Cable	4-100/11
LINK, Cable Adjusting - 1978-79	4-400/13
LINK, Cylinder Connecting	5-650/23
LINK, Door Knob To Elect. Switch	23-8200/31
LINK, Door to Electric Switch, 1979-80-81	23-1400/48

GROUP-FIGURE/KEY NO.	GROUP-FIGURE/KEY NO.
LINK, Dr. Elect. Lock Door to Switch	8-9700/9
LINK, Elect. Door Locks Solenoid to Lock	8-9200/5
LINK, Frt. DR. Elect. Locks Solenoid to Lock	8-9700/4
LINK, Lock Assy. to Lock	23-1800/36
LINK, Lock Cylinder to Lock	23-1900/28
LINK, Lock To Lock Cyl.	23-8200/34
LINK, P/Brake Lever	4-1000/22
LINK, Shift Rail	21M-1125/25
LINK, Solenoid To Lock, 1979-80-81	23-8200/36
LINK, Solenoid to Lock, 1979-80-81	23-1900/30
LINK,Center-With 3300,3600 Lb.Axle	2-1150/18
LINK,Center-With 4000 Lb.Axle	2-1150/18A
LINK,Drag-With Diesel Eng.	2-1150/23
LINK,Frt.Door Outside Handle to Lock	23-1400/30
LINK,Lock Remote Control	23-1400/19
LINK,Sway Eliminator Shaft	17-53/30
LINTLE, Rear, "A" Body	23-4100/7
LOCK ASSEMBLY	23-1400/53
LOCK ASSEMBLY	23-1900/29
LOCK ASSEMBLY	23-4400/47
LOCK ASSY, Frt. Door	23-8200/35
LOCK NUT, Hold Down Stud	5-700/22
LOCK PKG.	22-1100/13
LOCK PKG., Door - Left	23-4500/4
LOCK PKG., Door - Right	23-4500/9
LOCK, Adjusting Nut	22-350/3
LOCK, Adjusting Nut	22-400/3
LOCK, Adjusting Nut, 1978	22-450/3
LOCK, Bearing Adjusting Nut, 1978	22-800/13
LOCK, Brake Hose	5-1300/4
LOCK, Brake Hose	5-1400/8
LOCK, Brake Hose	5-1700/6
LOCK, Drive Shaft	3-100/33
LOCK, Drive Shaft	3-300/22
LOCK, Hose Anchor	5-1600/5
LOCK, Lift Gate	23-5300/21
LOCK, Side Door	23-1800/37
LOCK, Single Rr. Dr.	23-1900/1
LOCK, Sldg. Dr.	23-1600/9
LOCK, Tailgate, Up to 3-15-80	23-5400/2
LOCK, Wheel Bearing Adjusting Nut	22-900/14
LOCK,Frt Door	23-1400/25
LOCK,Shaft	19-1700/22
LOCK,Side & Rear w/Inside Release	23-1800/16
LOCK,Slam Bolt	23-1800/21
LOCK,shaft-not used on w models-spacer used-refer to item A	19-1700/22
LOCKNUT,1980-81	22-500/2
LOCKSTRIP, Frt. w/Shield, 16 Ft. Roll, Bright	23-1100/11
LOCKWASHER	16-400/18
LOCKWASHER, Shoe Anchor Pin	5-650/2
LOCKWASHER, Wingnut	22-1400/4
LOUVERS, Left	24-1005/5
MAINSHAFT, (Use w/3641115 Trans. Assy.) 27-1/4" Lg. (S40-40-30Spl)	21M-100/31
MAINSHAFT, (Use w/Trans. Service Assy. No. 2952805,4210629) 17-3/8" Lg. (S34-10-23Spl)	21M-500/42
MAINSHAFT, (Use w/Trans. Assy. No. 3633462) 17-3/16" Lg. (S35-R38-S23Spl-S28T)	21M-700/19
MAINSHAFT, 52-16-38-32 Teeth, 14-23/64" Long, Use w/Transfer Case As Purchased Assy. No. 4213148	21M-1150/30
MAINSHAFT, Trans.	21M-300/34
MANIFOLD, EXHAUST	9C-300/1
MANIFOLD, Intake	9C-300/7
MANIFOLD,INTAKE & EXHAUST (MMC DIESEL)	9B-900
MASK, Ammeter and Oil Indicator	8-2200/22
MASK, Fuel and Temp. Gauges, w/Brake, Turn, Hi-Beam Signal Lenses	8-2200/21
MAT, Frt. Drivers Side w/Jute Back, Black -1978	23-2500/1
MAT, Rr. Flr.- Frt. STD. w/127" W.B., w/Sldg. Dr.-Black, 1978-79-80	23-2600/1
MATERIAL TRIMMING	23-5650
MATS & RETAINERS, FLOOR	23-6600
MATS - CARPETS & SCUFF PLATES, FRONT	23-2500
MATS - CARPETS & SCUFF PLATES, REAR	23-2600
MEDALLION, Frt. Fndr. N/Plate - 1981	23-5000/27
MEDALLION, Frt. Fndr. N/Plate - 1981	23-7200/6
MEDALLION, Frt. Fndr. N/Plate - 1981	23-7300/13
MICROPHONE, CB Radio 1978-79	1-500/8
MIRROR ASSY., Inside Rr. View -Non-Prismatic, 10"	23-6500/3
MIRROR ASSY.,Rear View-Non-Prismatic, 10"	23-2300/4
MIRROR PKG. Stainless Steel Dual Velvac (Not Shown)	23-350/—
MIRROR-REAR VIEW & VISOR	23-2300
MIRRORS, OUTSIDE REAR VIEW	23-350
MISCELLANEOUS ITEMS,POWER STEERING	19-4700
MODULE, Emiss. Maint. Reminder (Not Shown) - 1980	8-2400/21
MODULE,Emiss. Maint. Reminder (Not Shown) 1980-81	8-2200/25
MOTOR ASSY., A/C Blower	24-425/7
MOTOR, Blower Heater	1-300/3
MOTOR, Heater Blower	1-150/15
MOTOR, Two Speed - 1978	23-2200/1
MOTOR, Wiper, Two Speed - 1978	23-7800/5
MOTOR, hr. blower aux. B-CB-MB	1-200/3
MOULDING, Headlining Panel	23-5250/4
MOULDINGS - REAR QTR. WINDOW	23-5225
MOULDINGS, EXTERIOR & ROOF	23-5000
MOUNTING BRACKET, Front	25-86/4
MOUNTING BRACKET, Rear	25-86/11
MOUNTING,ENGINE FRONT (MMC DIESEL)	9B-2900
MUD FLAP - "A" & "C" Body	23-4000/4
MUFFLER, Discharge w/225 Eng. 1981	24-250/5
MUFFLER, Exhaust	11-550/8
MUFFLER, Exhaust, 1978	11-560/3
NAME PLATE - Dodge, Grille - 1978	23-5000/1
NAME PLATE, "Adventurer", 1978-79-80	23-7200/6
NAME PLATE, "Power Wagon", 1979-80	23-7200/6
NAME PLATE, Frt. Fndr. "RAM CHARGER"- 1981	23-5000/28
NAME PLATE, Frt. Fndr. "RAM" - 1981	23-7200/6
NAME PLATE, Frt. Fndr. "RAM" - 1981	23-7300/13
NAME PLATE, Hood "Power Wagon" - 1978	23-7200/3

	GROUP-FIGURE/KEY NO.
NAME PLATE, Inst. "Custom"	23-5700/3
NAME PLATE, Rear Cargo Dr. "Dodge", 1978-79-80	23-400/28
NAME PLATE, Rr. c/Dr. "DODGE RAM" - 1981	23-400/28
NAME PLATE, Tailgate "DODGE RAM" - 1981	23-7200/12
NAME PLATE, Tailgate "Dodge Ram" - 1981	23-7300/20
NAMEPLATE,Inst./Panel "Custom" - 1981	23-2800/12
NERF STRIP, Frt. Bumper Guard	13-800/6
NERF STRIP, Frt. Bumper, Ends 1979-80-81	13-800/4
NERF STRIP, Frt. Bumper, Center 1979-80-81	13-800/7
NERF STRIP, Rear Bumper 1979-80	13-800/22
NIPPLE, Eng. Manif. A/C and Htr. Hose 3/8-18 x 2	24-250/17
NIPPLE, Grease 1/8-Pipe	16-200/21
NIPPLE, Spark Plug Cable, up to Approx. 3-22-77	8-4100/7
NOZZLE (MMC DIESEL)	9B-1700
NUT "U", Hsg. to Bracket Mtg. Screw	8-8900/4
NUT & WASHER,s/gear mounting bracket to frame	2-1350/1
NUT AND WA. PACKAGE, Transmission Flange	4-1000/41
NUT, (Snap In)	7-525/3
NUT, Adapter to Knuckle Bolt, 1978	5-300/9
NUT, Adjusting	22-350/4
NUT, Adjusting	22-400/4
NUT, Adjusting Screw Pivot	5-500/25
NUT, Adjusting Screw Pivot	5-600/16
NUT, Adjusting, 1978	22-450/4
NUT, Bearing Adjusting, 1978	22-800/12
NUT, Chrome w/Alum. Wheels	22-300/4
NUT, Chrome w/Steel Wheels	22-300/4
NUT, Clock Mtg. Bracket (3/16) (Not Shown or Serviced)	8-2200/24
NUT, Front Axle Yoke	16-400/3
NUT, H/Lamp Switch Mtg. (Not Shown)	8-5300/14
NUT, Lock	22-600/2
NUT, Parking Brake Lever Anchor	4-600/6
NUT, Rear Axle Yoke	16-100/9
NUT, Rear Axle Yoke	16-800/38
NUT, Shoe Anchor Pin	5-650/1
NUT, Support Bolt, w/12x2.5 Brakes	5-600/4
NUT, Wheel Bearing Adjusting	22-900/13
NUT, Wheel Stud	22-800/6
NUT, Wheel Stud, 1/2-20	22-500/12
NUT, Wheel Stud, 1/2-20	22-600/10
NUT, Wheel Stud, 5/8-18	22-450/8
NUT, Wheel Stud, w/13x3.5 Brakes, 5/8-18	22-900/6
NUT, Wheel Stud, w/3300 lb. Front Axle, 1/2-20	22-350/8
NUT, Wheel Stud, w/Single Rears, 5/8-18	22-400/8
NUT, Wheel Stud, w/o Styled Wheel, 1/2-20	22-700/3
NUT,1980-81	22-500/2
NUT,Intermediate Shaft Coupling Clamp Bolt	19-900/19
NUT,Pivot Bar Bolt	17-52/15
NUT-(metric-m14 x 1.5-6 H)	19-2925/3
NYLON TUBING CONNECTOR CHART	5-5650
O-RING	19-3500/1
O-RING Distributor Housing	8-200/14
O-RING,Flange Plate	9B-550/24
O-RING,Flange Plate	9B-550/25
O-RING,Fuel Control Motor Kit	9B-550/23

	GROUP-FIGURE/KEY NO.
O-RING,Oil Pipe	9B-550/21
O-RING-In 3633527 Repair Kit	19-2100/36
O-RING-In-3633527 Repair Kit	19-2100/29
OIL FILLER TUBE	10-295
OIL PAN & INDICATOR	10-400
OIL PAN AND INDICATOR	10-500
OIL PAN, INDICATOR & FILTER	10-410
OIL PUMP AND FILTER	10-100
OIL PUMP AND FILTER	10-125
OIL PUMP AND FILTER	10-150
OIL PUMP AND FILTER	10-175
OIL PUMP, PAN, INDICATOR & FILTER	10-420
OIL SEAL, 3" O.D., 1 11/16" I.D.	21M-1000/63
OIL SEAL, Case Extension	21M-500/11
OIL SEAL, Case Input	21M-1150/63
OIL SEAL, Diff. Housing	21M-1100/27
OIL SEAL, Front Output Shaft - 1980	21M-1150/58
OIL SEAL, M/Drive Gear Brg. Retainer	21M-700/32
OIL SEAL, Oil Pump Hsg.	21M-1150/55
OIL SEAL, Rear Extension (Use w/Trans. Assy. No. 3633462)	21M-700/49
OIL SEAL, Rear Output Shaft - 1980	21M-1150/15
OIL SEAL, Rear Wheel Output Shaft Bearing	21M-1100/36
OSAC SPARK ADVANCE SYSTEM & TIDC VALVE	25-800
OVERLAY, Tailgate, 1978-79-80	23-5000/17
PACKING SET, Starter	8-600/4
PAD AND PLATE, Pedal	5-800/9
PAD W/LINING, Axle Set	5-100/7
PAD W/LINING, Axle Set, 1978	5-300/12
PAD W/LINING, Axle Set, w/3500 lb. Front Axle	5-200/7
PAD, Auto. Trans.	5-1100/6
PAD, Clutch Pedal	6-300/9
PAD, Clutch Pedal - 1978	6-600/1
PAD, Dash Pnl. Insul. Rt. Side (Not Shown)	23-5700/19
PAD, Foam Seat Cushion	23-3750/9
PAD, Foot Lever	4-100/4
PAD, Foot Lever	4-150/4
PAD, Foot Lever	4-200/4
PAD, Foot Lever	4-300/3
PAD, Foot Lever	4-400/5
PAD, Horn, w/o Inlay, Low and Medium Line, Black	8-3500/1
PAD, Pedal, 1978	5-1000/6
PAD,HORN	8-3500
PAN, Housing, w/10" Clutch, w/225 Eng.	6-200/4
PAN, Trans. Oil, A727	21A-100/25
PANEL - INSTRUMENT	23-2700
PANEL ASSEMBLY, Left Side, "A" Body	23-4100/2
PANEL ASSEMBLY, Right Side, "A" Body	23-4100/5
PANEL ASSY, U/Body Eng. Hsg. Heat Shield, Right, w/400 - 440 Eng.	23-2400/12
PANEL ASSY., Frt. Fender Complete - 1981	12-200/1
PANEL ASSY., H/Gate Trim - Black	23-9375/15
PANEL ASSY., Rear Corner, Outer	23-5150/13
PANEL ASSY., Side CompLete	23-5150/11
PANEL ASSY., Side Step Sill, w/Hinge Cargo Doors, w/109" W.B. , Right	

	GROUP-FIGURE/KEY NO.
PANEL ASSY., Side, Outer	23-700/10
PANEL ASSY., T/Lamp Close off	23-5150/12
PANEL ASSY.,Roof S/Rail Hdr.-Rt.w/109"W.B.- 1978	23-5175/17
PANEL TRIM-COWL SIDE	23-600/4
PANEL w/HARDWARE, Less Lock Assy., 70" Door	23-8700
PANEL, Cab Back, Black	23-4300/1
PANEL, Cab Side,Outer 1978-79-80	23-9300/4
PANEL, Center Pillar, Inner	23-9700/2
PANEL, Center, w/109" W.B.	23-9800/18
PANEL, Cowl Hinge Plr. Lwr. Trim	23-900/3
PANEL, Cowl Plenum Grille	23-2850/1
PANEL, Cowl Plenum, Lower	23-2850/5
PANEL, Cowl Plenum, Upper	23-550/5
PANEL, Cowl Plenum, Upper - Up To 11-24-78	23-550/12
PANEL, Cowl Side, w/o Air Cond., Rt. Up TO 5-1-79	23-500/2
PANEL, Dash, Center	23-550/6
PANEL, Dash, w/o Air Conditioning - Up To 9-15-78	12-150/1
PANEL, Door Header	23-500/7
PANEL, Door Header	23-500/7
PANEL, Ext. To Side Pnl. Inr.	23-500/7
PANEL, Extension to Side Panel, Inner	23-550/1
PANEL, Fender Rear - Up To 3-1-79	23-9700/5
PANEL, Fender, Up To 1-10-79	23-9800/6
PANEL, Floor Center, "A" Body, 1978-79-80	23-5175/5
PANEL, Front Step Sill, Left	23-5150/1
PANEL, Frt. Fl. Corner, Lt. "A" Body, 1978-79-80	12-150/10
PANEL, Frt. Fl. Corner, Rt. "A" Body, 1978-79-80	12-150/7
PANEL, Header Trim (See Group 23)	23-4200/6
PANEL, Headlining, Front, 1979-80	23-700/10
PANEL, Headlining, Rear, 1979-80	23-4200/3
PANEL, Inner to Outer Pillar Filler	23-4200/5
PANEL, Instrument - Black	8-8900/12
PANEL, Instrument, w/o Air	23-5250/3
PANEL, Intermediate, 70" Door	23-5250/6
PANEL, Long Rail to Side Sill	23-550/10
PANEL, Outside door Repair, Side Cargo Frt.w/Window,(ALL W.B.)- 1978	23-5750/1
PANEL, Quarter Window Trim, Club Cab - 1979	23-5700/1
PANEL, Rad, Grille Ext. 1979-80	23-4300/2-3
PANEL, Rear Door Header	23-5150/7
PANEL, Rear Floor Corner, Left, "A" Body	23-1800/31
PANEL, Rear Floor Corner, Right, "A" Body	23-9350/4
PANEL, Rear Floor Outer	7-525/10
PANEL, Rear Window Lower Trim - 1979	23-600/5
PANEL, Rear Window Upper Trim - 1979	23-4200/1
PANEL, Rear, Inside, Upper	23-4200/7
PANEL, Rear, Outer, 1978-79-80	23-4200/7
PANEL, Rear, Outer, 1978-79-80	23-5175/26
PANEL, Rear,Inside,Upper 1978-79-80	23-9350/7
PANEL, Right Side Rr. w/109" W.B., w/o Wdo., w/Hinge Door	23-9350/6
	23-9700/14
	23-9700/4
	23-9800/2
	23-9800/3
	23-700/4
PANEL, Roof	23-600/1
PANEL, Roof Inner	23-5175/20
PANEL, Roof Outer	23-5175/21

	GROUP-FIGURE/KEY NO.
PANEL, Roof Outer	23-9800/1
PANEL, Roof Rail Header Trim - 1979	23-9350/3
PANEL, Roof, Outer, 1978-79-80	23-9700/1
PANEL, Rr. Corner, w/109" and 127" W.B., Right - 1978	23-700/2
PANEL, Rr. Floor Sill Close Off (Not Shown)	23-8850/9
PANEL, Side Cargo Dr. Lower Trim Ext.,Up To 11-1-80	23-1800/32
PANEL, Side Front Splash Shield - Up To 10-6-78	12-150/6
PANEL, Side Frt. Dr. Hdr. Trim	23-9375/1
PANEL, Side Frt. W/House, Inner	23-500/11
PANEL, Side Inr. Pnl. Fuel Filler Hsg.	23-5175/25
PANEL, Side Lock Pillar, Inner - Right	23-5150/10
PANEL, Side Rear Corner Trim, Upper - 1979	23-9350/5
PANEL, Side Rr. Lower Close Off	23-5175/11
PANEL, Sill, Center	23-9700/8
PANEL, Sill, Center	23-9800/10
PANEL, Sill, Front, 1978-79-80	23-9800/9
PANEL, Sill, Front, Up To 4-2-79	23-9700/9
PANEL, Sill, Rear, 1978-79-80	23-9800/11
PANEL, TRIM - FRONT DOOR	23-8400
PANEL, TRIM - FRONT DOOR	23-8500
PANEL, TRIM - FRONT DOOR	23-8550
PANEL, Top, w/Hardware, 70" Door	23-4300/4
PANEL, U/Body Fir. Rr.	23-900/-
PANEL, U/Body Front - 1978	23-900/2
PANEL, Underbody to Floor Close Off	23-5150/8
PANEL, Underbody to Floor Close Off	23-5150/9
PANEL, Wheelhouse	23-5150/15
PANEL, Windshield Frame - 1979	23-550/11
PANEL, Windshield Header Trim - 1979	23-9350/2
PANEL, Windshield Side Trim - 1979	23-9350/1
PANEL, w/House	23-5175/9
PANEL, w/Shield Hdr. Trim	23-9375/2
PANEL, w/Shield Side Trim	23-9375/3
PANEL,Floor Center-6 1/2' Box 1981(Not Shown)	23-7600/16
PANEL,Front Floor Outer-1981 (Not Shown)	23-7600/16
PANEL,Frnt.Seat Back Cover - 1978 (Not Shown)	23-8900/-
PANEL,Instrument w/o Air - 1978	23-2700/1
PANEL,QUARTER TRIM	23-6700
PANEL,Rear Floor Outer - 1981 (Not Shown)	23-7600/16
PANEL,Repair Frt.Door, 1978-79-80	23-1400/42
PANELS - HEADLINER	23-3000
PANELS - HEADLINER	23-3100
PANELS - LOWER TRIM	23-3300
PANELS - UPPER TRIM	23-3200
PANELS TRIM - CARGO & FRONT DOORS	23-2900
PANELS, EXTERIOR - PILLARS - REINFORCEMENTS	23-700
PANELS, ROOF HEADER AND ROOF RAILS	23-600
PANELS, Roof w/109" W.B.	23-600/1
PANELS, Side w/o Wdo., w/109" W.B. Left	23-700/1
PANELS,TRIM - COWL SIDE	23-2850
PASSENGER BUCKET SEAT	23-5600
PEDAL W/BUSHING, w/Man. Brakes, 1978	5-1000/3
PEDAL, BRAKE	5-1000
PEDAL, Brake, W/MANUAL TRANS.	5-1100/5
PEDAL, Clutch - 1978	6-600/2

	GROUP-FIGURE/KEY NO.
PEDAL, Clutch - 1978-79-80	6-300/8
PEDAL, Lower Half, 1978	5-800/4
PEDAL, Upper Half	5-800/3
PICK-UP & PLATE, Distributor	8-100/6
PICK-UP & PLATE, Distributor, Approx. After 5/15	8-300/4
PICK-UP and PLATE, Distributor	8-200/13
PILLAR ASSY., Side Lock Frt.Dr., All W.B. - Left	23-700/13
PILLAR, Center	23-9800/5
PILLAR, Cowl Hinge, Inner - Up To 9-22-78	23-550/8
PILLAR, Cowl Hinge, Outer	23-550/7
PILLAR, Cowl W/Shield Frame	23-500/1
PILLAR, Cowle Hinge Lower, Inner, w/o Air, Rt.	23-500/10
PILLAR, Door Lock, Right, 1978	23-9700/3
PILLAR, Frt. Dr. Lock	23-5175/1
PILLAR, Rear Door Lock, Left, 1978	23-9800/4
PILLAR, Rear w/ Single C/Dr., Right - 1978	23-700/15
PILLAR, Rr. Corner Outer	23-5175/14
PILLAR, Side C/Dr. Hge. Rear, All W.B.	23-700/12
PILLAR, Side Lk. Outer Lwr.	23-5175/2
PILLAR, Side Lock	23-5150/5
PILLAR, Side Lock, Outer	23-5150/3
PILOT, Compr. Discharge Flange 1980-81	24-250/3
PIN, Adjusting Lever	5-600/22
PIN, Adjusting Lever	5-700/21
PIN, Automatic Adjusting Lever (Not Shown)	5-500/14
PIN, Cotter (Not Serviced)	22-350/2
PIN, Cotter (Not Serviced)	22-400/2
PIN, Shoe Anchor	5-650/6
PIN, Shoe Hold Down	5-500/1
PIN, Shoe Hold Down Spring	5-600/25
PIN, Shoe Hold Down Spring	5-650/4
PIN, Shoe Return Spring	5-700/4
PIN, Starter Shifting Fork Pivot	8-400/2
PIN,Col.Shaft Coupling Body	19-300/52
PIN,Extension Spring	2-1150/2
PIN,Upper Hinge Frt.Door	23-1400/44
PIN,Vent Wing Handle	23-1400/8
PIN,gear shift hand lever spring	19-300/23
PINION	3-1000/6
PINION	3-1500/17
PINION CHART, SPEEDOMETER - 1978-79	21M-1220
PINION CHART, SPEEDOMETER - 1980-81	21M-1220
PINION CHART, SPEEDOMETER, WITH N.P.G. 203,205 TRANSFER CASE, AW1-W1,2,3,4	21M-1250
PINION CHART, SPEEDOMETER - A727 TRANS. - 1978-79	21A-1400
PINION CHART, SPEEDOMETER - A727,A904,A999 TRANS. AND N.P.G. 208 TRANSFER CASE - 1980-81	21A-1400
PINION CHART, SPEEDOMETER, WITH N.P.G. 203,205 TRANSFER CASE, AW1-W1,2,3,4- 203 1978-79, 205 1980-8	21A-1550
PINION, Diff.	3-300/29
PINION, Diff.	3-500/20
PINION,differential	3-1400/8
PIPE, Exhaust, Front, 1978	11-560/1
PIPE, Exhaust, Rear, Except Crew Cab, 1978	11-560/2
PIPE, Tail, w/109" W.B.	11-550/7

	GROUP-FIGURE/KEY NO.
PIPE, Tail, w/115" W.B., Conv. Cab, 1978	11-560/4
PISTON, Cylinder, w/ 7/8" Cylinder	5-600/28
PISTON, Cylinder, w/1-3/8" Dia. Cyl.	5-700/25
PISTON, Frt. Clutch, w/225 Eng., A904	21A-300/4
PISTON, Rr. Clutch	21A-300/26
PISTON, Wheel Cylinder	5-500/31
PISTON, Wheel Cylinder	5-650/25
PISTON,BOOT & SEAL PKG.,w/3500 lb. Frt.Axle 1980	5-200/9
PISTON,BOOT & SEAL PKG.,w/3500 lb. Frt.Axle 1981	5-200/9
PISTONS, CRANKSHAFT, CONNECTING RODS	98-200
PIVOT PKG., Upper Vent Wing	23-1400/6
PIVOT, Release Fork, w/10" clutch - 1978	6-400/7
PIVOT, Shift Lever Mtg.	21M-1175/20
PIVOT, Shoe Adjusting Screw	5-650/14
PLANETARY ASSY., Complete	21M-1150/75
PLATE & SEAL,S/Col.Jacket Support	19-1200/5
PLATE & Stud,Rear Spring Clip-With Spicer 60 Rear Axle	17-900/13
PLATE AND SEAL, Booster	5-1800/27
PLATE AND SEAL, Booster	5-1850/9
PLATE and Brush PACKAGE, Starter Brush Holder	8-400/15
PLATE, Alternator	8-800/5
PLATE, Alternator	8-1000/5
PLATE, Alternator Drive End Shield Ret.	8-900/5
PLATE, Anchor	4-1100/33
PLATE, Cover Latch	23-4400/32
PLATE, Cover Latch	23-4400/43
PLATE, Frt. Clutch Pressure	21A-300/10
PLATE, Frt. Clutch, w/225 Eng., A904	21A-300/11
PLATE, Hole Cover (Not Shown)	23-3700/--
PLATE, Lock Handle Mounting	23-4400/30
PLATE, Low Range Lock, 37 Teeth	21M-1150/68
PLATE, Parking Brake Lever Anchor	4-600/4
PLATE, Rr. Clutch Pressure, Rear	21A-300/20
PLATE, Rr. Clutch Pressure, Front	21A-300/22
PLATE, Shoe Guide	5-500/13
PLATE, Shoe Guide	5-650/7
PLATE, Threshold, Front, 1978-79-80	23-4200/4
PLATE, Threshold, Rear, "A" Body	23-4200/12
PLATE, Transfer Case Skid	21M-900/40
PLATE, Transfer Case Skid	21M-1175/45
PLATE,Col. Lock Lever Guide	19-300/16
PLATE,Col. Shaft Brg. Retainer	19-300/2
PLATE,Col. Shaft Lock	19-300/12
PLATE,Col.Shaft Lock	19-1100/12
PLATE,Column Jacket Support & Seal	19-1300/5
PLATE,Column Shaft Bearing Retainer	19-100/19
PLATE,Column Shaft Lock	19-100/14
PLATE,Lock Lever Guide	19-100/12
PLATE,steering column jacket support	19-600/11
PLUG & WIRE	8-10800/1A
PLUG, Case Interlock Hole	21M-1125/31
PLUG, Drive Gear Cup	21M-1150/72
PLUG, Frt. Mat	23-2500/12
PLUG, P/Brake Cable Hole	4-800/6
PLUG, Side Pnl. Inner Right (Not Shown)	23-5150/--

	GROUP-FIGURE/KEY NO.		GROUP-FIGURE/KEY NO.
PLUG, Spring	23-4300/12	RAIL, Front Wheel Shift - 1980	21M-1125/28
PLUG, Glow	9B-600/34	RAIL, Gearshift First and Reverse	21M-200/24
PLUG, Strg. Gear Hsg. End	19-2200/2	RAIL, Lockout Shift	21M-1100/1
PLUGS, CONNECTORS	8-10800	RAIL, Roof Rear	23-600/7
POPPET-In 3491351 Repair Kit	19-2100/24	RAIL, Roof Rear Corner	23-600/8
POST, Corner, Left, Rear, "A" Body, 1978-79-80	23-4100/10	RAIL, Roof Side w/109" W.B., Right	23-600/6
POST, Corner, Right, Rear, "A" Body, 1978-79-80	23-4100/9	RAIL, Third and Fourth Speed Shift	21M-600/22
PROP, Hood Panel	15-180/12	RAM DECALS - 1980	23-7180
PROPELLER SHAFT, 2 PIECE	16-700	RANGE BOX, Partial	21M-1000/12
PROPELLER SHAFT, 2 PIECE	16-1000	REAR AXLE RATIO	21M-1220
PROPELLER SHAFT, 2 PIECE, CB-MB3,4 (145,163 W.B.)	16-200	REAR AXLE RATIO	21A-1400
PROPELLER SHAFT, 2 PIECE, AW1	16-400	REATAINER, Thermostat	7-450/11
PROPELLER SHAFT, 2 PIECE, D1,2,3,4-RD2	16-600	RECEPTABLE, Complete	23-5800/4
PROPELLER SHAFT, 3 PIECE, W1,2 (w/149" W.B.)	16-800	RECLINER ASSY. Frt. Seat Back - Up To 12-4-78	23-3550/2
PROPELLER SHAFT, 3 PIECE, M6 (w/208" W.B.)	16-1100	REFLECTOR, Rear Side Corner	8-10000/28
PROPELLER SHAFT, SINGLE, B-CB-MB	16-100	REGULATOR - ELECTRIC WINDOW	23-1450
PROPELLER SHAFT, SINGLE, AD1	16-300	REGULATOR - ELECTRIC WINDOW	23-8250
PROPELLER SHAFT, SINGLE, D1,2,3-RD2	16-500	REGULATOR, Alternator Voltage (Not Shown)	8-1100/32
PROPELLER SHAFT, SINGLE, M3 (w/104,125 W.B.)	16-900	REGULATOR, Front Door Window - 1978	23-8200/11
PROTECTOR, Upper - 1978	23-2900/3	REGULATOR, Voltage	8-3000/5
PULL HANDLE, Frt. & Side c/Dr. Blue, 1978-9	23-2900/9	REGULATOR, Voltage	8-6600/9
PULL HANDLE, Trim Panel, Black	23-8500/4	REGULATOR, Frt. Door Wdo.	23-1400/11
PULLEY Water Pump	7-450/3	REINF. ASSY., I/Pnl. Lwr. Rt. & Ctr. (Not Shown)	23-5750/-
PULLEY, Accessory Drive Four Groove 1979-80	7-1350	REINFORCEMENT, Cowl Hge. Lwr. Inner To Outer Plr.	23-500/9
PULLEY, Air Pump	7-1350	REINFORCEMENT, Cross Sill Hold Down	23-9700/12
PULLEY, Alternator	8-800/1	REINFORCEMENT, Lower Hinge	23-550/9
PULLEY, Alternator	8-900/1	REINFORCEMENT, Rear Cross Sill	23-9800/15
PULLEY, Alternator, 2 3/4" S.G., 3/8 Belt w/4111944	8-1000/1	REINFORCEMENT, Roof to Lift Rod & Striker Mtg.- 1978	23-5300/2
PULLEY, Drive Auto Trans. w/Pwr. Strg. w/Air Cond and or Air Pump Single Groove 1979-80-81	7-900/7	REINFORCEMENT, Rr. Corner to Inner Pnl.- Up To 4-23-79	23-5150/14
PULLEY, Drive W/Auto W/AC 1978	7-925/C	REINFORCEMENT, Rr. Seat & Safty Belt, Outer, 1978-79	23-6300/7
PULLEY, Idler W/Air Cond.	7-900/9	REINFORCEMENT, S/Lk. Frt. Dr. Plr. Shldr. Belt Retractor	23-9100/9
PULLEY, Idler w/ Air. Cond	7-850/21	REINFORCEMENT, Seat Belt Anchor	23-9800/5
PULLEY, Idler w/Air Cond. Compressor 1979-80-81	7-925/C	REINFORCEMENT, Shoulder Belt Mounting	23-9800/5
PULLEY, Idler w/Air Cond. Compressor	7-1350	REINFORCEMENT, Shoulder Belt Retractor	23-9800/5
PULLEY, Single Groove	25-86/8	REINFORCEMENT, Side C/Dr. Hge. & Sldg. w/109" W.B.	23-700/11
PULLEY, POWER STEERING PUMP	19-4300	REINFORCEMENT, Side Pnl. to U/Body Pnl. Left, w/109" W.B.	23-700/5
PULLEY-Refer To Figure 19-4300	19-3100/1	REINFORCEMENT, Side Sill, 1978-79-80	23-9700/10
PULLEY-refer to figure 19-4300	19-3300/11	REINFORCEMENT, Side Sill, 1978-79-80	23-9800/13
PUMP & MOUNTING BRACKETS, POWER STEERING	19-3100	REINFORCEMENT, Side Step Sill Frt.- Right	23-700/8
PUMP WATER (MMC DIESEL)	9B-1200	REINFORCEMENT, Side Stepsill, Right	12-150/5
PUMP w/ Gasket	7-450/5	REINFORCEMENT, Wiper Motor Mounting	23-550/13
PUMP, Air 1979	25-86/10	REINFORCEMENT, I/Panel Lower	23-5700/1
PUMP, Rear Output Shaft Oil	21M-1100/25	RELAY, Diesel Engine Starter	8-6200/20
PUMP, Snow Plow Lift 1978-79	1-800	RELAY, Door Electric Locks	8-9600/9
PUMP, Washer	23-2200/23	RELAY, Elect. Door Locks	8-9000/3
PUMP, Washer - 1978	23-7900/5	RELAY, Glow Plug	8-6200/10
PUMP, POWER STEERING	19-3000	RELAY, H/Lamp Switch (Not Shown)	8-5300/14
RACK, Ign. Switch Actuator (Not Shown)	8-6800/14	RELAY, Horn, Exc. Tuff Strg. Wheel - 1978-9	8-3900/7
RACK, Side Assy. w/Tapes	23-7100/5	RELAY, Starter	8-3000/2
RACK, Switch Actuator	19-1700/29	RELAY, Starter	8-3300/8
RADIATOR	7-810/4	RELAY, Starter	8-7200/5
RADIATOR	7-810/15	RELAY, Starter - 1978	8-6000/6
RADIO, AM	1-500/1	RELAY, Starter - 1978	8-6100/40
RAIL, First and Second Speed Shift	21M-800/19	RELAY, Starter - 1978	8-7100/1

	GROUP-FIGURE/KEY NO.
RELAY, w/BRACKET, Heated Rear Window Wiring	8-9100/5
RELAY, Horn (Not Shown)	8-3900/15
RELAY, Start Run or Dual Pick Up	8-3000/16
RELAY, Start Run or Switching	8-200/14
RELUCTOR, Distributor	8-100/9
RELUCTOR, Distributor, Approx. After 5/15/79 - 1979-80	8-300/3
REMOTE CONTROL, Frt. Door	23-1400/15
REPAIR PACKAGE, Governor, A727	21A-500
REPAIR PACKAGE, Master Cylinder	5-1800/16
REPAIR PACKAGE, Master Cylinder	5-1825/5A
REPAIR PACKAGE, Master Cylinder, 1978	5-1850/21
REPAIR PACKAGE, SPEEDO. PINION SMALL PARTS	21M-1200
REPAIR PACKAGE, SPEEDO. PINION SMALL PARTS	21A-1300
REPAIR PACKAGE, Wheel Cylinder	5-500/16
REPAIR PANEL, Door Outer, Front, 1978-79-80	23-8200/12
REPAIR PKG. Outside Handle	23-1400/32
RESERVOIR	5-1800/35
RESERVOIR	5-1825/31
RESERVOIR - 1978	23-2200/22
RESISTOR, A/C and Htr. Blower Motor, 5 Prong	24-425/30
RESISTOR, Ballast - 1979	8-3000/3
RESISTOR, Htr. Blwr. Mtr.	1-100/10
RESISTOR, aux. htr. blwr. mtr.	1-200/3
RETAINER	7-810/19
RETAINER & SEAL PKG., Frt. Clutch, w/225 Eng. A904	21A-300/1
RETAINER AND PLATE	5-100/12
RETAINER AND PLATE, 1978	5-300/5
RETAINER, A/C Unit Drain Tube	24-425/10
RETAINER, Alternator Drive End Shield Bearing	8-1100/7
RETAINER, BEARING AND SEAL KIT	22-500/10
RETAINER, Bolt	22-1400/3
RETAINER, Boot Hold Down, Bright Finish	21M-1175/41
RETAINER, Brake Drum to Axle Shaft	22-700/2
RETAINER, Cable	4-150/5
RETAINER, Cable	4-400/8
RETAINER, Center Bearing Insulator	16-200/11
RETAINER, Center Bearing	16-200/12
RETAINER, Co/Shaft Rear Bearing	21M-700/44
RETAINER, Distributor Oil, .920 I.D.	8-100/18
RETAINER, Engine Housing Cover Seal	23-550/4
RETAINER, Front Output Shaft Bearing	21M-1000/64
RETAINER, Frt Output Shaft Rear Bearing	21M-1000/72
RETAINER, Frt. Clutch Piston Spring	21A-300/6
RETAINER, Frt. Output Shaft Bearing - 1980	21M-1130/31
RETAINER, Frt. Output, Rear Bearing	21M-1130/22
RETAINER, Housing Gasket	5-1800/18
RETAINER, Input D/Gear Bearing	21M-1000/4
RETAINER, Input Shaft Bearing	21M-1000/46
RETAINER, Insulators to B/Hd. Connector	8-2700/26
RETAINER, Kickdown Piston, Inner, w/225,318,360 and MMC DIESEL Eng., A727	21A-400/8
RETAINER, M/Drive Gear Bearing	21M-100/33
RETAINER, M/Drive Gear Bearing	21M-200/56
RETAINER, M/Drive Gear Bearing	21M-300/38
RETAINER, M/Drive Gear Bearing	21M-500/2

	GROUP-FIGURE/KEY NO.
RETAINER, M/Drive Gear Brg.	21M-700/29
RETAINER, P/Brake Lever Pin Lock	4-800/1
RETAINER, Push On	23-4400/38
RETAINER, Push Rod	5-900/19
RETAINER, Rear Brg.	21M-100/14
RETAINER, Rear Clutch	21A-300/12
RETAINER, Rear Output Shaft Bearing, Use w/Transfer Case As Purchased Assy. No. 4213148	21M-1150/13
RETAINER, Rect. H/Lp. Bulb	8-2700/13
RETAINER, Rect. H/Lp. Bulb	8-2900/23
RETAINER, Reverse Servo Piston Spring, A727	21A-400/10
RETAINER, Rr. Clutch	21A-200/20
RETAINER, Rr. Clutch Piston	21A-200/15
RETAINER, Rr. Crn. Pnl. Glass - Inside	23-1100/15
RETAINER, Rr. Crn. Pnl. Glass - Outside	23-1100/19
RETAINER, Rr. Output Shaft Oil Seal	21M-1140/7
RETAINER, Shoe Hold Down Spring	5-500/10
RETAINER, Side Lk. Frt. Dr. Plr. Striker T/Plate	23-5175/6
RETAINER, Silencer	5-1850/9
RETAINER, Silencer, w/3893594 Booster	5-1800/21
RETAINER, Speedometer Cable	8-2200/12
RETAINER, Temp. Control Cable, Control End	24-425/28
RETAINER, Valve Silencer, w/3632657-4088810 Assy.	5-1825/20
RETAINER, w/131 and 133 W.B.	16-600/10
RETAINER, w/3500 lb. Front Axle	5-200/3
RETAINER, w/BUSHING, Front Clutch, w/318 Eng. A999	21A-300/1
RETAINER, w/Bushing, Frt. Clutch,	21A-200/1
RETAINER, Lock Cylinder	23-1400/28
RETAINER, steering column wiring trough	19-1700/40
RETAINER, steering knuckle socket	2-200/19
RING and LUGS, H/Lp. Bulb Retaining	8-2700/8
RING, Distributor Snap	8-200/14
RING, Push Rod Retaining	5-1800/38
RING, Push Rod Retaining	5-1825/34
RING, Starter Pinion Shaft Gear Retainer Snap	8-400/4
RING, Trim, 15" Styled 1978-79	22-300/3
RING, Trim, w/16.5 x 6.00 Wheel 1978-79-80-81	22-100/3
RING, w/CABLE, Horn Contact	8-3400/2
RING, w/LUGS, Rd. H/Lp.	8-2900/18
RING, Column Shaft Lower Bearing	19-300/44
RING, Housing End Plug Retaining	19-2100/1
RING, Shift Tube Retaining	19-1700/46
RING-In 3633527 Repair Kit	19-2100/40
RISER ASSY, Bucket Seat	23-3400/6
RISER ASSY., Bucket Seat	23-3500/6
RISER ASSY., Rear Seat Crew Cab	23-8900/1
RISER, Bucket Seat, 1978-9	23-5500/4
RISER, Int. Seat, 3 Pass. (w/Quick Release)	23-3700/1
RISER, W/Folding Seat	23-5600/3
RIVET, Latch	23-4400/35
RIVET, Lining	5-700/19
RIVET, Strap	23-4400/34
ROD and BOLT, Upper - 1978	23-1800/22
ROD, Adjusting, Rear	4-300/26
ROD, Booster Push	5-1800/22

	GROUP-FIGURE/KEY NO.		GROUP-FIGURE/KEY NO.
ROD, Cl. Release, Lower	6-700/28	SCREW AND VENT, w/Spicer Axle	5-1400/11
ROD, Clutch Pedal - 1978-79-80	6-300/6	SCREW AND WASHER, Retainer	5-100/10
ROD, Clutch Pedal - 1978-79-80	6-400/25	SCREW AND WASHER, Retainer	5-200/1
ROD, Control Shift	21M-900/10	SCREW AND WASHER, Retainer, 1978	5-300/4
ROD, First and Reverse, w/A230 Trans. - 1978	21M-250/6	SCREW AND WASHER, Shield, 1978	5-300/1
ROD, First and Second Shift Control	21M-400/9	SCREW, 1/4-20x3/4	23-1900/33
ROD, Hydro-Booster Push	5-1825/23	SCREW, Adapter to Cyl. Blk. 1/2-13 x 2" w/6 Point Head, w/I.H.C. 446	
ROD, Latch	23-4400/27	Eng.	21A-100/3
ROD, Latch	23-4400/46	SCREW, Adjusting	5-500/24
ROD, Master Cylinder Push	5-1800/26	SCREW, Adjusting	5-600/17
ROD, Parking Sprag	4-1900/4	SCREW, Adjusting	5-700/16
ROD, Pedal to Bellcrank, 1978	5-1825/13	SCREW, Alternator	8-900/11A
ROD, Primary Piston Push, 1978	5-1800/4	SCREW, Alternator Frame	8-800/2
ROD, Push	5-900/18	SCREW, Alternator Frame, 10-24-1-5/8	8-1100/28
ROD, Push, 1978	5-1825/36	SCREW, Bleeder	5-100/8
ROD, Second and Third, w/A230 Trans. - 1978	21M-250/5	SCREW, Bleeder	5-300/11
ROD, Shift Control - 1980	21M-1175/9	SCREW, Bleeder	5-600/5
ROD, Shift Lever	21M-1175/25	SCREW, Bleeder	5-700/27
ROD, Shoe Push	5-500/15	SCREW, Bleeder, w/3500 lb. Front Axle	5-200/12
ROD, Shoe Push	5-600/26	SCREW, Brake Hose	5-1300/20
ROD, Shoe Push	5-700/23	SCREW, Cap, 5/16-18x1/2"	23-4400/40
ROD, Vent Wing Adjusting	23-1400/10	SCREW, Clamp Attaching	16-100/7
ROLL BAR PKG., w/6 1/2 Ft. Box	23-6900/6	SCREW, Clamp Attaching	16-200/5
ROLL BAR, 1978-79-80	23-5000/22	SCREW, Clamp Attaching	16-400/11
ROLLER ASSEMBLY	23-4300/10	SCREW, Clock Mtg. (3 - 16 x 1/2) (Not Shown or Serviced)	8-2200/24
ROLLER, Top, w/Bracket	23-4300/24	SCREW, Cylinder Bleeder	5-500/17
ROOF ASSEMBLY, "A" Body	23-4100/3	SCREW, Cylinder Bleeder	5-650/27
ROOF BOW, 1978-79-80	23-4100/13	SCREW, Cylinder Mounting	5-600/2
ROOF SHELL	23-5200/2	SCREW, Cylinder Mounting	5-650/5
ROOF VENT	23-5275	SCREW, Cylinder Mounting	5-700/13
ROOF, Hard Top, 1978-79-80	23-5000/25	SCREW, Dome Mounting	22-300/5
ROOF, WEATHERSTRIPS AND GLASS	23-5200	SCREW, Hose, w/3500 lb. Axle	5-1400/16
ROTOR PACKAGE, Frt. Oil Pump, A727	21A-350	SCREW, Housing Mounting, Except 4000 lb. Front Axle	5-100/2
ROTOR, Alternator	8-800/6	SCREW, Hsg. to Bracket Mtg. (8 - 18 x 5/8) (Not Serviced)	8-8900/5
ROTOR, Alternator	8-900/6	SCREW, Lamp Mtg.	8-7000/3
ROTOR, Alternator	8-1000/6	SCREW, Piston Stop	5-1800/14
ROTOR, Distributor	8-100/11	SCREW, Round Head, 10-24x1"	23-4400/39
ROTOR, Distributor	8-200/2	SCREW, Sheet Metal	23-4400/41
ROTOR, Distributor, Approx. After 5/15/79 - 1979-80	8-300/2	SCREW, Shoe Adjusting	5-650/15
RUB RAIL, Front, "A" Body	23-4000/3	SCREW, Splash Shield to Knuckle	5-100/5
RUB RAIL, Rear, "A" Body	23-4000/5	SCREW, Starter Frame	8-400/19
RUN, Division Channel	23-1400/40	SCREW, Starter Set	8-600/1
RUN, Frt. Door Glass - Up To 11-1-78	23-1400/2	SCREW, Wheel Cylinder Mounting	5-500/2
RUNNING BOARD, Chrome Plated - Left	23-7100/6	SCREW, w/NUT, H/Lp. Bulb Mtg. Seat Adj.	8-2700/5
RUNNING BOARDS (MOPAR)	23-375	SCREW, gear to bracket-1978	2-1350/4
RYD-A-BED SEATING SYSTEM	23-3750	SCREW, gear to bracket-metric-1979-80	2-1350/4
RYD-A-BED SEATING SYSTEM	23-3760	SCREW-not serviced	19-2925/1
RYD-A-BED SEATING SYSTEM (FRONT)	23-3765	SCUFF PAD, Frt. Stepwell, Up To 3-1-80	23-2500/8
RYD-A-BED SEATING SYSTEM (Rear)	23-3770	SCUFF PLATE, Rr. Flr. Side Door, w/109" W.B.	23-2600/7
RYD-BED SEATING SYSTEM	23-3755	SCUFF Plate, Frt. Dr. Opng. S/Step Sill	23-2500/6
Reluctor, Distributor	8-200/3	SEAL AND BOOT PKG., w/4500 lb. Front Axle	5-200/10
SAGINAW-refer to figure 19-2400, 1978	19-1800	SEAL AND PLATE, Front Shell, w/3632657 Assy.	5-1825/20
SAGINAW-refer to figure 19-2400, up to approx. 6-12-79	19-1800	SEAL ASSY, U/Body Trans. & Shift Cont. Lever	23-2500/10
SAGINAW-refer to figure 19-2400, after approx. 6-12-79	19-1800	SEAL ASSY., steering gear u-joint	19-3700/45
SCREEN, Regulator Valve	21A-700/9	SEAL, A/C Compr. Clutch Drive (Not Shown)	24-1400/12

	GROUP-FIGURE/KEY NO.
SEAL, A/C Evaporator Coil, Ret Bend End	24-425/1A
SEAL, A/C Evaporator Coil, Hair Pin End	24-425/1A
SEAL, A/C Recirc. Hsg. to Dash	24-425/5
SEAL, BOOT AND PISTON PACKAGE	5-100/9
SEAL, BOOT AND PISTON PACKAGE, 1978 & 80	5-300/10
SEAL, Bearing Outer	22-500/7
SEAL, Booster Front Shell	5-1800/28
SEAL, Booster to Dash	5-1825/20
SEAL, Bottom, 70" Door	23-4300/8
SEAL, Bracket, 1978	5-1825/3
SEAL, Brake Pedal Bushing, 1979-80	5-800/35
SEAL, Cable to Floor Pan	4-300/29
SEAL, Cable to Floor Pan	4-400/7
SEAL, Case Extension	21M-200/18
SEAL, Dash, 1978	5-1800/2
SEAL, Distributor	8-100/3
SEAL, Distributor	8-200/7
SEAL, Exhaust Pipe	11-560/6
SEAL, Frt. Output Shaft Brg. Retainer	21M-1130/32
SEAL, Input D/Gear, 2 9/16" O.D., 2" I.D.	21M-1000/6
SEAL, M/Drive Gear Brg. Retainer Oil	21M-300/41
SEAL, Oil	22-400/12
SEAL, Oil, 1978	22-450/12
SEAL, Oil, Long Ext.	21M-100/20
SEAL, Oil, Up to 11-15-1978	16-200/15
SEAL, Oil, w/3300 lb. Front Axle, 5 Stud Rotor	22-350/12
SEAL, Pan Dust, w/10" Clutch, w/225 Eng.	6-200/7
SEAL, Side	23-4300/7
SEAL, Splash Shield to Knuckle, w/3300 lb. Front Axle	5-100/4
SEAL, Starter	8-400/25
SEAL, Starter Solenoid Contact	8-400/24
SEAL, Top, 70" Door	23-4300/9
SEAL, Wheel	22-600/9
SEAL, Wheel Cylinder to Support	5-500/3
SEAL, Wheel Oil	22-800/7
SEAL, Wheel Oil, w/13x3.5 Brakes	22-900/8
SEAL, Yoke Oil	16-100/6
SEAL, Col.G/Shift Tube To Shaft-With A230,A390 Trans.-Up To Approx.6-1-79	19-1300/17
SEAL, Col.G/Shift-With A727 Trans.-Up To Approx.6-1-79	19-1300/3
SEAL, Column Jacket Support Plate	19-100/39
SEAL, Column Jacket Support Plate	19-300/53
SEAL, Drag Link End Stud	2-1150/32
SEAL, G/shift Tube-W/435,445,A833 Trans.-Up To Approx.6-1-79	19-1300/11
SEAL, Gearshift Tube-With A230,A390 Trans.	19-900/12
SEAL, Oil Front	9B-550/8
SEAL, Side	9B-550/10
SEAL, Tie Rod End Dust-W/3300,3600 Lb. Axle-1979-80	2-1150/29
SEAL, Tie Rod End Dust-W/3300,3600,4000 lb. axle-1981	2-1150/29
SEAL, Tie Rod End Dust-With 4000 Lb. Axle-1979-80	2-1150/29
SEAL, Tie Rod End Assy.-w/4000 lb. axle-1981	2-1150/29
SEAL, Valve Ring-In 3491350 Repair Kit	19-2100/31
SEAL, Valve Ring-In 3633527 Repair Kit	19-2100/32
SEAL, drive pinion oil-1978	3-400/19

	GROUP-FIGURE/KEY NO.
SEAL, drive pinion oil-1978	3-500/6
SEAL, drive pinion front bearing oil	3-100/8
SEAL, oil-use with 5380 & 7260 serier companion yoke-1978	3-800/5
SEAL, Oil Assy.	9B-550/4
SEAL, Oil Rear	9B-550/5
SEAT & SHOULDER BELT - BUCKET SEAT	23-6100
SEAT - SWIVEL	23-3600
SEAT ASSY, Std. Bucket (Sales Code KN2)	23-5500/1
SEAT BACK RELEASE	23-9400
SEAT BELT - BUCKET SEAT	23-6050
SEAT BELT, Tip Half, Drivers & Pass., Blue	23-3600/11
SEAT BELTS - BUCKET SEAT	23-6000
SEAT BELTS - INNER - BENCH SEAT	23-9075
SEAT, PEDESTAL, ARM, REST, BELTS AND ADJUSTER	23-3625
SEAT, Automatic Adjusting Lever Spring	5-700/3
SEAT, Bulb Mtg. - 1978	8-2500/3
SEAT, DRIVERS	23-5500
SEAT, REAR - AD,AW1 (1980-81)	23-6250
SEAT, Rd. H/Lp.	8-2700/4
SEAT, Rd. H/Lp. Mtg.	8-2900/15
SEAT, Rect. H/Lp. Bulb Mtg. (Hi Beam)	8-2700/15
SEAT, Rect. H/Lp. Bulb Mtg. (Hi-Lo Beam)	8-2900/28
SEAT, Shoe Hold Down Spring	5-500/8
SEAT, BUCKET W/CONSOLE	23-9050
SEAT, REAR - AD-AW1 (1978-9)	23-6200
SEAT, Rear Spring Clip-With 5700 Lb.Spring At Pad	17-1200/12
SEATS - HIGH BACK BUCKET	23-3500
SEATS - LOW BACK BUCKET	23-3400
SEATS, FRONT BENCH - A,J,W	23-5450
SEATS, REAR - B	23-3650
SECTOR, Ign. Switch Actuator (Not Shown)	8-6800/14
SECTOR, Switch Actuator	19-500/32
SECTOR, Switch Actuator	19-1700/32
SELECTOR VALVE - AUXILIARY FUEL TANK	14-610
SENDING UNIT, Oil Pressure Gauge	8-6600/21
SENDING UNIT, Trans. Oil Temp.	8-2250/7
SENSOR, Eng. Coolant Level	8-2250/6
SENSOR, Eng. Oil	8-2250/9
SENSOR, Eng. Temp.	8-5900/4
SENSOR, R.V. & WIRING	8-2250
SENSOR, Trip Computer Fuel Flow (Not Shown)	8-8900/14
SENSOR, Trip Computer Speed (Not Shown)	8-8900/14
SENSORS & SENDING UNITS	8-7600
SEPERATOR	8-9900/1
SEPERATORS & BRKTS., IGNITION CABLE	8-9900
SERVICE KIT - Accumulator Valve	5-900
SERVICE KIT - Accumulator Cap Seal	5-900
SERVICE KIT - General Seal	5-900
SERVICE KIT - Power Piston	5-900
SERVICE KIT, Spool Plug Seal	5-900
SHACKLE, Rear Spring Rear	17-1000/19
SHACKLE, Rear Spring Rear	17-1000/19
SHAFT	3-1000/7
SHAFT	3-1500/1
SHAFT & COUPLING-Refer To Figure 19-900	19-600/13

	GROUP-FIGURE/KEY NO.		GROUP-FIGURE/KEY NO.
SHAFT & FLANGE,Manual Steering Column	19-200/14	SHAFT,Front Axle Drive-Outer	2-100/13
SHAFT & FLANGE,Power Steering Column	19-200/14	SHAFT,Front Axle Drive-Outer	2-200/13
SHAFT & FLANGE,Strg. Column-Refer To Figure 19-700	19-900/5	SHAFT,M/Strg.Col.Cplg.Intermediate-21.67"long	19-1200/21
SHAFT & FLANGE-refer to inset-item 49	19-100/26	SHAFT,M/Strg.Col.Cplg.Intermediate-18.54"long	19-1200/21
SHAFT & GOVERNOR, Serviced in Distributor Partial Assy.	8-300/5	SHAFT,P/Strg.Col.Coupling Intermediate-19.85"long	19-1200/21
SHAFT & NUT PACKAGE,Steering Column	19-700/2	SHAFT,Race and Upper	19-1700/51
SHAFT & NUT PACKAGE,Steering Column	19-700/2	SHAFT,Race and Upper	19-1700/51
SHAFT & NUT PACKAGE,strg. column-54.25" long	19-1300/1	SHAFT,STEERING COLUMN-1978	19-1500/20
SHAFT ASSY., Frt. Output, Lower, Use w/Transfer Case As Purchased		SHAFT,STEERING COLUMN-1979	19-1500/20
Assy. No. 4115082	21M-1000/69	SHAFT,STEERING COLUMN-1978	19-1500/20
SHAFT ASSY.,P/Strg.Col.Cplg.Intermediate-Up To Approx.6-1-79		SHAFT,STEERING COLUMN-1979	19-1500/20
	19-1500/13	SHAFT,Starter Pinion	8-400/8
SHAFT ASSY.,lower steering-1979-80	19-1700/49	SHAFT,Steering Column Intermediate-1978	19-1500/13
SHAFT ASSY.,lower steering-1981	19-1700/49	SHAFT,Steering Column Intermediate-1978	19-1500/13
SHAFT ASSY.,lower steering-1981	19-1700/49	SHAFT,Steering Gear-1978	19-1900/13
SHAFT ASSY.,steering column-lower	19-500/49	SHAFT,Steering Gear-Used In 4088079,4117998 Gear	19-2400/15
SHAFT PACKAGE, Output Consists of: Output Shaft, Thrust Washer,		SHAFT,Steering Gear-Used In 3496910 Gear	19-2400/15
Thrust Plate	21A-800/9	SHAFT,Strg. Column	19-300/14
SHAFT and GOVERNOR, Distributor	8-100/10	SHAFT,Sway Eliminator	17-53/31
SHAFT w/GEAR, Input	21M-1140/30	SHAFT,diff.pinion cross	3-1400/4
SHAFT w/GEAR, Package Speedo. Drive, Rr. Output	21M-1140/24	SHAFT,differential pinion-serviced in item 31	3-100/20
SHAFT w/LEVER, Lockout	21M-1000/24	SHAFT,drive	3-100/1
SHAFT w/LEVERS, Cl. Release Torque - 1978-79-80	6-700/18	SHAFT,drive- 5500 lb. axle	3-500/11
SHAFT w/LEVERS, Clutch Torque, Up To 3-1-1979	6-400/27	SHAFT,drive-1978	3-300/1
SHAFT w/PLUG, Output	21A-850/13	SHAFT,drive-1979-80-81	3-300/1
SHAFT w/SUPPORT, Reaction, w/Lock Up Torque Converter		SHAFT,drive-5500 Lb.axle	3-400/27
	21A-350/8	SHAFT,drive-D3 except sweptime,with dual wheels & D4 ambulance	
SHAFT w/SUPPORT, Reaction, A904-A999	21A-350/17		3-800/10
SHAFT, Balancer, 70" Door	23-4300/16	SHAFT,steering column	19-600/19
SHAFT, Bellcrank, 1978	5-1825/9	SHAFT,steering column	19-600/19
SHAFT, Brake Pedal	5-1100/2	SHAFT,steering column-36.45" long	19-1200/7
SHAFT, Cl. Release Idler Lever	6-700/30	SHAFT,steering column-36.45" long	19-1400/5
SHAFT, Clutch Pedal	6-300/1	SHAFT,steering gear-1979-80-81	19-1900/13
SHAFT, Diff. Pinion, w/o Anti Spin	3-300/12	SHELL ASSY., w/Shield Cowl,1978-79	23-9700/6
SHAFT, Front Output	21M-1130/13	SHELL ASSY., w/Shield Cowl- 1978	23-9800/7
SHAFT, Front Output, 6-15/16" Long (32-61T)- 1980	21M-1150/4	SHELL and CLAMP, use w/light, Cigar Lighter	8-7800/4
SHAFT, Frt. Output, Lower, Shaft Use w/Transfer Case As Purchased		SHELL, Door Front - 1978	23-8200/12
Assy. No. 3898654	21M-1000/69	SHELL, Rear Door, 1978-79-80	23-8300/22
SHAFT, Input	21M-1000/40	SHELL, Sun Gear Driving	21A-850/11
SHAFT, Input 26T,23 Teeth	21A-300/17	SHIELD Bearing Dust	7-925/C
SHAFT, Input, All Eng. w/o Lock Up Torque Converter	21A-200/17	SHIELD, Alternator Rectifier End	8-900/15
SHAFT, Output	21M-200/48	SHIELD, Alternator Drive End	8-1000/3
SHAFT, Parking Sprag	4-1900/2	SHIELD, Alternator Drive End	8-1100/5
SHAFT, Pedal, w/Auto. Trans.	5-1000/2	SHIELD, Alternator Heat (Not Shown)	8-1600/22
SHAFT, Rev. Idler 5-3/8" Long .9880 Dia.	21M-500/53	SHIELD, Alternator Rectifier End	8-800/15
SHAFT, Rev. Idler Gear, 4-13/32" Long (1.075 Dia.)	21M-700/54	SHIELD, Alternator Rectifier End	8-1000/15
SHAFT, Reverse Idler Gear	21M-300/60	SHIELD, Altr. Heat	8-1700/22
SHAFT, Starter Gear	8-600/8	SHIELD, C/Dr. Lock Striker	23-1800/25
SHAFT, w/ GOVERNOR, Distributor	8-200/12	SHIELD, Cowl Hge. Plr. Lower Inner - Upper	23-500/10
SHAFT, w/Oil Pump, Output	21M-1100/20	SHIELD, Cowl Side Water - Up To 11-23-78	12-150/3
SHAFT,Drive	19-1700/7	SHIELD, Grease	4-1000/36
SHAFT,Front Axle Drive,Inner,Right,16-1/8"Long	2-200/13	SHIELD, Heat	5-800/33
SHAFT,Front Axle Drive-Inner-Right-16 7/8" Long	2-100/13	SHIELD, Maintenance Lamp Switch	8-10200/7
SHAFT,Front Axle Drive-Inner-Left-37 1/8" Long	2-100/13	SHIELD, Rad. Inlet Hose 400,440 Eng. 1978-79	7-200/10
SHAFT,Front Axle Drive-Inner-Left-36-1/2"Long	2-200/13	SHIELD, Splash	5-100/3

	GROUP-FIGURE/KEY NO.
SHIELD, Splash, "A" Body	23-4200/10
SHIELD, Splash, 1978	5-300/2
SHIELD, Splash, w/3500 lb. Front Axle	5-200/6
SHIELD, Starter Heat	8-400/25
SHIELD, Starter Heat, (Not Shown)	8-500/7
SHIELD, Strtr. Cbl. Heat	8-3300/24
SHIELD, U/Body Rr. Floor Pnl. Heat Right (Not Shown)	23-900/--
SHIELD,Alternator Drive End	8-800/3
SHIELD,Alternator Rectifier End	8-1100/15
SHIELD,Tilt Lever Opening	19-1700/11
SHIFTER ASSY., Gearshift	21M-400/18
SHIFTER ASSY., Hurst	21M-900/5
SHIM,rear bearing adjusting-.003	3-800/21
SHIM,rear bearing-.003	3-400/10
SHOCK ABSORBER,Front Wheel Damper	2-1600/11
SHOCK ABSORBER,H.D.,With 4000 Lb. Front Axle	17-53/15
SHOCK ABSORBER-1 3/16" Dia.-1979-80-81	17-53/15
SHOCK ABSORBER-1" Dia.-1979-80-81	17-53/15
SHOE AND LINING PACKAGE	5-650/20
SHOE W/LINING, Axle Set	5-500/5
SHOE W/LINING, Axle Set, w/12x2.5 Brakes	5-600/21
SHOE W/LINING, Parking Brake	4-1000/34
SHOE W/Lining, Axle Set	5-700/7
SHOE or BEARING ,S/Gear U-Joint	19-900/17
SHOE w/LINING, Parking Brake	4-1000/21
SHOE w/LINING, Parking Brake, Kit	4-1050/16
SHOE, w/o Lining	5-700/8
SHOE,Column Shaft Coupling Body	19-300/50
SHOE,Steering Wheel Lock	19-1700/8
SHOE,Steering Wheel Lock	19-1700/8A
SHOE,Strg.Col.Coupling	19-1200/24
SHROUD, Fan (Up To 5-15-79)	7-810/16
SHUNT, Ammeter, w/100 Amp. Alternator (Not Shown)	8-2200/24
SILENCER, Booster Cylinder Valve	5-1825/20
SILENCER, Valve	5-1800/21
SILENCER, Valve	5-1850/9
SILL ASSEMBLY, Rear, "A" Body, 1978-79-80	23-4100/6
SILL ASSY., Rr. w/Whiting Roll Up Dr. "A" Body - 1981	23-4100/6
SILL, Rear Cross	23-9800/12
SILL, U/Body Rr. Flr. Cross (Not Shown)	23-5150/--
SILL, U/Body Rr. Flr. Cross	23-5175/18
SILL, Underbody, Front, 1978-9	23-5150/6
SKIRTING, Left Front, "A" Body	23-4200/9
SKIRTING, Left Rear, "A" Body	23-4200/8
SKIRTING, Right Front, "A" Body	23-4200/13
SKIRTING, Right Rear, "A" Body	23-4200/14
SLEEVE - Std.	9B-500/2
SLEEVE, Alternator (Serviced in Rectifier End Shield)	8-1100/14
SLEEVE, Alternator (serviced in Drive End Shield)	8-1100/2
SLEEVE, Altr. Mtg. Bolt	8-2100/8
SLEEVE, P/Brake Spacer	4-1000/29
SLEEVE, Shoe Adjusting	4-1000/39
SLEEVE,Oil Seal	9B-550/6
SLINGER, Brake Drum, w/13x3.5 Brakes	22-900/7
SLINGER, Center Bearing	16-200/13

	GROUP-FIGURE/KEY NO.
SLINGER, Center Bearing	16-1100/29
SLINGER, Front Output Shaft Flange, w/208 T/Case	16-400/21
SLINGER, Front Output Shaft Flange	21M-1150/59
SLINGER, Grease	22-800/2
SLINGER, Yoke	16-400/1
SNAP RING, Input Shaft	21M-1125/3
SNAP RING, Input Shaft Bearing	21M-1125/2
SNAP RING, Piston Stop	5-1800/37
SNAP RING, Piston Stop	5-1825/33
SOCKET & BOOT	8-11000/1
SOCKET KIT,Front Axle Steering Knuckle	2-100/3
SOCKET KIT,Front Axle Strg.Knuckle-Upper & Lower	2-200/3
SOCKET, A/C and Htr. Control Illum.	24-425/26
SOCKET, Adjusting Screw	5-500/21
SOCKET, Adjusting Screw	5-600/19
SOCKET, Heated Rear Window Indicator Lamp	8-9100/8
SOCKET, Park., T/Sig. and Side Marker Lp.	8-2900/6
SOCKET, Printed Circuit Board Lights	8-2200/13
SOCKET, Radio Wiring (Not Shown)	8-5200/43
SOCKET, Shoe Adjusting Screw	5-650/16
SOCKET, Side Marker Lp.	8-2700/32
SOCKET,w/Wiring	8-4600/21
SOCKETS,BULB	8-11000
SOLENOID ASSEMBLY, 1979-80-81	23-1400/56
SOLENOID ASSEMBLY, 1979-80-81	23-1600/32
SOLENOID ASSEMBLY, 1979-80-81	23-1800/41
SOLENOID ASSEMBLY, 1979-80-81	23-1900/31
SOLENOID ASSY., 1979-80-81	23-8200/37
SOLENOID PACKAGE, Starter	8-400/21
SOLENOID, Elect. Door Locks	8-9200/4
SOLENOID, Frt. Dr. Elect. Locks	8-9700/2
SOLENOID, Side and Rear Door Locks, Rt.	8-9400/2
SOLENOID, Sliding Door Electric Door Lock	8-9500/2
SPACER NUT, Bolt	22-1400/6
SPACER or HUB-With 15" Tilt Tuff Steering Wheel	19-2900/3
SPACER, Alternator (Serviced in Rotor Package)	8-1100/9
SPACER, Alternator (Serviced in 3838078 Pkg.)	8-1100/25
SPACER, Altr. Mtg. - 1979	8-1700/10
SPACER, Co/Shaft Gear, Long	21M-1000/34
SPACER, Co/Shaft Gear, Short	21M-1000/32
SPACER, Distributor	8-100/4
SPACER, Distributor Reluctor Sleeve	8-200/14
SPACER, Exhaust Pipe Flange	11-560/8
SPACER, Fan 225 Eng. w/o Sound Control HK4 1.30" lg. 1978-79	7-300/12
SPACER, Inner to Outer Panel	23-9800/1
SPACER, Parking Brake Lever	4-1000/42
SPACER, Rr. Seat A/Rest Pivot Bolt (Not Shown)	23-3700/--
SPACER, Sun Gear, 4 Inner Teeth, 2" O.D.	21A-850/10
SPACER,Column Gearshift Tube Lever-Rubber	19-1200/17
SPACER,Column Support Bracket	19-1000/3
SPACER,Gearshift	19-1300/16
SPACER,Gearshift Tube Lever	19-1300/14
SPACER-Gearshift Tube Lever-Steel	19-800/3
SPACER-Gearshift Tube Lever-Rubber	19-800/4

	GROUP-FIGURE/KEY NO.
SPARK PLUG PKG., Consists of (6) 4091678 Spark Plugs	8-4100/4
SPARK PLUG, Medium Duty Cycle Engine, No. RBL-16Y or 560PR	8-4100/4
SPEAKER, Radio w/AM 1978-79	1-500/2
SPEAKER, Single Rear	1-500/28
SPEED CONTROL CABLES	14-225
SPEEDOMETER, Mile/Kilo (U.S.) - 1978	8-2400/15
SPEEDOMETER CABLE, w/SHAFT and HOUSING, Trans. To Transfer Case, 80" Long - 1978	21M-1240/3
SPEEDOMETER CABLE, w/SHAFT and HOUSING, 80" Long, w/203 T/Case - 1978	21A-1500/3
SPEEDOMETER CABLE, w/SHAFT and HOUSING, 106" Long, - 1978	21A-1600/8
SPEEDOMETER, Mile/Kilo., w/o Trip (Illustrated)	8-2200/2
SPHERE and SPRING, Centering	19-1700/50
SPIDER, Diff. Pinion, Use w/Transfer Case As Purchased Assy. No. 3898654	21M-1100/22
SPINDLE KIT, Wheel Bearing	2-300/43
SPINDLE KIT, front wheel bearing-1980	2-270/34
SPINDLE KIT, front wheel bearing-1981	2-270/34
SPRAG, Parking	4-1900/1
SPRING & SHOCK ABSORBER, FRONT SUSPENSION	
COIL-1978CB, MB, B100-200-300	17-50
SPRING AND EXPANDER ASSY.	5-500/35
SPRING AND EXPANDER ASSY., Cylinder	5-650/28
SPRING AND EXPANDER PKG., w/ 7/8" Cylinder	5-600/32
SPRING PACKAGE, Starter Brush	8-400/16
SPRING REPLACEMENT CHART, REAR-LIGHT DUTY	17-3100
SPRING WASHER, Anti-Rattle	4-900/2
SPRING WITH AUXILIARY & SHOCK ABSORBER, REAR LEAF AD100, D100-200-300-400	17-900
SPRING WITH AUXILIARY AND SHOCK ABSORBER	17-1050
SPRING WITH SHOCK ABSORBER, FRONT LEAF	17-450
SPRING WITH SHOCK ABSORBER, FRONT LEAF	17-600
SPRING WITH SHOCK ABSORBER, REAR LEAF-B100-200	17-700
SPRING WITH SHOCK ABSORBER, REAR LEAF	17-800
SPRING WITH SHOCK ABSORBER, REAR LEAF	17-1200
SPRING, Adjusting Cable	5-500/20
SPRING, Adjusting Lever	5-500/19
SPRING, Adjusting Lever	5-600/18
SPRING, Adjusting Screw Hold Down	5-700/15
SPRING, Anti-Rattle	4-1100/31
SPRING, Automatic Adjusting	5-500/26
SPRING, Automatic Adjusting Lever	5-650/18
SPRING, Automatic Adjusting Retaining	5-700/5
SPRING, Brake Lever	5-800/28
SPRING, Bulb Mtg. Seat Adjusting	8-2500/4
SPRING, Curbside, 70" Door	23-4300/13
SPRING, Cylinder	5-600/31
SPRING, Cylinder	5-700/28
SPRING, Cylinder Cup	5-650/30
SPRING, Cylinder Piston	5-500/34
SPRING, Distributor	8-100/8
SPRING, Distributor Cap	8-200/11
SPRING, Extension, 5-1/2"	5-800/27

	GROUP-FIGURE/KEY NO.
SPRING, H/Lp. Bulb Mtg. Seat Adj.	8-2700/6
SPRING, INSULATOR and CONTACT PKG., Pk. and Turn Sig. Lp. (Not Shown)	8-2700/40
SPRING, INSULATOR and CONTACT PKG. Parking and Turn Sig. Lp. Socket (Not Shown) - 1978	8-2800/31
SPRING, INSULATOR and CONTACT PKG., Park., T/Sig. and Side Marker Lp.	8-2900/6A
SPRING, INSULATOR and CONTACT PKG., Park. and Turn Sig. Lp. Socket (Not Shown)	8-7000/5
SPRING, Lever Strut	4-900/5
SPRING, Lockout Shift Rail Poppet Ball	21M-1000/58
SPRING, P/Brake Lever Strut, w/10 & 11 x 2.5 Brakes	4-800/4
SPRING, Parking Brake Lever Anti-Rattle	4-600/2
SPRING, Parking Sprag	4-1900/7
SPRING, Poppet Plate	21M-1000/28
SPRING, Rd. H/Lp. Seat Adj.	8-2900/16
SPRING, Rect. H/Lp. Bulb Seat Adj.	8-2700/17
SPRING, Rect. H/Lp. Bulb Seat Adj.	8-2900/15
SPRING, Retainer	5-100/21
SPRING, Retainer, w/3500 lb. Front Axle	5-200/2
SPRING, Roadside, 70" Door	23-4300/14
SPRING, Rr. Clutch Wave	21A-300/23
SPRING, Rr. Seat A/Rest Pivot (Not Shown)	23-3700/—
SPRING, Shoe Anchor	5-650/9
SPRING, Shoe Guide	4-1000/20
SPRING, Shoe Hold Down	5-500/9
SPRING, Shoe Hold Down	5-600/9
SPRING, Shoe Hold Down	5-650/12
SPRING, Shoe Return	4-1000/40
SPRING, Shoe Return	5-500/18
SPRING, Shoe Return	5-700/1
SPRING, Shoe Return, Upper	5-600/24
SPRING, Shoe to Strut	4-900/5
SPRING, Col. Shaft Coupling Body	19-300/51
SPRING, Col. Shaft Lock Lever	19-300/20
SPRING, Col. Shaft Lock Plate	19-1100/11
SPRING, Col. Shaft Lower Bearing	19-300/32
SPRING, FRONT SUSPENSION COIL	17-55
SPRING, Front Susp. Coil	17-53/11
SPRING, Front-1550/1800 LB.	17-450/5
SPRING, Lock Control Housing	19-100/3
SPRING, Rack Preload	19-1700/30
SPRING, Rear Auxiliary-585 Lb.-1 Leaf	17-900/3
SPRING, Rear Auxiliary-900 Lb.-4 Leaf	17-900/3
SPRING, Rear Auxiliary-360 LB.-1 Leaf	17-900/3
SPRING, Rear Main	17-900/5
SPRING, SHOCK ABSORBER & SWAY ELIMINATOR, FRONT LEAF-3500 LB. Axle-AW100	17-300
SPRING, SHOCK ABSORBER & SWAY ELIMINATOR, FRONT LEAF-3500, 4500 Lb. AXLE-W100-200-300-400	17-400
SPRING, Shaft Lock Lever	19-1100/20
SPRING, Shift Lever	19-300/28
SPRING, Shift Lever	19-1700/42
SPRING, Shoe	19-1700/4
SPRING, Steering Column Coupling Shoe	19-1200/25

1978-81 LIGHT DUTY TRUCK PARTS CATALOG

	GROUP-FIGURE/KEY NO.
SPRING,Strg.Col.Shaft Lower Bearing	19-1200/2
SPRING,Upper Bearing	19-1700/20
SPRING,Wheel Tilt	19-1700/36
SPRING,col.lock plate	19-300/11
SPROCKET, Chain Drive, Lower, Use w/Transfer Case As Purchased Assy. No. 3898654	21M-1000/69
SPROCKET, Chain Drive, Upper, Use w/Transfer Case As Purchased Assy. No 3898654	21M-1100/14
SPROCKET, Drive, 32 Int. 34 Ext. Teeth	21M-1150/38
SPROCKET, Driven, 61-34 Ext. Teeth - 1980	21M-1150/5
STABILIZER, Lift Gate to Tailgate	23-5300/31
STABILIZER OR DAMPER,STEERING	2-1600
STARTER	8-400
STARTER	8-500/2
STARTER	8-600
STARTER (DIESEL ENG.)	8-600
STARTER-I.H.C. 446 ENG.	8-500
STARTER-WIRING-BATTERY MTG.	8-3300
STATOR, Alternator	8-800/8
STATOR, Alternator	8-900/8
STATOR, Alternator	8-1000/8
STATOR, Alternator	8-1100/12
STEM, Valve, w/15" Wheel	22-300/11
STONE SHIELD, "A" Body, 1978-79-80	23-4000/1-2
STOP, Pedal, 1978	5-800/19
STOP, Primary Piston	5-1800/17
STORAGE COMPARTMENT (SIDE PANEL)	23-7700
STRAINERS,Side Pnl.Vert.Short - ALL W.B. Left	23-1000/19
STRAP, Altr. Adj.	8-1300/11
STRAP, Altr. Adj.	8-2100/12
STRAP, Lifting	23-4300/11
STRAP, Pull Down	23-4400/33
STRAP,Strg.Column Coupling-Refer To Item A	19-1200/31
STRIKER	23-1500/9
STRIKER, Door	23-4500/8
STRIKER, Door	23-9700/16
STRIKER, Door	23-9800/16
STRIKER, Dr. Latch	23-1800/27
STRIKER, Lift Gate Lock to Roof Inner Panel Lwr. Rear - 1978	23-5300/5
STRIKER, Rear Corner Pnl. Tailgate Bolt (See Item #2 Latch Assy. For 1981 Appl.)	23-5400/1
STRIKER, Single Rr. Dr.	23-1900/20
STRIKER, Stabilizer	23-5300/28
STRIKER,Front,Up To 8-11-80	23-1500/43
STRUT, P/Brake Lever, w/10 x 2.5 Brake - 1978-79	4-800/5
STRUT, Parking Brake Lever	4-900/4
STRUT, T/Case To Insulator Mtg. Plate	21M-1175/47
STRUT,Lower Control Arm	17-53/7
STUD and WASHER PACKAGE, Starter Solenoid	8-400/22
STUD, (Serviced in 3838078 Pkg.)	8-1100/23
STUD, 6200 lb. Axle, Budd Wheel - 1978	3-400/23
STUD, Axle Driveshaft (Refer to Group 3)	22-800/5
STUD, Case Adapter	21M-1150/66
STUD, Starter Mounting	8-400/25

	GROUP-FIGURE/KEY NO.
STUD, Starter Mtg., (Not Shown)	8-500/7
STUD, Wheel	22-400/9
STUD, Wheel	22-500/4
STUD, Wheel	22-600/6
STUD, Wheel	22-700/4
STUD, Wheel	22-800/4
STUD, Wheel, 1978	22-450/9
STUD, Wheel, w/13x3.5 Brakes	22-900/4
STUD, Wheel, w/Kelsey Rotor	22-350/9
STUD,Steering Column Bracket	19-1000/2
STUD,Steering Gear To Bracket-1980	2-1150/5
STUD,Strg.Gear To Bracket-Up To Approx.5-1-79	2-1150/5
STUD,Strg.Gear To Bracket-After Approx.5-1-79	2-1150/5
SUN ROOF ASSY. (EXCEL)	23-325
SUN ROOF ASSY. (MOPAR) SERT # GN 7001	23-300
SUN ROOF ASSY.(WISCO) SERT # GN 7002	23-335
SUPPORT ASSEMBLY, Spare Tire, Up to 3-1-78	22-1000/4
SUPPORT ASSY., Oil Pump And Reaction Shaft, A904-A999	21A-350/23
SUPPORT ASSY.,Steering Column Bearing Housing	19-1700/47
SUPPORT, 3 Pass., Right, 1978-9	23-3700/7
SUPPORT, Brake	5-500/27
SUPPORT, Brake	5-600/4
SUPPORT, Brake	5-650/21
SUPPORT, Brake	5-700/11
SUPPORT, Brake Pedal, 1978	5-1100/1
SUPPORT, C/Membr. Skid Plate	21M-1175/48
SUPPORT, Exhaust Pipe	11-560/10
SUPPORT, Front Floor Corner, "A" Body	23-4200/2
SUPPORT, Frt. Fender Panel Rect. H/Lamp 1979	8-2900/38
SUPPORT, Grille	7-650/2
SUPPORT, Int. & Rear Seat Back Lwr. Right - Up To 10-2-78	23-3700/1
SUPPORT, Muffler, Rear, Except 149" W.B. Club Cab, 1978	11-560/14
SUPPORT, P/Brake	4-1000/25
SUPPORT, Pedal, 1978	5-1000/1
SUPPORT, Rr. Annulus Gear, 62T, 28T, 4" O.D.	21A-850/15
SUPPORT, Side Frt. Fender Pnl. H/Lp., Rt. - 1978	8-2500/6
SUPPORT, Side Lock Pillar to Inner Pillar	23-5150/2
SUPPORT, Starter, After 5-1-78, M4,5,6	8-400/25
SUPPORT, Upper	23-800/8
SUPPORT, Upper	23-800/11
SUPPORT, Upper Right - Up To 6-1-78	23-800/6
SUPPORT,Col.Shaft Brg.-W/A230,A390 Trans.-Up To Approx.6-1-79	19-1300/12
SUPPORT,Col.Shaft Brg.-W/A230,A390 Trans.-After Approx.6-1-79	19-1300/12
SUPPORT,Starter	8-500/3
SUPPORT,Steering Column Shaft Bearing	19-1200/15
SUPPORT,Steering Column Shaft Bearing	19-1200/20
SUPPORT,Steering Gear Mounting Bracket	2-1150/4
SUPPORT,Tilt Steering Bearing Housing	19-1500/27
SUPPORT,Tire Carrier Brkt.(6-1/2 Foot Utliline Only)	22-1100/3
SUPPORT,Upr.Rear w/109"W.B.	23-1000/1
SUPPORT,Upr.Rear w/127"W.B.	23-1000/1

GROUP-FIGURE/KEY NO.	GROUP-FIGURE/KEY NO.		
SUPPORT, column shaft bearing	19-900/9	SWIVEL, G/Shift Rod	21M-400/10
SUPPORTS AND CHANNELS (RIGHT)	23-800	SWIVEL, G/Shift Rod - 1978	21M-250/7
SUPPORTS-STRAINERS & RETAINERS	23-1000	SWIVEL, Shift Lever Rod	21M-1175/22
SWITCH	24-1005/10	SYNCHRONIZER ASSY., First Speed - 1978	21M-100/3
SWITCH	8-6900/3	SYNCHRONIZER ASSY., Second and Third	21M-300/20
SWITCH & LAMP, E.G.R MAINTENANCE	8-10200	SYNCHRONIZER ASSY., First and Second Speed	21M-700/4
SWITCH PLATE--Post Office	8-10000/26	SYNCHRONIZER, Third and Fourth Speed, w/o Outer Stop Rings	21M-500/32
SWITCH, A/C Temperature Sensing w/225 Eng.	24-250/23	SYNCHRONIZER, Third and Fourth, w/o Outer Stop Rings	21M-700/10
SWITCH, A/C and Htr. 6 P/Button Control 1979	24-425/23	Saginaw-Refer To Figure 19-2200-1980	19-1800
SWITCH, A/C and Htr. Blower Control	24-400/24	Saginaw-Refer To Figure 19-2200-1978	19-1800
SWITCH, A/C and Htr. Blower Control	24-425/32	Saginaw-Refer To Figure 19-2200-1979-80	19-1800
SWITCH, Ajar, Liftgate	8-4200/21	Saginaw-refer to figure 19-2000, up to approx.6-12-79	19-1800
SWITCH, Aux. A/cond. And Heater Blower	1-100/21	Saginaw-refer to figure 19-2000, after approx.6-12-79	19-1800
SWITCH, B/U Lamp	21M-200/19	Saginaw-refer to figure 19-2000, 1980-81	19-1800
SWITCH, B/U Light	21M-100/68	Saginaw-refer to figure 19-2100, 1978	19-1800
SWITCH, B/U Light	21M-600/14	Saginaw-refer to figure 19-2100, 1979	19-1800
SWITCH, B/U Light	21M-800/8	Saginaw-refer to figure 19-2100, 1978	19-1800
SWITCH, Blwr. aux htr.	1-200/30	Saginaw-refer to figure 19-2100, 1979	19-1800
SWITCH, Cont. Vacuum, 6 P/Button	24-400/25	Saginaw-refer to figure 19-2100, 1978	19-1800
SWITCH, Dome Lp.	8-10000/6	Saginaw-refer to figure 19-2100, 1979	19-1800
SWITCH, Door Lock	23-8200/32	Saginaw-refer to figure 19-2100, 1980-81	19-1800
SWITCH, Dwell, w/Intermittent, Delay	23-2200/25	Saginaw-refer to figure 19-2200, 1978-79	19-1800
SWITCH, Foot Dimmer	8-5200/5	Sway Eliminator Parts Package	17-53/A
SWITCH, Front Door Electric Locks	8-9200/2	T/PLATE, Side Lk. Frt. Dr. Plr. Striker	23-5175/7
SWITCH, Frt. DR. Elect. Locks	8-9700/3	TABLE ASSEMBLY, Dinette	23-3750/1
SWITCH, H/Lamp (Not Shown) - 1978	8-5300/14	TACHOMETER (6 Cyl.)	8-2300/18
SWITCH, Heater Blower Control 1978-79-80	1-300/21	TAILGATE	23-5400
SWITCH, Htr. And Aux. Htr. Cont. Blower 1978-79-80	1-100/21	TAILGATE, Utiline	23-5400/7
SWITCH, Ign. and Starter	8-6900/3	TAPE SET - "HIGH COUNTRY"	23-495
SWITCH, Ign., w/o Tilt Steering	8-7800/32	TAPE SET - "PULLMAN" - FILIGREE	23-7195
SWITCH, Ignition (Not Shown) - 1978-79,9-Terminal	8-6800/14	TAPE SET, w/Overlay "Pick-M-Up" - 1979	23-7175/8
SWITCH, Ignition, w/WIRING	8-3400/7	TAPE STRIPES	23-6975
SWITCH, Lift Gate Ajar	8-4350/4	TAPE STRIPES "MACHO SPORT"	23-6985
SWITCH, Lock Warning	21M-900/53	TAPE STRIPES, A,D,W - (1979-80)	23-7175
SWITCH, Maintenance Lamp	8-10200/5	TAPE STRIPES, BIG HORN - 1980	23-7190
SWITCH, Oil Pressure Lamp and Elect. Choke (6 Cyl. Eng.) (Not Shown) - 1979	8-5900/29	TAPES	23-450
SWITCH, Oil Pressure Lp. and Elect. Choke (6 Cyl. Eng.) (Dom.) (Not Shown) - 1979	8-6100/41	TAPES "TOWN & COUNTRY WOODGRAIN"	23-485
SWITCH, Rear Window Elect. Defroster (Not Shown)	8-9100/8	TAPES - "DECORATOR"	23-475
SWITCH, Starter	8-600/2	TAPES, MACHO	23-6900
SWITCH, Stop Light	8-5800/3	TAPES, MACHO	23-6950
SWITCH, Trans. Oil Temp. (Not Shown) - 1980	8-5700/12	TAPES, RETRIEVER	23-7000
SWITCH, Turn Signal & Hazard Warning (Not Shown) - 1978-9 w/Wiring	8-6800/14	TAPES, WARLOCK	23-7100
SWITCH, Wiper Motor	23-7800/5	TAPES-WARLOCK 	23-7125
SWITCH, w/INSERT, Horn	8-3500/7	TAPPING PLATE, Striker	23-5150/5
SWITCH, w/WIRING, Turn Sig.	8-3400/4	TEE, A/C and Htr. Supply Hose 5/8 x 5/8 x 1/2	24-250/17
SWITCH, Cargo Lamp	8-4200	TEE, Brake Line	5-1700/3
SWITCH, Dome Light 70-1914	8-10000/25	TEES, ELBOWS, BLOCKS AND CONNECTORS, BRAKE	5-6200
SWITCH, Wiper & Washer	23-2200/12	TERMINAL	8-10300/1
SWITCH, buzzer-refer to group 8	19-1700/14	TERMINAL	8-10400/1
SWITCHES & CONTROLS, INSTRUMENT PANEL	8-7400	TERMINAL & INSULATOR PACKAGES	8-11100
SWITCHES - STOP & PARKING LAMP	8-7900	TERMINAL PACKAGE, Alternator Batt.(Pos. Heat Sink)	8-800/13
SWITCHES - STOP & PARKING BRAKE LAMP	8-8000	TERMINAL PKG., Alternator Batt. (Pos. Heat Sink)	8-1000/13
		TERMINAL and CONNECTOR PKG.	8-8800/11
		TERMINAL, A/C Motor	24-425/7
		TERMINAL, Alternator	8-800/9

1978-81 LIGHT DUTY TRUCK PARTS CATALOG

	GROUP-FIGURE/KEY NO.
TERMINAL, Alternator	8-900/9
TERMINAL, Alternator Stator	8-1100/11
TERMINAL, And Insulator Pkg.	1-150/14
TERMINAL, Elect. Door Lk. Wiring to Cab Wiring (Not Shown)	8-8800/11
TERMINAL, Elect. Door Locks Wiring	8-9000/9
TERMINAL, Elect. Heated Rr. C/Dr. Glass	23-1100/10
TERMINAL, Glow Plug LP. and Switch Wiring (Not Shown)	8-8700/14
TERMINAL, Heated Rear Cargo Door Glass Wiring (Not Shown)	8-9300/16
TERMINAL, Heated Rear Window Wiring	8-9300/14
TERMINAL, Pk. and Turn Sig. Lp. Cable	8-7000/5
TERMINAL, Side and Rear Cargo Door Pillar Wiring	8-8800/10
TERMINAL, Sliding Door Pillar Wiring	8-8800/8
TERMINAL, Trip Computer Inst. Panel Wiring (Not Shown)	8-8900/14
TERMINAL, Turn Sig. Sw. Lever Speed Control Wiring	8-6800/11
TERMINALS, WIRING	8-10300
TERMINAL, Lamp Wiring (Not Shown)	8-7300/6
TERMINAL, to Body Ext. Wiring (Not Shown)	8-9000/9
THERMOSTAT	9B-1300/3
THERMOSTAT, 195 Degrees, 6 Cyl. And 8 Cyl. 1978	7-400/1
THROTTLE CONTROLS	14-800
THROTTLE CONTROLS	14-805
THROTTLE CONTROLS	14-810
THROTTLE CONTROLS	14-815
THROTTLE CONTROLS	14-823
THROTTLE CONTROLS	14-875
THROTTLE CONTROLS	14-880
THROTTLE CONTROLS	14-900
THROTTLE CONTROLS	14-925
THROTTLE CONTROLS	14-945
THROTTLE CONTROLS	14-975
THROTTLE CONTROLS	14-980
TIMING GEAR & CASE (MMC DIESEL)	9B-1100
TIMING INDICATOR	9C-750
TIMING INDICATOR	9C-775
TIRE-WHEEL CHART	22-250
TRACK ASSY, Adjuster, Right - Up To 4-3-78	23-3400/4
TRACK ASSY., Adjuster, Right - Up To 4-3-78	23-3500/7
TRACK, w/Mounting Angle (Curbside)	23-4300/5
TRACK, w/Mounting Angle (Roadside)	23-4300/6
TRANS. ASSY.	21M-500
TRANS. ASSY.	21M-500
TRANS. ASSY. 445, (4.56 to 1 Ratio in Low) SERVICED	21M-700
TRANS. AUXILIARY OIL COOLER & LINES	9C-875
TRANS. AUXILIARY OIL COOLER & LINES	9C-885
TRANS. AUXILIARY OIL COOLER & LINES	9C-895
TRANS. AUXILIARY OIL COOLER & LINES	9C-896
TRANSFER CASE ASSEMBLY, SERVICED, Use With As Purchased Assy. No. 3898654	21M-900/22
TRANSFER CASE ASSY., SERVICED - 1980	21M-1150
TRANSFER CASE ASSY., SERVICED - 1981	21M-1150
TRANSFER CASE, N.P.G. MODEL 203	21M-900
TRANSFER CASE, N.P.G. MODEL 203	21M-1000
TRANSFER CASE, N.P.G. MODEL 203	21M-1100

	GROUP-FIGURE/KEY NO.
TRANSFER CASE, N.P.G. MODEL 205	21M-1125
TRANSMISSION ASSY IDENTIFICATION	21A-50
TRANSMISSION ASSY. A390, w/LONG EXT., B1,2,3-CB3-D1,2	21M-200
TRANSMISSION ASSY., A230 w/SHORT EXT.,D100 w/133"-149" W.B., D200 w/149" W.B., 10" Clutch w/225 Eng	21M-100
TRANSMISSION ASSY., Model A833, w/LONG EXTENSION, B1,2-D1 w/10" Clutch, w/225 Eng., B1,2-D1 w/10-1/	21M-300
TRANSMISSION, 3 SPEED A727-A904-A999 AUTOMATIC	21A-100
TRANSMISSION, 3 SPEED A727 AUTOMATIC	21A-200
TRANSMISSION, 3 SPEED A727-A904-A999 AUTOMATIC	21A-350
TRANSMISSION, 3 SPEED A727-A904-A999 AUTOMATIC	21A-400
TRANSMISSION, 3 SPEED A727-A904-A999 AUTOMATIC	21A-500
TRANSMISSION, 3 SPEED A727-A904-A999 AUTOMATIC	21A-600
TRANSMISSION, 3 SPEED A727-A904-A999 AUTOMATIC	21A-700
TRANSMISSION, 3 SPEED A727 AUTOMATIC	21A-800
TRANSMISSION, 3 SPEED A904-A999 AUTOMATIC	21A-300
TRANSMISSION, 3 SPEED A904-A999 AUTOMATIC	21A-850
TRANSMISSION, 3 SPEED, N.P.G. MODEL A230	21M-100
TRANSMISSION, 3 SPEED, TREMEC MODEL A390	21M-200
TRANSMISSION, 4 SPEED - N.P.G. MODEL 445	21M-700
TRANSMISSION, 4 SPEED, N.P.G. MODEL 435	21M-500
TRANSMISSION, OVERDRIVE 4-SPEED	21M-300
TRIM PANEL, Door, Black	23-8400/6
TRIM PANELS	23-9375
TRIM PANELS - UPPER - D-W	23-9350
TRIM,REAR DOOR	23-8600
TRIMMING MATERIAL	23-3975
TRIMMING MATERIAL	23-5675
TRIMMING MATERIAL, B - MB	23-3950
TROUGH,steering column wiring-1981	19-1700/40
TUBE & LEVER,Strg. Col. G/Shift-With A727 Trans.-Up To Approx. 6-1-79	19-1000/15
TUBE & LEVER,Strg. Col. G/Shift-With A727 Trans.-After Approx. 6-1-79	19-1000/15
TUBE & LEVER,gearshift-1978	19-1700/52
TUBE & LEVER,gearshift-1979-80-81	19-1700/52
TUBE & LEVER,s/col.g/shift-with A727 trans.	19-600/20
TUBE & LEVER,s/col.g/shift-with A230,A390 trans.	19-600/20
TUBE ASSY,Power Steering Gear To Pump-Pressure	19-4600
TUBE ASSY,Power Steering Return-Make From Item A & B	19-4600
TUBE ASSY,pump hose to hydroboost pressure	19-4600
TUBE ASSY., Intermediate w/Center Brg., w/203 T/Case	16-800/28
TUBE ASSY., w/Center Bearing (7290)	16-200/6
TUBE ASSY., w/Center Bearing 145"W.B. (7260)- 1980	16-200/6
TUBE ASSY.,Steering Gear Column Gearshift-1980	19-1000/15
TUBE ASSY.,Steering Gear Column Gearshift-1981	19-1000/15
TUBE ASSY.,Tie Rod-With 3300,3600 Lb.Axle	2-1150/17
TUBE ASSY.,Tie Rod-With 4000 Lb. Axle	2-1150/30
TUBE ASSY.,shift-1981	19-1700/52
TUBE ASSY.-Refer To Figure 19-1000	19-1200/8
TUBE ONLY, Front Propeller Shaft (7290)	16-200/6
TUBE ONLY, Intermediate Propeller Shaft, w/o Center Brg., w/203 T/Case	16-800/28
TUBE WITHOUT CLAMP,Tie Rod-1978	2-1500/23

	GROUP-FIGURE/KEY NO.		GROUP-FIGURE/KEY NO.
TUBE WITHOUT CLAMP,Tie Rod-1978	2-1500/23	VALVE, Diverter 1979	25-86/19
TUBE with LEVER,Shift-in item A	19-500/52	VALVE, EGR	25-480/1
TUBE without CLAMP,Tie Rod-1978	2-1500/23	VALVE, Htr. Water w/Diesel Eng. 1978-79 (Not Shown)	1-100/30
TUBE, A/C Motor Cooling	24-425/31	VALVE, Metering and Warning, 1978	5-1300/17
TUBE, A/C Unit Drain	24-425/9	VALVE, Metering and Warning, 1978	5-1400/14
TUBE, Booster Vacuum, w/225 Eng., Up to 2-15-79	5-1300/18	VALVE, Metering and Warning	5-1600/8
TUBE, Brake Signal	8-2200/19	VALVE, Water	1-400/1
TUBE, Discharge, Compr. End w/225 Eng. 1980	24-250/3	VALVE, Water Aux. Htr. Vacum	1-400/1
TUBE, High Beam and Turn Signal	8-2200/18	VALVE, Water w/Diesel Eng 1978-79	1-400/1
TUBE, Propeller Shaft	16-100/3	VALVE, water	1-300/20
TUBE, Suction, Compr. End 225 Eng.	24-250/2	VALVE,Check-In 3491351 Repair Kit	19-2100/26
TUBE, Wheel Cylinder	5-700/29	VALVE,HEAT BOOST VALVE & CONTROL	9B-2600
TUBE,Col.Gearshift-Except A727 Trans.-1979	19-300/27	VALVE,STEERING GEAR CONTROL	19-2500
TUBE,Column Gearshift	19-100/31	VALVE,STEERING GEAR CONTROL	19-2600
TUBE,Column Gearshift Upper	19-200/27	VAPOR CANISTER - DUAL	25-530
TUBE,POWER STEERING	19-4600	VAPOR CANISTER - DUAL	25-560
TUBE,Tie Rod	2-1475/10	VAPOR CANISTER - DUAL & TRIPLE	25-575
TUBE,col.gearshift-with A727 trans.-1979-80-81	19-300/27	VAPOR CANISTER - SINGLE	25-525
TUBING, Brake Line, 25 Ft. Roll, 3/16" O.D.	5-1300/1	VAPOR CANISTER - SINGLE	25-550
TUBING, Brake Line, 25 Ft. Roll, 3/16" O.D.	5-1400/2	VISOR AND REAR VIEW MIRROR	23-6500
TUBING, Brake Line, 25 Ft. Roll, 3/16" O.D.	5-1600/3	VISOR, W/Shield, Black - 1978	23-6500/2
TUBING, Brake Line, 25 Ft. Roll, 3/16" O.D.	5-1700/1	VISOR,W/Shield White - 1978	23-2300/2
TUBING, Heated Rear Window Wiring Terminal (Ru.)	8-9300/13	W/AUX. Air Cond. and RR. Htr.	24-425/27
UNIVERSAL JOINT IDENTIFICATION	16-1700	WASHER OR SPACER, Pedal Shaft	5-1000/7
VACUUM CONNECTORS AND HOSE, BOOSTER	5-5600	WASHER PKG.,Starter Armature Thrust	8-400/14
VACUUM SUPPLY CONNECTORS	25-520	WASHER, Adjusting Screw	5-700/17
VALVE ASSY., 7 Way Control 1978	1-1000	WASHER, Adjusting Screw Socket	5-500/29
VALVE ASSY., 7 Way Control 1979-80	1-1000	WASHER, Adjusting Screw Socket	5-600/15
VALVE ASSY., 7 Way Control 1979-80	1-1000	WASHER, Flat, 1/4"	23-4400/36
VALVE ASSY., 7 Way Control 1979-80	1-1000/7	WASHER, Front Axle Yoke	16-400/2
VALVE ASSY.,Control-After Approx.11-14-78-Refer To Figure 19-2600	19-2500	WASHER, Frt. Output High Gear Thrust	21M-1130/16
VALVE ASSY.,Control-Up To Approx.11-14-78	19-2500	WASHER, Input Gear Thrust Brg., 2" I.D., 3/32" Thick	21M-1150/69
VALVE ASSY.,S/Gear Control-Refer To Figure 19-2500-1978	19-1900/66	WASHER, Lock	22-600/3
VALVE ASSY.,S/Gear Control-Use With 4031920 Gear-1978	19-2000/30	WASHER, P/Brake Lever Pin	4-800/2
VALVE ASSY.,S/Gear Control-Use With 4112638 Gear-1979	19-2000/30	WASHER, P/Brake Lever Pin	4-1100/30
VALVE ASSY.,control-1979-80	19-2600/A	WASHER, PKG., Side Gear Thrust, (Consists of 2 Each of .031-.033; .036-.038; .041-.043; .046-.048 t	3-100/30
VALVE ASSY.,s/gear control-refer to figure 19-2600,1979-80-81	19-1900/66	WASHER, Parking Brake Lever Anti-Rattle Spring	4-600/1
VALVE ASSY.,s/gear control-use w/4117497,4117499 Gear -1980-81	19-2000/30	WASHER, Rear Axle Yoke	16-100/10
VALVE BODY ASSY., w/225 and MMC DIESEL Eng.- 1978	21A-700	WASHER, Shoe Adjusting Screw	5-650/17
VALVE w/SEAL, Expansion	24-200/12	WASHER, Shoe Anchor Pin	5-650/3
VALVE, A/C & Htr. Aux. Water Vac. On-Off. 1978-79	1-200/11	WASHER, Shoe Hold Down Stud	5-700/2
VALVE, A/C and Htr. Water Vacuum	24-250/16	WASHER, Shoe to Strut Spring	4-900/5
VALVE, Brake Line Residual, 1978	5-1600/14	WASHER, Spring	21M-1175/4
VALVE, Brake Tube Metering and Warning (See Gr. 5)	8-6100/15	WASHER, Star	23-4400/37
VALVE, Check	5-1800/25	WASHER, Starter Pinion Shaft Friction	8-400/12
VALVE, Check	5-1850/14	WASHER, T/Case Rear Output Shaft	16-400/23
VALVE, Check, Except Hydro-Booster	5-1825/20	WASHER, Thrust	22-350/5
VALVE, Coolant Controlled EGR	25-480/3	WASHER, Thrust	22-400/5
VALVE, Disch. Line Check w/225 Eng. 79-80-81	24-250/5	WASHER, Thrust, 1978	22-450/5
		WASHER,Pivot Bar-After Approx.5-15-79	17-52/1
		WASHER,differential side gear thrust	3-100/30
		WASHER,gear to bracket	2-1350/5
		WASHERS, WINDSHIELD - A-D-W	23-7900
		WEATHER SEAL, Door	23-4500/2

1978-81 LIGHT DUTY TRUCK PARTS CATALOG

	GROUP-FIGURE/KEY NO.
WEATHERSTRIP	23-1100/13
WEATHERSTRIP - SIDE & REAR CARGO DOORS	23-1300
WEATHERSTRIP ASSY.	23-2100/5
WEATHERSTRIP ASSY., Vent Window	23-2100/20
WEATHERSTRIP, Door Top & Btm.- Right (A-Body)	23-4500/11
WEATHERSTRIP, Door Top Left (A-Body)	23-4500/10
WEATHERSTRIP, Left Btm. (A-Body)	23-4500/14
WEATHERSTRIP, Rear Window	23-8000/4
WEATHERSTRIP, Roof Pnl. to Header	23-5200/1
WEATHERSTRIP, Side Cargo Dr. Fixed Wdo.	23-1100/7
WEATHERSTRIP, Side Glass - 1978	23-5200/7
WEATHERSTRIP, Side Panel	23-5200/3
WEATHERSTRIP, Tailgate Side and Lower - 1978	23-5400/1
WEATHERSTRIP, Window	23-4500/3
WEATHERSTRIP, Windshield Glass, w/o Mldg., 1978-9	23-8000/2
WEATHERSTRIP, w/Vented Glass, 1978-9	23-9500/6
WEATHERSTRIP, Frt. Door - Up To 2-1-80	23-1400/1
WEATHERSTRIP, Frt. Door Glass, 1978-9	23-1400/4
WEATHERSTRIP, Sliding Dr.	23-1500/17
WEDGE, Rr. Cargo Dr. Upper	23-1800/43
WEIGHT, Wheel Balance, 1/2 Ounce	22-300/13
WHEEL, 15", Styled 1978-79	22-300/2
WHEEL, A/C Scroll	24-425/7
WHEEL, POWER STEERING	19-2925
WHEEL, STEERING	19-2700
WHEEL, STEERING	19-2800
WHEEL, STEERING	19-2900
WHEEL, steering-(35 Serrations)	19-2925/2
WHEEL, steering-(40 serrations)	19-2925/2
WHEELHOUSE ASSEMBLY, "A" Body	23-4200/11
WHEELS, DISC	22-300/1
WHITING SIX PANEL ROLL UP DOOR	23-4450
WINDOW, SLIDING REAR	23-8100
WINDOWS VENTED - ATTACHING PARTS	23-2100
WINDSHIELD & BACKLITE	23-8000
WINGNUT	22-1100/13
WINGNUT, Bolt	22-1400/5
WIPER & WASHER, WINDSHIELD	23-2200
WIPERS, WINDSHIELD	23-7800
WIRE, Ground	8-6600/17
WIRE, Intermittent Wipe Control - 1978	23-2200/21
WIRE, (Roll Stock)	8-10000/23
WIRING	8-8900/11
WIRING & ISOLATOR-AUX. BATTERY	8-6300
WIRING & LIGHTS, FRT. DOOR STEPWELL	8-8600
WIRING (16 Ga.) (See Rough Stock Illus.)	8-10000/4
WIRING (FRT. END)	8-3000
WIRING (See Illus. 2900)	8-3000/10
WIRING ASSY., Eng. Complete 1978	24-100/2
WIRING ASSY., Eng. Complete 1979-80-81	24-100/2
WIRING ASSY., Inst. Panel	24-100/1
WIRING, 225 Engine - 1978	8-6100/1
WIRING, A/C and Heater Inst. Panel	8-9800/3
WIRING, A/C-HEATER-SPEED CONTROL, INSTRUMENT PNL.	8-9800
WIRING, AC & Htr. (Eng. Comp.) (Not Shown) - 1980	8-5900/29

	GROUP-FIGURE/KEY NO.
WIRING, AC & Htr. (Eng. Comp.) 225 Eng. (Not Shown) - 1980-81	8-6100/41
WIRING, Aux. F/Tank - LHD - 18 Gal & 21 Gal (Not Shown) - 1980	8-5700/12
WIRING, Aux. Htr. to Bulkhead	1-200/15
WIRING, Auxiliary Battery to Isolator (Pos.) (Not Serviced)	8-6300/7
WIRING, Auxiliary Battery to Isolator (Pos.) (Not Serviced)	8-6300/7
WIRING, Auxiliary Battery (Pos.)	8-6300/9
WIRING, BATTERY	8-6200
WIRING, Body Main 70-1901 (Not Serviced)	8-10000/2
WIRING, Body Rear	8-10000/1
WIRING, CHASSIS	8-5700
WIRING, CHASSIS	8-5800
WIRING, CLOCK, TACH., & VOLTMETER	8-8500
WIRING, COURTESY LAMP	8-8300
WIRING, Cab to Body Extension (Not Shown) - 1978 -Up to 12/18/78	8-5200/43
WIRING, Cab, w/o 100 Amp. Alternator, LHD - 1978	8-5300/1
WIRING, Chassis	8-5800/1
WIRING, Chassis - 1978	8-5700/6
WIRING, Clock (Not Shown)	8-2200/24
WIRING, DOOR LOCKS, FRT. DOOR	8-9700
WIRING, DOOR LOCKS, HINGED	8-9400
WIRING, DOOR LOCKS, INSTRUMENT PANEL	8-9000
WIRING, DOOR LOCKS, INSTRUMENT PANEL	8-9800
WIRING, DOOR LOCKS, SLIDING	8-9500
WIRING, Dome Lamp Ext., Club Cab, w/Headliner - 1979 (Not Serviced)	8-4200/19
WIRING, Door Electric Locks Instrument Panel - 1979	8-9600/1
WIRING, Door Light and Speaker - 1978	8-8600/8
WIRING, Door Locks Body	8-8800/1
WIRING, E.G.R. Lamp (Eng. Comp.) (Not Serviced)	8-10200/4
WIRING, ENGINE	8-5900
WIRING, ENGINE	8-6100
WIRING, ENGINE	8-6600
WIRING, ENGINE (DIESEL)	8-6000
WIRING, Elect. Door Locks Instrument Panel - 1979	8-9000/1
WIRING, Electric Door Lock (Not Serviced - See items not Illus.)	8-9400/1
WIRING, Emissions - H/Duty Cycle w/Emiss. Reduction Cycle (Not Shown) - 1980	8-6500/30
WIRING, Engine - 1978	8-6400/2
WIRING, Engine - 1979	8-6600/1
WIRING, Engine - w/60 Amp. Alt. - 1978	8-6000/1
WIRING, Front Crossover - 1978	8-5800/22
WIRING, Front Door Electric Locks, Speaker and Courtesy Lamp - 1979-80	8-9200/1
WIRING, Frt Door Electric Locks, w/o Radio Speaker-1979	8-9700/1
WIRING, Frt. Crossover (Not Shown) - 1978	8-5300/14
WIRING, Frt. End	8-2700/3
WIRING, Frt. End H/Lp Ext. - Dual H/Lps	8-2900/37
WIRING, Frt. End, w/100 Amp. Alternator - 1979	8-3000/1
WIRING, HEATED REAR WINDOW, INSTRUMENT PANEL	8-9100
WIRING, HEATED REAR WINDOW	8-9300
WIRING, Heated Rear Window Instrument Panel - 1979	8-9100/1

GROUP-FIGURE/KEY NO.	GROUP-FIGURE/KEY NO.		
WIRING, Heated Rear Window Body (Not Serviced)	8-9300/1	YOKE, w/Slinger, Rear Axle	16-100/1
WIRING, Horn Ring to Horn Switch	8-6800/3	YOKE, w/Slinger, Rear Axle, (7290), 29 Spline, 2 5/8" Span . .	16-200/20
WIRING, Horns (Not Shown) - 1978	8-3900/10		
WIRING, INSTRUMENT PANEL & CAB	8-5300		
WIRING, Isolator Engine (Not Serviced)	8-6300/6		
WIRING, Lock Switch To Bulkhead	21M-900/54		
WIRING, R.V. Sensor	8-2250/4		
WIRING, R.V. Sensor Engine	8-2250/5		
WIRING, R.V. Sensor Inst.Panel	8-2250/1		
WIRING, Rectangular H/Lp. Extension	8-2700/2		
WIRING, SIDE & REAR DOOR LOCKS	8-8800		
WIRING, STEERING COLUMN	8-6900		
WIRING, STEERING COLUMN (W/O TILT WHEEL)	8-6700		
WIRING, Sliding Door Electric Lock (Not Serviced - See items not illustrated)	8-9500/1		
WIRING, Speed Control Instrument Panel	8-9800/1		
WIRING, Starter Relay Coil (Not Shown)	8-7200/30		
WIRING, Stereo Rdo. l/pnl 4 speakers	1-500/29		
WIRING, Strtr. Relay to Strtr.	8-3300/4		
WIRING, T/Stop and Turn Sig. Lamp Crossover (44" Long) . . .	8-5800/22		
WIRING, TRANSFER CASE & WARNING LAMP	8-8100		
WIRING, Terminal Block to Starter Relay (Not Shown)	8-7100/33		
WIRING, Tilt Steering Column Jumper	8-6800/6		
WIRING, Time Delay Lamp - 1978	8-7800/28		
WIRING, Trip Computer Jumper (Not Shown)	8-8900/14		
WIRING, w/SOCKET, Chassis Wiring to Rear Lamps - 1978 . . .	8-4700/4		
WIRING,(TRAILER TOW)	8-5400		
WIRING,(TRAILER TOW)	8-5500		
WIRING,(TRAILER TOW)	8-5600		
WIRING,BATTERY & STARTER	8-3200		
WIRING,Body Main 70-1901 (Not Serv)	8-10000/22		
WIRING,Body Rear (Not Serv)	8-10000/16		
WIRING,ENGINE	8-6400		
WIRING,ENGINE	8-6500		
WIRING,Extension	8-10000/19		
WIRING,FRT.DOOR LOCKS	8-9200		
WIRING,ICC Light (Not Serv)	8-10000/17		
WIRING,INSTRUMENT PANEL	8-5200		
WIRING,Lift Gate Ajar,Body	8-4350/1		
WIRING,Round H/Lp. Extension (See Items 33 & 34)	8-2700/1		
WIRING,STARTER & BATTERY	8-7100		
WIRING,STARTER & BATTERY	8-7200		
WIRING,STEERING COLUMN	8-3400		
WIRING,STEERING COLUMN (W/TILT WHEEL)	8-6800		
YOKE & SLINGER, w/3500 Lb. Front Axle, 26 Spline	16-400/1		
YOKE, Rear Output Shaft	21M-1150/16		
YOKE, Sliding	16-100/4		
YOKE, Sliding (7290) 29 Spline	16-300/4		
YOKE, Starter	8-600/9		
YOKE, Trans. Brake Drum Flange (5380)	16-1000/9		
YOKE, Trans. Output Shaft, w/435,445 Trans., 23 Spl.	16-500/9		
YOKE, Transfer Case Front Output Shaft, w/203 T/Case	16-400/21		
YOKE, Transfer Case Rear Output Shaft, w/203 T/Case	16-400/22		
YOKE, Transfer Case Rear Output Shaft, w/208 T/Case	16-400/22		
YOKE, Transmission	4-1050/39		